

LinuxCNC Manual Pages

Table of Contents

1. linuxcnc(1)	1
1.1. NAME	1
1.2. SYNOPSIS	1
1.3. DESCRIPTION	1
1.4. OPTIONS	1
1.5. EXAMPLES	2
1.6. SEE ALSO	2
1.7. BUGS	2
1.8. AUTHOR	3
1.9. REPORTING BUGS	3
1.10. COPYRIGHT	3
2. 5axisgui(1)	4
2.1. NAME	4
2.2. DESCRIPTION	4
2.3. SEE ALSO	4
2.4. BUGS	4
2.5. AUTHOR	4
2.6. REPORTING BUGS	4
2.7. COPYRIGHT	4
3. axis-remote(1)	5
3.1. NAME	5
3.2. SYNOPSIS	5
3.3. DESCRIPTION	5
3.4. OPTIONS	5
3.5. SEE ALSO	5
3.6. BUGS	6
3.7. AUTHOR	6
3.8. REPORTING BUGS	6
3.9. COPYRIGHT	6
4. axis(1)	7
4.1. NAME	7
4.2. SYNOPSIS	7
4.3. DESCRIPTION	7
4.4. OPTIONS	7
4.5. SEE ALSO	7
4.6. BUGS	7
4.7. AUTHOR	7
4.8. REPORTING BUGS	7
4.9. COPYRIGHT	7
5. debuglevel(1)	9

5.1. NAME	9
5.2. SYNOPSIS	9
5.3. DESCRIPTION	9
5.4. SEE ALSO	9
5.5. BUGS	9
5.6. AUTHOR	9
5.7. REPORTING BUGS	9
5.8. COPYRIGHT	9
6. elbpcom(1)	10
6.1. NAME	10
6.2. SYNOPSIS	10
6.3. DESCRIPTION	10
6.4. SEE ALSO	11
7. emccalib(1)	12
7.1. NAME	12
7.2. SYNOPSIS	12
7.3. DESCRIPTION	12
7.4. USAGE	12
7.5. EXIT STATUS	12
7.6. SEE ALSO	12
7.7. AUTHOR	12
7.8. COPYRIGHT	13
8. gladevc(1)	14
8.1. NAME	14
8.2. SYNOPSIS	14
8.3. OPTIONS	14
8.4. SEE ALSO	15
9. gladevc_demo(1)	16
9.1. NAME	16
9.2. SYNOPSIS	16
9.3. DESCRIPTION	16
9.4. SEE ALSO	16
9.5. BUGS	16
9.6. AUTHOR	16
9.7. REPORTING BUGS	16
9.8. COPYRIGHT	16
10. gmocopy(1)	17
10.1. NAME	17
10.2. SYNOPSIS	17
10.3. DESCRIPTION	17
10.4. OPTIONS	17
10.5. SEE ALSO	17

10.6. BUGS	17
10.7. AUTHOR	17
10.8. REPORTING BUGS	17
10.9. COPYRIGHT	18
11. gremlin_view(1)	19
11.1. NAME	19
11.2. SYNOPSIS	19
11.3. DESCRIPTION	19
11.4. SEE ALSO	20
11.5. BUGS	20
11.6. AUTHOR	20
11.7. REPORTING BUGS	21
11.8. COPYRIGHT	21
12. gs2_vfd(1)	22
12.1. NAME	22
12.2. SYNOPSIS	22
12.3. DESCRIPTION	22
12.4. OPTIONS	22
12.5. PINS	23
12.6. PARAMETERS	24
12.7. SEE ALSO	25
12.8. AUTHOR	25
12.9. LICENSE	25
13. gscreen(1)	26
13.1. NAME	26
13.2. SYNOPSIS	26
13.3. DESCRIPTION	26
13.4. OPTIONS	26
13.5. SEE ALSO	26
13.6. BUGS	26
13.7. AUTHOR	26
13.8. REPORTING BUGS	26
13.9. COPYRIGHT	26
14. hal-histogram(1)	28
14.1. NAME	28
14.2. SYNOPSIS	28
14.3. DESCRIPTION	28
14.4. SEE ALSO	28
14.5. BUGS	28
14.6. AUTHOR	28
14.7. REPORTING BUGS	28
14.8. COPYRIGHT	28

15. hal_input(1)	29
15.1. NAME	29
15.2. SYNOPSIS	29
15.3. DESCRIPTION	29
15.4. INPUT SPECIFICATION	29
15.5. DEVICE FEATURES SUPPORTED	30
15.6. HAL PINS AND PARAMETERS	30
15.7. PERMISSIONS AND UDEV	31
15.8. BUGS	32
15.9. SEE ALSO	32
16. hal_manualtoolchange(1)	33
16.1. NAME	33
16.2. SYNOPSIS	33
16.3. DESCRIPTION	33
16.4. PINS	33
16.5. USAGE	33
16.6. SEE ALSO	34
17. halcmd(1)	35
17.1. NAME	35
17.2. SYNOPSIS	35
17.3. DESCRIPTION	35
17.4. OPTIONS	35
17.5. COMMANDS	36
17.6. SUBSTITUTION	40
17.7. LINE CONTINUATION	41
17.8. BUGS	41
17.9. AUTHOR	41
17.10. REPORTING BUGS	41
17.11. COPYRIGHT	41
17.12. SEE ALSO	42
18. halcmd_twopass(1)	43
18.1. NAME	43
18.2. SYNOPSIS	43
18.3. DESCRIPTION	43
18.4. SEE ALSO	43
18.5. BUGS	43
18.6. AUTHOR	43
18.7. REPORTING BUGS	43
18.8. COPYRIGHT	43
19. halcompile(1)	44
19.1. NAME	44
19.2. SYNOPSIS	44

19.3. OPTIONS	44
19.4. DESCRIPTION	45
19.5. SEE ALSO	46
20. halmeter(1)	47
20.1. NAME	47
20.2. SYNOPSIS	47
20.3. DESCRIPTION	47
20.4. OPTIONS	47
20.5. USAGE	47
20.6. EXAMPLE	48
20.7. AUTHOR	48
20.8. REPORTING BUGS	48
20.9. COPYRIGHT	48
21. halreport(1)	49
21.1. NAME	49
21.2. SYNOPSIS	49
21.3. DESCRIPTION	49
21.4. SEE ALSO	49
21.5. BUGS	50
21.6. AUTHOR	50
21.7. REPORTING BUGS	50
21.8. COPYRIGHT	50
22. halrmt(1)	51
22.1. NAME	51
22.2. SYNOPSIS	51
22.3. OPTIONS	51
22.4. DESCRIPTION	51
22.5. SEE ALSO	55
22.6. BUGS	55
22.7. AUTHOR	55
22.8. REPORTING BUGS	55
22.9. COPYRIGHT	55
23. halrun(1)	56
23.1. NAME	56
23.2. SYNOPSIS	56
23.3. DESCRIPTION	56
23.4. OPTIONS	56
23.5. BUGS	57
23.6. AUTHOR	57
23.7. REPORTING BUGS	57
23.8. COPYRIGHT	57
23.9. SEE ALSO	57

24. halsampler(1)	58
24.1. NAME	58
24.2. SYNOPSIS	58
24.3. DESCRIPTION	58
24.4. OPTIONS	58
24.5. USAGE	58
24.6. EXIT STATUS	59
24.7. SEE ALSO	59
24.8. AUTHOR	59
24.9. REPORTING BUGS	59
24.10. COPYRIGHT	59
25. halscope(1)	60
25.1. NAME	60
25.2. SYNOPSIS	60
25.3. DESCRIPTION	60
25.4. SEE ALSO	60
25.5. BUGS	60
25.6. AUTHOR	60
25.7. REPORTING BUGS	60
25.8. COPYRIGHT	60
26. halshow(1)	61
26.1. NAME	61
26.2. SYNOPSIS	61
26.3. OPTIONS	61
26.4. DESCRIPTION	61
26.5. SEE ALSO	61
26.6. HISTORY	61
26.7. BUGS	62
26.8. AUTHOR	62
26.9. REPORTING BUGS	62
26.10. COPYRIGHT	62
27. halstreamer(1)	63
27.1. NAME	63
27.2. SYNOPSIS	63
27.3. DESCRIPTION	63
27.4. OPTIONS	63
27.5. USAGE	63
27.6. EXIT STATUS	64
27.7. SEE ALSO	64
27.8. AUTHOR	64
27.9. REPORTING BUGS	64
27.10. COPYRIGHT	64

28. haltcl(1)	65
28.1. NAME	65
28.2. SYNOPSIS	65
28.3. DESCRIPTION	65
28.4. OPTIONS	65
28.5. COMMANDS	66
28.6. REPORTING BUGS	66
28.7. COPYRIGHT	66
28.8. SEE ALSO	66
29. halui(1)	67
29.1. NAME	67
29.2. SYNOPSIS	67
29.3. DESCRIPTION	67
29.4. OPTIONS	67
29.5. USAGE	67
29.6. PINS	67
29.7. SEE ALSO	78
29.8. BUGS	78
29.9. AUTHOR	78
29.10. REPORTING BUGS	78
29.11. COPYRIGHT	78
30. hbmgui(1)	80
30.1. NAME	80
30.2. DESCRIPTION	80
30.3. SEE ALSO	80
30.4. BUGS	80
30.5. AUTHOR	80
30.6. REPORTING BUGS	80
30.7. COPYRIGHT	80
31. hexagui(1)	81
31.1. NAME	81
31.2. DESCRIPTION	81
31.3. SEE ALSO	81
31.4. BUGS	81
31.5. AUTHOR	81
31.6. REPORTING BUGS	81
31.7. COPYRIGHT	81
32. hy_gt_vfd(1)	82
32.1. NAME	82
32.2. SYNOPSIS	82
32.3. DESCRIPTION	82
32.4. Hardware setup	82

32.5. Firmware setup	82
32.6. OPTIONS	83
32.7. PINS	84
32.8. ISSUES	86
32.9. AUTHOR	86
32.10. LICENSE	86
33. hy_vfd(1)	87
33.1. NAME	87
33.2. SYNOPSIS	87
33.3. DESCRIPTION	87
33.4. OPTIONS	88
33.5. PINS	90
33.6. AUTHOR	92
33.7. LICENSE	92
34. image-to-gcode(1)	93
34.1. NAME	93
34.2. SYNOPSIS	93
34.3. DESCRIPTION	93
34.4. SEE ALSO	93
34.5. BUGS	93
34.6. AUTHOR	93
34.7. REPORTING BUGS	93
34.8. COPYRIGHT	93
35. inivalue(1)	94
35.1. NAME	94
35.2. SYNOPSIS	94
35.3. DESCRIPTION	94
35.4. OPTIONS	94
35.5. INI-FILE FORMAT	95
35.6. EXIT STATUS	96
35.7. BUGS	96
35.8. AUTHOR	96
35.9. REPORTING BUGS	96
35.10. COPYRIGHT	96
36. inivar(1)	98
36.1. NAME	98
36.2. SYNOPSIS	98
36.3. DESCRIPTION	98
36.4. OPTIONS	98
36.5. EXIT STATUS	98
36.6. BUGS	99
36.7. SEE ALSO	99

36.8. AUTHOR	99
36.9. REPORTING BUGS	99
36.10. COPYRIGHT	99
37. io(1)	100
37.1. NAME	100
37.2. SYNOPSIS	100
37.3. DESCRIPTION	100
37.4. PINS	100
37.5. REPORTING BUGS	101
37.6. AUTHOR	101
37.7. COPYRIGHT	101
38. latency-histogram(1)	102
38.1. NAME	102
38.2. SYNOPSIS	102
38.3. DESCRIPTION	102
38.4. OPTIONS	102
38.5. SEE ALSO	103
38.6. BUGS	103
38.7. AUTHOR	103
38.8. REPORTING BUGS	103
38.9. COPYRIGHT	103
39. latency-plot(1)	104
39.1. NAME	104
39.2. SYNOPSIS	104
39.3. DESCRIPTION	104
39.4. OPTIONS	104
39.5. SEE ALSO	104
39.6. BUGS	105
39.7. AUTHOR	105
39.8. REPORTING BUGS	105
39.9. COPYRIGHT	105
40. latency-test(1)	106
40.1. NAME	106
40.2. SYNOPSIS	106
40.3. DESCRIPTION	106
40.4. SEE ALSO	106
40.5. BUGS	106
40.6. AUTHOR	106
40.7. REPORTING BUGS	106
40.8. COPYRIGHT	106
41. lineardelta(1)	107
41.1. NAME	107

41.2. DESCRIPTION	107
41.3. SEE ALSO	107
41.4. BUGS	107
41.5. AUTHOR	107
41.6. REPORTING BUGS	107
41.7. COPYRIGHT	107
42. linuxcnc_check_ini(1)	108
42.1. NAME	108
42.2. SYNOPSIS	108
42.3. DESCRIPTION	108
42.4. OPTIONS	108
42.5. EXIT VALUE	108
42.6. SEE ALSO	108
42.7. AUTHOR	108
42.8. REPORTING BUGS	109
42.9. COPYRIGHT	109
43. linuxcnc_info(1)	110
43.1. NAME	110
43.2. SYNOPSIS	110
43.3. DESCRIPTION	110
43.4. SEE ALSO	110
43.5. BUGS	110
43.6. AUTHOR	110
43.7. REPORTING BUGS	110
43.8. COPYRIGHT	110
44. linuxcnc_module_helper(1)	111
44.1. NAME	111
44.2. SYNOPSIS	111
44.3. DESCRIPTION	111
44.4. SEE ALSO	111
44.5. BUGS	111
44.6. AUTHOR	111
44.7. REPORTING BUGS	111
44.8. COPYRIGHT	111
45. linuxcnc_var(1)	112
45.1. NAME	112
45.2. SYNOPSIS	112
45.3. DESCRIPTION	112
45.4. OPTIONS	112
45.5. SEE ALSO	112
45.6. BUGS	112
45.7. AUTHOR	112

45.8. REPORTING BUGS	113
45.9. COPYRIGHT	113
46. linuxcncld(1)	114
46.1. NAME	114
46.2. SYNOPSIS	114
46.3. DESCRIPTION	114
46.4. OPTIONS	114
46.5. SEE ALSO	114
46.6. BUGS	114
46.7. AUTHOR	114
46.8. REPORTING BUGS	114
46.9. COPYRIGHT	115
47. linuxcncmkdesktop(1)	116
47.1. NAME	116
47.2. SYNOPSIS	116
47.3. DESCRIPTION	116
47.4. SEE ALSO	116
47.5. BUGS	116
47.6. AUTHOR	116
47.7. REPORTING BUGS	116
47.8. COPYRIGHT	116
48. linuxcncrsh(1)	117
48.1. NAME	117
48.2. SYNOPSIS	117
48.3. DESCRIPTION	117
48.4. OPTIONS	117
48.5. RUNNING LINUXCNCRSH	118
48.6. COMMANDS	119
48.7. SUBCOMMANDS	120
48.8. EXAMPLE SESSION	128
48.9. SEE ALSO	129
49. linuxcncsvr(1)	130
49.1. NAME	130
49.2. SYNOPSIS	130
49.3. DESCRIPTION	130
49.4. SEE ALSO	130
49.5. BUGS	130
49.6. AUTHOR	130
49.7. REPORTING BUGS	130
49.8. COPYRIGHT	130
50. linuxcncctop(1)	131
50.1. NAME	131

50.2. SYNOPSIS	131
50.3. DESCRIPTION	131
50.4. SEE ALSO	131
50.5. BUGS	131
50.6. AUTHOR	131
50.7. REPORTING BUGS	131
50.8. COPYRIGHT	131
51. maho600gui(1)	132
51.1. NAME	132
51.2. DESCRIPTION	132
51.3. SEE ALSO	132
51.4. BUGS	132
51.5. AUTHOR	132
51.6. REPORTING BUGS	132
51.7. COPYRIGHT	132
52. max5gui(1)	133
52.1. NAME	133
52.2. DESCRIPTION	133
52.3. SEE ALSO	133
52.4. BUGS	133
52.5. AUTHOR	133
52.6. REPORTING BUGS	133
52.7. COPYRIGHT	133
53. mb2hal(1)	134
53.1. NAME	134
53.2. SYNOPSIS	134
53.3. DESCRIPTION	134
53.4. PINS	134
53.5. AUTHOR	135
53.6. LICENSE	135
54. mdi(1)	136
54.1. NAME	136
54.2. SYNOPSIS	136
54.3. DESCRIPTION	136
54.4. USAGE	136
54.5. SEE ALSO	136
54.6. BUGS	136
54.7. AUTHOR	136
54.8. REPORTING BUGS	137
54.9. COPYRIGHT	137
55. mdro(1)	138
55.1. NAME	138

55.2. SYNOPSIS	138
55.3. DESCRIPTION	138
55.4. OPTIONS	138
55.5. SCREEN CONFIGURATION	138
55.6. USAGE	139
55.7. EXAMPLE	139
55.8. AUTHOR	140
55.9. COPYRIGHT	140
56. melfagui(1)	141
56.1. NAME	141
56.2. DESCRIPTION	141
56.3. SEE ALSO	141
56.4. BUGS	141
56.5. AUTHOR	141
56.6. REPORTING BUGS	141
56.7. COPYRIGHT	141
57. mesambccc(1)	142
57.1. NAME	142
57.2. SYNOPSIS	142
57.3. DESCRIPTION	142
57.4. OPTIONS	142
57.5. MBCCS FILE FORMAT	142
57.6. SEE ALSO	155
57.7. AUTHOR	155
57.8. REPORTING BUGS	155
57.9. COPYRIGHT	155
58. milltask(1)	156
58.1. NAME	156
58.2. DESCRIPTION	156
58.3. PINS	156
58.4. NOTES	158
59. millturn(1)	159
59.1. NAME	159
59.2. DESCRIPTION	159
59.3. SEE ALSO	159
59.4. BUGS	159
59.5. AUTHOR	159
59.6. REPORTING BUGS	159
59.7. COPYRIGHT	159
60. mitsub_vfd(1)	160
60.1. NAME	160
60.2. SYNOPSIS	160

60.3. DESCRIPTION	160
60.4. HARDWARE SETUP	160
60.5. NOTES	161
60.6. PINS	162
60.7. SAMPLE HAL	163
60.8. ISSUES	164
61. modcompile(1)	165
61.1. NAME	165
61.2. SYNOPSIS	165
61.3. DESCRIPTION	165
61.4. OPTIONS	165
61.5. SEE ALSO	165
61.6. BUGS	166
61.7. AUTHOR	166
61.8. REPORTING BUGS	166
61.9. COPYRIGHT	166
62. monitor-xhc-hb04(1)	167
62.1. NAME	167
62.2. SYNOPSIS	167
62.3. DESCRIPTION	167
62.4. SEE ALSO	167
62.5. BUGS	167
62.6. AUTHOR	167
62.7. REPORTING BUGS	167
62.8. COPYRIGHT	167
63. motion-logger(1)	168
63.1. NAME	168
63.2. SYNOPSIS	168
63.3. DESCRIPTION	168
63.4. SEE ALSO	168
63.5. BUGS	168
63.6. AUTHOR	168
63.7. REPORTING BUGS	168
63.8. COPYRIGHT	168
64. moveoff_gui(1)	169
64.1. NAME	169
64.2. SYNOPSIS	169
64.3. DESCRIPTION	169
64.4. OPTIONS	169
64.5. OTHER OPTIONS	170
64.6. NOTES	170
64.7. USAGE	171

64.8. SEE ALSO	172
65. mqtt-publisher(1)	173
65.1. NAME	173
65.2. SYNOPSIS	173
65.3. DESCRIPTION	173
65.4. OPTIONS	173
65.5. FUNCTIONS	174
65.6. PINS	174
65.7. EXAMPLE	174
65.8. SEE ALSO	175
65.9. AUTHOR	175
65.10. COPYRIGHT	175
66. ngcgui(1)	176
66.1. NAME	176
66.2. SYNOPSIS	176
66.3. DESCRIPTION	176
66.4. SEE ALSO	176
66.5. BUGS	176
66.6. AUTHOR	176
66.7. REPORTING BUGS	176
66.8. COPYRIGHT	176
67. panelui(1)	177
67.1. NAME	177
67.2. SYNOPSIS	177
67.3. DESCRIPTION	177
67.4. SEE ALSO	177
67.5. BUGS	177
67.6. AUTHOR	177
67.7. REPORTING BUGS	177
67.8. COPYRIGHT	177
68. PI500_VFD(1)	178
68.1. NAME	178
68.2. SYNOPSIS	178
68.3. PINS	178
68.4. PARAMETERS	179
68.5. LICENSE	179
69. pmx485-test(1)	180
69.1. NAME	180
69.2. SYNOPSIS	180
69.3. DESCRIPTION	180
69.4. USAGE	180
69.5. AUTHOR	180

69.6. LICENSE	180
70. pmx485(1)	181
70.1. NAME	181
70.2. SYNOPSIS	181
70.3. DESCRIPTION	181
70.4. SEE ALSO	181
70.5. AUTHOR	181
70.6. LICENSE	181
71. pncconf(1)	182
71.1. NAME	182
71.2. SYNOPSIS	182
71.3. DESCRIPTION	182
71.4. SEE ALSO	182
71.5. BUGS	182
71.6. AUTHOR	182
71.7. REPORTING BUGS	182
71.8. COPYRIGHT	182
72. puma560gui(1)	183
72.1. NAME	183
72.2. DESCRIPTION	183
72.3. SEE ALSO	183
72.4. BUGS	183
72.5. AUTHOR	183
72.6. REPORTING BUGS	183
72.7. COPYRIGHT	183
73. pumagui(1)	184
73.1. NAME	184
73.2. DESCRIPTION	184
73.3. SEE ALSO	184
73.4. BUGS	184
73.5. AUTHOR	184
73.6. REPORTING BUGS	184
73.7. COPYRIGHT	184
74. pyngcgui(1)	185
74.1. NAME	185
74.2. SYNOPSIS	185
74.3. DESCRIPTION	185
74.4. SEE ALSO	185
74.5. BUGS	185
74.6. AUTHOR	185
74.7. REPORTING BUGS	185
74.8. COPYRIGHT	185

75. pyui(1)	186
75.1. NAME	186
75.2. SYNOPSIS	186
75.3. DESCRIPTION	186
75.4. SEE ALSO	186
75.5. BUGS	186
75.6. AUTHOR	186
75.7. REPORTING BUGS	186
75.8. COPYRIGHT	186
76. pyvcp(1)	187
76.1. NAME	187
76.2. SYNOPSIS	187
76.3. OPTIONS	187
76.4. SEE ALSO	187
77. pyvcp_demo(1)	188
77.1. NAME	188
77.2. SYNOPSIS	188
77.3. DESCRIPTION	188
77.4. USAGE	188
77.5. SEE ALSO	188
77.6. BUGS	188
77.7. AUTHOR	188
77.8. REPORTING BUGS	188
77.9. COPYRIGHT	188
78. qtplasmac-materials(1)	190
78.1. NAME	190
78.2. SYNOPSIS	190
78.3. DESCRIPTION	190
78.4. SEE ALSO	190
78.5. AUTHOR	190
78.6. LICENSE	190
79. qtplasmac_gcode(1)	191
79.1. NAME	191
79.2. DESCRIPTION	191
79.3. SEE ALSO	191
79.4. BUGS	191
79.5. AUTHOR	191
79.6. REPORTING BUGS	191
79.7. COPYRIGHT	191
80. qtvcp(1)	192
80.1. NAME	192
80.2. SYNOPSIS	192

80.3. DESCRIPTION	192
80.4. OPTIONS	192
80.5. SEE ALSO	193
80.6. BUGS	193
80.7. AUTHOR	193
80.8. REPORTING BUGS	193
80.9. COPYRIGHT	193
81. rotarydelta(1)	194
81.1. NAME	194
81.2. DESCRIPTION	194
81.3. SEE ALSO	194
81.4. BUGS	194
81.5. AUTHOR	194
81.6. REPORTING BUGS	194
81.7. COPYRIGHT	194
82. rs274(1)	195
82.1. NAME	195
82.2. SYNOPSIS	195
82.3. DESCRIPTION	195
82.4. OPTIONS	195
82.5. EXAMPLE	196
82.6. SEE ALSO	196
82.7. BUGS	196
82.8. AUTHOR	196
82.9. REPORTING BUGS	197
82.10. COPYRIGHT	197
83. rtapi_app(1)	198
83.1. NAME	198
83.2. SYNOPSIS	198
83.3. DESCRIPTION	198
83.4. SEE ALSO	198
83.5. BUGS	198
83.6. AUTHOR	198
83.7. REPORTING BUGS	198
83.8. COPYRIGHT	198
84. scaragui(1)	199
84.1. NAME	199
84.2. DESCRIPTION	199
84.3. SEE ALSO	199
84.4. BUGS	199
84.5. AUTHOR	199
84.6. REPORTING BUGS	199

84.7. COPYRIGHT	199
85. schedrmt(1)	200
85.1. NAME	200
85.2. SYNOPSIS	200
85.3. DESCRIPTION	200
85.4. SEE ALSO	203
85.5. BUGS	203
85.6. AUTHOR	203
85.7. REPORTING BUGS	203
85.8. COPYRIGHT	204
86. scorbot-er-3(1)	205
86.1. NAME	205
86.2. DESCRIPTION	205
86.3. SEE ALSO	205
86.4. BUGS	205
86.5. AUTHOR	206
86.6. REPORTING BUGS	206
86.7. COPYRIGHT	206
87. sendkeys(1)	207
87.1. NAME	207
87.2. SYNOPSIS	207
87.3. DESCRIPTION	207
87.4. PINS	208
87.5. PARAMETERS	208
87.6. EXAMPLE	208
87.7. AUTHOR	209
87.8. LICENSE	209
88. setup_designer(1)	210
88.1. NAME	210
88.2. DESCRIPTION	210
88.3. SEE ALSO	210
88.4. BUGS	210
88.5. AUTHOR	210
88.6. REPORTING BUGS	210
88.7. COPYRIGHT	210
89. shuttle(1)	211
89.1. NAME	211
89.2. SYNOPSIS	211
89.3. DESCRIPTION	211
89.4. UDEV	211
89.5. A warning about the Jog Wheel	212
89.6. Pins	212

90. sim-torch(1)	213
90.1. NAME	213
90.2. SYNOPSIS	213
90.3. DESCRIPTION	213
90.4. PINS	213
90.5. AUTHOR	214
90.6. LICENSE	214
91. sim_pin(1)	215
91.1. NAME	215
91.2. SYNOPSIS	215
91.3. DESCRIPTION	215
91.4. NOTES	215
91.5. USAGE	216
91.6. EXAMPLE	216
92. simulate_probe(1)	217
92.1. NAME	217
92.2. SYNOPSIS	217
92.3. DESCRIPTION	217
92.4. SEE ALSO	217
92.5. BUGS	217
92.6. AUTHOR	217
92.7. REPORTING BUGS	217
92.8. COPYRIGHT	217
93. stepconf(1)	218
93.1. NAME	218
93.2. SYNOPSIS	218
93.3. DESCRIPTION	218
93.4. SEE ALSO	218
93.5. BUGS	218
93.6. AUTHOR	218
93.7. REPORTING BUGS	218
93.8. COPYRIGHT	218
94. svd-ps_vfd(1)	219
94.1. NAME	219
94.2. SYNOPSIS	219
94.3. DESCRIPTION	219
94.4. Hardware setup	219
94.5. Firmware setup	219
94.6. OPTIONS	219
94.7. PINS	220
94.8. AUTHOR	221
94.9. LICENSE	221

95. teach-in(1)	222
95.1. NAME	222
95.2. SYNOPSIS	222
95.3. DESCRIPTION	222
95.4. SEE ALSO	222
95.5. BUGS	222
95.6. AUTHOR	222
95.7. REPORTING BUGS	222
95.8. COPYRIGHT	222
96. THERMISTOR(1)	223
96.1. NAME	223
96.2. SYNOPSIS	223
96.3. DESCRIPTION	223
96.4. PINS	223
96.5. LICENSE	224
97. tool_mmap_read(1)	225
97.1. NAME	225
97.2. DESCRIPTION	225
97.3. SEE ALSO	225
97.4. BUGS	225
97.5. AUTHOR	225
97.6. REPORTING BUGS	225
97.7. COPYRIGHT	225
98. tool_watch(1)	226
98.1. NAME	226
98.2. DESCRIPTION	226
98.3. SEE ALSO	226
98.4. BUGS	226
98.5. AUTHOR	226
98.6. REPORTING BUGS	226
98.7. COPYRIGHT	226
99. tooledit(1)	227
99.1. NAME	227
99.2. SYNOPSIS	227
99.3. DESCRIPTION	227
99.4. SEE ALSO	227
99.5. BUGS	227
99.6. AUTHOR	227
99.7. REPORTING BUGS	227
99.8. COPYRIGHT	227
100. touchy(1)	228
100.1. NAME	228

100.2. SYNOPSIS	228
100.3. DESCRIPTION	228
100.4. OPTIONS	228
100.5. SEE ALSO	228
100.6. BUGS	228
100.7. AUTHOR	228
100.8. REPORTING BUGS	228
100.9. COPYRIGHT	228
101. update_ini(1)	230
101.1. NAME	230
101.2. SYNOPSIS	230
101.3. DESCRIPTION	230
101.4. SEE ALSO	230
101.5. BUGS	230
101.6. AUTHOR	230
101.7. REPORTING BUGS	230
101.8. COPYRIGHT	230
102. vfdb_vfd(1)	231
102.1. NAME	231
102.2. SYNOPSIS	231
102.3. DESCRIPTION	231
102.4. QUICK START	231
102.5. OPTIONS	231
102.6. INI CONFIG VARIABLES	232
102.7. PINS	233
102.8. PARAMETERS	234
102.9. USAGE	235
102.10. AUTHOR	235
102.11. LICENSE	235
103. vfs11_vfd(1)	236
103.1. NAME	236
103.2. SYNOPSIS	236
103.3. DESCRIPTION	236
103.4. OPTIONS	236
103.5. PINS	236
103.6. PARAMETERS	239
103.7. USAGE	239
103.8. AUTHOR	239
103.9. LICENSE	239
104. WJ200_VFD(1)	240
104.1. NAME	240
104.2. SYNOPSIS	240

104.3. PINS	240
104.4. PARAMETERS	241
104.5. LICENSE	241
105. xhc-hb04-accel(1)	242
105.1. NAME	242
105.2. SYNOPSIS	242
105.3. DESCRIPTION	242
105.4. SEE ALSO	242
105.5. BUGS	242
105.6. AUTHOR	242
105.7. REPORTING BUGS	242
105.8. COPYRIGHT	242
106. xhc-hb04(1)	243
106.1. NAME	243
106.2. DESCRIPTION	243
106.3. UDEV	243
106.4. Standalone Usage	243
106.5. Options	244
106.6. button-cfg-file format	244
106.7. HAL Usage	244
106.8. Input Pins (Control)	245
106.9. Input Pins (to the pendant LCD display)	245
106.10. Output Pins (Status)	246
106.11. Output Pins (for jogging using axis.N.jog-counts)	246
106.12. Experimental: Pins for halui plus/minus jogging.	246
106.13. Button output pins (for the 18 button, layout2 pendant)	247
106.14. Synthesized button pins	247
106.15. DEBUGGING	248
106.16. Sim Configs	248
106.17. AUTHOR	249
107. xhc-whb04b-6(1)	250
107.1. NAME	250
107.2. SYNOPSIS	250
107.3. DESCRIPTION	250
107.4. OPTIONS	250
107.5. UDEV	251
107.6. Standalone Usage	252
107.7. HAL Usage	252
107.8. HAL Configuration Example	260
107.9. SEE ALSO	264
107.10. NOTES	264
107.11. AUTHOR	264

107.12. HISTORY	265
107.13. COPYRIGHT	265
108. xyzab-tdr-gui(1)	266
108.1. NAME	266
108.2. DESCRIPTION	266
108.3. SEE ALSO	266
108.4. BUGS	266
108.5. AUTHOR	266
108.6. REPORTING BUGS	266
108.7. COPYRIGHT	266
109. xyzac-trt-gui(1)	267
109.1. NAME	267
109.2. DESCRIPTION	267
109.3. SEE ALSO	267
109.4. BUGS	267
109.5. AUTHOR	267
109.6. REPORTING BUGS	267
109.7. COPYRIGHT	267
110. xyzbc-trt-gui(1)	268
110.1. NAME	268
110.2. DESCRIPTION	268
110.3. SEE ALSO	268
110.4. BUGS	268
110.5. AUTHOR	268
110.6. REPORTING BUGS	268
110.7. COPYRIGHT	268
111. hal(3)	269
111.1. NAME	269
111.2. DESCRIPTION	269
111.3. REALTIME CONSIDERATIONS	270
111.4. HAL STATUS CODES	270
111.5. SEE ALSO	270
112. hal_add_funct_to_thread(3)	271
112.1. NAME	271
112.2. SYNTAX	271
112.3. ARGUMENTS	271
112.4. DESCRIPTION	271
112.5. RETURN VALUE	271
112.6. REALTIME CONSIDERATIONS	271
112.7. SEE ALSO	272
113. hal_create_thread(3)	273
113.1. NAME	273

113.2. SYNTAX	273
113.3. ARGUMENTS	273
113.4. DESCRIPTION	273
113.5. REALTIME CONSIDERATIONS	273
113.6. RETURN VALUE	273
113.7. SEE ALSO	274
114. hal_exit(3)	275
114.1. NAME	275
114.2. SYNTAX	275
114.3. ARGUMENTS	275
114.4. DESCRIPTION	275
114.5. REALTIME CONSIDERATIONS	275
114.6. RETURN VALUE	275
115. hal_export_func(3)	276
115.1. NAME	276
115.2. SYNTAX	276
115.3. ARGUMENTS	276
115.4. DESCRIPTION	276
115.5. RETURN VALUE	277
115.6. SEE ALSO	277
116. hal_init(3)	278
116.1. NAME	278
116.2. SYNTAX	278
116.3. ARGUMENTS	278
116.4. DESCRIPTION	278
116.5. REALTIME CONSIDERATIONS	278
116.6. RETURN VALUE	278
117. hal_malloc(3)	279
117.1. NAME	279
117.2. SYNTAX	279
117.3. ARGUMENTS	279
117.4. DESCRIPTION	279
117.5. RETURN VALUE	279
118. hal_param_alias(3)	280
118.1. NAME	280
118.2. SYNTAX	280
118.3. ARGUMENTS	280
118.4. DESCRIPTION	280
118.5. RETURN VALUE	280
118.6. SEE ALSO	280
119. hal_param_new(3)	281
119.1. NAME	281

119.2. SYNTAX	281
119.3. ARGUMENTS	281
119.4. DESCRIPTION	282
119.5. RETURN VALUE	282
119.6. SEE ALSO	282
120. hal_parport(3)	283
120.1. NAME	283
120.2. SYNTAX	283
120.3. ARGUMENTS	283
120.4. DESCRIPTION	283
120.5. HIGH ADDRESS PROBING	283
120.6. PARPORT STRUCTURE	284
120.7. RETURN VALUE	284
120.8. NOTES	284
121. hal_pin_alias(3)	285
121.1. NAME	285
121.2. SYNTAX	285
121.3. ARGUMENTS	285
121.4. DESCRIPTION	285
121.5. RETURN VALUE	285
121.6. SEE ALSO	285
122. hal_pin_new(3)	286
122.1. NAME	286
122.2. SYNTAX	286
122.3. ARGUMENTS	286
122.4. DESCRIPTION	287
122.5. RETURN VALUE	287
122.6. SEE ALSO	287
123. hal_port(3)	288
123.1. NAME	288
123.2. SYNOPSIS	288
123.3. DESCRIPTION	288
123.4. ARGUMENTS	289
123.5. SAMPLE CODE	290
123.6. REALTIME CONSIDERATIONS	290
123.7. SEE ALSO	290
124. hal_ready(3)	291
124.1. NAME	291
124.2. SYNTAX	291
124.3. ARGUMENTS	291
124.4. DESCRIPTION	291
124.5. RETURN VALUE	291

125. hal_set_constructor(3)	292
125.1. NAME	292
125.2. SYNTAX	292
125.3. ARGUMENTS	292
125.4. DESCRIPTION	292
125.5. RETURN VALUE	292
125.6. SEE ALSO	292
126. hal_set_lock(3)	293
126.1. NAME	293
126.2. SYNTAX	293
126.3. ARGUMENTS	293
126.4. RETURN VALUE	293
127. hal_signal_new(3)	294
127.1. NAME	294
127.2. SYNTAX	294
127.3. ARGUMENTS	294
127.4. DESCRIPTION	294
127.5. RETURN VALUE	295
127.6. SEE ALSO	295
128. hal_start_threads(3)	296
128.1. NAME	296
128.2. SYNTAX	296
128.3. DESCRIPTION	296
128.4. RETURN VALUE	296
128.5. SEE ALSO	296
129. hal_stream(3)	297
129.1. NAME	297
129.2. SYNOPSIS	297
129.3. DESCRIPTION	297
129.4. ARGUMENTS	299
129.5. SAMPLE CODE	300
129.6. REALTIME CONSIDERATIONS	300
129.7. RETURN VALUE	300
129.8. BUGS	300
129.9. SEE ALSO	300
130. hal_type_t(3)	301
130.1. NAME	301
130.2. DESCRIPTION	301
130.3. NOTES	302
130.4. SEE ALSO	302
131. rtapi(3)	303
131.1. NAME	303

131.2. DESCRIPTION	303
131.3. HEADER FILES	303
131.4. REALTIME CONSIDERATIONS	304
131.5. RTAPI STATUS CODES	304
132. rtapi_app_exit(3)	305
132.1. NAME	305
132.2. SYNTAX	305
132.3. ARGUMENTS	305
132.4. DESCRIPTION	305
132.5. RETURN VALUE	305
132.6. REALTIME CONSIDERATIONS	305
132.7. SEE ALSO	305
133. rtapi_app_main(3)	306
133.1. NAME	306
133.2. SYNTAX	306
133.3. ARGUMENTS	306
133.4. DESCRIPTION	306
133.5. RETURN VALUE	306
133.6. REALTIME CONSIDERATIONS	306
133.7. SEE ALSO	306
134. rtapi_atomic(3)	307
134.1. NAME	307
134.2. SYNTAX	307
134.3. ARGUMENTS	307
134.4. DESCRIPTION	307
134.5. REALTIME CONSIDERATIONS	308
134.6. RETURN VALUE	308
134.7. SEE ALSO	308
135. rtapi_bool(3)	309
135.1. NAME	309
135.2. SYNTAX	309
135.3. DESCRIPTION	309
135.4. REALTIME CONSIDERATIONS	309
135.5. NOTES	309
136. rtapi_byteorder(3)	310
136.1. NAME	310
136.2. SYNTAX	310
136.3. DESCRIPTION	310
136.4. REALTIME CONSIDERATIONS	310
136.5. RETURN VALUE	310
137. rtapi_clock_set_period(3)	311
137.1. NAME	311

137.2. SYNTAX	311
137.3. ARGUMENTS	311
137.4. DESCRIPTION	311
137.5. REALTIME CONSIDERATIONS	311
137.6. RETURN VALUE	311
138. rtapi_delay(3)	312
138.1. NAME	312
138.2. SYNTAX	312
138.3. ARGUMENTS	312
138.4. DESCRIPTION	312
138.5. REALTIME CONSIDERATIONS	312
138.6. RETURN VALUE	312
138.7. SEE ALSO	312
139. rtapi_device(3)	313
139.1. NAME	313
139.2. SYNTAX	313
139.3. DESCRIPTION	313
139.4. REALTIME CONSIDERATIONS	313
139.5. RETURN VALUE	313
140. rtapi_div_u64(3)	314
140.1. NAME	314
140.2. SYNTAX	314
140.3. ARGUMENTS	314
140.4. DESCRIPTION	314
140.5. RETURN VALUE	314
140.6. NOTES	314
140.7. REALTIME CONSIDERATIONS	315
141. rtapi_exit(3)	316
141.1. NAME	316
141.2. SYNTAX	316
141.3. ARGUMENTS	316
141.4. DESCRIPTION	316
141.5. REALTIME CONSIDERATIONS	316
141.6. RETURN VALUE	316
142. rtapi_firmware(3)	317
142.1. NAME	317
142.2. SYNTAX	317
142.3. DESCRIPTION	317
142.4. REALTIME CONSIDERATIONS	317
142.5. RETURN VALUE	317
143. rtapi_get_msg_level(3)	318
143.1. NAME	318

143.2. SYNTAX	318
143.3. ARGUMENTS	318
143.4. DESCRIPTION	318
143.5. REALTIME CONSIDERATIONS	318
143.6. RETURN VALUE	318
143.7. SEE ALSO	318
144. rtapi_get_time(3)	319
144.1. NAME	319
144.2. SYNTAX	319
144.3. DESCRIPTION	319
144.4. RETURN VALUE	319
144.5. NOTES	319
144.6. REALTIME CONSIDERATIONS	320
145. rtapi_gfp(3)	321
145.1. NAME	321
145.2. SYNTAX	321
145.3. DESCRIPTION	321
145.4. REALTIME CONSIDERATIONS	321
145.5. RETURN VALUE	321
146. rtapi_init(3)	322
146.1. NAME	322
146.2. SYNTAX	322
146.3. ARGUMENTS	322
146.4. DESCRIPTION	322
146.5. REALTIME CONSIDERATIONS	322
146.6. RETURN VALUE	322
147. rtapi_io(3)	323
147.1. NAME	323
147.2. SYNTAX	323
147.3. DESCRIPTION	323
147.4. REALTIME CONSIDERATIONS	323
147.5. RETURN VALUE	323
147.6. SEE ALSO	323
147.7. AUTHOR	323
148. rtapi_is(3)	324
148.1. NAME	324
148.2. SYNTAX	324
148.3. DESCRIPTION	324
148.4. REALTIME CONSIDERATIONS	324
148.5. RETURN VALUE	324
149. rtapi_list(3)	325
149.1. NAME	325

149.2. SYNTAX	325
149.3. DESCRIPTION	325
149.4. REALTIME CONSIDERATIONS	325
149.5. RETURN VALUE	325
150. rtapi_module_param(3)	326
150.1. NAME	326
150.2. SYNTAX	326
150.3. ARGUMENTS	326
150.4. DESCRIPTION	326
150.5. NOTES	327
150.6. Interpretation of license strings	327
150.7. REALTIME CONSIDERATIONS	327
151. rtapi_mutex(3)	328
151.1. NAME	328
151.2. SYNTAX	328
151.3. ARGUMENTS	328
151.4. DESCRIPTION	328
151.5. REALTIME CONSIDERATIONS	328
151.6. RETURN VALUE	328
152. rtapi_open_as_root(3)	329
152.1. NAME	329
152.2. SYNTAX	329
152.3. ARGUMENTS	329
152.4. DESCRIPTION	329
152.5. RETURN VALUE	329
152.6. REALTIME CONSIDERATIONS	329
152.7. SEE ALSO	329
153. rtapi_outb(3)	330
153.1. NAME	330
153.2. SYNTAX	330
153.3. ARGUMENTS	330
153.4. DESCRIPTION	330
153.5. REALTIME CONSIDERATIONS	330
153.6. RETURN VALUE	330
153.7. NOTES	330
153.8. SEE ALSO	330
154. rtapi_parport(3)	331
154.1. NAME	331
154.2. SYNTAX	331
154.3. ARGUMENTS	331
154.4. DESCRIPTION	331
154.5. HIGH ADDRESS PROBING	331

154.6. PARPORT STRUCTURE	332
154.7. RETURN VALUE	332
154.8. NOTES	332
155. rtapi_pci(3)	333
155.1. NAME	333
155.2. SYNTAX	333
155.3. DESCRIPTION	333
155.4. REALTIME CONSIDERATIONS	333
155.5. RETURN VALUE	333
156. rtapi_print(3)	334
156.1. NAME	334
156.2. SYNTAX	334
156.3. ARGUMENTS	334
156.4. DESCRIPTION	334
156.5. REALTIME CONSIDERATIONS	334
156.6. RETURN VALUE	335
156.7. SEE ALSO	335
157. rtapi_prio(3)	336
157.1. NAME	336
157.2. SYNTAX	336
157.3. ARGUMENTS	336
157.4. DESCRIPTION	336
157.5. REALTIME CONSIDERATIONS	336
157.6. RETURN VALUE	336
157.7. SEE ALSO	336
158. rtapi_region(3)	337
158.1. NAME	337
158.2. SYNTAX	337
158.3. ARGUMENTS	337
158.4. DESCRIPTION	337
158.5. REALTIME CONSIDERATIONS	337
158.6. RETURN VALUE	337
159. rtapi_shmem(3)	338
159.1. NAME	338
159.2. SYNTAX	338
159.3. ARGUMENTS	338
159.4. DESCRIPTION	338
159.5. REALTIME CONSIDERATIONS	339
160. rtapi_slab(3)	340
160.1. NAME	340
160.2. SYNTAX	340
160.3. DESCRIPTION	340

160.4. REALTIME CONSIDERATIONS	340
160.5. RETURN VALUE	340
161. rtapi_snprintf(3)	341
161.1. NAME	341
161.2. SYNTAX	341
161.3. ARGUMENTS	341
161.4. DESCRIPTION	341
161.5. REALTIME CONSIDERATIONS	341
161.6. RETURN VALUE	341
161.7. SEE ALSO	341
162. rtapi_stdint(3)	342
162.1. NAME	342
162.2. SYNTAX	342
162.3. DESCRIPTION	342
162.4. REALTIME CONSIDERATIONS	342
162.5. RETURN VALUE	342
163. rtapi_string(3)	343
163.1. NAME	343
163.2. SYNTAX	343
163.3. DESCRIPTION	343
163.4. REALTIME CONSIDERATIONS	343
163.5. RETURN VALUE	343
164. rtapi_strncpy(3)	344
164.1. NAME	344
164.2. SYNTAX	344
164.3. DESCRIPTION	344
164.4. RETURN VALUE	344
164.5. SEE ALSO	344
165. rtapi_task_new(3)	345
165.1. NAME	345
165.2. SYNTAX	345
165.3. ARGUMENTS	345
165.4. DESCRIPTION	345
165.5. REALTIME CONSIDERATIONS	345
165.6. RETURN VALUE	345
165.7. SEE ALSO	346
166. rtapi_task_pause(3)	347
166.1. NAME	347
166.2. SYNTAX	347
166.3. ARGUMENTS	347
166.4. DESCRIPTION	347
166.5. REALTIME CONSIDERATIONS	347

166.6. RETURN VALUE	347
166.7. SEE ALSO	348
167. rtapi_task_self(3)	349
167.1. NAME	349
167.2. SYNTAX	349
167.3. DESCRIPTION	349
167.4. REALTIME CONSIDERATIONS	349
167.5. RETURN VALUE	349
167.6. SEE ALSO	349
168. rtapi_task_start(3)	350
168.1. NAME	350
168.2. SYNTAX	350
168.3. ARGUMENTS	350
168.4. DESCRIPTION	350
168.5. REALTIME CONSIDERATIONS	350
168.6. RETURN VALUE	350
168.7. SEE ALSO	350
169. rtapi_task_wait(3)	351
169.1. NAME	351
169.2. SYNTAX	351
169.3. DESCRIPTION	351
169.4. REALTIME CONSIDERATIONS	351
169.5. RETURN VALUE	351
169.6. SEE ALSO	351
170. hm2_allocate_bspi_tram(3)	352
170.1. NAME	352
170.2. SYNTAX	352
170.3. DESCRIPTION	352
170.4. REALTIME CONSIDERATIONS	352
170.5. RETURN VALUE	352
170.6. SEE ALSO	352
171. hm2_bspi_set_read_function(3)	353
171.1. NAME	353
171.2. SYNTAX	353
171.3. DESCRIPTION	353
171.4. REALTIME CONSIDERATIONS	353
171.5. RETURN VALUE	353
171.6. SEE ALSO	353
172. hm2_bspi_set_write_function(3)	354
172.1. NAME	354
172.2. SYNTAX	354
172.3. DESCRIPTION	354

172.4. REALTIME CONSIDERATIONS	354
172.5. RETURN VALUE	354
172.6. SEE ALSO	354
173. hm2_bsp_i_setup_chan(3)	356
173.1. NAME	356
173.2. SYNTAX	356
173.3. DESCRIPTION	356
173.4. REALTIME CONSIDERATIONS	357
173.5. RETURN VALUE	357
173.6. SEE ALSO	357
174. hm2_bsp_i_write_chan(3)	358
174.1. NAME	358
174.2. SYNTAX	358
174.3. DESCRIPTION	358
174.4. REALTIME CONSIDERATIONS	358
174.5. RETURN VALUE	358
174.6. SEE ALSO	358
175. hm2_pktuart(3)	359
175.1. NAME	359
175.2. SYNOPSIS	359
175.3. DESCRIPTION	359
175.4. PINS	363
175.5. EXAMPLE	364
175.6. Testing	364
175.7. AUTHOR	364
175.8. LICENSE	364
176. hm2_pktuart_read(3)	365
176.1. NAME	365
176.2. SYNTAX	365
176.3. DESCRIPTION	365
177. hm2_pktuart_send(3)	366
177.1. NAME	366
177.2. SYNTAX	366
177.3. DESCRIPTION	366
178. hm2_pktuart_setup(3)	367
178.1. NAME	367
178.2. SYNTAX	367
178.3. DESCRIPTION	367
179. hm2_tram_add_bsp_i_frame(3)	368
179.1. NAME	368
179.2. SYNTAX	368
179.3. DESCRIPTION	368

179.4. REALTIME CONSIDERATIONS	368
179.5. RETURN VALUE	368
179.6. SEE ALSO	368
180. hm2_uart_read(3)	369
180.1. NAME	369
180.2. SYNTAX	369
180.3. DESCRIPTION	369
180.4. RETURN VALUE	369
180.5. SEE ALSO	369
181. hm2_uart_send(3)	370
181.1. NAME	370
181.2. SYNTAX	370
181.3. DESCRIPTION	370
181.4. RETURN VALUE	370
181.5. SEE ALSO	370
182. hm2_uart_setup(3)	371
182.1. NAME	371
182.2. SYNTAX	371
182.3. DESCRIPTION	371
182.4. RETURN VALUE	371
182.5. SEE ALSO	372
183. ABS(9)	373
183.1. NAME	373
183.2. SYNOPSIS	373
183.3. FUNCTIONS	373
183.4. PINS	373
183.5. AUTHOR	373
183.6. LICENSE	373
184. ABS_S32(9)	374
184.1. NAME	374
184.2. SYNOPSIS	374
184.3. FUNCTIONS	374
184.4. PINS	374
184.5. AUTHOR	374
184.6. LICENSE	374
185. ABS_S64(9)	375
185.1. NAME	375
185.2. SYNOPSIS	375
185.3. FUNCTIONS	375
185.4. PINS	375
185.5. AUTHOR	375
185.6. LICENSE	375

186. AND2(9)	376
186.1. NAME	376
186.2. SYNOPSIS	376
186.3. DESCRIPTION	376
186.4. FUNCTIONS	376
186.5. PINS	376
186.6. SEE ALSO	376
186.7. AUTHOR	376
186.8. LICENSE	377
187. ANGLEJOG(9)	378
187.1. NAME	378
187.2. SYNOPSIS	378
187.3. DESCRIPTION	378
187.4. FUNCTIONS	378
187.5. PINS	379
187.6. AUTHOR	380
187.7. LICENSE	380
188. at_pid(9)	381
188.1. NAME	381
188.2. DESCRIPTION	381
188.3. SEE ALSO	381
189. AXISTEST(9)	382
189.1. NAME	382
189.2. SYNOPSIS	382
189.3. FUNCTIONS	382
189.4. PINS	382
189.5. PARAMETERS	383
189.6. AUTHOR	383
189.7. LICENSE	383
190. BIN2GRAY(9)	384
190.1. NAME	384
190.2. SYNOPSIS	384
190.3. DESCRIPTION	384
190.4. FUNCTIONS	384
190.5. PINS	384
190.6. AUTHOR	384
190.7. LICENSE	384
191. BIQUAD(9)	385
191.1. NAME	385
191.2. SYNOPSIS	385
191.3. DESCRIPTION	385
191.4. FUNCTIONS	385

191.5. PINS	385
191.6. PARAMETERS	386
191.7. AUTHOR	386
191.8. LICENSE	386
192. BITMERGE(9)	387
192.1. NAME	387
192.2. SYNOPSIS	387
192.3. DESCRIPTION	387
192.4. FUNCTIONS	387
192.5. PINS	387
192.6. AUTHOR	387
192.7. LICENSE	387
193. BITSlice(9)	388
193.1. NAME	388
193.2. SYNOPSIS	388
193.3. DESCRIPTION	388
193.4. FUNCTIONS	388
193.5. PINS	388
193.6. AUTHOR	388
193.7. LICENSE	388
194. BITWISE(9)	389
194.1. NAME	389
194.2. SYNOPSIS	389
194.3. FUNCTIONS	389
194.4. PINS	389
194.5. AUTHOR	389
194.6. LICENSE	390
195. BLDC(9)	391
195.1. NAME	391
195.2. SYNOPSIS	391
195.3. DESCRIPTION	391
195.4. FUNCTIONS	392
195.5. PINS	393
195.6. PARAMETERS	396
195.7. AUTHOR	399
195.8. LICENSE	399
196. BLEND(9)	400
196.1. NAME	400
196.2. SYNOPSIS	400
196.3. FUNCTIONS	400
196.4. PINS	400
196.5. PARAMETERS	400

196.6. AUTHOR	400
196.7. LICENSE	400
197. CAROUSEL(9)	401
197.1. NAME	401
197.2. SYNOPSIS	401
197.3. DESCRIPTION	401
197.4. FUNCTIONS	402
197.5. PINS	402
197.6. PARAMETERS	404
197.7. AUTHOR	405
197.8. LICENSE	405
198. CHARGE_PUMP(9)	406
198.1. NAME	406
198.2. SYNOPSIS	406
198.3. DESCRIPTION	406
198.4. FUNCTIONS	406
198.5. PINS	406
198.6. AUTHOR	406
198.7. LICENSE	406
199. CLARKE2(9)	407
199.1. NAME	407
199.2. SYNOPSIS	407
199.3. DESCRIPTION	407
199.4. FUNCTIONS	407
199.5. PINS	407
199.6. SEE ALSO	407
199.7. AUTHOR	407
199.8. LICENSE	408
200. CLARKE3(9)	409
200.1. NAME	409
200.2. SYNOPSIS	409
200.3. DESCRIPTION	409
200.4. FUNCTIONS	409
200.5. PINS	409
200.6. SEE ALSO	409
200.7. AUTHOR	409
200.8. LICENSE	410
201. CLARKEINV(9)	411
201.1. NAME	411
201.2. SYNOPSIS	411
201.3. DESCRIPTION	411
201.4. FUNCTIONS	411

201.5. PINS	411
201.6. SEE ALSO	411
201.7. AUTHOR	411
201.8. LICENSE	412
202. classicladder(9)	413
202.1. NAME	413
202.2. SYNOPSIS	413
202.3. DESCRIPTION	413
202.4. PINS	413
202.5. PARAMETERS	414
202.6. FUNCTIONS	414
202.7. BUGS	414
202.8. SEE ALSO	414
203. COMP(9)	415
203.1. NAME	415
203.2. SYNOPSIS	415
203.3. FUNCTIONS	415
203.4. PINS	415
203.5. PARAMETERS	415
203.6. AUTHOR	415
203.7. LICENSE	416
204. CONV_BIT_FLOAT(9)	417
204.1. NAME	417
204.2. SYNOPSIS	417
204.3. FUNCTIONS	417
204.4. PINS	417
204.5. AUTHOR	417
204.6. LICENSE	417
205. CONV_BIT_S32(9)	418
205.1. NAME	418
205.2. SYNOPSIS	418
205.3. FUNCTIONS	418
205.4. PINS	418
205.5. AUTHOR	418
205.6. LICENSE	418
206. CONV_BIT_S64(9)	419
206.1. NAME	419
206.2. SYNOPSIS	419
206.3. FUNCTIONS	419
206.4. PINS	419
206.5. AUTHOR	419
206.6. LICENSE	419

207. CONV_BIT_U32(9)	420
207.1. NAME	420
207.2. SYNOPSIS	420
207.3. FUNCTIONS	420
207.4. PINS	420
207.5. AUTHOR	420
207.6. LICENSE	420
208. CONV_BIT_U64(9)	421
208.1. NAME	421
208.2. SYNOPSIS	421
208.3. FUNCTIONS	421
208.4. PINS	421
208.5. AUTHOR	421
208.6. LICENSE	421
209. CONV_FLOAT_S32(9)	422
209.1. NAME	422
209.2. SYNOPSIS	422
209.3. FUNCTIONS	422
209.4. PINS	422
209.5. PARAMETERS	422
209.6. AUTHOR	422
209.7. LICENSE	422
210. CONV_FLOAT_S64(9)	423
210.1. NAME	423
210.2. SYNOPSIS	423
210.3. FUNCTIONS	423
210.4. PINS	423
210.5. PARAMETERS	423
210.6. AUTHOR	423
210.7. LICENSE	423
211. CONV_FLOAT_U32(9)	424
211.1. NAME	424
211.2. SYNOPSIS	424
211.3. FUNCTIONS	424
211.4. PINS	424
211.5. PARAMETERS	424
211.6. AUTHOR	424
211.7. LICENSE	424
212. CONV_FLOAT_U64(9)	425
212.1. NAME	425
212.2. SYNOPSIS	425
212.3. FUNCTIONS	425

212.4. PINS	425
212.5. PARAMETERS	425
212.6. AUTHOR	425
212.7. LICENSE	425
213. CONV_S32_BIT(9)	426
213.1. NAME	426
213.2. SYNOPSIS	426
213.3. FUNCTIONS	426
213.4. PINS	426
213.5. PARAMETERS	426
213.6. AUTHOR	426
213.7. LICENSE	426
214. CONV_S32_FLOAT(9)	427
214.1. NAME	427
214.2. SYNOPSIS	427
214.3. FUNCTIONS	427
214.4. PINS	427
214.5. AUTHOR	427
214.6. LICENSE	427
215. CONV_S32_S64(9)	428
215.1. NAME	428
215.2. SYNOPSIS	428
215.3. FUNCTIONS	428
215.4. PINS	428
215.5. AUTHOR	428
215.6. LICENSE	428
216. CONV_S32_U32(9)	429
216.1. NAME	429
216.2. SYNOPSIS	429
216.3. FUNCTIONS	429
216.4. PINS	429
216.5. PARAMETERS	429
216.6. AUTHOR	429
216.7. LICENSE	429
217. CONV_S32_U64(9)	430
217.1. NAME	430
217.2. SYNOPSIS	430
217.3. FUNCTIONS	430
217.4. PINS	430
217.5. PARAMETERS	430
217.6. AUTHOR	430
217.7. LICENSE	430

218. CONV_S64_BIT(9)	431
218.1. NAME	431
218.2. SYNOPSIS	431
218.3. FUNCTIONS	431
218.4. PINS	431
218.5. PARAMETERS	431
218.6. AUTHOR	431
218.7. LICENSE	431
219. CONV_S64_FLOAT(9)	432
219.1. NAME	432
219.2. SYNOPSIS	432
219.3. FUNCTIONS	432
219.4. PINS	432
219.5. AUTHOR	432
219.6. LICENSE	432
220. CONV_S64_S32(9)	433
220.1. NAME	433
220.2. SYNOPSIS	433
220.3. FUNCTIONS	433
220.4. PINS	433
220.5. PARAMETERS	433
220.6. AUTHOR	433
220.7. LICENSE	433
221. CONV_S64_U32(9)	434
221.1. NAME	434
221.2. SYNOPSIS	434
221.3. FUNCTIONS	434
221.4. PINS	434
221.5. PARAMETERS	434
221.6. AUTHOR	434
221.7. LICENSE	434
222. CONV_S64_U64(9)	435
222.1. NAME	435
222.2. SYNOPSIS	435
222.3. FUNCTIONS	435
222.4. PINS	435
222.5. PARAMETERS	435
222.6. AUTHOR	435
222.7. LICENSE	435
223. CONV_U32_BIT(9)	436
223.1. NAME	436
223.2. SYNOPSIS	436

223.3. FUNCTIONS	436
223.4. PINS	436
223.5. PARAMETERS	436
223.6. AUTHOR	436
223.7. LICENSE	436
224. CONV_U32_FLOAT(9)	437
224.1. NAME	437
224.2. SYNOPSIS	437
224.3. FUNCTIONS	437
224.4. PINS	437
224.5. AUTHOR	437
224.6. LICENSE	437
225. CONV_U32_S32(9)	438
225.1. NAME	438
225.2. SYNOPSIS	438
225.3. FUNCTIONS	438
225.4. PINS	438
225.5. PARAMETERS	438
225.6. AUTHOR	438
225.7. LICENSE	438
226. CONV_U32_S64(9)	439
226.1. NAME	439
226.2. SYNOPSIS	439
226.3. FUNCTIONS	439
226.4. PINS	439
226.5. AUTHOR	439
226.6. LICENSE	439
227. CONV_U32_U64(9)	440
227.1. NAME	440
227.2. SYNOPSIS	440
227.3. FUNCTIONS	440
227.4. PINS	440
227.5. AUTHOR	440
227.6. LICENSE	440
228. CONV_U64_BIT(9)	441
228.1. NAME	441
228.2. SYNOPSIS	441
228.3. FUNCTIONS	441
228.4. PINS	441
228.5. PARAMETERS	441
228.6. AUTHOR	441
228.7. LICENSE	441

229. CONV_U64_FLOAT(9)	442
229.1. NAME	442
229.2. SYNOPSIS	442
229.3. FUNCTIONS	442
229.4. PINS	442
229.5. AUTHOR	442
229.6. LICENSE	442
230. CONV_U64_S32(9)	443
230.1. NAME	443
230.2. SYNOPSIS	443
230.3. FUNCTIONS	443
230.4. PINS	443
230.5. PARAMETERS	443
230.6. AUTHOR	443
230.7. LICENSE	443
231. CONV_U64_S64(9)	444
231.1. NAME	444
231.2. SYNOPSIS	444
231.3. FUNCTIONS	444
231.4. PINS	444
231.5. PARAMETERS	444
231.6. AUTHOR	444
231.7. LICENSE	444
232. CONV_U64_U32(9)	445
232.1. NAME	445
232.2. SYNOPSIS	445
232.3. FUNCTIONS	445
232.4. PINS	445
232.5. PARAMETERS	445
232.6. AUTHOR	445
232.7. LICENSE	445
233. COREXY_BY_HAL(9)	446
233.1. NAME	446
233.2. SYNOPSIS	446
233.3. DESCRIPTION	446
233.4. FUNCTIONS	446
233.5. PINS	446
233.6. AUTHOR	447
233.7. LICENSE	447
234. counter(9)	448
234.1. NAME	448
234.2. SYNOPSIS	448

234.3. DESCRIPTION	448
234.4. FUNCTIONS	448
234.5. PINS	448
234.6. SEE ALSO	449
235. DBOUNCE(9)	450
235.1. NAME	450
235.2. SYNOPSIS	450
235.3. DESCRIPTION	450
235.4. FUNCTIONS	450
235.5. PINS	450
235.6. AUTHOR	450
235.7. LICENSE	450
236. DDT(9)	451
236.1. NAME	451
236.2. SYNOPSIS	451
236.3. DESCRIPTION	451
236.4. FUNCTIONS	451
236.5. PINS	451
236.6. NOTES	451
236.7. AUTHOR	451
236.8. LICENSE	451
237. DEADZONE(9)	452
237.1. NAME	452
237.2. SYNOPSIS	452
237.3. FUNCTIONS	452
237.4. PINS	452
237.5. PARAMETERS	452
237.6. AUTHOR	452
237.7. LICENSE	452
238. debounce(9)	453
238.1. NAME	453
238.2. SYNOPSIS	453
238.3. SEE ALSO	453
238.4. DESCRIPTION	453
238.5. FUNCTIONS	453
238.6. PINS	453
239. DEMUX(9)	454
239.1. NAME	454
239.2. SYNOPSIS	454
239.3. DESCRIPTION	454
239.4. FUNCTIONS	454
239.5. PINS	454

239.6. PARAMETERS	454
239.7. SEE ALSO	454
239.8. AUTHOR	454
239.9. LICENSE	455
240. demux_generic(9)	456
240.1. NAME	456
240.2. SYNOPSIS	456
240.3. FUNCTIONS	456
240.4. PINS	456
240.5. PARAMETERS	457
240.6. DESCRIPTION	457
240.7. SEE ALSO	457
240.8. AUTHOR	458
240.9. LICENSE	458
241. DIFFERENTIAL(9)	459
241.1. NAME	459
241.2. SYNOPSIS	459
241.3. FUNCTIONS	459
241.4. PINS	459
241.5. AUTHOR	459
241.6. LICENSE	460
242. DIV2(9)	461
242.1. NAME	461
242.2. SYNOPSIS	461
242.3. DESCRIPTION	461
242.4. FUNCTIONS	461
242.5. PINS	461
242.6. PARAMETERS	461
242.7. SEE ALSO	461
242.8. AUTHOR	461
242.9. LICENSE	462
243. EDGE(9)	463
243.1. NAME	463
243.2. SYNOPSIS	463
243.3. FUNCTIONS	463
243.4. PINS	463
243.5. PARAMETERS	463
243.6. AUTHOR	463
243.7. LICENSE	464
244. encoder(9)	465
244.1. NAME	465
244.2. SYNOPSIS	465

244.3. DESCRIPTION	465
244.4. FUNCTIONS	465
244.5. NAMING	466
244.6. PINS	466
244.7. PARAMETERS	468
245. encoder_ratio(9)	469
245.1. NAME	469
245.2. SYNOPSIS	469
245.3. DESCRIPTION	469
245.4. FUNCTIONS	469
245.5. NAMING	469
245.6. PINS	469
245.7. PARAMETERS	470
245.8. SEE ALSO	470
246. enum(9)	471
246.1. NAME	471
246.2. SYNOPSIS	471
246.3. DESCRIPTION	471
246.4. OPTIONS	471
246.5. FUNCTIONS	472
246.6. PINS	472
246.7. BUGS	472
246.8. AUTHOR	472
246.9. REPORTING BUGS	472
246.10. COPYRIGHT	473
247. EOFFSET_PER_ANGLE(9)	474
247.1. NAME	474
247.2. SYNOPSIS	474
247.3. DESCRIPTION	474
247.4. FUNCTIONS	474
247.5. PINS	474
247.6. EXAMPLES	476
247.7. NOTES	476
247.8. AUTHOR	476
247.9. LICENSE	476
248. ESTOP_LATCH(9)	477
248.1. NAME	477
248.2. SYNOPSIS	477
248.3. DESCRIPTION	477
248.4. FUNCTIONS	477
248.5. PINS	478
248.6. AUTHOR	478

248.7. LICENSE	478
249. FEEDCOMP(9)	479
249.1. NAME	479
249.2. SYNOPSIS	479
249.3. FUNCTIONS	479
249.4. PINS	479
249.5. PARAMETERS	479
249.6. NOTES	479
249.7. AUTHOR	479
249.8. LICENSE	479
250. FILTER_KALMAN(9)	480
250.1. NAME	480
250.2. SYNOPSIS	480
250.3. DESCRIPTION	480
250.4. FUNCTIONS	480
250.5. PINS	480
250.6. PARAMETERS	481
250.7. AUTHOR	481
250.8. LICENSE	481
251. FLIPFLOP(9)	482
251.1. NAME	482
251.2. SYNOPSIS	482
251.3. FUNCTIONS	482
251.4. PINS	482
251.5. AUTHOR	482
251.6. LICENSE	482
252. GANTRY(9)	483
252.1. NAME	483
252.2. SYNOPSIS	483
252.3. DESCRIPTION	483
252.4. FUNCTIONS	483
252.5. PINS	484
252.6. AUTHOR	484
252.7. LICENSE	484
253. gantrykins(9)	485
253.1. NAME	485
253.2. SYNOPSIS	485
253.3. SEE ALSO	485
254. GEARCHANGE(9)	486
254.1. NAME	486
254.2. SYNOPSIS	486
254.3. FUNCTIONS	486

254.4. PINS	486
254.5. PARAMETERS	486
254.6. AUTHOR	487
254.7. LICENSE	487
255. gentrivkins(9)	488
255.1. NAME	488
255.2. SEE ALSO	488
256. gladevc(9)	489
256.1. NAME	489
256.2. SYNOPSIS	489
256.3. DESCRIPTION	489
256.4. ISSUES	489
257. GRAY2BIN(9)	490
257.1. NAME	490
257.2. SYNOPSIS	490
257.3. DESCRIPTION	490
257.4. FUNCTIONS	490
257.5. PINS	490
257.6. AUTHOR	490
257.7. LICENSE	490
258. hal_bb_gpio(9)	491
258.1. NAME	491
258.2. SYNOPSIS	491
258.3. USER LEDS	491
258.4. INPUT PINS	491
258.5. OUTPUT PINS	492
258.6. PARAMETERS	492
258.7. FUNCTIONS	492
258.8. LICENSE	492
259. hal_parport(9)	493
259.1. NAME	493
259.2. SYNOPSIS	493
259.3. DESCRIPTION	493
259.4. OPTIONS	493
259.5. PINS	494
259.6. PARAMETERS	494
259.7. FUNCTIONS	495
259.8. USAGE	495
259.9. SEE ALSO	497
259.10. AUTHOR	497
260. HISTOBINS(9)	498
260.1. NAME	498

260.2. SYNOPSIS	498
260.3. DESCRIPTION	498
260.4. FUNCTIONS	499
260.5. PINS	499
260.6. AUTHOR	499
260.7. LICENSE	499
261. HISTOBINSTREAM(9)	500
261.1. NAME	500
261.2. SYNOPSIS	500
261.3. DESCRIPTION	500
261.4. FUNCTIONS	501
261.5. PINS	501
261.6. AUTHOR	502
261.7. LICENSE	502
262. hm2_7i43(9)	503
262.1. NAME	503
262.2. SYNOPSIS	503
262.3. DESCRIPTION	503
262.4. Jumper settings	504
262.5. Communicating with the board	504
262.6. SEE ALSO	504
262.7. LICENSE	504
263. hm2_7i90(9)	505
263.1. NAME	505
263.2. SYNOPSIS	505
263.3. DESCRIPTION	505
263.4. Communicating with the board	506
263.5. SEE ALSO	506
263.6. LICENSE	506
264. hm2_eth(9)	507
264.1. NAME	507
264.2. SYNOPSIS	507
264.3. DESCRIPTION	507
264.4. INTERFACE CONFIGURATION	507
264.5. PACKET LOSS	508
264.6. PINS	509
264.7. PARAMETERS	509
264.8. NOTES	509
264.9. BUGS	511
264.10. SEE ALSO	511
264.11. LICENSE	511
265. hm2_modbus(9)	512

265.1. NAME	512
265.2. SYNOPSIS	512
265.3. DESCRIPTION	512
265.4. SEE ALSO	516
265.5. AUTHOR	516
265.6. REPORTING BUGS	516
265.7. COPYRIGHT	516
266. hm2_pci(9)	517
266.1. NAME	517
266.2. SYNOPSIS	517
266.3. DESCRIPTION	517
266.4. SEE ALSO	517
266.5. LICENSE	517
267. hm2_rpspi(9)	518
267.1. NAME	518
267.2. SYNOPSIS	518
267.3. DESCRIPTION	519
267.4. INTERFACE CONFIGURATION	519
267.5. REALTIME PERFORMANCE OF THE BCM2835-SPI DRIVER	519
267.6. SPI CLOCK RATES	520
267.7. NOTE	521
267.8. SEE ALSO	521
267.9. LICENSE	521
268. hm2_spi(9)	522
268.1. NAME	522
268.2. SYNOPSIS	522
268.3. DESCRIPTION	522
268.4. INTERFACE CONFIGURATION	522
268.5. REALTIME PERFORMANCE OF LINUX SPIDEV DRIVERS	522
268.6. SPI CLOCK RATES	523
268.7. NOTE	523
268.8. SEE ALSO	523
268.9. LICENSE	523
269. hm2_spix(9)	524
269.1. NAME	524
269.2. SYNOPSIS	524
269.3. DESCRIPTION	525
269.4. HARDWARE DRIVERS	525
269.5. INTERFACE CONFIGURATION	526
269.6. REALTIME PERFORMANCE OF THE HM2_SPIX DRIVER	526
269.7. SPI CLOCK RATES	527
269.8. NOTES	528

269.9. SEE ALSO	528
269.10. LICENSE	528
270. HOMECOMP(9)	529
270.1. NAME	529
270.2. SYNOPSIS	529
270.3. DESCRIPTION	529
270.4. PINS	530
270.5. AUTHOR	530
270.6. LICENSE	530
271. hostmot2(9)	531
271.1. NAME	531
271.2. SYNOPSIS	531
271.3. DESCRIPTION	531
271.4. FUNCTIONS	561
271.5. SEE ALSO	562
271.6. LICENSE	562
272. HYPOT(9)	563
272.1. NAME	563
272.2. SYNOPSIS	563
272.3. FUNCTIONS	563
272.4. PINS	563
272.5. AUTHOR	563
272.6. LICENSE	563
273. ILOWPASS(9)	564
273.1. NAME	564
273.2. SYNOPSIS	564
273.3. DESCRIPTION	564
273.4. FUNCTIONS	564
273.5. PINS	564
273.6. PARAMETERS	564
273.7. AUTHOR	565
273.8. LICENSE	565
274. INTEG(9)	566
274.1. NAME	566
274.2. SYNOPSIS	566
274.3. FUNCTIONS	566
274.4. PINS	566
274.5. AUTHOR	566
274.6. LICENSE	566
275. INVERT(9)	567
275.1. NAME	567
275.2. SYNOPSIS	567

275.3. FUNCTIONS	567
275.4. PINS	567
275.5. PARAMETERS	567
275.6. SEE ALSO	567
275.7. AUTHOR	567
275.8. LICENSE	567
276. JOINT_AXIS_MAPPER(9)	568
276.1. NAME	568
276.2. SYNOPSIS	568
276.3. DESCRIPTION	568
276.4. FUNCTIONS	568
276.5. PINS	568
276.6. LICENSE	568
277. JOYHANDLE(9)	569
277.1. NAME	569
277.2. SYNOPSIS	569
277.3. DESCRIPTION	569
277.4. FUNCTIONS	569
277.5. PINS	569
277.6. PARAMETERS	570
277.7. AUTHOR	570
277.8. LICENSE	570
278. kins(9)	571
278.1. NAME	571
278.2. SYNOPSIS	571
278.3. DESCRIPTION	571
278.4. SEE ALSO	578
279. KNOB2FLOAT(9)	579
279.1. NAME	579
279.2. SYNOPSIS	579
279.3. FUNCTIONS	579
279.4. PINS	579
279.5. PARAMETERS	579
279.6. AUTHOR	579
279.7. LICENSE	579
280. LASERPOWER(9)	580
280.1. NAME	580
280.2. SYNOPSIS	580
280.3. DESCRIPTION	580
280.4. FUNCTIONS	580
280.5. PINS	580
280.6. LICENSE	581

281. LATENCYBINS(9)	582
281.1. NAME	582
281.2. SYNOPSIS	582
281.3. DESCRIPTION	582
281.4. FUNCTIONS	583
281.5. PINS	583
281.6. AUTHOR	583
281.7. LICENSE	583
282. LATENCYBINSTREAM(9)	584
282.1. NAME	584
282.2. SYNOPSIS	584
282.3. DESCRIPTION	584
282.4. FUNCTIONS	585
282.5. PINS	585
282.6. AUTHOR	586
282.7. LICENSE	586
283. lcd(9)	587
283.1. NAME	587
283.2. SYNOPSIS	587
283.3. FUNCTIONS	587
283.4. PINS	587
283.5. PARAMETERS	587
283.6. DESCRIPTION	587
283.7. AUTHOR	589
283.8. LICENSE	590
284. LED_DIM(9)	591
284.1. NAME	591
284.2. SYNOPSIS	591
284.3. DESCRIPTION	591
284.4. FUNCTIONS	591
284.5. PINS	591
284.6. AUTHOR	591
284.7. LICENSE	591
285. LIMIT1(9)	592
285.1. NAME	592
285.2. SYNOPSIS	592
285.3. FUNCTIONS	592
285.4. PINS	592
285.5. AUTHOR	592
285.6. LICENSE	592
286. LIMIT2(9)	593
286.1. NAME	593

286.2. SYNOPSIS	593
286.3. FUNCTIONS	593
286.4. PINS	593
286.5. AUTHOR	593
286.6. LICENSE	593
287. LIMIT3(9)	594
287.1. NAME	594
287.2. SYNOPSIS	594
287.3. FUNCTIONS	594
287.4. PINS	594
287.5. AUTHOR	594
287.6. LICENSE	595
288. LIMIT_AXIS(9)	596
288.1. NAME	596
288.2. SYNOPSIS	596
288.3. DESCRIPTION	596
288.4. FUNCTIONS	596
288.5. PINS	597
288.6. AUTHOR	597
288.7. LICENSE	598
289. LINCURVE(9)	599
289.1. NAME	599
289.2. SYNOPSIS	599
289.3. DESCRIPTION	599
289.4. FUNCTIONS	599
289.5. PINS	599
289.6. PARAMETERS	600
289.7. AUTHOR	600
289.8. LICENSE	600
290. lineardeltakins(9)	601
290.1. NAME	601
290.2. SYNOPSIS	601
290.3. KINEMATICS	601
290.4. PINS	601
290.5. NOTES	601
291. LOGIC(9)	602
291.1. NAME	602
291.2. SYNOPSIS	602
291.3. DESCRIPTION	602
291.4. FUNCTIONS	602
291.5. PINS	602
291.6. EXAMPLES	603

291.7. SEE ALSO	603
291.8. AUTHOR	603
291.9. LICENSE	603
292. LOWPASS(9)	604
292.1. NAME	604
292.2. SYNOPSIS	604
292.3. FUNCTIONS	604
292.4. PINS	604
292.5. PARAMETERS	604
292.6. NOTES	604
292.7. AUTHOR	605
292.8. LICENSE	605
293. LUT5(9)	606
293.1. NAME	606
293.2. SYNOPSIS	606
293.3. DESCRIPTION	606
293.4. FUNCTIONS	608
293.5. PINS	608
293.6. PARAMETERS	608
293.7. SEE ALSO	608
293.8. AUTHOR	608
293.9. LICENSE	608
294. MAJ3(9)	609
294.1. NAME	609
294.2. SYNOPSIS	609
294.3. FUNCTIONS	609
294.4. PINS	609
294.5. PARAMETERS	609
294.6. AUTHOR	609
294.7. LICENSE	609
295. MATCH8(9)	610
295.1. NAME	610
295.2. SYNOPSIS	610
295.3. FUNCTIONS	610
295.4. PINS	610
295.5. AUTHOR	610
295.6. LICENSE	611
296. matrix_kb(9)	612
296.1. NAME	612
296.2. SYNOPSIS	612
296.3. DESCRIPTION	612
296.4. FUNCTIONS	612

296.5. PINS	613
296.6. PARAMETERS	613
297. MATRIXKINS(9)	614
297.1. NAME	614
297.2. SYNOPSIS	614
297.3. DESCRIPTION	614
297.4. PINS	616
297.5. SEE ALSO	617
297.6. LICENSE	617
298. MAX31855(9)	618
298.1. NAME	618
298.2. SYNOPSIS	618
298.3. DESCRIPTION	618
298.4. FUNCTIONS	618
298.5. PINS	618
298.6. AUTHOR	619
298.7. LICENSE	619
299. MESA_7I65(9)	620
299.1. NAME	620
299.2. SYNOPSIS	620
299.3. DESCRIPTION	620
299.4. PINS	620
299.5. PARAMETERS	620
299.6. AUTHOR	621
299.7. LICENSE	621
300. MESA_PKTGYRO_TEST(9)	622
300.1. NAME	622
300.2. SYNOPSIS	622
300.3. DESCRIPTION	622
300.4. FUNCTIONS	622
300.5. PINS	623
300.6. AUTHOR	623
300.7. LICENSE	623
301. MESA_UART(9)	624
301.1. NAME	624
301.2. SYNOPSIS	624
301.3. DESCRIPTION	624
301.4. FUNCTIONS	624
301.5. PINS	625
301.6. AUTHOR	625
301.7. LICENSE	625
302. MESSAGE(9)	626

302.1. NAME	626
302.2. SYNOPSIS	626
302.3. DESCRIPTION	626
302.4. FUNCTIONS	626
302.5. PINS	626
302.6. PARAMETERS	627
302.7. AUTHOR	627
302.8. LICENSE	627
303. MILLTURN(9)	628
303.1. NAME	628
303.2. SYNOPSIS	628
303.3. DESCRIPTION	628
303.4. FUNCTIONS	628
303.5. PINS	628
303.6. AUTHOR	628
303.7. LICENSE	629
304. MINMAX(9)	630
304.1. NAME	630
304.2. SYNOPSIS	630
304.3. FUNCTIONS	630
304.4. PINS	630
304.5. AUTHOR	630
304.6. LICENSE	630
305. motion(9)	631
305.1. NAME	631
305.2. SYNOPSIS	631
305.3. DESCRIPTION	632
305.4. MOTION PINS	633
305.5. AXIS PINS	638
305.6. JOINT PINS	639
305.7. JOINT posthome pins	642
305.8. JOINT unlock pins	642
305.9. SPINDLE PINS	642
305.10. MOTION PARAMETERS	644
305.11. FUNCTIONS	644
305.12. BUGS	645
305.13. SEE ALSO	645
306. MOVEOFF(9)	646
306.1. NAME	646
306.2. SYNOPSIS	646
306.3. DESCRIPTION	646
306.4. FUNCTIONS	647

306.5. PINS	647
306.6. EXAMPLES	649
306.7. SEE ALSO	649
306.8. AUTHOR	649
306.9. LICENSE	649
307. MULT2(9)	650
307.1. NAME	650
307.2. SYNOPSIS	650
307.3. FUNCTIONS	650
307.4. PINS	650
307.5. SEE ALSO	650
307.6. AUTHOR	650
307.7. LICENSE	650
308. MULTICLICK(9)	651
308.1. NAME	651
308.2. SYNOPSIS	651
308.3. DESCRIPTION	651
308.4. FUNCTIONS	651
308.5. PINS	651
308.6. PARAMETERS	652
308.7. AUTHOR	652
308.8. LICENSE	652
309. MULTISWITCH(9)	653
309.1. NAME	653
309.2. SYNOPSIS	653
309.3. FUNCTIONS	653
309.4. PINS	653
309.5. PARAMETERS	653
309.6. AUTHOR	653
309.7. LICENSE	653
310. MUX16(9)	654
310.1. NAME	654
310.2. SYNOPSIS	654
310.3. FUNCTIONS	654
310.4. PINS	654
310.5. PARAMETERS	655
310.6. SEE ALSO	655
310.7. AUTHOR	655
310.8. LICENSE	655
311. MUX2(9)	656
311.1. NAME	656
311.2. SYNOPSIS	656

311.3. FUNCTIONS	656
311.4. PINS	656
311.5. SEE ALSO	656
311.6. AUTHOR	656
311.7. LICENSE	656
312. MUX4(9)	657
312.1. NAME	657
312.2. SYNOPSIS	657
312.3. FUNCTIONS	657
312.4. PINS	657
312.5. SEE ALSO	657
312.6. AUTHOR	657
312.7. LICENSE	658
313. MUX8(9)	659
313.1. NAME	659
313.2. SYNOPSIS	659
313.3. FUNCTIONS	659
313.4. PINS	659
313.5. SEE ALSO	660
313.6. AUTHOR	660
313.7. LICENSE	660
314. mux_generic(9)	661
314.1. NAME	661
314.2. SYNOPSIS	661
314.3. FUNCTIONS	661
314.4. PINS	661
314.5. PARAMETERS	662
314.6. DESCRIPTION	662
314.7. SEE ALSO	662
314.8. AUTHOR	662
314.9. LICENSE	663
315. NEAR(9)	664
315.1. NAME	664
315.2. SYNOPSIS	664
315.3. FUNCTIONS	664
315.4. PINS	664
315.5. PARAMETERS	664
315.6. AUTHOR	664
315.7. LICENSE	664
316. NOT(9)	665
316.1. NAME	665
316.2. SYNOPSIS	665

316.3. DESCRIPTION	665
316.4. FUNCTIONS	665
316.5. PINS	665
316.6. SEE ALSO	665
316.7. AUTHOR	665
316.8. LICENSE	665
317. OFFSET(9)	666
317.1. NAME	666
317.2. SYNOPSIS	666
317.3. FUNCTIONS	666
317.4. PINS	666
317.5. AUTHOR	666
317.6. LICENSE	666
318. OHMIC(9)	667
318.1. NAME	667
318.2. SYNOPSIS	667
318.3. DESCRIPTION	667
318.4. FUNCTIONS	667
318.5. PINS	667
318.6. EXAMPLES	668
318.7. AUTHOR	669
318.8. LICENSE	669
319. ONESHOT(9)	670
319.1. NAME	670
319.2. SYNOPSIS	670
319.3. DESCRIPTION	670
319.4. FUNCTIONS	670
319.5. PINS	670
319.6. PARAMETERS	671
319.7. AUTHOR	671
319.8. LICENSE	671
320. opto_ac5(9)	672
320.1. NAME	672
320.2. SYNOPSIS	672
320.3. DESCRIPTION	672
320.4. PINS	672
320.5. PARAMETERS	673
320.6. FUNCTIONS	673
320.7. BUGS	673
320.8. SEE ALSO	673
321. OR2(9)	674
321.1. NAME	674

321.2. SYNOPSIS	674
321.3. DESCRIPTION	674
321.4. FUNCTIONS	674
321.5. PINS	674
321.6. SEE ALSO	674
321.7. AUTHOR	674
321.8. LICENSE	675
322. ORIENT(9)	676
322.1. NAME	676
322.2. SYNOPSIS	676
322.3. DESCRIPTION	676
322.4. FUNCTIONS	676
322.5. PINS	677
322.6. AUTHOR	677
322.7. LICENSE	677
323. OUTPUT_BUFFER(9)	678
323.1. NAME	678
323.2. SYNOPSIS	678
323.3. DESCRIPTION	678
323.4. FUNCTIONS	678
323.5. PINS	678
323.6. EXAMPLES	679
323.7. AUTHOR	679
323.8. LICENSE	679
324. pid(9)	680
324.1. NAME	680
324.2. SYNOPSIS	680
324.3. DESCRIPTION	680
324.4. NAMING	682
324.5. FUNCTIONS	682
324.6. PINS	682
324.7. PARAMETERS	686
324.8. BUGS	686
325. PLASMAC(9)	688
325.1. NAME	688
325.2. SYNOPSIS	688
325.3. DESCRIPTION	688
325.4. FUNCTIONS	688
325.5. PINS	688
325.6. AUTHOR	701
325.7. LICENSE	701
326. PUSHMSG(9)	702

326.1. NAME	702
326.2. SYNOPSIS	702
326.3. DESCRIPTION	702
326.4. FUNCTIONS	703
326.5. PINS	703
326.6. AUTHOR	704
326.7. LICENSE	704
327. pwmgen(9)	705
327.1. NAME	705
327.2. SYNOPSIS	705
327.3. DESCRIPTION	705
327.4. FUNCTIONS	705
327.5. PINS	706
328. RASTER(9)	708
328.1. NAME	708
328.2. SYNOPSIS	708
328.3. DESCRIPTION	708
328.4. FUNCTIONS	709
328.5. PINS	709
328.6. LICENSE	710
329. RESET(9)	711
329.1. NAME	711
329.2. SYNOPSIS	711
329.3. DESCRIPTION	711
329.4. FUNCTIONS	711
329.5. PINS	711
329.6. AUTHOR	712
329.7. LICENSE	712
330. rosekins(9)	713
330.1. NAME	713
330.2. SYNOPSIS	713
330.3. KINEMATICS	713
330.4. PINS	713
330.5. NOTES	713
331. SAFETY_LATCH(9)	714
331.1. NAME	714
331.2. SYNOPSIS	714
331.3. DESCRIPTION	714
331.4. FUNCTIONS	714
331.5. PINS	714
331.6. AUTHOR	715
331.7. LICENSE	715

332. SAMPLE_HOLD(9)	716
332.1. NAME	716
332.2. SYNOPSIS	716
332.3. FUNCTIONS	716
332.4. PINS	716
332.5. SEE ALSO	716
332.6. AUTHOR	716
332.7. LICENSE	716
333. sampler(9)	717
333.1. NAME	717
333.2. SYNOPSIS	717
333.3. DESCRIPTION	717
333.4. OPTIONS	717
333.5. FUNCTIONS	717
333.6. PINS	717
333.7. PARAMETERS	718
333.8. SEE ALSO	718
333.9. AUTHOR	718
333.10. REPORTING BUGS	718
333.11. COPYRIGHT	718
334. SCALE(9)	719
334.1. NAME	719
334.2. SYNOPSIS	719
334.3. FUNCTIONS	719
334.4. PINS	719
334.5. AUTHOR	719
334.6. LICENSE	719
335. SCALED_S32_SUMS(9)	720
335.1. NAME	720
335.2. SYNOPSIS	720
335.3. FUNCTIONS	720
335.4. PINS	720
335.5. SEE ALSO	720
335.6. AUTHOR	720
335.7. LICENSE	720
336. SELECT8(9)	721
336.1. NAME	721
336.2. SYNOPSIS	721
336.3. FUNCTIONS	721
336.4. PINS	721
336.5. SEE ALSO	721
336.6. AUTHOR	721

336.7. LICENSE	721
337. SERPORT(9)	722
337.1. NAME	722
337.2. SYNOPSIS	722
337.3. FUNCTIONS	722
337.4. PINS	722
337.5. PARAMETERS	723
337.6. LICENSE	723
338. setsserial(9)	724
338.1. NAME	724
338.2. SYNOPSIS	724
338.3. FUNCTIONS	724
338.4. PINS	724
338.5. USAGE	724
338.6. LICENSE	726
339. siggen(9)	727
339.1. NAME	727
339.2. SYNOPSIS	727
339.3. DESCRIPTION	727
339.4. NAMING	727
339.5. FUNCTIONS	727
339.6. PINS	727
339.7. PARAMETERS	728
340. SIM_AXIS_HARDWARE(9)	729
340.1. NAME	729
340.2. SYNOPSIS	729
340.3. DESCRIPTION	729
340.4. FUNCTIONS	729
340.5. PINS	729
340.6. AUTHOR	733
340.7. LICENSE	733
341. sim_encoder(9)	734
341.1. NAME	734
341.2. SYNOPSIS	734
341.3. DESCRIPTION	734
341.4. FUNCTIONS	734
341.5. NAMING	734
341.6. PINS	734
341.7. PARAMETERS	735
342. SIM_HOME_SWITCH(9)	736
342.1. NAME	736
342.2. SYNOPSIS	736

342.3. DESCRIPTION	736
342.4. FUNCTIONS	736
342.5. PINS	736
342.6. AUTHOR	736
342.7. LICENSE	737
343. SIM_MATRIX_KB(9)	738
343.1. NAME	738
343.2. SYNOPSIS	738
343.3. FUNCTIONS	738
343.4. PINS	738
343.5. AUTHOR	739
343.6. LICENSE	739
344. SIM_PARPORT(9)	740
344.1. NAME	740
344.2. SYNOPSIS	740
344.3. DESCRIPTION	740
344.4. FUNCTIONS	740
344.5. PINS	740
344.6. PARAMETERS	742
344.7. AUTHOR	743
344.8. LICENSE	743
345. SIM_SPINDLE(9)	744
345.1. NAME	744
345.2. SYNOPSIS	744
345.3. FUNCTIONS	744
345.4. PINS	744
345.5. PARAMETERS	744
345.6. AUTHOR	744
345.7. LICENSE	744
346. SIMPLE_TP(9)	745
346.1. NAME	745
346.2. SYNOPSIS	745
346.3. FUNCTIONS	745
346.4. PINS	745
346.5. AUTHOR	745
346.6. LICENSE	745
347. SPHEREPROBE(9)	746
347.1. NAME	746
347.2. SYNOPSIS	746
347.3. FUNCTIONS	746
347.4. PINS	746
347.5. AUTHOR	746

347.6. LICENSE	746
348. SPINDLE(9)	747
348.1. NAME	747
348.2. SYNOPSIS	747
348.3. DESCRIPTION	747
348.4. FUNCTIONS	747
348.5. PINS	747
348.6. SEE ALSO	748
348.7. NOTES	748
348.8. AUTHOR	749
348.9. LICENSE	749
349. SPINDLE_MONITOR(9)	750
349.1. NAME	750
349.2. SYNOPSIS	750
349.3. FUNCTIONS	750
349.4. PINS	750
349.5. PARAMETERS	750
349.6. AUTHOR	750
349.7. LICENSE	750
350. sserial(9)	751
350.1. NAME	751
350.2. SYNOPSIS	751
350.3. PORTS	751
350.4. DEVICES	752
351. stepgen(9)	760
351.1. NAME	760
351.2. SYNOPSIS	760
351.3. DESCRIPTION	760
351.4. FUNCTIONS	761
351.5. PINS	762
351.6. PARAMETERS	762
351.7. TIMING	763
351.8. SEE ALSO	764
352. STEPTEST(9)	765
352.1. NAME	765
352.2. SYNOPSIS	765
352.3. FUNCTIONS	765
352.4. PINS	765
352.5. PARAMETERS	766
352.6. AUTHOR	766
352.7. LICENSE	766
353. streamer(9)	767

353.1. NAME	767
353.2. SYNOPSIS	767
353.3. DESCRIPTION	767
353.4. OPTIONS	767
353.5. FUNCTIONS	767
353.6. PINS	767
353.7. SEE ALSO	768
353.8. BUGS	768
353.9. AUTHOR	768
353.10. REPORTING BUGS	768
353.11. COPYRIGHT	769
354. SUM2(9)	770
354.1. NAME	770
354.2. SYNOPSIS	770
354.3. FUNCTIONS	770
354.4. PINS	770
354.5. PARAMETERS	770
354.6. SEE ALSO	770
354.7. AUTHOR	770
354.8. LICENSE	770
355. supply(9)	771
355.1. NAME	771
355.2. SYNOPSIS	771
355.3. DESCRIPTION	771
355.4. FUNCTIONS	771
355.5. PINS	771
356. THC(9)	773
356.1. NAME	773
356.2. SYNOPSIS	773
356.3. DESCRIPTION	773
356.4. FUNCTIONS	774
356.5. PINS	774
356.6. PARAMETERS	775
356.7. AUTHOR	775
356.8. LICENSE	775
357. THCUD(9)	776
357.1. NAME	776
357.2. SYNOPSIS	776
357.3. DESCRIPTION	776
357.4. FUNCTIONS	777
357.5. PINS	777
357.6. PARAMETERS	778

357.7. AUTHOR	778
357.8. LICENSE	778
358. threads(9)	779
358.1. NAME	779
358.2. SYNOPSIS	779
358.3. DESCRIPTION	779
358.4. FUNCTIONS	779
358.5. PINS	779
358.6. PARAMETERS	779
358.7. BUGS	779
359. THREADTEST(9)	781
359.1. NAME	781
359.2. SYNOPSIS	781
359.3. FUNCTIONS	781
359.4. PINS	781
359.5. AUTHOR	781
359.6. LICENSE	781
360. TIME(9)	782
360.1. NAME	782
360.2. SYNOPSIS	782
360.3. DESCRIPTION	782
360.4. FUNCTIONS	783
360.5. PINS	783
360.6. AUTHOR	784
360.7. LICENSE	784
361. TIMEDELAY(9)	785
361.1. NAME	785
361.2. SYNOPSIS	785
361.3. FUNCTIONS	785
361.4. PINS	785
361.5. AUTHOR	785
361.6. LICENSE	785
362. TIMEDELTA(9)	786
362.1. NAME	786
362.2. SYNOPSIS	786
362.3. FUNCTIONS	786
362.4. PINS	786
362.5. AUTHOR	787
362.6. LICENSE	787
363. TOF(9)	788
363.1. NAME	788
363.2. SYNOPSIS	788

363.3. FUNCTIONS	788
363.4. PINS	788
363.5. PARAMETERS	788
363.6. AUTHOR	788
363.7. LICENSE	788
364. TOGGLE(9)	789
364.1. NAME	789
364.2. SYNOPSIS	789
364.3. DESCRIPTION	789
364.4. FUNCTIONS	789
364.5. PINS	789
364.6. PARAMETERS	789
364.7. AUTHOR	789
364.8. LICENSE	789
365. TOGGLE2NIST(9)	790
365.1. NAME	790
365.2. SYNOPSIS	790
365.3. DESCRIPTION	790
365.4. FUNCTIONS	790
365.5. PINS	790
365.6. AUTHOR	791
365.7. LICENSE	791
366. TON(9)	792
366.1. NAME	792
366.2. SYNOPSIS	792
366.3. FUNCTIONS	792
366.4. PINS	792
366.5. PARAMETERS	792
366.6. AUTHOR	792
366.7. LICENSE	792
367. TP(9)	793
367.1. NAME	793
367.2. SYNOPSIS	793
367.3. FUNCTIONS	793
367.4. PINS	793
367.5. PARAMETERS	793
367.6. AUTHOR	793
367.7. LICENSE	793
368. TPCOMP(9)	794
368.1. NAME	794
368.2. SYNOPSIS	794
368.3. DESCRIPTION	794

368.4. PINS	794
368.5. AUTHOR	794
368.6. LICENSE	795
369. TRISTATE_BIT(9)	796
369.1. NAME	796
369.2. SYNOPSIS	796
369.3. FUNCTIONS	796
369.4. PINS	796
369.5. AUTHOR	796
369.6. LICENSE	796
370. TRISTATE_FLOAT(9)	797
370.1. NAME	797
370.2. SYNOPSIS	797
370.3. FUNCTIONS	797
370.4. PINS	797
370.5. AUTHOR	797
370.6. LICENSE	797
371. UPDOWN(9)	798
371.1. NAME	798
371.2. SYNOPSIS	798
371.3. FUNCTIONS	798
371.4. PINS	798
371.5. PARAMETERS	798
371.6. AUTHOR	799
371.7. LICENSE	799
372. USERKINS(9)	800
372.1. NAME	800
372.2. SYNOPSIS	800
372.3. DESCRIPTION	800
372.4. FUNCTIONS	801
372.5. PINS	801
372.6. AUTHOR	801
372.7. LICENSE	801
373. watchdog(9)	802
373.1. NAME	802
373.2. SYNOPSIS	802
373.3. FUNCTIONS	802
373.4. PINS	802
373.5. PARAMETERS	802
373.6. LICENSE	803
374. WCOMP(9)	804
374.1. NAME	804

374.2. SYNOPSIS	804
374.3. FUNCTIONS	804
374.4. PINS	804
374.5. NOTES	804
374.6. AUTHOR	804
374.7. LICENSE	805
375. weighted_sum(9)	806
375.1. NAME	806
375.2. SYNOPSIS	806
375.3. DESCRIPTION	806
375.4. FUNCTIONS	806
375.5. PINS	806
375.6. SEE ALSO	807
376. XHC_HB04_UTIL(9)	808
376.1. NAME	808
376.2. SYNOPSIS	808
376.3. DESCRIPTION	808
376.4. FUNCTIONS	808
376.5. PINS	808
376.6. AUTHOR	809
376.7. LICENSE	809
377. XOR2(9)	810
377.1. NAME	810
377.2. SYNOPSIS	810
377.3. DESCRIPTION	810
377.4. FUNCTIONS	810
377.5. PINS	810
377.6. SEE ALSO	810
377.7. AUTHOR	810
377.8. LICENSE	811
378. XYZAB_TDR_KINS(9)	812
378.1. NAME	812
378.2. SYNOPSIS	812
378.3. DESCRIPTION	812
378.4. PINS	812
378.5. AUTHOR	812
378.6. LICENSE	813
379. XYZACB_TRSRN(9)	814
379.1. NAME	814
379.2. SYNOPSIS	814
379.3. DESCRIPTION	814
379.4. FUNCTIONS	814

379.5. PINS	814
379.6. AUTHOR	814
379.7. LICENSE	814
380. XYZBCA_TRSRN(9)	815
380.1. NAME	815
380.2. SYNOPSIS	815
380.3. DESCRIPTION	815
380.4. FUNCTIONS	815
380.5. PINS	815
380.6. AUTHOR	815
380.7. LICENSE	815

Chapter 1. linuxcnc(1)

1.1. NAME

linuxcnc - LinuxCNC (The Enhanced Machine Controller)

1.2. SYNOPSIS

linuxcnc [-h] [-v] [-d] [-r] [-l] [-k] [/ -m <homemodulename>] [-H <dirname>_] [*INI file*]

1.3. DESCRIPTION

linuxcnc is used to start LinuxCNC (The Enhanced Machine Controller). It starts the realtime system and then initializes a number of LinuxCNC components (IO, Motion, GUI, HAL, etc). The most important parameter is *INI file*, which specifies the configuration name you would like to run. If *INI file* is not specified, the **linuxcnc** script presents a graphical wizard to let you choose one.

1.4. OPTIONS

-h

Shows the help

-v

Be a little bit verbose. This causes the script to print information as it works.

-d

Print lots of debug information. All executed commands are echoed to the screen. This mode is useful when something is not working as it should.

-r

Disable redirection of stdout and stderr to `~/linuxcnc_print.txt` and `~/linuxcnc_debug.txt` when stdin is not a tty. Used when running linuxcnc tests non-interactively.

-l

Use the last-used INI file without prompting. This is often a good choice for a shortcut command or startup item.

-k

Continue in the presence of errors in HAL files

-t <tpmodulename> [parameters]

Specify custom trajectory_planning_module overrides optional INI setting [TRAJ]TPMOD

-m <homemodulename> [parameters]

Specify custom homing_module overrides optional INI setting [EMCMOT]HOMEMOD

-H <dirname>

Search dirname for HAL files before searching INI directory and system library: \$HALLIB_DIR

<INIFILE>

The INI file is the main piece of a LinuxCNC configuration. It is not the entire configuration; there are various other files that go with it (NML files, HAL files, TBL files, VAR files). It is, however, the most important one, because it is the file that holds the configuration together. It can adjust a lot of parameters itself, but it also tells **linuxcnc** which other files to load and use.

There are several ways to specify which config to use:

Specify the absolute path to an INI, e.g.,

linuxcnc /usr/local/linuxcnc/configs/sim/sim.ini

Specify a relative path from the current directory, e.g.

linuxcnc configs/sim/sim.ini

Otherwise, in the case where the **INIFILE** is not specified, the behavior will depend on whether you configured LinuxCNC with **--enable-run-in-place**. If so, the LinuxCNC config chooser will search only the configs directory in your source tree. If not (or if you are using a packaged version of LinuxCNC), it may search several directories. The config chooser is currently set to search the path:

```
~/linuxcnc/configs:/usr/local/etc/linuxcnc/configs:/usr/share/doc/linuxcnc/examples/sample-configs
```

1.5. EXAMPLES

linuxcnc

linuxcnc configs/sim/sim.ini

linuxcnc /etc/linuxcnc/sample-configs/stepper/stepper_mm.ini

1.6. SEE ALSO

halcmd(1)

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at /usr/share/doc/linuxcnc/.

Web: <https://www.linuxcnc.org/>

User forum: <https://forum.linuxcnc.org/>

1.7. BUGS

None known at this time.

1.8. AUTHOR

This man page written by Alex Joni, as part of the LinuxCNC Enhanced Machine Controller project.

1.9. REPORTING BUGS

Please report any bugs at <https://github.com/LinuxCNC/linuxcnc>.

1.10. COPYRIGHT

Copyright © 2003 The LinuxCNC authors.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 2. 5axisgui(1)

2.1. NAME

5axisgui - Vismach Virtual Machine GUI

2.2. DESCRIPTION

5axisgui is one of the sample **Vismach** GUIs for LinuxCNC.

2.3. SEE ALSO

linuxcnc(1)

See the main LinuxCNC documentation for more details at <https://linuxcnc.org/docs/html/gui/vismach.html>.

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at /usr/share/doc/LinuxCNC/.

2.4. BUGS

None known at this time.

2.5. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

2.6. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

2.7. COPYRIGHT

Copyright © 2020 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 3. axis-remote(1)

3.1. NAME

axis-remote - AXIS Remote Interface

3.2. SYNOPSIS

axis-remote *OPTIONS* | *FILENAME*

3.3. DESCRIPTION

axis-remote is a small script that triggers commands in a running AXIS GUI.

Use **axis-remote --help** for further information.

3.4. OPTIONS

--ping, -p

Check whether AXIS is running.

--reload, -r

Make AXIS reload the currently loaded file.

--clear, -c

Make AXIS clear the backplot.

--quit, -q

Make AXIS quit.

--help, -h, -?

Display a list of valid parameters for **axis-remote**.

--mdi COMMAND, -m COMMAND

Run the MDI command *COMMAND*.

FILENAME

Load the G-code file *FILENAME*.

3.5. SEE ALSO

axis(1)

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at `/usr/share/doc/linuxcnc/`.

3.6. BUGS

None known at this time.

3.7. AUTHOR

This man page written by Alex Joni, as part of the LinuxCNC project.

3.8. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

3.9. COPYRIGHT

Copyright © 2007 Alex Joni.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 4. axis(1)

4.1. NAME

axis - AXIS LinuxCNC Graphical User Interface

4.2. SYNOPSIS

axis *-ini INIFILE*

4.3. DESCRIPTION

axis is one of the Graphical User Interfaces (GUI) for LinuxCNC. It gets run by the runscript usually.

4.4. OPTIONS

INIFILE

The INI file is the main piece of an LinuxCNC configuration. It is not the entire configuration; there are various other files that go with it (NML files, HAL files, TBL files, VAR files). It is, however, the most important one, because it is the file that holds the configuration together. It can adjust a lot of parameters itself, but it also tells **LinuxCNC** which other files to load and use.

4.5. SEE ALSO

linuxcnc(1)

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at /usr/share/doc/LinuxCNC/.

4.6. BUGS

None known at this time.

4.7. AUTHOR

This man page written by Alex Joni, as part of the LinuxCNC project.

4.8. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

4.9. COPYRIGHT

Copyright © 2007 Alex Joni.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 5. debuglevel(1)

5.1. NAME

debuglevel - sets the debug level for the non-realtime part of LinuxCNC

5.2. SYNOPSIS

debuglevel -ini *INIFILE*

5.3. DESCRIPTION

debuglevel displays a checkbox GUI to select the current debug level of some parts of LinuxCNC.

5.4. SEE ALSO

halcmd(1) - debug subcommand **linuxcnc(1)**

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at `/usr/share/doc/LinuxCNC/`.

5.5. BUGS

None known at this time.

5.6. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

5.7. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

5.8. COPYRIGHT

Copyright © 2020 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 6. elbpcom(1)

6.1. NAME

elbpcom - Communicate with Mesa ethernet cards

6.2. SYNOPSIS

Common options

```
elbpcom  [--ip=IP]    [--port=PORT]    [--timeout=TIMEOUT]    [--space=MEMSPACE]    [--size=TRANSFER_SIZE]
```

Reading data

```
elbpcom [common options] [--info] --address=ADDRESS --read=LENGTH
```

Writing data

```
elbpcom [common options] --address=ADDRESS --write=HEXDATA
```

Read and decode memory space info area

```
elbpcom [--space=MEMSPACE] --read-info
```

Sending arbitrary packets

```
elbpcom [common options] HEXDATA
```

6.3. DESCRIPTION

Read or write data from a Mesa ethernet card that uses the LBP16 protocol, such as the 7I80. This can be useful for performing certain low-level tasks.

For more information about the meaning of each address space, see the card documentation. Incorrect use of this utility can have negative effects such as changing the board's IP address or even corrupting the FPGA bitfile in the EEPROM. For some tasks, such as updating FPGA bitfiles and setting IP addresses, **mesaflash**(1) is a more appropriate tool.

If not specified, the default values are

```
--ip=192.168.1.121 --port=27181 --timeout=.2 --space=0 --size=0
```

If the **--size** argument *TRANSFER_SIZE* is 0, elbpcom will look up the preferred transfer size of the space in the space's info area.

This example demonstrates reading the HOSTMOT2 identifying string from the IDROM in space 0:

```
$ elbpcom --address 0x104 --read 8
> 82420401
< 484f53544d4f5432
    HOSTMOT2
```

First the request is shown in hex. Then the response (if any) is shown in hex. Finally, the response is shown in ASCII, with "." replacing any non-ASCII characters. This is similar to the following invocations of mesaflash:

```
$ ./mesaflash --device 7i80 --rpo 0x104
54534F48
$ ./mesaflash --device 7i80 --rpo 0x108
32544F4D
```

Notice its different treatment of byte order.

6.4. SEE ALSO

mesaflash(1), hostmot2(9), hm2_eth(9), [Mesa's documentation for the Anything I/O boards](#).

Chapter 7. emccalib(1)

7.1. NAME

emccalib - Adjust ini tuning variables on the fly with save option

7.2. SYNOPSIS

emccalib.tcl [*options*]

7.3. DESCRIPTION

The Calibration assistant. This tool Reads the HAL file and for every *setp* that uses a variable from the INI file that is in an [AXIS_L], [JOINT_N], [SPINDLE_S], or [TUNE] section it creates an entry that can be edited and tested.

7.4. USAGE

The calibration/tuning tool supports the following stanzas:

```
[JOINT_N], [AXIS_L], [SPINDLE_S], [TUNE]
```

where *N* is a joint number (0 .. ([KINS]JOINTS-1)), *L* is an axis coordinate letter (X,Y,Z,A,B,C,U,V,W), and *S* is a spindle number (0 .. 9).

- | | |
|-------------|---|
| NOTE | The number of allowed spindles is 8 but legacy configurations may include a stanza [SPINDLE_9] unrelated to an actual spindle number. |
| NOTE | The [TUNE] stanza may be used for specifying tunable items not relevant to the other supported stanzas. |

7.5. EXIT STATUS

Return exit code 1 if the ini file is incompatible with the current version of emccalib.

7.6. SEE ALSO

linuxcnc(1)

7.7. AUTHOR

Original version by Petter Reinholdtsen as part of the LinuxCNC project. Improvements by several other members of the LinuxCNC development team.

7.8. COPYRIGHT

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 8. gladevcp(1)

8.1. NAME

gladevcp - Virtual Control Panel for LinuxCNC based on Glade, Gtk and HAL widgets

8.2. SYNOPSIS

gladevcp [-g *WxH+X+Y*] [-c *component-name*] [-u *handler*] [-U *useroption*] [-H *HAL-file*] [-d] *myfile.ui*

8.3. OPTIONS

-g *WxH+X+Y*

This sets the initial geometry of the root window. Use *WxH* for just size, *+X+Y* for just position, or *WxH+X+Y* for both. Size / position use pixel units. Position is referenced from top left.

-c *component-name*

Use *component-name* as the HAL component name. If the component name is not specified, the basename of the UI file is used.

-u *handler*

Instructs GladeVCP to inspect the Python script *handler* for event handlers, and connect them to signals in the UI file.

-U *useroption*

GladeVCP collects all *useroption* strings and passes them to the handler *init()* method as a list of strings without further inspection.

-x *XID*

Reparent GladeVCP into an existing window *XID* instead of creating a new top level window.

-H *halfile*

GladeVCP runs *HAL file* - a list of HAL commands - by executing *halcmd -c filename* after the HAL component is finalized.

-d

enable debug output.

-R *gtkrcfile*

explicitly load a gtkrc file.

-t *THEME*

set gtk theme. Default is the *system* theme. Different panels can have different themes.

-m *MAXIMUM*

force panel window to maximize. Together with the *-g geometry* option one can move the panel to a

second monitor and force it to use all of the screen

-R

explicitly deactivate workaround for a GTK bug which makes matches of widget and widget_class matches in GTK theme and gtkrc files fail. Normally not needed.

8.4. SEE ALSO

GladeVCP in the LinuxCNC documentation for a description of GladeVCP's capabilities and the associated HAL widget set, along with examples.

Chapter 9. gladevcp_demo(1)

9.1. NAME

gladevcp_demo - used by sample configs to deonstrate Glade Virtual_demo

9.2. SYNOPSIS

gladevcp_demo Control Panels

9.3. DESCRIPTION

gladevcp_demo is a sample GladeVCP handler

9.4. SEE ALSO

linuxcnc(1), <https://linuxcnc.org/docs/html/gui/gladevcp.html>

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at /usr/share/doc/LinuxCNC/.

9.5. BUGS

None known at this time.

9.6. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

9.7. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

9.8. COPYRIGHT

Copyright © 2020 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 10. gmoccapy(1)

10.1. NAME

gmoccapy - TOUCHY LinuxCNC Graphical User Interface

10.2. SYNOPSIS

gmoccapy -ini <INI file>

10.3. DESCRIPTION

GMOCCAPY is one of the Graphical User Interfaces (GUI) for LinuxCNC. It gets run by the runsript usually.

10.4. OPTIONS

INI file

The *INI file* is the main piece of an LinuxCNC configuration. It is not the entire configuration; there are various other files that go with it (NML files, HAL files, TBL files, VAR files). It is, however, the most important one, because it is the file that holds the configuration together. It can adjust a lot of parameters itself, but it also tells **LinuxCNC** which other files to load and use.

10.5. SEE ALSO

linuxcnc(1)

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at /usr/share/doc/LinuxCNC/.

10.6. BUGS

None known at this time.

10.7. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

10.8. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

10.9. COPYRIGHT

Copyright © 2020 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 11. gremlin_view(1)

11.1. NAME

gremlin_view - G-code graphical preview

11.2. SYNOPSIS

gremlin_view

11.3. DESCRIPTION

gremlin_view is a Python wrapper for the gremlin G-code graphical preview.

PGremlinView for gremlin with buttons for simpler embedding Standalone functionality if linuxcnc running A default ui file (gremlin_view.ui) is provided for a default button arrangement but a user may provide their own by supplying the glade_file argument. The following objects are mandatory:

gremlin_view_window

toplevel window

gremlin_view_hal_gremlin

hal_gremlin

gremlin_view_box

HBox or VBox containing hal_gremlin

Optional radiobutton group names:

- *select_p_view*
- *select_x_view*
- *select_y_view*
- *select_z_view*
- *select_z2_view*

Optional checkbuttons names:

- *enable_dro*
 - *show_machine_speed*
 - *show_distance_to_go*
 - *show_limits*
 - *show_extents*
 - *show_tool*
-

- *show_metric*

Callbacks are provided for the following button actions:

- on_clear_live_plotter_clicked
- on_enable_dro_clicked
- on_zoomin_pressed
- on_zoomout_pressed
- on_pan_x_minus_pressed
- on_pan_x_plus_pressed
- on_pan_y_minus_pressed
- on_pan_y_plus_pressed
- on_show_tool_clicked
- on_show_metric_clicked
- on_show_extents_clicked
- on_select_p_view_clicked
- on_select_x_view_clicked
- on_select_y_view_clicked
- on_select_z_view_clicked
- on_select_z2_view_clicked
- on_show_distance_to_go_clicked
- on_show_machine_speed_clicked
- on_show_limits_clicked

11.4. SEE ALSO

linuxcnc(1), <https://wiki.linuxcnc.org/cgi-bin/wiki.pl?Gremlin>

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at `/usr/share/doc/LinuxCNC/`.

11.5. BUGS

None known at this time.

11.6. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

11.7. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

11.8. COPYRIGHT

Copyright © 2020 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 12. gs2_vfd(1)

12.1. NAME

gs2_vfd - HAL non-realtime component for Automation Direct GS2 VFDs

12.2. SYNOPSIS

gs2_vfd [OPTIONS]

12.3. DESCRIPTION

This manual page explains the **gs2_vfd** component. This component reads and writes to the GS2 via a modbus connection.

gs2_vfd is for use with LinuxCNC.

12.4. OPTIONS

-b, --bits *n*

Set number of data bits to *n*, where *n* must be from 5 to 8 inclusive (default 8).

-d, --device *path*

Set the path to the file representing the serial device to use (default /dev/ttyS0).

-v, --verbose

Turn on verbose mode.

-g, --debug

Turn on debug messages. Note that if there are serial errors, this may become annoying. Debug mode will cause all modbus messages to be printed in hex on the terminal.

-n, --name *string*

Set the name of the HAL module. The HAL comp name will be set to *string*, and all pin and parameter names will begin with *string* (default gs2_vfd).

-p, --parity [even,odd,none]

Set serial parity to even, odd, or none (default odd).

-r, --rate *n*

Set baud rate to *n*. It is an error if the rate is not one of the following: 110, 300, 600, 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200 (default 38400).

-s, --stopbits [1,2]

Set serial stop bits to 1 or 2 (default 1).

-t, --target *n*

Set MODBUS target (slave) number. This must match the device number you set on the GS2 (default 1).

-A, --accel-seconds *n*

Seconds to accelerate the spindle from 0 to Max RPM (default 10.0).

-D, --decel-seconds *n*

Seconds to decelerate the spindle from Max RPM to 0. If set to 0.0 the spindle will be allowed to coast to a stop without controlled deceleration (default 0.0).

-R, --braking-resistor

This argument should be used when a braking resistor is installed on the GS2 VFD (see Appendix A of the GS2 manual). It disables deceleration over-voltage stall prevention (see GS2 modbus Parameter 6.05), allowing the VFD to keep braking even in situations where the motor is regenerating high voltage. The regenerated voltage gets safely dumped into the braking resistor.

12.5. PINS

<name>.DC-bus-volts (float, out)

from the VFD

<name>.at-speed (bit, out)

when drive is at commanded speed

<name>.err-reset (bit, in)

reset errors sent to VFD

<name>.firmware-revision (s32, out)

from the VFD

<name>.frequency-command (float, out)

from the VFD

<name>.frequency-out (float, out)

from the VFD

<name>.is-stopped (bit, out)

when the VFD reports 0 Hz output

<name>.load-percentage (float, out)

from the VFD

<name>.motor-RPM (float, out)

from the VFD

<name>.output-current (float, out)

from the VFD

<name>.output-voltage (float, out)

from the VFD

<name>.power-factor (float, out)

from the VFD

<name>.scale-frequency (float, out)

from the VFD

<name>.speed-command (float, in)

speed sent to VFD in RPM. It is an error to send a speed faster than the Motor Max RPM as set in the VFD.

<name>.spindle-fwd (bit, in)

1 for FWD and 0 for REV sent to VFD

<name>.spindle-on (bit, in)

1 for ON and 0 for OFF sent to VFD, only on when running

<name>.spindle-rev (bit, in)

1 for ON and 0 for OFF, only on when running

<name>.status-1 (s32, out)

Drive Status of the VFD (see the GS2 manual)

<name>.status-2 (s32, out)

Drive Status of the VFD (see the GS2 manual) Note that the value is a sum of all the bits that are on. So a 163 which means the drive is in the run mode is the sum of 3 (run) + 32 (freq set by serial) + 128 (operation set by serial).

12.6. PARAMETERS

<name>.error-count (s32, RW)**<name>.loop-time (float, RW)**

how often the modbus is polled (default 0.1)

<name>.nameplate-HZ (float, RW)

Nameplate Hz of motor (default 60)

<name>.nameplate-RPM (float, RW)

Nameplate RPM of motor (default 1730)

<name>.retval (s32, RW)

the return value of an error in HAL

<name>.tolerance (float, RW)

speed tolerance (default 0.01)

<name>.ack-delay (s32, RW)

number of read/write cycles before checking at-speed (default 2)

12.7. SEE ALSO

GS2 Driver in the LinuxCNC documentation for a full description of the **GS2** syntax

GS2 Examples in the LinuxCNC documentation for examples using the **GS2** component

12.8. AUTHOR

John Thornton

12.9. LICENSE

GPL

Chapter 13. gscreen(1)

13.1. NAME

gscreen - TOUCHY LinuxCNC Graphical User Interface

13.2. SYNOPSIS

gscreen -ini *INIFILE*

13.3. DESCRIPTION

gscreen is one of the Graphical User Interfaces (GUI) for LinuxCNC. It gets run by the runscrip usually.

13.4. OPTIONS

INIFILE

The INI-file is the main piece of an LinuxCNC configuration. It is not the entire configuration; there are various other files that go with it (NML files, HAL files, TBL files, VAR files). It is, however, the most important one, because it is the file that holds the configuration together. It can adjust a lot of parameters itself, but it also tells **LinuxCNC** which other files to load and use.

13.5. SEE ALSO

linuxcnc(1)

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at /usr/share/doc/LinuxCNC/.

13.6. BUGS

None known at this time.

13.7. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

13.8. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

13.9. COPYRIGHT

Copyright © 2020 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 14. hal-histogram(1)

14.1. NAME

hal-histogram - plots the value of a HAL pin as a histogram

14.2. SYNOPSIS

hal-histogram

14.3. DESCRIPTION

hal-histogram represents the values of a HAL pin graphically.

Details: https://linuxcnc.org/docs/html/hal/tools.html#_hal_histogram

14.4. SEE ALSO

linuxcnc(1)

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at /usr/share/doc/LinuxCNC/.

14.5. BUGS

None known at this time.

14.6. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

14.7. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

14.8. COPYRIGHT

Copyright © 2020 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 15. hal_input(1)

15.1. NAME

hal_input - control HAL pins with any Linux input device, including USB HID devices

15.2. SYNOPSIS

loadusr **hal_input** [-KRAL] *inputspec* ...

15.3. DESCRIPTION

hal_input is an interface between HAL and any Linux input device, including USB HID devices. For each device named, **hal_input** creates pins corresponding to its keys, absolute axes, and LEDs. At a fixed rate of approximately 10 ms, it synchronizes the device and the HAL pins.

15.4. INPUT SPECIFICATION

The *inputspec* may be in one of several forms:

A string *S*

A substring or shell-style pattern match will be tested against the "name" of the device, the "phys" (which gives information about how it is connected), and the "id", which is a string of the form "Bus=... Vendor=... Product=... Version=...". You can view the name, phys, and id of attached devices by executing 'less /proc/bus/input/devices'. Examples:

- SpaceBall
- "Vendor=001f Product=0001"
- serio*/input0

A number *N*

This opens **/dev/input/eventN**. Except for devices that are always attached to the system, this number may change over reboots or when the device is removed. For this reason, using an integer is not recommended.

When several devices are identified by the same string, add ":*N*" where *N* is the index of the desired device. For example, if **Mouse** matches **input3** and **input10**, then **Mouse** and **Mouse:0** select **input3**. Specifying **mouse:1** selects input10.

For devices that appear as multiple entries in /dev/input, these indices are likely to stay the same every time. For multiple identical devices, these indices are likely to depend on the insertion order, but stay the same across reboots as long as the devices are not moved to different ports or unplugged while the machine is booted.

If the first character of the *inputspec* is a "+", then **hal_input** requests exclusive access to the device. The first device matching an *inputspec* is used. Any number of *inputspecs* may be used.

A *subset option* may precede each *inputspec*. The subset option begins with a dash. Each letter in the subset option specifies a device feature to **include**. Features that are not specified are excluded. For instance, to export keyboard LEDs to HAL without exporting keys, use

```
hal_input -L keyboard ...
```

15.5. DEVICE FEATURES SUPPORTED

- EV_KEY (buttons and keys). Subset -K
- EV_ABS (absolute analog inputs). Subset -A
- EV_REL (relative analog inputs). Subset -R
- EV_LED (LED outputs). Subset -L

15.6. HAL PINS AND PARAMETERS

15.6.1. For buttons

input.N.btn-name bit out

input.N.btn-name-not bit out

Created for each button on the device.

15.6.2. For keys

input.N.key-name

inputN.key-name-not

Created for each key on the device.

15.6.3. For absolute axes

input.N.abs-name-counts s32 out

input.N.abs-name-position float out

input.N.abs-name-scale parameter float rw

input.N.abs-name-offset parameter float rw

input.N.abs-name-fuzz parameter s32 rw

input.N.abs-name-flat parameter s32 rw

input.N.abs-name-min parameter s32 r

input.N.abs-name-max parameter s32 r

Created for each absolute axis on the device. Device positions closer than **flat** to **offset** are reported as **offset** in **counts**, and **counts** does not change until the device position changes by at least **fuzz**. The position is computed as **position** = (**counts** - **offset**) / **scale**. The default value of **scale** and **offset** map the range of the axis reported by the operating system to [-1,1]. The default values of **fuzz** and **flat** are those reported by the operating system. The values of **min** and **max** are those reported by the operating system.

15.6.4. For relative axes**input.N.rel-name-counts** s32 out**input.N.rel-name-position** float out**input.N.rel-name-reset** bit in**input.N.rel-name-scale** parameter float rw**input.N.rel-name-absolute** parameter s32 rw**input.N.rel-name-precision** parameter s32 rw**input.N.rel-name-last** parameter s32 rw

Created for each relative axis on the device. As long as **reset** is true, **counts** is reset to zero regardless of any past or current axis movement. Otherwise, **counts** increases or decreases according to the motion of the axis. **counts** is divided by position-scale to give **position**. The default value of **position** is 1. There are some devices, notably scroll wheels, which return signed values with less resolution than 32 bits. The default value of **precision** is 32. **precision** can be set to 8 for a device that returns signed 8 bit values, or any other value from 1 to 32. **absolute**, when set true, ignores duplicate events with the same value. This allows for devices that repeat events without any user action to work correctly. **last** shows the most recent count value returned by the device, and is used in the implementation of **absolute**.

15.6.5. For LEDs**input.N.led-name** bit out**input.N.led-name-invert** parameter bit rw

Created for each LED on the device.

15.7. PERMISSIONS AND UDEV

By default, the input devices may not be accessible to regular users — **hal_input** requires read-write access, even if the device has no outputs.

Different versions of udev have slightly different, incompatible syntaxes. For this reason, it is not possible for this manual page to give an accurate example. The **udev(7)** manual page documents the syntax used on your Linux distribution. To view it in a terminal, the command is **man 7 udev**.

15.8. BUGS

The initial state of keys, buttons, and absolute axes are erroneously reported as FALSE or 0 until an event is received for that key, button, or axis.

15.9. SEE ALSO

udev(8), udev(7)

Chapter 16. hal_manualtoolchange(1)

16.1. NAME

hal_manualtoolchange - HAL non-realtime component to enable manual tool changes.

16.2. SYNOPSIS

loadusr hal_manualtoolchange

16.3. DESCRIPTION

hal_manualtoolchange is a LinuxCNC non-realtime component that allows users with machines lacking automatic tool changers to make manual tool changes. In use when a M6 tool change is encountered, the motion component will stop the spindle and pause the program. The hal_manualtoolchange component will then receive a signal from the motion component causing it to display a tool change window prompting the user which tool number to load based on the last T- number programmed. The dialog will stay active until the "continue" button is pressed. When the "continue" button is pressed, hal_manualtoolchange will then signal the motion component that the tool change is complete thus allowing motion to turn the spindle back on and resume program execution.

Additionally, the hal_manualtoolchange component includes a hal pin for a button that can be connected to a physical button to complete the tool change and remove the window prompt (hal_manualtoolchange.change_button).

hal_manualtoolchange can be used even when AXIS is not used as the GUI. This component is most useful if you have presettable tools and you use the tool table.

16.4. PINS

hal_manualtoolchange.number s32 in

Receives last programmed T- number.

hal_manualtoolchange.change bit in

Receives signal to do tool change.

hal_manualtoolchange.changed bit out

Signifies that the tool change is complete.

hal_manualtoolchange.change_button bit in

Pin to allow an external switch to signify that the tool change is complete.

16.5. USAGE

Normal usage is to load the component in your HAL file and net the appropriate pins from the *motion*

and *io* components. The following lines are typical in a HAL file when using the `hal_manualtoolchange` non-realtime component.

loadusr -W hal_manualtoolchange

This will load the `hal_manualtoolchange` non-realtime component waiting for the component to be ready before continuing.

net tool-change iocontrol.0.tool-change => hal_manualtoolchange.change

When an M6 code is run, motion sets *iocontrol.0.tool-change* to high indicating a tool change. This pin should be netted to *hal_manualtoolchange.change*. This causes the Tool change dialog to be displayed on screen and wait for the user to either click the continue button on the dialog or press an externally connected button.

net tool-changed iocontrol.0.tool-changed <= hal_manualtoolchange.changed

When the Tool change dialog's continue button is pressed, it will set the *hal_manualtoolchange.changed* pin to high, this should be netted to the *iocontrol.0.tool-changed* pin, indicating to the motion controller that the tool change has been completed and can continue with the execution of the G-code program.

net tool-number iocontrol.0.tool-prep-number => hal_manualtoolchange.number

When a *T-* command is executed in a G-code program, the tool number will held in the *iocontrol.0.tool-prep-number*. This pin should be netted to *hal_manualtoolchange.number*. The value of this pin, the tool number is displayed in the tool change dialog to let the user know which tool should be loaded.

net tool-prepare-loopback iocontrol.0.tool-prepare => iocontrol.0.tool-prepared

The *iocontrol.0.tool-prepare* pin will go true when a *Tn* tool prepare is requested. Since there is not automated tool changer this pin should be netted to *iocontrol.0.tool-prepared* to indicate that the tool has been prepared.

If you wish to use an external button to signal the `hal_manualtoolchange` component that the tool change is complete simply bring the button into HAL (via a parport input pin or a hostmot2 gpio input or similar), and wire it directly to the *hal_manualtoolchange.change_button* pin. For Example:

```
net tool-changed-btn hal_manualtoolchange.change_button <= parport.0.pin-15-in
```

16.6. SEE ALSO

`motion(1)`, `iocontrol(1)`, `halcmd(1)`.

Chapter 17. halcmd(1)

17.1. NAME

halcmd - manipulate the LinuxCNC HAL from the command line

17.2. SYNOPSIS

halcmd [*OPTIONS*] [*COMMAND* [*ARG*]]

17.3. DESCRIPTION

The tool **halcmd** is used to manipulate the HAL (Hardware Abstraction Layer) from the command line. **halcmd** can optionally read commands from a file, allowing complex HAL configurations to be set up with a single command.

If the **readline** library is available when LinuxCNC is compiled, then **halcmd** offers commandline editing and completion when running interactively. Use the up arrow to recall previous commands, and press tab to complete the names of items such as pins and signals.

17.4. OPTIONS

-I

Before tearing down the realtime environment, run an interactive halcmd. **halrun** only. If **-I** is used, it must precede all other commandline arguments.

-f [*<file>*]

Ignore commands on command line, take input from *file* instead. If *file* is not specified, take input from *stdin*.

-i *<INI file>*

Use variables from the specified *INI file* for substitutions. See **SUBSTITUTION** below.

-k

Keep going after failed command(s). The default is to stop and return failure if any command fails.

-q

display errors only (default)

-Q

display nothing, execute commands silently

-s

Script-friendly mode. In this mode, *show* will not output titles for the items shown. Also, module names will be printed instead of ID codes in pin, param, and funct listings. Threads are printed on a single line, with the thread period, FP usage and name first, followed by all of the functions in the

thread, in execution order. Signals are printed on a single line, with the type, value, and signal name first, followed by a list of pins connected to the signal, showing both the direction and the pin name.

-R

Release the HAL mutex. This is useful for recovering when a HAL component has crashed while holding the HAL mutex.

-v

display results of each command

-V

display lots of debugging junk

-h [command]

display a help screen and exit, displays extended help on *command* if specified

17.5. COMMANDS

Commands tell **halcmd** what to do. Normally **halcmd** reads a single command from the command line and executes it. If the **-f** option is used to read commands from a file, **halcmd** reads each line of the file as a new command. Anything following **#** on a line is a comment.

loadrt *modname*

(short for "load realtime module") Loads a realtime HAL module called *modname*. **halcmd** looks for the module in a directory specified at compile time.

In systems with kernel-based realtime support (e.g. RTAI), **halcmd** calls the **linuxcnc_module_helper** to load realtime modules. **linuxcnc_module_helper** is a setuid program and is compiled with a whitelist of modules it is allowed to load. This is currently just a list of **LinuxCNC**-related modules. The **linuxcnc_module_helper** execs insmod, so return codes and error messages are those from insmod. Administrators who wish to restrict which users can load these **LinuxCNC**-related kernel modules can do this by setting the permissions and group on **linuxcnc_module_helper** appropriately.

In systems with userspace-based realtime support (e.g. Preempt-RT) and in systems without realtime support **halcmd** calls the **rtapi_app** which creates the realtime environment (simulated realtime, on systems with no userspace realtime support) if it did not yet exist, and then loads the requested component with a call to **dlopen(3)**.

unloadrt *modname*

(*unload* realtime module) Unloads a realtime HAL module called *modname*. If *modname* is "all", it will unload all currently loaded realtime HAL modules. **unloadrt** also works by execing **linuxcnc_module_helper** or **rtapi_app**, just like **loadrt**.

loadusr [*flags*] *UNIX-command*

(*load* Userspace component) Executes the given *UNIX-command*, usually to load a non-realtime component. [*flags*] may be one or more of: +

- **-W** to wait for the component to become ready. The component is assumed to have the same

name as the first argument of the command.

- **-Wn name** to wait for the component, which will have the given name.
- **-w** to wait for the program to exit
- **-i** to ignore the program return value (with -w)

waitusr name

(wait for Userspace component) Waits for non-realtime component *name* to disconnect from HAL (usually on exit). The component must already be loaded. Useful near the end of a HAL file to wait until the user closes some user interface component before cleaning up and exiting.

unloadusr compname

(unload Userspace component) Unloads a non-realtime component called *compname*. If *compname* is "all", it will unload all non-realtime components. **unloadusr** works by sending SIGTERM to all non-realtime components.

unload compname

Unloads a non-realtime component or realtime module. If *compname* is "all", it will unload all non-realtime components and realtime modules.

newsig signame type

(OBSOLETE - use **net** instead) (*new signal*) Creates a new HAL signal called *signame* that may later be used to connect two or more HAL component pins. *type* is the data type of the new signal, and must be one of "**bit**", "**s32**", "**u32**", or "**float**". Fails if a signal of the same name already exists.

delsig signame

(delete signal) Deletes HAL signal *signame*. Any pins currently linked to the signal will be unlinked. Fails if *signame* does not exist.

sets signame value

(set signal) Sets the value of signal *signame* to *value*. Fails if *signame* does not exist, if it already has a writer, or if *value* is not a legal value. Legal values depend on the signals's type.

stype name

(signal type) Gets the type of signal *name*. Fails if *name* does not exist as a signal.

gets signame

(get signal) Gets the value of signal *signame*. Fails if *signame* does not exist.

linkps pinname [arrow] signame

(OBSOLETE - use **net** instead) (*link pin to signal*) Establishes a link between a HAL component pin *pinname* and a HAL signal *signame*. Any previous link to *pinname* will be broken. *arrow* can be "**=>**", "**<=**", "**<=>**", or omitted. **halcmd** ignores arrows, but they can be useful in command files to document the direction of data flow. Arrows should not be used on the command line since the shell might try to interpret them. Fails if either *pinname* or *signame* does not exist, or if they are not the same type type.

linksp *signame* [*arrow*] *pinname*

(OBSOLETE - use **net** instead) (*link signal to pin*) Works like **linkps** but reverses the order of the arguments. **halcmd** treats both link commands exactly the same. Use whichever you prefer.

linkpp *pinname1* [*arrow*] *pinname2*

(OBSOLETE - use **net** instead) (*link pin to pin*) Shortcut for **linkps** that creates the signal (named like the first pin), then links them both to that signal. **halcmd** treats this just as if it were: **halcmd newsig *pinname1* **halcmd linksp** *pinname1* *pinname1* **halcmd linksp** *pinname1* *pinname2***

net *signame pinname* ...

Create *signame* to match the type of *pinname* if it does not yet exist. Then, link *signame* to each *pinname* in turn. Arrows may be used as in **linkps**. When linking a pin to a signal for the first time, the signal value will inherit the pin's default value.

unlinkp *pinname*

(*unlink pin*) Breaks any previous link to *pinname*. Fails if *pinname* does not exist. An unlinked pin will retain the last value of the signal it was linked to.

setp *name value*

(*set parameter or pin*) Sets the value of parameter or pin *name* to *value*. Fails if *name* does not exist as a pin or parameter, if it is a parameter that is not writable, if it is a pin that is an output, if it is a pin that is already attached to a signal, or if *value* is not a legal value. Legal values depend on the type of the pin or parameter. If a pin and a parameter both exist with the given name, the parameter is acted on.

paramname* = *value***pinname* = *value***

Identical to **setp**. This alternate form of the command may be more convenient and readable when used in a file.

ptype *name*

(*parameter or pin type*) Gets the type of parameter or pin *name*. Fails if *name* does not exist as a pin or parameter. If a pin and a parameter both exist with the given name, the parameter is acted on.

getp *name*

(*get parameter or pin*) Gets the value of parameter or pin *name*. Fails if *name* does not exist as a pin or parameter. If a pin and a parameter both exist with the given name, the parameter is acted on.

addf *funcname threadname*

(*add function*) Adds function *funcname* to realtime thread *threadname*. *funcname* will run after any functions that were previously added to the thread. Fails if either *funcname* or *threadname* does not exist, or if they are incompatible.

initf *funcname threadname*

(*init function*) Registers *funcname* to run once in realtime context on a dedicated init cycle of *threadname*, before the cyclic function list executes. Intended for one-shot setup that must run in the realtime task (for example EtherCAT slave configuration). Once the init cycle has run, further **initf**

calls on that thread are rejected. Fails if either *funcname* or *threadname* does not exist.

delf *funcname threadname*

(delete function) Removes function *funcname* from realtime thread *threadname*. Fails if either *funcname* or *threadname* does not exist, or if *funcname* is not currently part of *threadname*.

start

Starts execution of realtime threads. Each thread periodically calls all of the functions that were added to it with the **addf** command, in the order in which they were added.

stop

Stops execution of realtime threads. The threads will no longer call their functions.

show [*item*]

Prints HAL items to *stdout* in human readable format. *item* can be one of "**comp**" (components), "**pin**", "**sig**" (signals), "**param**" (parameters), "**funct**" (functions), "**thread**", or "**alias**". The type "**all**" can be used to show matching items of all the preceding types. If *item* is omitted, **show** will print everything.

save [*item*]

Prints HAL items to *stdout* in the form of HAL commands. These commands can be redirected to a file and later executed using **halcmd -f** to restore the saved configuration. *item* can be one of the following:

"**comp**" generates a **loadrt** command for realtime component.

"**alias**" generates an **alias** command for each pin or parameter alias pairing

"**sig**" (or "**signal**") generates a **newsig** command for each signal, and "**sigu**" generates a **newsig** command for each unlinked signal (for use with **netl** and **netla**).

"**link**" and "**linka**" both generate **linkps** commands for each link. (**linka** includes arrows, while **link** does not.)

"**net**" and "**neta**" both generate one **newsig** command for each signal, followed by **linksp** commands for each pin linked to that signal. (**neta** includes arrows.)

"**netl**" generates one **net** command for each linked signal, and "**netla**" (or "**netal**") generates a similar command using arrows.

"**param**" (or "**parameter**") generates one **setp** command for each parameter.

"**thread**" generates one **addf** command for each function in each realtime thread.

"**unconnectedinpins**" generates a **setp** command for each unconnected HAL input pin.

If *item* is **allu**, **save** does the equivalent of **comp**, **alias**, **sigu**, **netla**, **param**, **thread**, and **unconnectedinpins**.

If *item* is omitted (or **all**), **save** does the equivalent of **comp**, **alias**, **sigu**, **netla**, **param**, and **thread**.

source *filename.hal*

Executes the commands from *filename.hal*.

alias *type name alias*

Assigns "**alias**" as a second name for the pin or parameter "*name*". For most operations, an alias provides a second name that can be used to refer to a pin or parameter, both the original name and the alias will work. "*type*" must be **pin** or **param**. "*name*" must be an existing name or **alias** of the specified type. Note that the "show" command will only show the aliased name, but the original name is still valid to use in HAL. The original names can still be seen with "show all" or "show alias". Existing nets will be preserved when a pin name is aliased.

unalias *type alias*

Removes any alias from the pin or parameter *alias*. "*type*" must be **pin** or **param** "*alias*" must be an existing name or **alias** of the specified type.

list *type [pattern]*

Prints the names of HAL items of the specified type. *type* is **comp**, **pin**, **sig**, **param**, **funct**, or **thread**. If *pattern* is specified it prints only those names that match the pattern, which may be a *shell glob*. For **sig**, **pin** and **param**, the first pattern may be **-datatype** where datatype is the data type (e.g., *float*) in this case, the listed pins, signals, or parameters are restricted to the given data type. Names are printed on a single line, space separated.

print [*message*]

Prints the filename, linenumber and an optional message. wrap the message in quotes if it has spaces.

lock [*all|tune|none*]

Locks HAL to some degree. none - no locking done. tune - some tuning is possible (**setp** & such). all - HAL completely locked.

unlock [*all|tune*]

Unlocks HAL to some degree. tune - some tuning is possible (**setp** & such). all - HAL completely unlocked.

status [*type*]

Prints status info about HAL. *type* is **lock**, **mem**, or **all**. If *type* is omitted, it assumes **all**.

debug [*level*]

Sets the rtapi messaging level (see man3 rtapi_set_msg_level).

help [*command*]

Give help information for command. If *command* is omitted, list command and brief description.

17.6. SUBSTITUTION

After a command is read but before it is executed, several types of variable substitution take place.

17.6.1. Environment Variables

Environment variables have the following formats:

\$ENVVAR followed by end-of-line or whitespace

\$(ENVVAR)

17.6.2. INI file variables

INI file variables are available only when an INI file was specified with the halcmd **-i** flag. They have the following formats:

[SECTION]VAR followed by end-of-line or whitespace

[SECTION](VAR)

17.7. LINE CONTINUATION

The backslash character (\) may be used to indicate the line is extended to the next line. The backslash character must be the last character before the newline.

17.8. BUGS

None known at this time.

17.9. AUTHOR

Original version by John Kasunich, as part of the LinuxCNC project. Now includes major contributions by several members of the project.

17.10. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

17.11. COPYRIGHT

Copyright © 2003 John Kasunich.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

17.12. SEE ALSO

halrun(1) — a convenience script to start a realtime environment, process a HAL or a .tcl file, and optionally start an interactive command session using **halcmd** (described here) or haltcl(1).

Chapter 18. halcmd_twopass(1)

18.1. NAME

halcmd_twopass - short description

18.2. SYNOPSIS

{name}

18.3. DESCRIPTION

halcmd_twopass is an utility script used when parsing HAL files. It is of little relevance to normal users and is used internally by the system.

18.4. SEE ALSO

linuxcnc(1), <https://linuxcnc.org/docs/html/hal/twopass.html>

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at /usr/share/doc/LinuxCNC/.

18.5. BUGS

None known at this time.

18.6. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

18.7. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

18.8. COPYRIGHT

Copyright © 2020 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 19. halcompile(1)

19.1. NAME

halcompile - Build, compile and install LinuxCNC HAL components

19.2. SYNOPSIS

halcompile [--compile | --preprocess | --document | --adoc | --view-doc] compfile...

sudo **halcompile** [--install | --install-doc] compfile...

halcompile --compile --userspace cfile...

sudo **halcompile** --install --userspace cfile...

sudo **halcompile** --install --userspace pyfile...

When personalities are used in a comp file, HAL instances are exported sequentially (typically by the mutually exclusive count= or names= parameters). If the number of exports exceeds the maximum number of personalities, subsequent personalities are assigned modulo the maximum number of personalities allowed.

By default, the maximum number of personalities is 64. To alter this limit, use the **--personalities=** option with halcompile. For example, to set the maximum of personality items to 4: [sudo] **halcompile --personalities=4 --install ...**

Do not use [sudo] for RIP installation.

19.3. OPTIONS

-a, --adoc

Extract only asciidoc format documentation from the component.

-c, --compile

Compile a component or C-source module.

-d, --document

Extract man-page format documentation from the component (builds asciidoc and then converts to manpage). This option requires **asciidoc**(1) or **a2x**(1) to be installed on your system.

-h, -?, --help

Show a brief usage message and exit.

-i, --install

Build and install a component.

-J, --view-doc

Deprecated. Live view the manpage of the component (builds asciidoc, converts to manpage and runs **man(1)**). This option requires **asciidoc(1)** or **a2x(1)** to be installed on your system.

-j, --install-doc

Install the man-page documentation in *usr/share/man1* or *usr/share/man9*, depending whether this is a userspace or realtime component.

-k file, --keep-adoc=file

Keep the generated asciidoc file when generating manpage documentation. The file is saved to *file*. You cannot specify multiple input files when using this option and it has no effect when only asciidoc formatted documentation is requested using the **-a** or **--adoc** option.

-l, --require-license

Obsolete. The component is always required to have a **licence** tag.

-o file, --outfile=file

Write output to *file*. Can *only* be used with **--preprocess**, **--adoc** and **--document** processing.

-P int, --personalities=int (default: 64)

Set the maximum number of personalities in the component.

-p, --preprocess

Only generate a C-file from the component file.

-U, --unix

Require the source to have unix-style NL-only line endings.

-u, --userspace

Create a userspace C-source (non-realtime). Default is to build realtime components.

--extra-compile-args=args

Extra arguments passed to the C-compiler.

--extra-link-args=args

Extra arguments passed to the linker.

19.4. DESCRIPTION

halcompile performs many different functions:

- Compile **.comp** and **.c** files into **.so** or **.ko** HAL realtime components (the **--compile** flag)
 - Compile **.comp** and **.c** files into HAL non-realtime components (the **--compile --userspace** flag)
 - Preprocess **.comp** files into **.c** files (the **--preprocess** flag)
 - Extract documentation from **.comp** files into asciidoc or manpage section **1** or **9** files (the **--adoc** and **--document** flags)
-

- Display documentation from **.comp** files onscreen (the **--view-doc** flag)
- Compile and install **.comp** and **.c** files into the proper directory for HAL realtime components (the **--install** flag), which may require *sudo* to write to system directories.
- Install **.c** and **.py** files into the proper directory for HAL non-realtime components (the **--install --userspace** flag), which may require *sudo* to write to system directories.
- Extract documentation from **.comp** files into **.1** or **.9** manpage files in the proper system directory (the **--install** flag), which may require *sudo* to write to system directories.
- Preprocess **.comp** files into **.c** files (the **--preprocess** flag)

19.5. SEE ALSO

- *Halcompile / HAL Component Generator* in the LinuxCNC documentation for a full description of the **.comp** syntax, along with examples
 - **pydoc**, **HAL** and *Creating Non-realtime Python Components* in the LinuxCNC documentation for documentation on the Python interface to HAL components
-

Chapter 20. halmeter(1)

20.1. NAME

halmeter - observe HAL pins, signals, and parameters

20.2. SYNOPSIS

halmeter [-s] [**pin** | **sig** | **param** *name*] [-g *X-position Y-position [Width]*]

20.3. DESCRIPTION

The tool **halmeter** is used to observe HAL (Hardware Abstraction Layer) pins, signals, or parameters. It serves the same purpose as a multimeter does when working on physical systems. It is a self-contained application and connects independently to HAL.

20.4. OPTIONS

pin *name*

Display the HAL pin *name*.

sig *name*

Display the HAL signal *name*.

param *name*

Display the HAL parameter *name*.

If neither **pin**, **sig**, or **param** are specified, the window starts out blank and the user must select an item to observe:

-s

Small window. Non-interactive, must be used with **pin**, **sig**, or **param** to select the item to display. The item name is displayed in the title bar instead of the window, and there are no "Select" or "Exit" buttons. Handy when you want a lot of meters in a small space.

-g

Geometry position. Allows one to specify the initial starting position and optionally the width of the meter. Referenced from top left of screen in pixel units. Handy when you want to load a lot of meters in a script with out them displaying on top of each other.

20.5. USAGE

Unless **-s** is specified, there are two buttons, "Select" and "Exit". "Select" opens a dialog box to select the item (pin, signal, or parameter) to be observed. "Exit" does what you expect.

The selection dialog has "OK", "Apply", and "Cancel" buttons. OK displays the selected item and closes the dialog. "Apply" displays the selected item but keeps the selection dialog open. "Cancel" closes the dialog without changing the displayed item.

20.6. EXAMPLE

halmeter

Opens a meter window, with nothing initially displayed. Use the "Select" button to choose an item to observe. Does not return until the window is closed.

halmeter &

Open a meter window, with nothing initially displayed. Use the "Select" button to choose an item. Runs in the background leaving the shell free for other commands.

halmeter pin *parport.0.pin-03-out* &

Open a meter window, initially displaying HAL pin *parport.0.pin-03-out*. The "Select" button can be used to display other items. Runs in background.

halmeter -s pin *parport.0.pin-03-out* &

Open a small meter window, displaying HAL pin *parport.0.pin-03-out*. The displayed item cannot be changed. Runs in background.

halmeter -s pin *parport.0.pin-03-out* -g 100 500 &

Open a small meter window, displaying HAL pin *parport.0.pin-03-out*. places it 100 pixels to the left and 500 pixels down from top of screen. The displayed item cannot be changed. Runs in background.

halmeter -s pin *parport.0.pin-03-out* -g 100 500 400 &

Open a small meter window, displaying HAL pin *parport.0.pin-03-out*. places it 100 pixels to the left and 500 pixels down from top of screen. The width will be 400 pixels (270 is default) The displayed item cannot be changed. Runs in background.

20.7. AUTHOR

Original version by John Kasunich, as part of the LinuxCNC project. Improvements by several other members of the LinuxCNC development team.

20.8. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

20.9. COPYRIGHT

Copyright © 2003 John Kasunich.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 21. halreport(1)

21.1. NAME

halreport - creates a report on the status of the HAL

21.2. SYNOPSIS

halreport [*outfilename*]

21.3. DESCRIPTION

halreport

1. Supports components made by halcompile and numerous legacy components.
2. Known unhandled components:

at_pid

naming conflicts with pid, seldom used

boss_plc

no manpage or docs (any users?)

watchdog

seldom used (no users in-tree)

3. Deprecated/obsolete components:

- counter
- supply

Identification of functions used according to pin name. Default handling works for components that:

1. use names= | count= (.comp components created with halcompile)
2. have a **single** function

Full docs: https://linuxcnc.org/docs/html/hal/tools.html#_halreport

21.4. SEE ALSO

linuxcnc(1)

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at /usr/share/doc/LinuxCNC/.

21.5. BUGS

None known at this time.

21.6. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

21.7. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

21.8. COPYRIGHT

Copyright © 2020 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 22. halrmt(1)

22.1. NAME

halrmt - remote-control interface for LinuxCNC

22.2. SYNOPSIS

halrmt [**--port** *<port number>*] [**--name** *<server name>*] [**--connectpw** *<password>*] [**--enablepw** *<password>*] [**--sessions** *<max sessions>*] [**-ini** *<INI file>*]

22.3. OPTIONS

--port *port*

Waits for socket connections (telnet) on specified socket, without port specification it uses default port 5006. (Note: linuxcncrsh uses 5007 as default.)

--name *server_name*

Sets the server name to specified name for Hello.

--connectpw *password*

Sets the connection password to *password*. Default: EMC.

--enablepw *password*

Sets the enable password to *password*. Default EMCTOO.

--sessions *<max sessions>*

Sets the maximum number of simultaneous connexctions to max sessions. Default is no limit (-1).

-ini *<INI file>*

Uses the specified *INI file* instead of the default emc.ini.

22.4. DESCRIPTION

The application **halrmt** supports six commands that are meant to be sent to an instance of HAL that is running on another machine. Of these, the commands *set* and *get* contain HAL specific sub-commands that are based on the commands supported by *halcmd*.

Commands and most parameters are not case sensitive. The exceptions are passwords, file paths and text strings. The supported commands are as follows:

Hello *<password>* *<client>* *<version>*

If a valid password was entered the server will respond with "HELLO ACK *<Server Name>* *<Server Version>*" where server name and server version are looked up from the implementation. If an invalid password or any other syntax error occurs then the server responds with "HELLO NAK".

Get

The get command includes one of the HAL sub-commands, described below and zero or more additional parameters.

Set

The set command includes one of the HAL sub-commands, described below and one or more additional parameters.

Quit

The quit command disconnects the associated socket connection.

Shutdown

The shutdown command tells LinuxCNC to shut down before quitting the connection. This command may only be issued if the Hello has been successfully negotiated and the connection has control of the CNC (see enable sub-command below). This command has no parameters.

Help

The help command will return help information in text format over the telnet connection. If no parameters are specified, it will itemize the available commands. If a command is specified, it will provide usage information for the specified command. Help will respond regardless of whether a "Hello" has been successfully negotiated.

HAL sub-commands:**echo on | off**

With get will return the current echo state, with set, sets the echo state. When echo is on, all commands will be echoed upon receipt. This state is local to each connection.

verbose on | off

With get will return the current verbose state, with set, sets the verbose state. When in verbose mode is on, all set commands return positive acknowledgement in the form SET <COMMAND> ACK. In addition, text error messages will be issued when in verbose mode. This state is local to each connection.

enable <pwd> | off

With get will return On or Off to indicate whether the current connection is enabled to perform control functions. With set and a valid password, the current connection is enabled for control functions. "OFF" may not be used as a password and disables control functions for this connection.

config [TBD] comm_mode ascii | binary

With get, will return the current communications mode. With set, will set the communications mode to the specified mode. The binary protocol is TBD.

comm_prot <version no>

With get, returns the current protocol version used by the server, with set, sets the server to use the specified protocol version, provided it is lower than or equal to the highest version number supported by the server implementation.

Comps [<substring>]

Get only, returns all components beginning with the specified substring. If no substring is specified then it returns all components.

Pins [<substring>]

Get only, returns all information about all pins beginning with the specified substring. If no substring is specified then it returns all pins.

PinVals [<substring>]

Get only, returns only value information about all pins beginning with the specified substring. If no substring is specified then it returns all pins.

Signals [<substring>]

Get only, returns all information about all signals beginning with the specified substring. If no substring is specified then it returns all signals.

SigVals [<substring>]

Get only, returns only value information about all signals beginning with the specified substring. If no substring is specified then it returns all pins.

Params [<substring>]

Get only, returns all information about all parameters beginning with the specified substring. If no substring is specified then it returns all parameters.

ParamVals [<substring>]

Get only, returns only value information about all parameters beginning with the specified substring. If no substring is specified then it returns all pins parameters.

Functs [<substring>]

Get only, returns all information about all functions beginning with the specified substring. If no substring is specified then it returns all functions.

Threads

Get only, returns all information about all functions.

Comp <name>

Get only, returns the component matching the specified name.

Pin <name>

Get only, returns all information about the pin matching the specified name.

PinVal <name>

Get only, returns the value of the pin matching the specified name.

Sig <name>

Get only, returns all information about the pin matching the specified name.

SigVal <name>

Get only, returns just the value of the signal matching the specified name.

Param <name>

Get only, returns all information about the parameter matching the specified name.

ParamVal <name>

Get only, returns just the value of the parameter matching the specified name.

Funct <name>

Get only, returns all information about the parameter matching the specified name.

Thread <name>

Get only, returns all information about the thread matching the specified name.

LoadRt <name>

Set only, loads the real time executable specified by name.

Unload <name>

Set only, unloads the executable specified by name.

LoadUsr <name>

Set only, loads the user executable specified by name.

Linkps <pin name> <signal name>

Set only, links the specified pin to the specified signal.

Linksp <signal name> <pin name>

Set only, links the specified signal to the specified pin.

Linkpp <pin name 1> <pin name 2>

Set only, links the pin specified by pin 1 with the pin specified by pin 2.

Net <net list>

Set only, nets the specified net list.

Unlinkp <pin name 1> <pin name 2>

Set only, unlinks the specified pins.

Lock

Unlock

NewSig <name> <type>

Set only, creates the signal specified by name and of type specified by type.

DelSig <name>

Set only, deletes the signal specified by name.

SetP <name> <value>

Set only, sets the parameter specified by name to the value specified by value.

SetS <name> <value>

Set only, sets the signal specified by name to the value specified by value.

AddF <name> <thread> [<parameters>]

Set only, adds the function specified by name, to the thread specified by thread, with the optional parameters specified by parameters.

DelF <name>

Set only, deletes the function specified by name.

Save

Start

Stop

22.5. SEE ALSO

linuxcnc(1)

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at `/usr/share/doc/LinuxCNC/`.

22.6. BUGS

It is not known if this interface currently works.

22.7. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

22.8. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

22.9. COPYRIGHT

Copyright © 2020 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 23. halrun(1)

23.1. NAME

halrun - manipulate the LinuxCNC HAL from the command line

23.2. SYNOPSIS

halrun -h

halrun [-I] [*halcmd_opts*] [*filename[.hal|.tcl]*]

halrun -T [*halcmd_opts*] [*filename[.hal|.tcl]*]

halrun -U

23.3. DESCRIPTION

The convenience script **halrun** can manipulate the HAL (Hardware Abstraction Layer) from the command line. When invoked, **halrun**:

- Sets up the realtime environment.
- Executes a command interpreter (**halcmd** or **haltcl**).
- (Optionally) runs an interactive session.
- Tears down the realtime environment.

If no filename is specified, an interactive session is started. The session will use **halcmd**(1) unless **-T** is specified in which case **haltcl**(1) will be used.

If a filename is specified and neither the **-I** nor the **-T** option is included, the filename will be processed by the command interpreter corresponding to the filename extension (**halcmd** or **haltcl**). After processing, the realtime environment will be torn down.

If a filename is specified and the **-I** or **-T** option is included, the file is processed by the appropriate command interpreter and then an interactive session is started for **halcmd** or **haltcl** according to the **-I** or **-T** option.

23.4. OPTIONS

halcmd_opts

When a .hal file is specified, the **halcmd_opts** are passed to **halcmd**. See the man page for **halcmd**(1). When a .tcl file is specified, the only valid options are: -i <INI file> -f <filename[.tcl|.hal]> (alternate means of specifying a file).

-I

Run an interactive **halcmd** session

-T

Run an interactive **haltcl** session.

-U

Forcibly cause the realtime environment to exit. It releases the HAL mutex, requests that all HAL components unload, and stops the realtime system. **-U** must be the only commandline argument.

-h

Display a brief help screen and exit.

23.5. BUGS

None known at this time.

23.6. AUTHOR

Original version by John Kasunich, as part of the LinuxCNC Enhanced Machine Controller project. Now includes major contributions by several members of the project.

23.7. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

23.8. COPYRIGHT

Copyright © 2003 John Kasunich.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

23.9. SEE ALSO

halcmd(1), haltcl(1)

Chapter 24. halsampler(1)

24.1. NAME

halsampler - sample data from HAL in realtime

24.2. SYNOPSIS

halsampler [*options*]

24.3. DESCRIPTION

sampler(9) and **halsampler** are used together to sample HAL data in real time and store it in a file. **sampler** is a realtime HAL component that exports HAL pins and creates a FIFO in shared memory. It then begins sampling data from the HAL and storing it to the FIFO. **halsampler** is a non-realtime program that copies data from the FIFO to stdout, where it can be redirected to a file or piped to some other program.

24.4. OPTIONS

-c CHAN

instructs **halsampler** to read from FIFO *CHAN*. FIFOs are numbered from zero, and the default value is zero, so this option is not needed unless multiple FIFOs have been created.

-n COUNT

instructs **halsampler** to read *COUNT* samples from the FIFO, then exit. If **-n** is not specified, **halsampler** will read continuously until it is killed.

-t

instructs **halsampler** to tag each line by printing the sample number in the first column.

FILENAME

instructs **halsampler** to write to *FILENAME* instead of to stdout.

24.5. USAGE

A FIFO must first be created by loading **sampler**(9) with **halcmd loadrt** or a **loadrt** command in a HAL file. Then **halsampler** can be invoked to begin printing data from the FIFO to stdout.

Data is printed one line per sample. If **-t** was specified, the sample number is printed first. The data follows, in the order that the pins were defined in the config string. For example, if the **sampler** config string was "ffbs" then a typical line of output (without **-t**) would look like:

```
123.55 33.4 0 -12
```

halsampler prints data as fast as possible until the FIFO is empty, then it retries at regular intervals,

until it is either killed or has printed *COUNT* samples as requested by **-n**. Usually, but not always, data printed by **halsampler** will be redirected to a file or piped to some other program.

The FIFO size should be chosen to absorb samples captured during any momentary disruptions in the flow of data, such as disk seeks, terminal scrolling, or the processing limitations of subsequent program in a pipeline. If the FIFO gets full and **sampler** is forced to overwrite old data, **halsampler** will print *overflow* on a line by itself to mark each gap in the sampled data. If **-t** was specified, gaps in the sequential sample numbers in the first column can be used to determine exactly how many samples were lost.

The data format for **halsampler** output is the same as for **halstreamer**(1) input, so *waveforms* captured with **halsampler** can be replayed using **halstreamer**. The **-t** option should not be used in this case.

24.6. EXIT STATUS

If a problem is encountered during initialization, **halsampler** prints a message to stderr and returns failure.

Upon printing *COUNT* samples (if **-n** was specified) it will shut down and return success. If it is terminated before printing the specified number of samples, it returns failure. This means that when **-n** is not specified, it will always return failure when terminated.

24.7. SEE ALSO

sampler(9), streamer(9), halstreamer(1)

24.8. AUTHOR

Original version by John Kasunich, as part of the LinuxCNC project. Improvements by several other members of the LinuxCNC development team.

24.9. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

24.10. COPYRIGHT

Copyright © 2006 John Kasunich.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 25. halscope(1)

25.1. NAME

halscope - short description

25.2. SYNOPSIS

halscope

25.3. DESCRIPTION

halscope Software oscilloscope for LinuxCNC/HAL

Digital oscilloscope for viewing real time waveforms of HAL pins and signals

25.4. SEE ALSO

linuxcnc(1)

Find more information in the HAL tutorial: <https://linuxcnc.org/docs/html/hal/tutorial.html#sec:tutorial-halscope>. More information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at /usr/share/doc/LinuxCNC/.

25.5. BUGS

None known at this time.

25.6. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

25.7. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

25.8. COPYRIGHT

Copyright © 2020 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 26. halshow(1)

26.1. NAME

halshow - Show HAL parameters, pins and signals

26.2. SYNOPSIS

halshow [*options*] [*watchfile*]

26.3. OPTIONS

--help

Displays the help

--fformat *format_string_for_float*

Float format string

--iformat *format_string_for_int*

Integer format string

For format see <https://www.tcl.tk/man/tcl8.6.11/TclCmd/format.html>

Example: "%.5f" displays a float with 5 digits right of the decimal point.

--noprefs

Don't use preference file to save settings.

26.4. DESCRIPTION

The program **halshow** creates a GUI interface to view and interact with a running HAL session.

26.5. SEE ALSO

linuxcnc(1)

Halshow is documented in the PDF and HTML documentation much more completely than is possible in a manpage: <https://linuxcnc.org/docs/html/hal/halshow.html>

26.6. HISTORY

LinuxCNC 2.9

- Added buttons for pin/parameter/signal manipulation.
 - Added menu entries for setting update interval, adding manually.
-

- Added right-click menu for copy, set, unlink pin and remove from view.
- Added button to expand/collapse the tree view.
- Added search entry.

26.7. BUGS

None known at this time.

26.8. AUTHOR

Raymond E. Henry

26.9. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

26.10. COPYRIGHT

Copyright © 2020 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 27. halstreamer(1)

27.1. NAME

halstreamer - stream file data into HAL in real-time

27.2. SYNOPSIS

halstreamer [*options*]

27.3. DESCRIPTION

The HAL component **streamer**(9) and the program **halstreamer** are used together to stream data from a file into the HAL in real-time. In real-time, **streamer** exports HAL pins and creates a FIFO (first in, first out queue) in shared memory. The non-realtime program **halstreamer** copies data from stdin into the FIFO, so that **streamer** can write it to the HAL pins.

27.4. OPTIONS

-c *CHAN*

Instructs **halstreamer** to write to FIFO *CHAN*. FIFOs are numbered from zero, and the default value is zero, so this option is not needed unless multiple FIFOs have been created.

FILENAME

Instructs **halsampler** to read from *FILENAME* instead of from stdin.

27.5. USAGE

A FIFO must first be created by loading **streamer**(9) with **halcmd loadrt** or a **loadrt** command in a HAL file. Then **halstreamer** can be invoked to begin writing data into the FIFO.

Data is read from stdin, and is almost always either redirected from a file or piped from some other program, since keyboard input would be unable to keep up with even slow streaming rates.

Each line of input must match the pins that are attached to the FIFO, for example, if the **streamer** config string was "ffbs" then each line of input must consist of two floats, a bit, and a signed integer, in that order and separated by whitespace. Floats must be formatted as required by **strtod**(3), signed and unsigned integers must be formatted as required by **strtol**(3) and **strtoul**(3), and bits must be either 0 or 1.

Input lines that begin with # will be treated as comments and silently skipped.

halstreamer transfers data to the FIFO as fast as possible until the FIFO is full, then it retries at regular intervals, until it is either killed or reads EOF from stdin. Data can be redirected from a file or piped from some other program.

The FIFO size should be chosen to ride through any momentary disruptions in the flow of data, such as disk seeks. If the FIFO is big enough, **halstreamer** can be restarted with the same or a new file before the FIFO empties, resulting in a continuous stream of data.

The data format for **halstreamer** input is the same as for **halsampler**(1) output, so *waveforms* captured with **halsampler** can be replayed using **halstreamer**.

27.6. EXIT STATUS

If a problem is encountered during initialization, **halstreamer** prints a message to stderr and returns failure.

If a badly formatted line is encountered while writing to the FIFO, it prints a message to stderr, skips the line, and continues (this behavior may be revised in the future).

Upon reading EOF from the input, it returns success. If it is terminated before the input ends, it returns failure.

27.7. SEE ALSO

streamer(9), sampler(9), halsampler(1)

27.8. AUTHOR

Original version by John Kasunich, as part of the LinuxCNC project. Improvements by several other members of the LinuxCNC development team.

27.9. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

27.10. COPYRIGHT

Copyright © 2006 John Kasunich.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 28. haltcl(1)

28.1. NAME

haltcl - manipulate the LinuxCNC HAL from the command line using a Tcl interpreter.

28.2. SYNOPSIS

haltcl [-i <INI file>] [filename]

28.3. DESCRIPTION

Tcl is a scripting language from the 90s that is very easy to extend. **Haltcl** extends the regular Tcl interpreter with a set of commands to interact with HAL, i.e. it allows to manipulate the HAL (Hardware Abstraction Layer) from the command line using a Tcl interpreter. **haltcl** can optionally read commands from a file (filename), allowing complex HAL configurations to be set up with a single command.

28.4. OPTIONS

-i <INI file>

If specified, the INI file is read and used to create Tcl global variable arrays. An array is created for each SECTION of the INI file with elements for each ITEM in the section.

For example, if the INI file contains:

```
[SECTION_A]
ITEM_1 = 1
[SECTION_A]
ITEM_2 = 2
[SECTION_B]
ITEM_1 = 10
```

The corresponding Tcl variables are:

```
SECTION_A(ITEM_1) = 1
SECTION_A(ITEM_2) = 2
SECTION_B(ITEM_1) = 10
```

-ini <INI file>

Declining usage, use **-i** <INI file>

filename

If specified, the Tcl commands of **filename** are executed. If no filename is specified, haltcl opens an interactive session.

28.5. COMMANDS

The executable **haltcl** includes the commands of a Tcl interpreter augmented with commands for the hal language as described for **halcmd**(1). The augmented commands can be listed with the command:

```
haltcl: hal --commands+
```

```
addf alias delf delsig getp gets initf ptype stype help linkpp linkps linksp list  
loadrt loadusr lock net newsig save setexact_for_test_suite_only setp sets show  
source start status stop unalias unlinkp unload unloadrt unloadusr unlock waitusr
```

Two of the augmented commands, *list* and *gets*, require special treatment to avoid conflict with Tcl built-in commands having the same names. To use these commands, precede them with the keyword *hal*:

```
hal list  
hal gets
```

28.6. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

28.7. COPYRIGHT

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

28.8. SEE ALSO

halcmd(1), halrun(1)

Chapter 29. halui(1)

29.1. NAME

halui - observe HAL pins and command LinuxCNC through NML

29.2. SYNOPSIS

halui [-ini <path-to-INI>]

29.3. DESCRIPTION

The program **halui** is used to build a User Interface using hardware knobs and switches. It exports a big number of pins, and acts accordingly when these change.

29.4. OPTIONS

-ini filename

Use the *filename* as the configuration file. Note: halui must find the nml file specified in the INI, usually that file is in the same folder as the INI, so it makes sense to run halui from that folder.

29.5. USAGE

When run, **halui** will export a large number of pins. A user can connect those to his physical knobs & switches & leds, and when a change is noticed halui triggers an appropriate event.

Caveat, **halui** expects the signals to be debounced, so if needed (bad knob contact) connect the physical button to a HAL debounce filter first.

29.6. PINS

29.6.1. Abort

halui.abort bit in

pin for clearing most errors

29.6.2. Tool

halui.tool.length-offset.a float out

current applied tool length offset for the A axis

halui.tool.length-offset.b float out

current applied tool length offset for the B axis

halui.tool.length-offset.c float out

current applied tool length offset for the C axis

halui.tool.length-offset.u float out

current applied tool length offset for the U axis

halui.tool.length-offset.v float out

current applied tool length offset for the V axis

halui.tool.length-offset.w float out

current applied tool length offset for the W axis

halui.tool.length-offset.x float out

current applied tool length offset for the X axis

halui.tool.length-offset.y float out

current applied tool length offset for the Y axis

halui.tool.length-offset.z float out

current applied tool length offset for the Z axis

halui.tool.diameter float out

Current tool diameter, or 0 if no tool is loaded.

halui.tool.number u32 out

current selected tool

29.6.3. Spindle

halui.spindle.N.brake-is-on bit out

status pin that tells us if brake is on

halui.spindle.N.brake-off bit in

pin for deactivating the spindle brake

halui.spindle.N.brake-on bit in

pin for activating the spindle brake

halui.spindle.N.decrease bit in

a rising edge on this pin decreases the current spindle speed by 100

halui.spindle.N.forward bit in

a rising edge on this pin makes the spindle go forward

halui.spindle.N.increase bit in

a rising edge on this pin increases the current spindle speed by 100

halui.spindle.N.is-on bit out

status pin telling if the spindle is on

halui.spindle.N.reverse bit in

a rising edge on this pin makes the spindle go reverse

halui.spindle.N.runs-backward bit out

status pin telling if the spindle is running backward

halui.spindle.N.runs-forward bit out

status pin telling if the spindle is running forward

halui.spindle.N.start bit in

a rising edge on this pin starts the spindle

halui.spindle.N.stop bit in

a rising edge on this pin stops the spindle

29.6.4. Spindle Override

(SO = spindle override. FO = feed override)

halui.spindle.N.override.count-enable bit in (default: TRUE)

When TRUE, modify spindle override when counts changes.

halui.spindle.N.override.counts s32 in

counts X scale = spindle override percentage

halui.spindle.N.override.decrease bit in

pin for decreasing the SO (--scale)

halui.spindle.N.override.direct-value bit in

pin to enable direct spindle override value input

halui.spindle.N.override.increase bit in

pin for increasing the SO (+=scale)

halui.spindle.N.override.reset bit in

pin for resetting the scale SO value (scale=1.0)

halui.spindle.N.override.scale float in

pin for setting the scale of counts for SO

halui.spindle.N.override.value float out

current FO value

29.6.5. Program

halui.program.block-delete.is-on bit out

status pin telling that block delete is on

halui.program.block-delete.off bit in

pin for requesting that block delete is off

halui.program.block-delete.on bit in

pin for requesting that block delete is on

halui.program.is-idle bit out

status pin telling that no program is running

halui.program.is-paused bit out

status pin telling that a program is paused

halui.program.is-running bit out

status pin telling that a program is running

halui.program.optional-stop.is-on bit out

status pin telling that the optional stop is on

halui.program.optional-stop.off bit in

pin requesting that the optional stop is off

halui.program.optional-stop.on bit in

pin requesting that the optional stop is on

halui.program.pause bit in

pin for pausing a program

halui.program.resume bit in

pin for resuming a program

halui.program.run bit in

pin for running a program

halui.program.step bit in

pin for stepping in a program

halui.program.stop bit in

pin for stopping a program (note: this pin does the same thing as halui.abort)

29.6.6. Mode

halui.mode.auto bit in

pin for requesting auto mode

halui.mode.is-auto bit out

pin for auto mode is on

halui.mode.is-joint bit out

pin showing joint by joint jog mode is on

halui.mode.is-manual bit out

pin for manual mode is on

halui.mode.is-mdi bit out

pin for MDI mode is on

halui.mode.is-teleop bit out

pin showing coordinated jog mode is on

halui.mode.joint bit in

pin for requesting joint by joint jog mode

halui.mode.manual bit in

pin for requesting manual mode

halui.mode.mdi bit in

pin for requesting MDI mode

halui.mode.teleop bit in

pin for requesting coordinated jog mode

29.6.7. MDI (optional)

halui.mdi-command-XX bit in

halui looks for INI variables named [HALUI]MDI_COMMAND, and exports a pin for each command it finds. When the pin is driven TRUE, **halui** runs the specified MDI command. XX is a two digit number starting at 00. If no [HALUI]MDI_COMMAND variables are set in the INI file, no halui.mdi-command-XX pins will be exported by halui.

29.6.8. Mist coolant

halui.mist.is-on bit out

pin for mist is on

halui.mist.off bit in

pin for stopping mist

halui.mist.on bit in

pin for starting mist

29.6.9. Max-velocity

halui.max-velocity.count-enable bit in (default: TRUE)

When True, modify max velocity when halui.max-velocity.counts changes.

halui.max-velocity.counts s32 in

When .count-enable is True, halui changes the max velocity in response to changes to this pin. It's usually connected to an MPG encoder on an operator's panel or jog pendant. When .count-enable is False, halui ignores this pin.

halui.max-velocity.direct-value bit in

When this pin is True, halui commands the max velocity directly to (.counts * .scale). When this pin is False, halui commands the max velocity in a relative way: change max velocity by an amount equal to (change in .counts * .scale).

halui.max-velocity.increase bit in

A positive edge (a False to True transition) on this pin increases the max velocity by the value of the .scale pin. (Note that halui always responds to this pin, independent of the .count-enable pin.)

halui.max-velocity.decrease bit in

A positive edge (a False to True transition) on this pin decreases the max velocity by the value of the .scale pin. (Note that halui always responds to this pin, independent of the .count-enable pin.)

halui.max-velocity.scale float in

This pin controls the scale of changes to the max velocity. Each unit change in .counts, and each positive edge on .increase and .decrease, changes the max velocity by .scale. The units of the .scale pin are machine-units per second.

halui.max-velocity.value float out

Current value for maximum velocity, in machine-units per second.

29.6.10. Machine

halui.machine.units-per-mm float out

pin for machine units-per-mm (inch:1/25.4, mm:1) according to INI file setting: [TRAJ] LINEAR_UNITS

halui.machine.is-on bit out

pin for machine is On/Off

halui.machine.off bit in

pin for setting machine Off

halui.machine.on bit in

pin for setting machine On

29.6.11. Joint

N = joint number (0 ... num_joints-1)

halui.joint. N .select bit in

pin for selecting joint N

halui.joint. N .is-selected bit out

status pin that joint N is selected

halui.joint. N .has-fault bit out

status pin telling that joint N has a fault

halui.joint. N .home bit in

pin for homing joint N

halui.joint. N .is-homed bit out

status pin telling that joint N is homed

halui.joint. N .on-hard-max-limit bit out

status pin telling that joint N is on the positive hardware limit

halui.joint. N .on-hard-min-limit bit out

status pin telling that joint N is on the negative hardware limit

halui.joint. N .on-soft-max-limit bit out

status pin telling that joint N is on the positive software limit

halui.joint. N .on-soft-min-limit bit out

status pin telling that joint N is on the negative software limit

halui.joint. N .override-limits bit out

status pin telling that joint N 's limits are temporarily overridden

halui.joint. N .unhome bit in

pin for unhoming joint N

halui.joint.selected u32 out

selected joint number (0 ... num_joints-1)

halui.joint.selected.has-fault bit out

status pin selected joint is faulted

halui.joint.selected.home bit in

pin for homing the selected joint

halui.joint.selected.is-homed bit out

status pin telling that the selected joint is homed

halui.joint.selected.on-hard-max-limit bit out

status pin telling that the selected joint is on the positive hardware limit

halui.joint.selected.on-hard-min-limit bit out

status pin telling that the selected joint is on the negative hardware limit

halui.joint.selected.on-soft-max-limit bit out

status pin telling that the selected joint is on the positive software limit

halui.joint.selected.on-soft-min-limit bit out

status pin telling that the selected joint is on the negative software limit

halui.joint.selected.override-limits bit out

status pin telling that the selected joint's limits are temporarily overridden

halui.joint.selected.unhome bit in

pin for unhomings the selected joint

29.6.12. Joint jogging (N = joint number (0 ... num_joints-1))

Joint jogging is possible in unhomed state except for joints having a negative HOME_SEQUENCE value. See Section "Homing Configuration" of the documentation.

halui.joint.jog-deadband float in

pin for setting jog analog deadband (jog analog inputs smaller/slower than this (in absolute value) are ignored).

halui.joint.jog-speed float in

pin for setting jog speed for plus/minus jogging.

halui.joint.N.analog float in

pin for jogging the joint *N* using an float value (e.g. joystick). The value, typically set between 0.0 and ± 1.0 , is used as a jog-speed multiplier.

halui.joint.N.increment float in

pin for setting the jog increment for joint *N* when using increment-plus/minus

halui.joint.N.increment-minus bit in

a rising edge will will make joint *N* jog in the negative direction by the increment amount

halui.joint.N.increment-plus bit in

a rising edge will will make joint *N* jog in the positive direction by the increment amount

halui.joint.N.minus bit in

pin for jogging joint *N* in negative direction at the halui.joint.jog-speed velocity

halui.joint.N.plus bit in

pin for jogging joint *N* in positive direction at the halui.joint.jog-speed velocity

halui.joint.selected.increment float in

pin for setting the jog increment for the selected joint when using increment-plus/minus

halui.joint.selected.increment-minus bit in

a rising edge will will make the selected joint jog in the negative direction by the increment amount

halui.joint.selected.increment-plus bit in

a rising edge will will make the selected joint jog in the positive direction by the increment amount

halui.joint.selected.minus bit in

pin for jogging the selected joint in negative direction at the halui.joint.jog-speed velocity

halui.joint.selected.plus bit in

pin for jogging the selected joint bit in in positive direction at the halui.joint.jog-speed velocity

29.6.13. Axis

L = axis letter (xyzabcuvw)

halui.axis.L.select bit in

pin for selecting axis by letter

halui.axis.L.is-selected bit out

status pin that axis *L* is selected

halui.axis.L.pos-commanded float out

Commanded axis position in machine coordinates

halui.axis.L.pos-feedback float out

Feedback axis position in machine coordinates

halui.axis.L.pos-relative float out

Commanded axis position in relative coordinates

29.6.14. Axis Jogging

This is only possible in homed state.

L = axis letter (xyzabcuvw)

halui.axis.jog-deadband float in

pin for setting jog analog deadband (jog analog inputs smaller/slower than this (in absolute value) are ignored)

halui.axis.jog-speed float in

pin for setting jog speed for plus/minus jogging.

halui.axis.L.analog float in

pin for jogging the axis L using an float value (e.g. joystick). The value, typically set between 0.0 and ± 1.0 , is used as a jog-speed multiplier.

halui.axis.L.increment float in

pin for setting the jog increment for axis L when using increment-plus/minus

halui.axis.L.increment-minus bit in

a rising edge will will make axis L jog in the negative direction by the increment amount

halui.axis.L.increment-plus bit in

a rising edge will will make axis L jog in the positive direction by the increment amount

halui.axis.L.minus bit in

pin for jogging axis L in negative direction at the halui.axis.jog-speed velocity

halui.axis.L.plus bit in

pin for jogging axis L in positive direction at the halui.axis.jog-speed velocity

halui.axis.selected u32 out

selected axis (by index: 0:x 1:y 2:z 3:a 4:b 5:cr 6:u 7:v 8:w)

halui.axis.selected.increment float in

pin for setting the jog increment for the selected axis when using increment-plus/minus

halui.axis.selected.increment-minus bit in

a rising edge will will make the selected axis jog in the negative direction by the increment amount

halui.axis.selected.increment-plus bit in

a rising edge will will make the selected axis jog in the positive direction by the increment amount

halui.axis.selected.minus bit in

pin for jogging the selected axis in negative direction at the halui.axis.jog-speed velocity

halui.axis.selected.plus bit in

pin for jogging the selected axis bit in in positive direction at the halui.axis.jog-speed velocity

29.6.15. Flood coolant

halui.flood.is-on bit out

pin for flood is on

halui.flood.off bit in

pin for stopping flood

halui.flood.on bit in

pin for starting flood

29.6.16. Feed Override**halui.feed-override.count-enable bit in (default: TRUE)**

When TRUE, modify feed override when counts changes.

halui.feed-override.counts s32 in

counts X scale = feed override percentage

halui.feed-override.decrease bit in

pin for decreasing the FO (-=scale)

halui.feed-override.direct-value bit in

pin to enable direct value feed override input

halui.feed-override.increase bit in

pin for increasing the FO (+=scale)

halui.feed-override.reset bit in

pin for resetting the FO (scale=1.0)

halui.feed-override.scale float in

pin for setting the scale on changing the FO

halui.feed-override.value float out

current feed override value

29.6.17. Rapid Override**halui.rapid-override.count-enable bit in (default: TRUE)**

When TRUE, modify rapid override when counts changes.

halui.rapid-override.counts s32 in

counts X scale = rapid override percentage

halui.rapid-override.decrease bit in

pin for decreasing the rapid override (-=scale)

halui.rapid-override.direct-value bit in

pin to enable direct value rapid override input

halui.rapid-override.increase bit in

pin for increasing the rapid override (+=scale)

halui.rapid-override.reset bit in

pin for resetting the rapid override (scale=1.0)

halui.rapid-override.scale float in

pin for setting the scale on changing the rapid override

halui.rapid-override.value float out

current rapid override value

29.6.18. E-stop**halui.estop.activate bit in**

pin for setting E-stop (LinuxCNC internal) On

halui.estop.is-activated bit out

pin for displaying E-stop state (LinuxCNC internal) On/Off

halui.estop.reset bit in

pin for resetting E-stop (LinuxCNC internal) Off

29.6.19. Homing**halui.home-all bit in**

pin for requesting home-all (only available when a valid homing sequence is specified)

29.7. SEE ALSO

axis(1), iocontrol(1)

29.8. BUGS

None known at this time.

29.9. AUTHOR

Written by Alex Joni, as part of the LinuxCNC project. Updated by John Thornton

29.10. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>

29.11. COPYRIGHT

Copyright © 2006 Alex Joni.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 30. hbmgui(1)

30.1. NAME

hbmgui - Vismach Virtual Machine GUI

30.2. DESCRIPTION

The **hbmgui** is one of the sample **Vismach** GUIs for LinuxCNC, simulating a Horizontal Boring Machine.

See the main LinuxCNC documentation for more details.

<https://linuxcnc.org/docs/html/gui/vismach.html>

30.3. SEE ALSO

linuxcnc(1)

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at `/usr/share/doc/LinuxCNC/`.

30.4. BUGS

None known at this time.

30.5. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

30.6. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

30.7. COPYRIGHT

Copyright © 2020 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 31. hexagui(1)

31.1. NAME

hexagui - Vismach Virtual Machine GUI

31.2. DESCRIPTION

The **hexagui** is one of the sample **Vismach** GUIs for LinuxCNC, simulating a Horizontal Boring Machine.

See the main LinuxCNC documentation for more details.

<https://linuxcnc.org/docs/html/gui/vismach.html>

31.3. SEE ALSO

linuxcnc(1)

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at `/usr/share/doc/LinuxCNC/`.

31.4. BUGS

None known at this time.

31.5. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

31.6. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>

31.7. COPYRIGHT

Copyright © 2020 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 32. hy_gt_vfd(1)

32.1. NAME

hy_gt_vfd - HAL non-realtime component for Huanyang GT-series VFDs

32.2. SYNOPSIS

hy_gt_vfd [*OPTIONS*]

32.3. DESCRIPTION

The hy_gt_vfd component interfaces a Huanyang GT-series VFD to the LinuxCNC HAL. The VFD is connected via RS-485 serial to the LinuxCNC computer.

32.4. Hardware setup

At least some Huanyang GT VFDs must be physically modified to enable Modbus communication.

The circuit board location marked "SW1" is identified in the manual as "Switch of terminal resistor for RS485 communication". On the only VFD I have experience with, the circuit board contained no switch at that location, instead holding a pair of crossed jumper wires (top-left pad connected to bottom-right pad, top-right to bottom-left). In this configuration, no Modbus communication is possible. We had to desolder the two crossed jumper wires and re-solder them parallel to each other (top-left to bottom-left, top-right to bottom-right).

32.5. Firmware setup

The Huanyang GT VFD must be configure via the faceplate to talk Modbus with LinuxCNC. Consult the Operation section of the Huanyang GT-series Inverter Manual for details. Set the following parameters:

P0.01 = 2

Set Run Command Source to Modbus serial port.

P0.03

Set Maximum Frequency to the maximum frequency you want the VFD to output, in Hz.

P0.04

Set Upper Frequency Limit to the maximum frequency you want the VFD to output, in Hz. This should be the same as the value in P0.03.

P0.05

Set Lower Frequency Limit to the minimum frequency you want the VFD to output, in Hz.

P0.07 = 7

Set Frequency A Command Source to Modbus serial port.

P2.01 = ???

Set Motor Rated Power to the motor's power rating in kW.

P2.02 = ???

Set Motor Rated Frequency to the motor's max frequency in Hz.

P2.03 = ???

Set Motor Rated Speed to the motor's speed in RPM at its rated maximum frequency.

P2.04 = ???

Set Motor Rated Voltage to the motor's maximum voltage, in Volts.

P2.05 = ???

Set Motor Rated Current to the motor's maximum current, in Amps.

PC.00 = 1

Set Local Address to 1. This matches the default in the hy_gt_vfd driver, change this if your setup has special needs.

PC.01 = 5

Set baud rate selection to 5 (38400 bps). This matches the default in the hy_gt_vfd driver, change this if your setup has special needs. + 0 = 1200 1 = 2400 2 = 4800 3 = 9600 4 = 19200 5 = 38400

PC.02 = 0

Set Data Format (8n1 RTU). This matches the default in the hy_gt_vfd driver, change this if your setup has special needs.

PC.03 = 1

Set Communication Delay Time to 1 ms. This is expected by the hy_gt_vfd driver.

32.6. OPTIONS

-b, --bits *N*

(default 8) For Modbus communication. Set number of data bits to *N*. *N* must be between 5 and 8 inclusive.

-p, --parity [Even,Odd,None]

(default None) For Modbus communication. Set serial parity to Even, Odd, or None.

-r, --rate *N*

(default 38400) For Modbus communication. Set baud rate to *N*. It is an error if the rate is not one of the following: 1200, 2400, 4800, 9600, 19200, 38400

-s, --stopbits [1,2]

(default 1) For Modbus communication. Set serial stop bits to 1 or 2.

-t, --target *N*

(default 1) For Modbus communication. Set Modbus target (slave) number. This must match the device number you set on the Huanyang GT VFD.

-d, --device *PATH*

(default /dev/ttyS0) For Modbus communication. Set the name of the serial device node to use.

-v, --verbose

Turn on verbose mode.

-S, --motor-max-speed *RPM*

The motor's max speed in RPM. This must match the motor speed value configured in VFD register P2.03.

-F, --max-frequency *HZ*

This is the maximum output frequency of the VFD in Hz. It should correspond to the motor's rated max frequency, and to the maximum and upper limit output frequency configured in VFD register P0.03 and P0.04.

-f, --min-frequency *HZ*

This is the minimum output frequency of the VFD in Hz. It should correspond to the minimum output frequency configured in VFD register P0.05.

32.7. PINS

hy_gt_vfd.period (float, in)

The period for the driver's update cycle, in seconds. This is how frequently the driver will wake up, check its HAL pins, and communicate with the VFD. Must be between 0.001 and 2.000 seconds. Default: 0.1 seconds.

hy_gt_vfd.speed-cmd (float, in)

The requested motor speed, in RPM.

hy_gt_vfd.speed-fb (float, out)

The motor's current speed, in RPM, reported by the VFD.

hy_gt_vfd.at-speed (bit, out)

True when the drive is on and at the commanded speed (within 2%), False otherwise.

hy_gt_vfd.freq-cmd (float, out)

The requested output frequency, in Hz. This is set from the .speed-cmd value, and is just shown for debugging purposes.

hy_gt_vfd.freq-fb (float, out)

The current output frequency of the VFD, in Hz. This is reported from the VFD to the driver.

hy_gt_vfd.spindle-on (bit, in)

Set this pin True to command the spindle on, at the speed requested on the .speed-cmd pin. Set this pin False to command the spindle off.

hy_gt_vfd.output-voltage (float, out)

The voltage that the VFD is current providing to the motor, in Volts.

hy_gt_vfd.output-current (float, out)

The current that the motor is currently drawing from the VFD, in Ampères.

hy_gt_vfd.output-power (float, out)

The power that the motor is currently drawing from the VFD, in Watts.

hy_gt_vfd.dc-bus-volts (float, out)

The current voltage of the VFD's internal DC power supply, in Volts.

hy_gt_vfd.modbus-errors (u32, out)

A count of the number of modbus communication errors between the driver and the VFD. The driver is resilient against communication errors, but a large or growing number here indicates a problem that should be investigated.

hy_gt_vfd.input-terminal (float, out)

The VFD's input terminal register.

hy_gt_vfd.output-terminal (float, out)

The VFD's output terminal register.

hy_gt_vfd.AI1 (float, out)

The VFD's AI1 register.

hy_gt_vfd.AI2 (float, out)

The VFD's AI2 register.

hy_gt_vfd.HDI-frequency (float, out)

The VFD's HDI-frequency register.

hy_gt_vfd.external-counter (float, out)

The VFD's external counter register.

hy_gt_vfd.fault-info (float, out)

The VFD's fault info register in floating point representation. This is kept for backwards compatibility with existing setups and will be removed in the future.

hy_gt_vfd.fault-info-code (u32, out)

The VFD's fault code register value. Introduced in LinuxCNC version 2.10. 0x00 if no fault is detected, see GT Series Inverter Manual page 87 for list of fault codes.

32.8. ISSUES

The VFD produces the output frequency that it sends to the motor by adding a manually specified offset to the frequency command it gets over modbus.

The manual offset is controlled by pressing the Up/Down arrows on the faceplate while the VFD is turning the motor.

If you command a speed on the .speed-cmd pin and get a different speed reported on the .speed-fb pin, first verify that the VFD registers listed in the FIRMWARE SETUP section above and the driver's command-line arguments all agree with the info on the motor's name plate. If you still aren't getting the speed you expect, zero the VFD's frequency offset by starting the motor running, then pressing the Up/Down buttons to zero the offset.

32.9. AUTHOR

Sebastian Kuzminsky

32.10. LICENSE

GPL-2.0+

Chapter 33. hy_vfd(1)

33.1. NAME

hy_vfd - HAL non-realtime component for Huanyang VFDs

33.2. SYNOPSIS

hy_vfd [OPTIONS]

33.3. DESCRIPTION

This component connects the Huanyang VFD to the LinuxCNC HAL via a serial (RS-485) connection.

The Huanyang VFD must be configured via the face plate user interface to accept serial communications:

PD001 = 2

Set register PD001 (source of run commands) to 2 (communication port).

PD002 = 2

Set register PD002 (source of operating frequency) to 2 (communication port).

PD004

Set register PD004 (Base Frequency) according to motor specs. This is the rated frequency of the motor from the motor's name plate, in Hz.

PD005

Set register PD005 (max frequency) according to motor specs. This is the maximum frequency of the motor's power supply, in Hz.

PD011

Set register PD011 (min frequency) according to motor specs. This is the minimum frequency of the motor's power supply, in Hz.

PD141

Set register PD141 (rated motor voltage) according to motor name plate. This is the motor's maximum voltage, in Volts.

PD142

Set register PD142 (rated motor current) according to motor name plate. This is the motor's maximum current, in Ampere.

PD143

Set register PD143 (Number of Motor Poles) according to motor name plate.

PD144

Set register PD144 (rated motor revolutions) according to motor name plate. This is the motor's speed in RPM at 50 Hz. Note: This is not the motor's max speed (unless the max motor frequency happens to be 50 Hz)!

PD163 = 1

Set register PD163 (communication address) to 1. This matches the default in the hy_vfd driver, change this if your setup has special needs.

PD164 = 2

Set register PD164 (baud rate) to 2 (19200 bps). This matches the default in the hy_vfd driver, change this if your setup has special needs.

PD165 = 3

Set register PD165 (communication data method) to 3 (8n1 RTU). This matches the default in the hy_vfd driver, change this if your setup has special needs. Note that the hy_vfd driver only supports RTU communication, not ASCII.

Consult the Huanyang instruction manual for details on using the face plate to program the VFDs registers, and alternative values for the above registers.

Access to devices such as /dev/ttyUSB0 is restricted to members of the "dialout" group. If you see error messages such as

open: Permission denied

ERROR Can't open the device /dev/ttyUSB0 (errno 13)

Check your groups membership with the command

groups

Then add your user to the dialout group with

sudo addgroup your-username dialout

You will need to log out and back in again for this to take effect.

33.4. OPTIONS

-d, --device <path>

Set the name of the serial device node to use (defaults to /dev/ttyS0).

-g, --debug

Turn on debug messages. Note that if there are serial errors, this may become annoying. Debug mode will cause all serial communication messages to be printed in hex on the terminal.

-y, --regdump

Print the current value of all registers as soon as the VFD is enabled.

-n, --name *string*

Sets the name of the HAL module. The HAL comp name will be set to *string*, and all pin and parameter names will begin with *string* (defaults to hy_vfd).

-b, --bits *n*

Set number of data bits to *n*, where *n* must be from 5 to 8 inclusive. This must match the setting in register PD165 of the Huanyang VFD (defaults to 8).

-p, --parity [even,odd,none]

Set serial parity to even, odd, or none. This must match the setting in register PD165 of the Huanyang VFD (default odd).

-r, --rate *n*

Set baud rate to *n*. It is an error if the rate is not one of the following: 110, 300, 600, 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200. This must match the setting in register PD164 of the Huanyang VFD (defaults to 38400).

-s, --stopbits [1,2]

Set serial stop bits to 1 or 2. This must match the setting in register PD165 of the HuanyangVFD (defaults to 1).

-t, --target *n*

Set HYCOMM target (slave) number. This must match the device number you set on the Hyanyang VFD in register PD163 (defaults to 1).

-F, --max-frequency *n*

If specified, program register PD005 of the VFD with the specified max frequency of *n* Hz (and use the same max frequency in the hy_vfd driver). If not specified, read the max frequency to use from register PD005 of the VFD (default: read from VFD).

-f, --min-frequency *n*

If specified, program register PD011 of the VFD with the specified minimum frequency of *n* Hz (and use the same minimum frequency in the hy_vfd driver). If not specified, read the minimum frequency to use from register PD011 of the VFD (default: read from VFD).

-V, --motor-voltage *n*

If specified, program register PD141 of the VFD with the specified max motor voltage of *n* Volts. If not specified, read the max motor voltage from register PD141 of the VFD (default: read from VFD).

-I, --motor-current *n*

If specified, program register PD142 of the VFD with the specified max motor current of *n* Amps. If not specified, read the max motor current from register PD142 of the VFD (default: read from VFD).

-S, --motor-speed *n*

(default: compute from value read from VFD P144) This command-line argument is the motor's max speed. If specified, compute the motor's speed at 50 Hz from this argument and from the motor's max frequency (from the --max-frequency argument or from P011 if --max-frequency is not specified) and program register PD144 of the VFD. If not specified, read the motor's speed at 50 Hz from register P144 of the VFD, and use that and the max frequency to compute the motor's max speed.

-P, --motor-poles *n*

(default: read value from VFD P143) This command-line argument is the number of poles in the motor. If specified, this value is sent to the VFD's register PD143. If not specified, the value is read from PD143 and reported on the corresponding HAL pin.

-x, --register PD*nnn*=*mmm* *n*

Set a specific register to a new value. Can be used to set up to 10 registers. Parameters will "stick" (but only after hy_vfd.enable has been set true) so to set more than ten parameters it is possible to repeatedly load the driver with a set of registers to set then enable (setp hy_vfd.enable 1) and unload (unload hy_vfd) the driver at a halrun(1) prompt. For example:

```
loadusr -W hy_vfd -d /ttyUSB0 --register PD014=30 --register PD015=30 +
```

Will set both ramp1 times to 3 seconds. The values should be scaled according to the manual data. The example above uses values with a resolution of 0.1 seconds, so the numbers are 10x larger than the required value.

33.5. PINS

<name>.enable (bit, in)

Enable communication from the hy_vfd driver to the VFD. <name>.SetF (float, out)

<name>.OutF (float, out)

<name>.OutA (float, out)

<name>.Rott (float, out)

<name>.DCV (float, out)

<name>.ACV (float, out)

<name>.Cont (float, out)

<name>.Tmp (float, out)

<name>.spindle-forward (bit, in)

<name>.spindle-reverse (bin, in)

<name>.spindle-on (bin, in)

<name>.CNTR (float, out)

<name>.CNST (float, out)

<name>.CNST-run (bit, out)

<name>.CNST-jog (bit, out)

<name>.CNST-command-rf (bit, out)

<name>.CNST-running (bit, out)

<name>.CNST-jogging (bit, out)

<name>.CNST-running-rf (bit, out)

<name>.CNST-bracking (bit, out)

<name>.CNST-track-start (bit, out)

<name>.speed-command (float, in)

<name>.spindle-speed-fb (float, out)

Current spindle speed as reported by Huanyang VFD (rpm).

<name>.spindle-speed-fb-rps (float, out)

Current spindle speed as reported by Huanyang VFD (rps).

<name>.spindle-at-speed-tolerance (float, in)

Spindle speed error tolerance. If the actual spindle speed is within `.spindle-at-speed-tolerance` of the commanded speed, then the `.spindle-at-speed pin` will go True. The default `.spindle-at-speed-tolerance` is 0.02, which means the actual speed must be within 2% of the commanded spindle speed.

<name>.spindle-at-speed (bit, out)

True when the current spindle speed is within `.spindle-at-speed-tolerance` of the commanded speed.

<name>.frequency-command (float, out)

<name>.max-freq (float, out)

<name>.base-freq (float, out)

<name>.freq-lower-limit (float, out)

<name>.rated-motor-voltage (float, out)

<name>.rated-motor-current (float, out)

<name>.rated-motor-rev (float, out)

<name>.motor-poles (u32, out)

<name>.hycomm-ok (bit, out)

<name>.error-count (s32, RO)

<name>.retval (u32, RO)

33.6. AUTHOR

Sebastian Kuzminsky

33.7. LICENSE

GPL

Chapter 34. image-to-gcode(1)

34.1. NAME

image-to-gcode - converts bitmap images to G-code

34.2. SYNOPSIS

image-to-gcode

34.3. DESCRIPTION

image-to-gcode converts a bitmap image to G-code inteerpreting the brightness of each pixel as a Z-height.

34.4. SEE ALSO

linuxcnc(1)

Detailed docs: <https://linuxcnc.org/docs/devel/html/gui/image-to-gcode.html>

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at /usr/share/doc/LinuxCNC/.

34.5. BUGS

None known at this time.

34.6. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

34.7. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

34.8. COPYRIGHT

Copyright © 2020 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 35. inivalue(1)

35.1. NAME

inivalue - Query an INI file

35.2. SYNOPSIS

inivalue [--var=*variable*] [--sec=*section*] [...options...] *INIFILE*

inivalue --variables [--sec=*section*] [...options...] *INIFILE*

inivalue --sections *INIFILE*

35.3. DESCRIPTION

Prints to stdout the result of a variable-in-section search in *INIFILE*, useful for scripts that want to pick things out of INI files.

The search for a variable can be limited by specifying the name of the *section* to search with the **--sec** option the name of the *variable* to search with the **--var** option. Neither are required and the program will simply find the first matching entry.

A list of variable's content, including optional section name prefix and variable name may be obtained with the **--variables** option. The list of sections present in *INIFILE* can be extracted with the **--sections** option.

35.4. OPTIONS

-V,--var *variable*

The variable to search for, if multiple matches exists and **-num** is not specified, the first match is returned.

-S,--sec *section*

The section to search in, if omitted, all sections are searched.

-N,--num *occurrence_number*

The *occurrence_number* specifies which instance of the *variable* within the *INIFILE*, and *section* if provided, should be returned. If omitted, the first matching occurrence is returned.

-a,--all

Print all matching variables instead of the first matching or the num'th matching. The **--all** option has precedence over the **--num** option.

-y,--type *cvtype*

Perform type-conversion after the search has been matched. Any errors in conversion will be flagged

and print an error message. The *cvtype* can be one of i[nTEGER], u[nsigned], r[eal], s[tring] or b[oolEan]. It defaults to string if not specified.

-T,--tildeexpand

Replace the tilde in a value containing *~/pathname* with the expansion of the *HOME* environment variable, as in *\$HOME/pathname*. Only relevant for searches that match a single value of string type.

-m,--minimum value

Check the converted value against *value* in integer, unsigned or real type conversions (see **--type**). The variable must be larger than or equal *value*.

-M,--maximum value

Check the converted value against *value* in integer, unsigned or real type conversions (see **--type**). The variable must be less than or equal *value*.

-b,--boolnum

Print boolean values (**--type=b**) using *0* for false and *1* for true instead of *true* and *false*.

-B,--boolpy

Print boolean values (**--type=b**) using *False* for false and *True* for true instead of *true* and *false*.

-q,--quiet

Do not print an error message when a variable is not found. The exit value is still 2 if no entry is found, regardless the setting of this option.

-e,--sections

Print all section names found in the INI-file. This option had highest precedence.

-o,--variables

Print all variable names found in the INI-file. You can limit the matched list by specifying a section with **--sec** option. This option has second highest precedence after **--sections**.

-c,--content

Print the content of a variable along with the variable's name in the form "VARNAME=value". This is only relevant when the **--variables** option is specified. This can be combined with the **--prefix** option.

-p,--prefix

Prefix the variable variable's name with the section's name in the form "[SECTION]VARNAME". This is only relevant when the **--variables** option is specified. This can be combined with the **--content** option.

35.5. INI-FILE FORMAT

The INI-file format uses the common standard for INI-files with a few additions and exceptions.

Section names and variable names may only consist of letters a-z, A-Z, digits 0-9 and underscore (_). The first character in the name cannot be a digit.

Comments are specified with the # or ; character and everything following either # or ; is ignored until the end of the line. Embedding a # or ; in a value can only be done if the value is single or double quoted.

Values can be free form text or in single or double quoted form. The double quoted form supports standard escapes and octal, hex, UTF-16 and UTF-32 escape sequences. Multiple quoted segments are concatenated into one value. All values are converted into UTF-8 and values are checked to be valid UTF-8.

Line continuation may be performed by adding a \ to the end of the line. A continuation merges the current line with the following line.

Ini-files can include other INI-files using the *#INCLUDE filepath* directive. It must start in the first column and the *filepath* following the directive is read as if it was text present in the original file. Include files can be nested 16 levels deep.

35.6. EXIT STATUS

0

Success, a matching value has been printed.

1

An error in the arguments, a missing INI-file name, an error while parsing the INI-file or an error while performing tilde expansion (missing HOME environment variable).

2

The searched *section*, *variable* and *num*'th entry was not found.

3

The matched value failed the minimum/maximum test and was determined to be outside the requested range.

35.7. BUGS

None known at this time.

35.8. AUTHOR

This man page written by B.Stultiens, as part of the LinuxCNC project.

35.9. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

35.10. COPYRIGHT

Copyright (c) 2026 B.Stultiens.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 36. inivar(1)

36.1. NAME

inivar - Query an INI file

36.2. SYNOPSIS

inivar -**var** *variable* [-**sec** *section*] [-**num** *occurrence_number*] [-**tildeexpand**] [-**ini** *FILE*]

36.3. DESCRIPTION

This program has been superseded by **inivalue**(1). The **inivar** program is now a script that translates the options and invokes inivalue.

Prints to stdout the INI file result of a variable-in-section search, useful for scripts that want to pick things out of INI files.

Uses *emc.ini* as default filename. *variable* needs to be supplied. If *section* is omitted, first instance of *variable* will be looked for in any section. Otherwise, only a match of the variable in *section* will be returned.

36.4. OPTIONS

-var *variable*

The variable to search for, if multiple matches exists and **-num** is not specified, the first match is returned.

-sec *section*

The section to search in, if omitted, all sections are searched.

-num *occurrence_number*

The occurrence number specifies which instance of the variable within the *FILE*, and *section* if provided, should be returned. If omitted, the first matching occurrence is returned.

-tildeexpand

Replace the tilde (~) with the home directory path (equivalent to **\$(HOME)**) in the value obtained from *variable* in *FILE*.

-ini *FILE*

The INI file to search in, defaults to *emc.ini*.

36.5. EXIT STATUS

0

Success.

1

variable was not found.

-1

Failure.

36.6. BUGS

None known at this time.

36.7. SEE ALSO

inivalue(1).

36.8. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

36.9. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

36.10. COPYRIGHT

Copyright (c) 2020 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 37. io(1)

37.1. NAME

io, iocontrol - interacts with HAL or G-code in non-realtime

37.2. SYNOPSIS

[EMCIO]

EMCIO = io

37.3. DESCRIPTION

I/O control handles I/O tasks like coolant, toolchange and E-stop. The signals are turned on and off in non-realtime with G-code or in the case of E-stop in HAL.

The following pins are created by the non-realtime IO controller, usually found in `$LINUXCNC_HOME/bin/io`.

iocontrol is a non-realtime process - if you have strict timing requirements or simply need more I/O, consider using the realtime synchronized I/O provided by **motion**(9) instead.

The INI file is searched for in the directory from which halcmd was run, unless an absolute path is specified.

37.4. PINS

iocontrol.0.coolant-flood (Bit, Out)

TRUE when flood coolant is requested.

iocontrol.0.coolant-mist (Bit, Out)

TRUE when mist coolant is requested.

iocontrol.0.emc-enable-in (Bit, In)

Should be driven FALSE when an external E-stop condition exists.

iocontrol.0.tool-change (Bit, Out)

TRUE when a tool change is requested.

iocontrol.0.tool-changed (Bit, In)

Should be driven TRUE when a tool change is completed.

iocontrol.0.tool-number (s32, Out)

Current tool number.

iocontrol.0.tool-prep-number (s32, Out)

The number of the next tool, from the RS274NGC T-word.

iocontrol.0.tool-prep-pocket (s32, Out)

This is the pocket number (location in the tool storage mechanism) of the tool requested by the most recent T-word.

iocontrol.0.tool-prepare (Bit, Out)

TRUE when a T_n tool prepare is requested.

iocontrol.0.tool-prepared (Bit, In)

Should be driven TRUE when a tool prepare is completed.

iocontrol.0.user-enable-out (Bit, Out)

FALSE when an internal E-stop condition exists.

iocontrol.0.user-request-enable (Bit, Out)

TRUE when the user has requested that E-stop be cleared.

iocontrol.0.tool-prep-index (s32, Out)

IO's internal array index of the prepped tool requested by the most recent T-word. 0 if no tool is prepped. On Random toolchanger machines this is the tool's pocket number (i.e., the same as the tool-prep-pocket pin), on Non-random toolchanger machines this is a small integer corresponding to the tool's location in the internal representation of the tool table. This parameter returns to 0 after a successful tool change (M6).

37.5. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

37.6. AUTHOR

Derived from a work by Fred Proctor & Will Shackleford.

37.7. COPYRIGHT

Copyright © 2004 the LinuxCNC project.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 38. latency-histogram(1)

38.1. NAME

latency-histogram - plot a histogram of machine latency

38.2. SYNOPSIS

latency-histogram [-? | **--help**] [**--base** *ns*] [**--servo** *ns*] [**--bbinsize** *ns*] [**--sbinsize** *ns*] [**--bbins** *ns*] [**--sbins** *ns*] [**--logscale** 0|1] [**--text** *note*] [**--show**] [**--nobase**] [**--verbose**] [**--nox**]

38.3. DESCRIPTION

The latency test is important when configuring a LinuxCNC system. An adjunct to the standard latency-test latency-histogram plots the distribution of latency. This can be useful to get a feel for how frequent the high latency excursions are.

LinuxCNC and HAL should not be running, stop with **halrun -U**. Large number of bins and/or small binsizes will slow updates. For single thread, specify **--nobase** (and options for servo thread). Measured latencies outside of the +/- bin range are reported with special end bars. Use **--show** to show count for the off-chart [pos|neg] pin.

More details: <https://linuxcnc.org/docs/html/install/latency-test.html>

38.4. OPTIONS

-?, --help

Show options and exit.

--base *ns*

base thread interval, default: 25000, min: 5000

--servo *ns*

servo thread interval, default: 1000000, min: 25000

--bbinsize *ns*

base bin size, default: 100

--sbinsize *ns*

servo bin size, default: 100

--bbins *ns*

base bins, default: 200

--sbins *ns*

servo bins, default: 200

--logscale 0|1

y axis log scale, default: 1

--text *note*

additional note, default: ""

--show

show count of undisplayed bins

--nobase

servo thread only

--verbose

progress and debug

--nox

no GUI, display elapsed, min, max, sdev for each thread

38.5. SEE ALSO

latency-plot(1), latency-test(1), linuxcnc(1)

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at `/usr/share/doc/linuxcnc/`.

38.6. BUGS

None known at this time.

38.7. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

38.8. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

38.9. COPYRIGHT

Copyright © 2020 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 39. latency-plot(1)

39.1. NAME

latency-plot - another way to view latency numbers

39.2. SYNOPSIS

latency-plot [**-?** | **--help**] [**-H** | **--hal**] [**-b** | **--base ns**] [**-s** | **--servo ns**] [**-t** | **--time ms**] [**--relative**] [**--actual**]

39.3. DESCRIPTION

latency-plot makes a strip chart recording for a base and a servo thread. It may be useful to see spikes in latency when other applications are started or used. Mainly superseded by latency-histogram.

LinuxCNC and HAL should not be running, stop with *halrun -U*.

More details: <https://linuxcnc.org/docs/html/install/latency-test.html>

39.4. OPTIONS

-?, --help

Show options and exit.

-H, --hal

-b, --base ns

base thread interval in nanoseconds, default: 25000

-s, --servo ns

servo thread interval in nanoseconds, default: 1000000

-t, --time ms

report interval in milliseconds, default: 1000, min: 100, max: 10000

--relative

relative clock time (default)

--actual

actual clock time

39.5. SEE ALSO

latency-histogram(1), **latency-test(1)**, **linuxcnc(1)**

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals,

found at */usr/share/doc/linuxcnc/*.

39.6. BUGS

None known at this time.

39.7. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

39.8. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

39.9. COPYRIGHT

Copyright © 2020 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 40. latency-test(1)

40.1. NAME

latency-test - test the realtime system latency

40.2. SYNOPSIS

latency-test [-h | --help] [*base-period* [*servo-period*]]

40.3. DESCRIPTION

latency-test runs a simple latency test.

Use **latency-test --help** for a description of available options.

40.4. SEE ALSO

linuxcnc(1)

<https://linuxcnc.org/docs/html/install/latency-test.html>

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at /usr/share/doc/LinuxCNC/.

40.5. BUGS

None known at this time.

40.6. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

40.7. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

40.8. COPYRIGHT

Copyright © 2020 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 41. lineardelta(1)

41.1. NAME

lineardelta - Vismach Virtual Machine GUI

41.2. DESCRIPTION

lineardelta is one of the sample **Vismach** GUIs for LinuxCNC, simulating a delta robot with linear actuators.

41.3. SEE ALSO

linuxcnc(1)

See the main LinuxCNC documentation for more details. <https://linuxcnc.org/docs/html/gui/vismach.html>

41.4. BUGS

None known at this time.

41.5. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

41.6. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

41.7. COPYRIGHT

Copyright © 2020 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 42. linuxcnc_check_ini(1)

42.1. NAME

linuxcnc_check_ini - LinuxCNC INI-file configuration checker

42.2. SYNOPSIS

linuxcnc_check_ini [-e] [-h] *INIfile*

42.3. DESCRIPTION

The **linuxcnc_check_ini** program is used to verify the LinuxCNC primary configuration. It takes the specified *INIfile* and performs a set of sanity checks on the variables in various sections.

This program is called automatically from **linuxcnc(1)** as to warn the user of problems that may exist in the configuration. The tests are not exhaustive and **linuxcnc_check_ini** does *not* protect your machine or hardware. It merely ensures some basic consistency in the configuration setup. You must not rely on passing the **linuxcnc_check_ini** tests to have a functional machine.

42.4. OPTIONS

-e,--error

Treat warnings as errors

-h,--help

Shows brief help message

42.5. EXIT VALUE

The exit value is 0 (zero) when no errors are detected and the program runs successfully.

The exit value is 1 (one) if any errors are detected. Additionally, if the **--error** option was specified, then any detected warnings also cause the exit value be 1 (one).

The exit value is 2 (two) in case of any other problem.

42.6. SEE ALSO

linuxcnc(1)

42.7. AUTHOR

This man page written by B.Stultiens, as part of the LinuxCNC Enhanced Machine Controller project.

42.8. REPORTING BUGS

Please report any bugs at <https://github.com/LinuxCNC/linuxcnc>.

42.9. COPYRIGHT

Copyright © 2026 The LinuxCNC authors.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 43. linuxcnc_info(1)

43.1. NAME

linuxcnc_info - collects information about the LinuxCNC version and the host

43.2. SYNOPSIS

linuxcnc_info

43.3. DESCRIPTION

linuxcnc_info supplies information about the LinuxCNC version and system info. It creates a text file and opens it in the default text editor.

43.4. SEE ALSO

linuxcnc(1)

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at `/usr/share/doc/LinuxCNC/`.

43.5. BUGS

It appears to hang until the text editor is closed.

43.6. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

43.7. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

43.8. COPYRIGHT

Copyright © 2020 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 44. linuxcnc_module_helper(1)

44.1. NAME

linuxcnc_module_helper - controls root access for system hardware

44.2. SYNOPSIS

linuxcnc_module_helper

44.3. DESCRIPTION

This module exists to give root access to system hardware for LinuxCNC. It is not directly useful to users.

44.4. SEE ALSO

linuxcnc(1)

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at `/usr/share/doc/LinuxCNC/`.

44.5. BUGS

None known at this time.

44.6. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

44.7. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

44.8. COPYRIGHT

Copyright © 2020 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 45. linuxcnc_var(1)

45.1. NAME

linuxcnc_var - retrieves LinuxCNC variables

45.2. SYNOPSIS

linuxcnc_var [*varname* | all]

45.3. DESCRIPTION

FIXME: missing

45.4. OPTIONS

Option *all* returns varname=value for all supported varnames

Varnames supported:

- LINUXCNCVERSION
- LINUXCNC_AUX_GLADEVCP
- LINUXCNC_AUX_EXAMPLES
- REALTIME
- RTS
- HALLIB_DIR

45.5. SEE ALSO

linuxcnc(1)

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at `/usr/share/doc/LinuxCNC/`.

45.6. BUGS

None known at this time.

45.7. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

45.8. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

45.9. COPYRIGHT

Copyright © 2020 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 46. linuxcnc(1)

46.1. NAME

linuxcncd - LinuxCNC Graphical User Interface for LCD character display

46.2. SYNOPSIS

linuxcncd -ini <INI file>

46.3. DESCRIPTION

linuxcncd is one of the Graphical User Interfaces (GUI) for LinuxCNC. It gets typically run by the runscript. Linuxcncd is designed to run on a 4 x 20 LCD character display. It is not clear if it has ever worked.

46.4. OPTIONS

INI file

The INI file is the main piece of an LinuxCNC configuration. It is not the entire configuration; there are various other files that go with it (NML files, HAL files, TBL files, VAR files). It is, however, the most important one, because it is the file that holds the configuration together. It can adjust a lot of parameters itself, but it also tells **LinuxCNC** which other files to load and use.

46.5. SEE ALSO

linuxcnc(1)

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at /usr/share/doc/LinuxCNC/.

46.6. BUGS

None known at this time.

46.7. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

46.8. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

46.9. COPYRIGHT

Copyright © 2020 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 47. linuxcncmkdesktop(1)

47.1. NAME

linuxcncmkdesktop - create a desktop icon for LinuxCNC

47.2. SYNOPSIS

linuxcncmkdesktop

47.3. DESCRIPTION

linuxcncmkdesktop Script used by pickconfig to create a desktop icon for LinuxCNC.

47.4. SEE ALSO

linuxcnc(1)

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at `/usr/share/doc/LinuxCNC/`.

47.5. BUGS

None known at this time.

47.6. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

47.7. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

47.8. COPYRIGHT

Copyright © 2020 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 48. linuxcncrsh(1)

48.1. NAME

linuxcncrsh - text-mode interface for commanding LinuxCNC over the network

48.2. SYNOPSIS

linuxcncrsh [OPTIONS] [-- LINUXCNC_OPTIONS]

48.3. DESCRIPTION

The command **linuxcncrsh** is a fully-functional text-based user interface for LinuxCNC. Instead of popping up a GUI window like AXIS(1) and Touchy(1) do, it processes text-mode commands that it receives via the network. A human (or a program) can interface with **linuxcncrsh** using telnet(1), nc(1) or similar programs.

It cannot be stressed enough that all features of LinuxCNC are available via the **linuxcncrsh** interface. It can substitute a graphical UI or be started in addition to it. If your environment needs to control/monitor more than one machine from a single location, this text interface may raise your interest. Also, a speech to text interface may be easier to adapt to this text-based interface than to a graphical one.

48.4. OPTIONS

-d,--path *PATH[:PATH...]*

Specify a colon separated list of paths used when opening files. The search path is used for both nc files and tool table files. The default search path is set to "\$HOME/nc_files" if this option is not specified.

-e,--enablepw *PASSWORD*

Specify the password required to enable LinuxCNC via **linuxcncrsh**. Note that the password is sent in the clear, so it can be read by anyone who can read packets on the network between the server and the client. Defaults to EMCTOO if omitted.

-h,--help

Prints a brief description of the command line options and exits.

-n,--name *SERVER_NAME*

Sets the server name that **linuxcncrsh** will use to identify itself during handshaking with a new client. Defaults to EMCNETSVR if omitted.

-p,--port *PORT_NUMBER*

Specify the port for **linuxcncrsh** to listen on. Defaults to 5007 if omitted.

-q,--quiet

Suppress informational messages to stdout like (dis)connecting clients and client's enable state.

-s,--sessions *MAX_SESSIONS*

Specify the maximum number of simultaneous connections. Defaults to 0 (zero) (no limit) if not specified.

-w,--connectpw *PASSWORD*

Specify the connection password to use during handshaking with a new client. Note that the password is sent in the clear, so it can be read by anyone who can read packets on the network between the server and the client. Defaults to EMC if omitted.

In addition to the options listed above, **linuxcncrsh** accepts an optional special LINUXCNC_OPTION at the end:

-ini *LINUXCNC_INI_FILE*

LinuxCNC INI file to use. The -ini option **must** be preceded by two dashes: "--". Defaults to *emc.ini* if omitted.

48.5. RUNNING LINUXCNCRSH

To use **linuxcncrsh** instead of a normal LinuxCNC GUI like AXIS or Touchy, specify it in your INI file like this:

```
[DISPLAY]

DISPLAY=linuxcncrsh

# You can also add options like this:
# DISPLAY=linuxcncrsh -n BigMachine
```

To use **linuxcncrsh** in addition to a normal GUI, you can either 1) start it at the end of your HAL file, or 2) run it by hand in a terminal window.

To start it from HAL, add a line like this to the end of your HAL file:

```
loadusr linuxcncrsh [OPTIONS] [-- LINUXCNC_OPTIONS]
```

To start it from the terminal, run **linuxcncrsh** manually like this:

```
linuxcncrsh [OPTIONS] [-- LINUXCNC_OPTIONS]
```

48.5.1. CONNECTING

Once LinuxCNC is up and **linuxcncrsh** is running, you can connect to it using **telnet** or **nc** or similar:

telnet *HOST PORT*

HOST is the hostname or IP address of the computer running **linuxcncrsh**, and *PORT* is the port it's listening on (5007 if you did not give **linuxcncrsh** the --port option).

48.5.2. NETWORK PROTOCOL

The **linuxcncrsh** server accepts TCP connections on the port specified by the `--port` option, or 5007 if not specified.

The client sends requests, and the **linuxcncrsh** server returns replies. Requests consist of a command word followed by optional command-specific parameters. Requests and most request parameters are case insensitive. The exceptions are passwords, file paths and text strings.

Requests to **linuxcncrsh** are terminated with line endings, any combination of one or more `|r` and `|n` characters. Replies from **linuxcncrsh** are terminated with the sequence `|r|n`.

48.6. COMMANDS

The supported commands are as follows:

hello *<password>* *<client>* [*<version>*]

<password> must match **linuxcncrsh**'s connect password, or "EMC" if no `--connectpw` was supplied. The three arguments may not contain whitespace. If a valid password was entered the server will respond with: `+ HELLO ACK <ServerName> <ServerVersion> +` If an invalid password or any other syntax error occurs then the server responds with: `+ HELLO NAK +` The *<version>* argument is optional and defaults to "1.1". It is compared to the [EMC]VERSION field of the INI file. An older INI file version than the requested version will result in a warning.

get *<subcommand>* [*<parameters>*]

The *GET* command takes one of the LinuxCNC sub-commands (see [SUBCOMMANDS](#) below) and zero or more additional subcommand-specific parameters.

set *<subcommand>* [*<parameters>*]

The *SET* command takes one of the LinuxCNC sub-commands (see [SUBCOMMANDS](#) below) and zero or more additional parameters.

quit

The *QUIT* command disconnects the associated socket connection but does not change the state of the machine. You can connect later to continue work on the machine, but you must again pass *HELLO* and *SET ENABLE* if you want control the machine again.

shutdown

The *SHUTDOWN* command tells LinuxCNC to shutdown and disconnect the session. This command may only be issued if the *HELLO* has been successfully negotiated and the connection has control of the CNC (see *SET ENABLE* sub-command in the [SUBCOMMANDS](#) section below). `+ Note that LinuxCNC will only shutdown automatically if linuxcncrsh is the DISPLAY program set in the INI file.`

help

The *HELP* command will return help information in text format over the connection. If no parameters are specified, it will itemize the available commands. If a command is specified, it will provide usage information for the specified command. Help will respond regardless of whether a *HELLO* has been successfully negotiated.

48.7. SUBCOMMANDS

Commands and parameters are not case sensitive, except for the password to *SET ENABLE*. Notes on the format of the parameters:

- {on,off} values may be:
 - *on 1, true, yes*
 - *off, 0, false, no*
- *<spindle>* is the spindle number as specified in the INI file, starting with 0 (zero) and up to the number of available spindles. A value of -1 (minus one) indicates "all spindles". An error will be emitted if *<spindle>* is not configured in the INI file.
- *<joint>* is the joint number as specified in the INI file, starting with 0 (zero) and up to the number of available joints. A value of -1 (minus one) indicates "all joints". An error will be emitted if *<joint>* is not configured in the INI file.
- *<axis>* is one of the letters XYZABCUVW or numbers 0 (zero) through 8 (eight) respectively. A value of -1 (minus one) indicates "all configured axes". An error will be emitted if *<axis>* is not configured in the INI file.

Subcommands for *GET* and *SET* are:

set abort

Abort program or MDI execution.

get abs_cmd_pos [*<axis>*|-1]

Returns the specified axis' commanded position in absolute coordinates. If no axis is specified, returns all axes' commanded absolute position. The *<axis>* can be specified as a letter (XYZABCUVW), an index 0..8 or -1.

get abs_act_pos [*<axis>*|-1]

Returns the specified axis' actual position in absolute coordinates. If no axis is specified, returns all axes' actual absolute position. The *<axis>* can be specified as a letter (XYZABCUVW), an index 0..8 or -1.

get angular_unit_conversion

set angular_unit_conversion {deg|rad|grad|auto}

With get, the active unit conversion is returned. With set, sets the units to be displayed. If it's *AUTO*, the units to be displayed match the program units.

get axis_velocity [*<axis>*|-1]

Returns the current velocity of the specified axis. If no axis is specified, returns all axes' velocity. The *<axis>* can be specified as a letter (XYZABCUVW), an index 0..8 or -1.

get brake [*<spindle>*|-1]

set brake {on|off} [*<spindle>*]

With get, the current brake setting is returned. With set, the brake is set as specified. If *<spindle>* is omitted, spindle 0 is selected. If *<spindle>* is -1, all spindles are selected.

get clients

Get the list of all connected clients and information which is in the linked and enabled state.

get comm_prot

DEPRECATED - API versioning is too complicated. + Shows the version from the *HELLO*.

get debug**set debug <value>**

With get, the current integer value of EMC_DEBUG is returned. Note that the value of EMC_DEBUG returned is the from the UI's INI file, which may be different than emc's INI file. With set, sends a command to the EMC to set the new debug level, and sets the EMC_DEBUG global here to the same value. This will make the two values the same, since they really ought to be the same.

set disable [<client>|-1]

Force <client> to relinquish the enabled state. All clients will be searched and the enabled client is forced to relinquish the enabled state if <client> is not present or -1.

get display_angular_units

Returns *DEG*, *RAD*, *GRAD*, or *CUSTOM*, for the angular units that are active in the display. This is effectively the value of angularUnitConversion.

get display_linear_units

Returns *INCH*, *MM*, *CM*, or *CUSTOM*, for the linear units that are active in the display. This is effectively the value of linearUnitConversion.

get echo**set echo {on|off}**

With get, any on/off parameter is ignored and the current echo state is returned. With set, sets the echo state as specified. Echo defaults to on when the connection is first established. When echo is on, all commands will be echoed upon receipt. This state is local to each connection.

get enable**set enable <passwd>|off**

The session's enable state indicates whether the current connection is enabled to perform control functions. With get, the current enable state is returned. With set, the current connection is enabled for control functions and a valid (case sensitive) password matching **linuxcncrshs** *--enablepw* (*EMCTOO if not specified*). A password of 'OFF' (case insensitive) can not be used as a password and disables control functions for this connection.

get error

Returns the current LinuxCNC error string, or *OK* if no error.

get estop**set estop {on|off}**

With get, returns the current estop setting as *ON* or *OFF*. With set, sets the estop as specified. E-stop *ON* means the machine is in the estop state and won't run.

get feed_override**set feed_override <percent>**

With get, the current feed override is returned (as a percentage of commanded feed). With set, sets the feed override as specified.

get flood**set flood {on|off}**

With get, returns the current flood coolant setting. With set, sets the flood setting as specified.

set home [<joint>|-1]

Alias for **joint_home**.

get ini <var> <section>

Return the string value of <var> in section <section> of the INI file.

get inifile

Returns the INI file's name set at startup.

set jog <joint>|<axis> <speed>

Jog the specified joint or axis at <speed>; sign of speed is direction. If *TELEOP_ENABLE* is *OFF*, use <joint> number. If *TELEOP_ENABLE* is *ON*, use <axis> letter (XYZABCUVW) or index 0..8.

set jog_incr <joint>|<axis> <speed> <incr>

Jog the indicated joint or axis by increment <incr> at the <speed>; sign of speed is direction. If *TELEOP_ENABLE* is *OFF*, use <joint> number. If *TELEOP_ENABLE* is *ON*, use <axis> letter (XYZABCUVW).

set jog_stop <joint>|<axis>

Stop any in-progress jog on the specified joint or axis. If *TELEOP_ENABLE* is *OFF*, use <joint> number. If *TELEOP_ENABLE* is *ON*, use <axis> letter (XYZABCUVW) or index 0..8.

get joint_fault [<joint>|-1]

Returns the fault status of the specified joint as *OK* or *FAULT*. Returns the fault status of all joints if no <joint> is specified or is -1.

set joint_home [<joint>|-1]

Homes the indicated joint or, if not specified or -1, homes all joints.

get joint_homed [<joint>|-1]

Returns the homed status of the specified joint as *YES* or *NO*. Returns the homed status of all joints if no <joint> is specified or is -1.

get joint_limit [<joint>|-1]

Returns limit status of the specified joint as *OK*, *MINSOFT*, *MINHARD*, *MAXSOFT*, or *MAXHARD*. Returns the limit status of all joints if no <joint> is specified or is -1.

get joint_pos [<joint>|-1]

Returns the specified joint's actual position in absolute coordinates, excluding tool length offset. If no joint is specified or -1, returns all joints' actual absolute position.

get joint_type [<joint>|-1]

Returns *LINEAR*, *ANGULAR*, or *CUSTOM* for the type of the specified <joint> or for all joints if not specified or is -1.

set joint_unhome [<joint>|-1]

Unhomes the indicated <joint> or unhomes all joints if -1 or not specified. If <joint> is -2, then all joints marked as "VOLATILE_HOME" are unhomed. Note that *TELEOP_ENABLE* must be *OFF* for unhoming.

get joint_units [<joint>|-1]

Returns *INCH*, *MM*, *CM*, OR *DEG*, *RAD*, *GRAD*, or *CUSTOM*, for the corresponding native units of the specified <joint> or all joints if not specified or is -1. The type of the joint (linear or angular) is used to resolve which type of units are returned. The units are obtained heuristically, based on the *EMC_AXIS_STAT::units* numerical value of user units per mm or deg. For linear joints, something close to 0.03937 is deemed *INCH*, 1.000 is *MM*, 0.1 is *CM*, otherwise it's *CUSTOM*. For angular joints, something close to 1.000 is deemed *DEG*, $\pi/180$ is *RAD*, 100/90 is *GRAD*, otherwise it's *CUSTOM*.

get joint_velocity [<joint>|-1]

Returns the specified joint's current velocity. If no joint is specified or -1, returns all joints' velocities.

set joint_wait_homed [<joint>|-1] [<timeout>]

Wait and stall until <joint> is homed. The joint must be currently homing or be homed. The <timeout> can be used to set the wait period maximum and is 10 seconds if not specified. If <joint> is not present or -1, then it waits for **all** non-homed joints currently in the process of homing. + Note: executing **joint_wait_homed** will currently cause the entire **linuxcncrsh** process to wait and input will not be read or processed *from any connected client* while it is running. The function will run until homing is finished or a timeout happens. This function cannot be interrupted. On timeout it will print *SET JOINT_WAIT NAK*.

get kinematics_type

Returns the type of kinematics functions used (identity=1, serial=2, parallel=3, custom=4).

get linear_unit_conversion**set linear_unit_conversion {inch|mm|cm|auto}**

With get, returns the active unit conversion. With set, sets the unit to be displayed. If it's *AUTO*, the units to be displayed match the program units.

set load_tool_table <filename>

Loads the tool table specified by <filename>.

get machine**set machine {on|off}**

With get, returns the current machine power setting as *ON* or *OFF*. With set, sets the machine on or

off as specified.

set mdi <string>

Sends <string> as an MDI command.

get mist**set mist {on|off}**

With get, returns the current mist coolant setting. With set, sets the mist setting as specified.

get mode**set mode {manual|auto|mdi}**

With get, returns the current machine mode. With set, sets the machine mode as specified.

get open set open <filename>:: With get, returns the last filename opened or *NONE* if no file was ever opened in this session. With set, opens the named file. The <filename> is opened by **linuxcncrsh**, so it should either be an absolute path or a relative path. A relative path filename is searched on a list of paths as set by the **-d** command line option.

get operator_display

Returns the current operator display string, or *OK* if none.

get operator_text

With get, returns the current operator text string, or *OK* if none.

get optional_stop**set optional_stop {on|off}**

With get, the current "optional stop on M1" setting is returned. With set, the setting is set as specified.

get override_limits**set override_limits {on|off}**

With get, the `override_limits` setting is returned. With set, the `override_limits` parameter is set as specified. If `override_limits` is on, disables end of travel hardware limits to allow jogging off of a limit. If parameters is off, then hardware limits are enabled.

set pause

Pause program execution. + WARNING: You must *SET WAIT_MODE RECEIVED* in order to run pause. If you don't then *SET PAUSE* will fail with an error. The reason behind this is that pausing execution will cause the internal pause command never to be done until you *SET RESUME*.

get plat

With get, returns the string *Linux*.

get pos_offset [<axis>|-1]

Returns the position offset associated with the world coordinate provided. The <axis> can be specified as a letter (XYZABCUVW), an index 0..8 or -1.

set probe <x> <y> <z>

Move toward a certain location. If the probe is tripped on the way stop motion, record the position and raise the probe tripped flag. + Important: the *SET PROBE* command is run as an MDI command by sending and executing "G38.2 X<x> Y<y> Z<z>". This is necessary because probing requires velocity, acceleration and jerk parameters to be specified that are only available in the LinuxCNC internal canon interface. Additionally, many sanity and boundary condition checks are performed that are hard to duplicate outside of the canon interface. + The *SET PROBE* command can only be run in MDI mode (use *SET MODE MDI*). Additionally, *SET PROBE* never returns a *SET PROBE NAK* if the probe fails to make contact. However, an error is produced (use *GET ERROR*) and the *GET PROBE_TRIPPED* returns *NO* in that case. + If you need more control over probing, then you should send the appropriate MDI command (G38.2, G38.3, G38.4 or G38.5) via the *SET MDI ...* command. You can still use the other probe functions to determine whether the probe value, if it tripped and clearing it.

set probe_clear

Clear the probe tripped flag.

get probe_tripped

Return the probe state - has the probe tripped since the last clear?

get probe_value

Return the current value of the probe signal.

get program

Returns the name of the currently opened program, or *NONE*.

get program_angular_units

Always returns *DEG*.

get program_codes

Returns the string for the currently active program codes.

get program_line

Returns the currently executing line of the program.

get program_linear_units

Returns *INCH*, *MM*, *CM*, or *CUSTOM*, for the corresponding linear units that are active in the program interpreter.

get program_status

Returns *IDLE*, *RUNNING*, or *PAUSED*.

get program_units

Synonym for *program_linear_units*.

get rel_act_pos [<axis>|-1]

Returns the specified axis' actual position in relative coordinates, including tool length offset. If no

axis is specified, returns all axes' actual relative position. The *<axis>* can be specified as a letter (XYZABCUVW), an index 0..8 or -1.

get rel_cmd_pos [*<axis>* |-1]

Returns the specified axis' commanded position in relative coordinates, including tool length offset. If no axis is specified, returns all axes' commanded relative position. The *<axis>* can be specified as a letter (XYZABCUVW), an index 0..8 or -1.

set resume

Resume program execution. + WARNING: You should *SET WAIT_MODE DONE* before you run resume. If you don't then *SET RESUME* may return too early before the system is actually resumed. See also *SET PAUSE*.

set run [*<startline>*]

Runs the opened program. Runs from the beginning if no *<startline>* is specified and from the *<startline>* if specified. A *<startline>* of -1 runs in verify mode.

get spindle [*<spindle>* |-1]**set spindle {forward|reverse|increase|decrease|constant|off} [*<spindle>*]**

With get, the current spindle state is returned as *FORWARD*, *REVERSE*, *INCREASE*, *DECREASE*, or *OFF*. With set, sets the spindle as specified. Note that *INCREASE* and *DECREASE* will cause a speed change in the corresponding direction until a *CONSTANT* command is sent. If *<spindle>* is omitted, spindle 0 is selected. If *<spindle>* is -1, all spindles are selected.

get spindle_override**set spindle_override *<percent>* [*<spindle>* |-1]**

With get, the current spindle override is returned (as a percentage of commanded speed). With set, sets the spindle override as specified. If *<spindle>* is omitted, spindle 0 is selected. If *<spindle>* is -1, all spindles are selected.

set step

Step the program one line.

set task_plan_init

Initializes the program interpreter.

get teleop_enable**set teleop_enable {on|off}**

With get, the current teleop mode is returned. With set, sets the teleop mode as specified. + Note on *GET TELEOP_ENABLE*: There is a possible race condition on activation of teleop mode just after all joints are homed. The teleop mode will automatically switch to *TELEOP_ENABLE ON* after homing, but that is done while the motion controller is run in the servo-thread. It may therefore take one [EMCMOT]SERVO_PERIOD time period for the automatic mode switch. + Using *SET JOINT_WAIT_HOMED* will automatically add a one servo-thread delay to prevent the race in normal use-cases. However, if you do not call *SET JOINT_WAIT_HOMED*, then you can use *SET WAIT_HEARTBEAT* if you just ran a homing process, ensuring the servo-thread has run at least once and updated the status.

get time

Returns the time, in seconds, from the start of the epoch. The starting time depends on the platform.

get timeout**set timeout <timeout>**

With set, set the timeout for commands functions send to LinuxCNC's core to return to <timeout> seconds. <timeout> is a real number. If it's ≤ 0.0 , it means wait forever. Default is 0.0, wait forever.

get timestamp**set timestamp {on|off} [{on|off}]**

Enable or disable printing of a timestamp on messages sent back from the server to the user. The optional format argument selects human readable date/time format when the format is on and seconds since epoch when off or not specified.

get tool

Returns the id of the currently loaded tool.

get tool_offset**set tool_offset <tool> <length> <diameter>**

With get, returns the currently applied tool length offset. With set, sets the specified <tool> to <length> and <diameter>.

get update**set update {none|auto}**

DEPRECATED - Don't use, it breaks things. + The update mode controls whether to return fresh or stale values for *GET* requests. When the update mode is *NONE* it returns stale values, when it's *AUTO* it returns fresh values. Defaults to *AUTO* for new connections. + **WARNING:** Only set this to *NONE* if you really know what you are doing. Things **will** break when you do.

set update_status

DEPRECATED - You should use automatic status updates (the default). + Manually read and update the machine status as seen by **linuxcncrsh**. This necessary when *SET UPDATE* is set to *NONE*. **WARNING:** when this is required, it **will** break things.

get user_angular_units

Returns *DEG*, *RAD*, *GRAD*, or *CUSTOM* for the corresponding native user angular units of the LinuxCNC trajectory level. Like with linear units, this is obtained heuristically.

get user_linear_units

Returns *INCH*, *MM*, *CM*, or *CUSTOM*, for the corresponding native user linear units of the LinuxCNC trajectory level. This is obtained heuristically, based on the `EMC_TRAJ_STAT::linearUnits` numerical value of user units per mm. Something close to 0.03937 is deemed *INCH*, 1.000 is *MM*, 0.1 is *CM*, otherwise it's *CUSTOM*.

get verbose**set verbose {on|off}**

With `get` the current verbose state is returned. With `set`, sets the verbose state as specified. When verbose mode is on all set commands return positive acknowledgement in the form `+ SET <COMMAND> ACK +`. The verbose state is local to each connection, and starts out *OFF* on new connections.

set wait {received|done}

Force a wait for the previous command to be received, or done.

set wait_heartbeat [<periods>]

Wait for the motion-controller function in the servo-thread to run at least for *<periods>* times before returning. It sleeps `[EMCMOT]SERVO_PERIOD` nanoseconds between checks to ensure other processes can run unimpeded. The value of *<periods>* must be 1 or larger and defaults to 1 when not specified. The maximum value of *<periods>* depends on the value of `[EMCMOT]SERVO_PERIOD`. The number of periods waiting may not result in a wait longer than 1.0 seconds. This function will wait and return with a failure if it times out. If the functions times out you probably have a non-functional LinuxCNC.

get wait_mode**set wait_mode {received|done}**

The `wait_mode` setting controls the wait after receiving a command. It can be *RECEIVED* (after the command was sent and received) or *DONE* (after the command was done). With `get`, the current `WAIT_MODE` setting is returned. With `set`, set the `WAIT_MODE` setting to the specified value.

48.8. EXAMPLE SESSION

This section shows an example session to the local machine (**localhost**). Bold items are typed by you, non-bold is machine output. Default values are shown for `--port PORT_NUMBER (5007)`, `--connectpw PASSWORD (EMC)`, and `--enablepw PASSWORD (EMCTOO)`.

The user connects to **linuxcncrsh**, handshakes with the server (*HELLO*), enables machine commanding from this session (*SET ENABLE*), brings the machine out of E-stop (*SET ESTOP OFF*) and turns it on (*SET MACHINE ON*), homes all the axes, switches the machine to mdi mode, sends an MDI G-code command, then disconnects and shuts down LinuxCNC.

```
$ telnet localhost 5007
Trying 127.0.0.1...
Connected to 127.0.0.1
Escape character is '^]'.
hello EMC user-typing-at-telnet 1.2
HELLO ACK EMCNETSVR 1.2
set echo off
set verbose on
SET VERBOSE ACK
set enable EMCTOO
SET ENABLE ACK
set wait_mode done
SET WAIT_MODE ACK
```

```
set estop off
SET ESTOP ACK
set machine on
SET MACHINE ACK
set mode manual
SET MODE ACK
set joint_home -1
SET JOINT_HOME ACK
set joint_wait_homed -1
SET JOINT_WAIT_HOMED ACK
set mode mdi
SET MODE ACK
set mdi g0x1
SET MDI ACK
...
set shutdown
  Connection closed by foreign host.
```

48.9. SEE ALSO

linuxcnc(1), axis(1)

Chapter 49. linuxcncsvr(1)

49.1. NAME

linuxcncsvr - Allows network access to LinuxCNC internals via NML

49.2. SYNOPSIS

linuxcncsvr

49.3. DESCRIPTION

FIXME: Missing

49.4. SEE ALSO

linuxcnc(1)

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at /usr/share/doc/LinuxCNC/.

49.5. BUGS

None known at this time.

49.6. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

49.7. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

49.8. COPYRIGHT

Copyright © 2020 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 50. linuxcnc(1)

50.1. NAME

linuxcnc(1) - live LinuxCNC status description

50.2. SYNOPSIS

linuxcnc(1) -ini *INIFILE*

50.3. DESCRIPTION

linuxcnc(1) displays much of the LinuxCNC state in a live format similar to the Linux "top" command.

It is more fully documented in the AXIS GUI documentation but can be run standalone or with other GUIs.

50.4. SEE ALSO

linuxcnc(1)

<https://linuxcnc.org/docs/html/gui/axis.html>

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at /usr/share/doc/LinuxCNC/.

50.5. BUGS

None known at this time.

50.6. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

50.7. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

50.8. COPYRIGHT

Copyright © 2020 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 51. maho600gui(1)

51.1. NAME

maho600gui - Vismach Virtual Machine GUI

51.2. DESCRIPTION

maho600gui is one of the sample **Vismach** GUIs for LinuxCNC, simulating a Maho 600 CNC Milling Machine.

See the main LinuxCNC documentation for more details.

<https://linuxcnc.org/docs/html/gui/vismach.html>

51.3. SEE ALSO

linuxcnc(1)

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at `/usr/share/doc/LinuxCNC/`.

51.4. BUGS

None known at this time.

51.5. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

51.6. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

51.7. COPYRIGHT

Copyright © 2020 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 52. max5gui(1)

52.1. NAME

max5gui - Vismach Virtual Machine GUI

52.2. DESCRIPTION

max5gui is one of the sample **Vismach** GUIs for LinuxCNC, simulating a 5 axis CNC Milling Machine.

See the main LinuxCNC documentation for more details.

<https://linuxcnc.org/docs/html/gui/vismach.html>

52.3. SEE ALSO

linuxcnc(1)

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at /usr/share/doc/LinuxCNC/.

52.4. BUGS

None known at this time.

52.5. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

52.6. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

52.7. COPYRIGHT

Copyright © 2020 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 53. mb2hal(1)

53.1. NAME

mb2hal - HAL non-realtime component for Modbus

53.2. SYNOPSIS

Default component name

```
loadusr -W mb2hal config=config_file.ini
```

Custom component name

```
loadusr -Wn mymodule mb2hal config=config_file.ini
```

53.3. DESCRIPTION

MB2HAL is a generic non-realtime HAL component to communicate with one or more Modbus devices. It supports Modbus RTU and Modbus TCP.

See <https://linuxcnc.org/docs/html/drivers/mb2hal.html> for more information.

53.4. PINS

53.4.1. fct_01_read_coils:

mb2hal.m.n.bit bit out

mb2hal.m.n.bit-inv bit out

53.4.2. fct_02_read_discrete_inputs:

mb2hal.m.n.bit bit out

mb2hal.m.n.bit-inv bit out

53.4.3. fct_03_read_holding_registers:

mb2hal.m.n.float float out

mb2hal.m.n.int s32 out

53.4.4. fct_04_read_input_registers:

mb2hal.m.n.float float out

mb2hal.m.n.int s32 out

53.4.5. **fnc_t_05_write_single_coil:**

mb2hal.m.n.bit bit in

NELEMENTS needs to be 1 or PIN_NAMES must contain just one name.

53.4.6. **fnc_t_06_write_single_register:**

mb2hal.m.n.float float in

mb2hal.m.n.int s32 in

NELEMENTS needs to be 1 or PIN_NAMES must contain just one name.

Both pin values are added and limited to 65535 (UINT16_MAX). Use one and let the other open (read as 0).

53.4.7. **fnc_t_15_write_multiple_coils:**

mb2hal.m.n.bit bit in

53.4.8. **fnc_t_16_write_multiple_registers:**

mb2hal.m.n.float float in

mb2hal.m.n.int s32 in

Both pin values are added and limited to 65535 (UINT16_MAX). Use one and let the other open (read as 0).

53.4.9. **Each transaction**

mb2hal.m.num_errors u32 in

Error counter

m = HAL_TX_NAME or transaction number if not set

n = element number (NELEMENTS)

Example:

```
mb2hal.00.01.int (TRANSACTION_00, second register)
mb2hal.readStatus.01.bit (HAL_TX_NAME=readStatus, first bit)
```

53.5. **AUTHOR**

Victor Rocco

53.6. **LICENSE**

GPL

Chapter 54. mdi(1)

54.1. NAME

mdi - Send G-code commands from the terminal to the running LinuxCNC instance

54.2. SYNOPSIS

mdi

54.3. DESCRIPTION

mdi sends G-code commands to LinuxCNC. The command starts an environment in which G-code commands are sent to the interpreter and machine feedback is displayed.

54.4. USAGE

send a single command and exit:

```
mdi m2 s1400
```

interactive session

```
$mdi  
MDI> m3 s1000  
MDI> G0 X100  
MDI> ^Z  
$stopped
```

54.5. SEE ALSO

linuxcnc(1)

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at `/usr/share/doc/LinuxCNC/`.

54.6. BUGS

None known at this time.

54.7. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

54.8. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

54.9. COPYRIGHT

Copyright © 2020 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 55. mdro(1)

55.1. NAME

mdro - manual only Digital Read Out (DRO)

55.2. SYNOPSIS

mdro [-v] [-p *point_size*] [-m] [-l *file.var*] [*axes*]

55.3. DESCRIPTION

mdro is a manual only DRO providing functionality similar to a traditional manual DRO. It is most useful for manual machines converted to CNC. It allows the user to manually control the machine while continuing to use the DRO scales on the axes. The GUI can be sized to match the user's screen. It is mouse-only and touchscreen friendly.

55.4. OPTIONS

These command line options are normally used when **mdro** is started in a HAL file. See below for the corresponding .ini file options.

v

Turn on verbose debug prints. **-vv** is even more verbose.

p *point_size*

Set the point size for the text in the application. This option controls the overall size of the window on the screen. Default is 20. Typical values range from 20 to 30.

m

Set this if the DRO scales provide data scaled in millimeters.

l *file.var*

Load G54 through G57 coordinates from *file.var*.

axes

This option is used to specify the names of the axes handled by the program. The default is "XYZ". A four axis mill would use "XYZA", and a lathe with a two axis DRO might use "XZ".

55.5. SCREEN CONFIGURATION

The top of the screen includes a row for each axis specified in *axes*. Data in these rows are derived from signals on the *mdro.axis.n* pins that are instantiated when **mdro** is started. Each row includes buttons that allow the value to be zeroed, to be halved or a new value to be entered. There is also a button that enables the index zero process for that axis.

The screen includes buttons that allow the selection of one of four different coordinate systems. The machine coordinate system can also be selected though it cannot be changed.

The screen includes a keypad that can be used with a mouse or a touch screen to enter coordinate data.

Finally, buttons on the screen allow the selection of inch or mm data display.

55.6. USAGE

mdro is normally started from the *[DISPLAY]* entry in a dedicated **mdro.ini** file. The INI file and the associated HAL files should include the pins and signals that support the DRO scales. The HAL connections to **mdro** must be done in the *POSTGUI_HALFILE* referenced in the INI file.

Other *[DISPLAY]* section options

GEOMETRY = axes

Names the coordinate axes used in the program. For example, "XYZ" for a 3 axis mill or "XZ" for a lathe, Default is "XYZ".

MDRO_VAR_FILE = file.var

Preload a VAR file. This is typically the VAR file used by the operational code.

POINT_SIZE = n

This option sets the size of the font used which sets the overall size of the window. The default point size is 20, Typical sizes are 20 to 30.

MM = 1

Set this if the DRO scales provide data scaled in millimeters.

55.7. EXAMPLE

Using an example of "XYZA" for an *axes* argument, these pins will be created when **mdro** starts:

- mdro.axis.0
- mdro.axis.1
- mdro.axis.2
- mdro.axis.3
- mdro.index-enable.0
- mdro.index-enable.1
- mdro.index-enable.2
- mdro.index-enable.3

In this example, the first row will be labeled "X" and will show the data associated with pin mdro.axis.0. In many configurations, mdro.axis.0 can be connected directly to x-pos-fb in the POSTGUI-HAL file. The index pins should be connected to the corresponding index-enable pins from the DRO.

mdro can also be started via a "loadusr" command in a HAL file for a trial. Here's an example of a sim setup:

```
loadusr -W mdro -l sim.var XYZ
net x-pos-fb => mdro.axis.0
net y-pos-fb => mdro.axis.1
net z-pos-fb => mdro.axis.2
```

55.8. AUTHOR

Robert Bond

55.9. COPYRIGHT

Copyright © 2022 Robert Bond

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 56. melfagui(1)

56.1. NAME

melfagui - Vismach Virtual Machine GUI

56.2. DESCRIPTION

melfagui is one of the sample **Vismach** GUIs for LinuxCNC, simulating a Mitsubishi serial manipulator.

56.3. SEE ALSO

linuxcnc(1)

<https://linuxcnc.org/docs/html/gui/vismach.html>

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at `/usr/share/doc/LinuxCNC/`.

56.4. BUGS

None known at this time.

56.5. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

56.6. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>

56.7. COPYRIGHT

Copyright © 2023 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 57. mesambccc(1)

57.1. NAME

mesambccc - Utility for compiling hm2_modbus command control description files

57.2. SYNOPSIS

mesambccc [-h|--help] [-v|--verbose] [-o file|--output=file] <filename.source.mbccc>

57.3. DESCRIPTION

The **mesambccc** utility is used to compile hm2_modbus driver command control description files for running Modbus devices with Mesa cards using the PktUARTs. The MBCCS source file is an XML formatted document which describes the devices connected, pins to create and commands to issue to the PktUART port using the Modbus protocol. See [MBCCS FILE FORMAT](#) below.

57.4. OPTIONS

-h, --help

Show a brief help message and exit.

-o file, --output=file

Save the compiled output to **file**. The file name *mesamodbus.output.mbccb* is used if no file is specified on the command line.

-v, --verbose

Output a verbose list of configuration parameters, devices, Modbus messages and HAL pins.

57.5. MBCCS FILE FORMAT

The Modbus command control source file (mbccs file) is an XML formatted document describing the communication parameters, connected devices, HAL pins and command functions to be sent over Modbus. The overall layout is as follows:

```
<?xml version="1.0" encoding="UTF-8"?>
<mesamodbus [attributes...]>
  <devices>...</devices>
  <initlist>...</initlist>
  <commands>...</commands>
</mesamodbus>
```

The *<devices>* tag must be defined before either *<initlist>* or *<commands>* are defined.

57.5.1. ATTRIBUTE VALUES

Attribute values are generally case insensitive, except for the *name* attributes, which should always be lower case.

Boolean attributes accept values "false" and "0" for false and "true" and "1" for true. Integer numerical values can be entered in decimal, hexadecimal, octal or binary form. The latter three require the value to be prefixed with "0x", "0o" or "0b" respectively. Floating point values follow standard rules for floating point values.

All values are checked to be within an acceptable range. Errors and warnings are emitted when values are out of bounds. In case of a warning they may be clamped to the acceptable range.

57.5.2. MODBUS FUNCTIONS

A subset of the Modbus functions is supported (with function number in parentheses):

- **R_COILS (1)**: Maps to 1..2000 HAL output pins of type *HAL_BIT*.
- **R_INPUTS (2)**: Maps to 1..2000 HAL output pins of type *HAL_BIT*.
- **R_REGISTERS (3)**: Maps to 1..125 HAL output pins depending *haltype* and *scale* attributes.
- **R_INPUTREGS (4)**: Maps to 1..125 HAL output pins depending *haltype* and *scale* attributes.
- **W_COIL (5)**: Maps to single HAL input pin of type *HAL_BIT*.
- **W_REGISTER (6)**: Maps to single HAL input pins depending *haltype* and *scale* attributes.
- **W_COILS (15)**: Maps to 1..2000 HAL input pins of type *HAL_BIT*.
- **W_REGISTERS (16)**: Maps to 1..125 HAL input pins depending *haltype* and *scale* attributes.

You can use the function's symbolic name or numerical value in *<command>* in the *function* attribute (as in **function="W_REGISTERS"** or **function="16"**).

57.5.3. MODBUS TYPES

The *modbustype* attribute declares the interpretation of values to or from a Modbus device's registers. They can be a signed integer (S), unsigned integer (U) or a floating point value (F). The size of the value can be 16-bit, 32-bit or 64-bit and the byte-ordering must be specified. The Modbus default, when speaking in "register" quantities, is an unsigned 16-bit value in big-endian (U_AB).

Modbus devices may implement other interpretations covering multiple consecutive registers to create larger or other types. In doing so, multiple device vendors have created some different interpretations of the data that needs to be covered. Differences are primarily byte-ordering.

The byte-ordering is specified with one of the following suffixes:

- **_A, _B**
- **_AB, _BA**
- **_ABCD, _BADCB, _CDAB, _DCBA**

- `_ABCDEFGH`, `_BADCFEHG`, `_CDABGHEF`, `_DCBAHGFE`, `_EFGHABCD`, `_FEHGBADC`, `_GHEFCDAB`, `_HGFEDCBA`

Modbus standard byte-ordering is big-endian, which is the first in each list (`_AB`, `_ABCD` and `_ABCDEFGH`). Little-endian is the last in each list. The user may use any of the byte-orderings necessary and required because some device vendors have not paid attention to the proper on-wire ordering.

The orderings `_A` and `_B` are single byte values from a modbus register. A single byte will be taken from the register value. You cannot access successive bytes from the same register using these types. (You require a second component that de-multiplexes the HAL value(s) into individual bytes from the data stream using the `hm2_modbus` presented pin values.)

The ordering `_A` will use the the least significant byte (LSB), with respect to the default big endian order for Modbus. Ordering `_B` will use the most significant byte (MSB). Note that there is no floating point type when only using sizes of one single byte.

Single byte values have the additional restriction that they cannot be used as data values in `<initlist>`/`<command>`/`<data>`.

The byte-ordering suffix is prefixed with S (signed), U (unsigned) or F (float) to complete the *modbustype* attribute value. For example, a 32-bit float in big-endian is named `F_ABCD`. A 64-bit signed integer value in little-endian is `S_HGFEDCBA`.

The types have following ranges and will be clamped to the min/max values if the *clamp* attribute is set in the `<command>`:

- 8-bit:
 - signed integer [-128..+127] (`S_A`, `S_B`)
 - unsigned integer [0..255] (`U_A`, `U_B`)
- 16-bit:
 - float16 [-65504.0..+65504.0] (`F_AB`, `F_BA`)
 - signed integer [-32768..+32767] (`S_AB`, `S_BA`)
 - unsigned integers [0..65535] (`U_AB`, `U_BA`)
- 32-bit:
 - float [-3.4e38..+3.4e38] (`F_ABCD...F_DCBA`)
 - signed integer [-2147483648..+2147483647] (`S_ABCD...S_DCBA`)
 - unsigned integer [0..4294967296] (`U_ABCD...U_DCBA`)
- 64-bit:
 - double [-1.7e308..+1.7e308] (`F_ABCDEFGH...F_HGFEDCBA`)
 - signed integer [-9223372036854775808..9223372036854775807] (`S_ABCDEFGH...S_HGFEDCBA`)
 - unsigned integer [0..18446744073709551615] (`U_ABCDEFGH...U_HGFEDCBA`)

57.5.4. `<mesamodbus>`

The main enclosing tag `<mesamodbus>` contains the communication parameters and other setup values as attributes:

baudrate [1200..1000000]

Communication speed. Any speed over 460800 will result in side-effects because the internal hardware timers may overflow to keep track of the Modbus protocol requirements. Default 9600.

drivedelay [auto, 1..31]

The delay, in bit-times, before transmission begins after enabling the transmitter hardware output driver. Default auto.

duplex [full, half]

Whether 2-wire (half duplex) or 4-wire (full duplex) communication is set. Default half.

icdelay [auto, 1..255]

The maximum allowed inter-character delay between two received characters in bit-times. Default: auto.

interval [0..3600000000]

The default command repeat interval in micro-seconds. This is effectively the time between repeating the *<commands>* list (sending writes and receiving reads from the Modbus devices). An interval shorter than the time it takes to work through the *<commands>* list will just repeat the *<commands>* list as fast as possible.

The *interval* may be overridden in the individual *<commands><command>* instructions. Default 0.

parity [N, O, E]

Communication parity none (N), odd (O) or even (E). Default E.

rxdelay, txdelay [auto, 1..1020]

Inter frame delay between packets sent/received. The value is in bit-times. The appropriate value will be calculated automatically when this attribute is omitted. If set manually, the *txdelay* value should generally be larger than *rxdelay* value. The value is limited to [1..255] for PktUART V2. Default auto.

stopbits [1, 2]

Communication number of stopbits. This attribute requires PktUART V3+ to have any effect. Default 1.

suspend [Boolean]

Start with suspended communication when set. This enables you to setup pin, scale and offset values in the HAL file(s) using setp/sets commands before data is written to any Modbus device. Default false.

timeout [auto, 10000..10000000]

The standard time a command may take in micro-seconds (send request plus handling plus receive reply) before the command is deemed lost. The special value of *auto* will calculate an appropriate timeout value from the request and reply sizes. The *timeout* value can be overridden in the *<command>* definitions. Default auto.

writeflush [Boolean]

Set to true when the first round of write commands must synchronize the internal state to the pin

state. The writes are calculated but not sent to the Modbus device (i.e. flushed). This flush happens either once when the module starts, each time when the module comes out of *suspend*, or specifically for a command when it gets re-enabled.

The write flush is necessary when you need to ensure proper and correct pin data is present *before* the Modbus commands start sending potentially harmful or invalid data because the pins have not yet been initialized to their proper values. When set, only pin values that are changed from their initial values are propagated in Modbus write commands.

This value represents the global default used by the individual commands from the `<commands>` section and can be overridden in the individual `<command>` instructions. Default true.

The default parameters, without any attributes defined in `<mesamodbus>`, are half duplex serial setup using 8E1@9600 and running all commands as fast as possible. Timeouts and other timing parameters are calculated automatically.

57.5.5. `<devices>`

Each connected device to the physical bus must be declared in a `<device>` tag with a *name* and an *address* attribute. A device with name *broadcast* is implicitly added with address zero (0). Device entries may include a `<description>` tag, which serves as a user's comment.

```
<devices>
  <device address="0x01" name="binbox" />
  <device address="0x02" name="vroom">
    <description>Round and round and round...</description>
  </device>
  <device address="0x66" name="clickies">
    <description>Many, many relays</description>
  </device>
</devices>
```

Recognized `<devices>/<device>` attributes:

address [1..247]

The Modbus slave device ID. The Modbus reserved address range 248..255 is accepted, but a warning is emitted.

name

The *name* of the device. The name must be in lower case ASCII and adhere to the HAL specification comprising of letters and numbers with optional dash and period. It is strongly advised to use letters only in a descriptive word. The device's *name* is used to construct the HAL pin names.

57.5.6. `<initlist>`

The `<initlist>` tag contains a list of `<command>` tags that are only sent *once* at the startup of the system. The commands can be used to initialize any devices on the bus prior to normal operation. Commands can be both read and write functions. Write functions must have data defined to be sent. Each `<command>` entry may include a `<description>` tag, which serves as a user's comment.

Note: if the driver starts in suspended mode (`suspend="true"` in `<mesamodbus>`), then the `<initlist>`

commands are first sent when the driver comes out of suspend.

```
<initlist>
  <command device="scd30" function="W_REGISTER" address="0x0034">
    <description>Soft reset</description>
    <data value="1" />
  </command>
  <command device="relay" function="W_COILS" address="0">
    <data value="0" />
    <data value="1" />
    <data value="1" />
    <data value="0" />
    <description>Four relays set to off-on-on-off</description>
  </command>
  <command device="boombox" function="W_COIL" address="0">
    <data value="0xff00" />
    <description>Single output set to on to hear the boombox</description>
  </command>
  <command delay="2000000">
    <description>Wait for reset to finish</description>
  </command>
  <command device="fltbox" function="W_REGISTERS" address="0xcafe">
    <data modbustype="F_ABCD" value="0.53" />
    <data modbustype="F_ABCD" value="99.999" />
    <description>Send four 16-bit words: 0x3f07 0xae14 0x42c7 0xff7d
      (floats in binary, big-endian)</description>
  </command>
</initlist>
```

A *<command>* is either a delay instruction, a communication parameter change or a Modbus transaction to perform. Only the *delay* attribute is supported in case of a delay instruction and all activity is suspended during the specified delay. A communication parameter change can use any communication related attribute from the *<mesamodbus>* tag and must revert to the defaults set in the *<mesamodbus>* tag at the end on the *<initlist>*.

Modbus write functions must include one or more *<data>* tags to encapsulate the data to send. The *<data>* tag has a mandatory attribute *value* to capture the value to send. An optional *modbustype* attribute models the data to send to the format of the *modbustype*. The default is U_AB if the type is not specified.

The write coils Modbus function **W_COILS** (15) further restrict the *value* to zero (0) or one (1). The write coil **W_COIL** (5) has a fixed type of U_AB and expects a value of 0x0000 or 0xff00. Other values may be given, but a warning will then be emitted.

The Modbus read functions **R_COILS** (1), **R_INPUTS** (2), **R_REGISTERS** (3) and **R_INPUTREGS** (4) are supported in the *<initlist>/<command>* but the returned data is ignored and discarded. Read functions are supported because some devices require a read function as a trigger.

Recognized *<initlist>/<command>* attributes when sending Modbus commands:

address [0..65535]

The Modbus coil/input/register starting address.

bcanswer [Boolean]

Set to true if a device sends an answer on broadcast, which must be ignored. Default false.

count [1..2000]/[1..125]

Modbus read functions **R_COILS** (1), **R_INPUTS** (2), **R_REGISTERS** (3) and **R_INPUTREGS** (4) must specify the number of coils, inputs, registers or inputregs to read. Write functions do not require the *count* attribute because the *<data>* tags dictate the size of the packet to send.

device

The Modbus device to communicate with. The *device* attribute references *<device>[name]*.

The device name **broadcast** will send the command to all devices on the bus.

function [see MODBUS FUNCTIONS]

The attribute value is one of the supported Modbus functions.

noanswer [Boolean]

Set to true if a device does not return a reply to a command. This can be intentional if you send a command to a non-existing device. Default false.

timeout [auto, 1..60000000]

The override timeout of *<mesamodbus>[timeout]* for this command in **micro-seconds** (send request plus handling plus receive reply) before the command is deemed lost. See also *timeoutbits* below. Default *<mesamodbus>[timeout]*.

timeoutbits [0..1000000]

The override timeout of *<mesamodbus>[timeout]* for this command in **bit times** (send request plus handling plus receive reply) before the command is deemed lost. The actual timeout is automatically calculated and scaled by the *<mesamodbus>[baudrate]* setting. See also *timeout* above. Default use *timeout* attribute.

timesout [Boolean]

Set to true if the command is known to (periodically) timeout and no error should be emitted when it does. This differs from *noanswer* in that a reply may be expected within the timeout period but not after the timeout expires. This may be required for flaky devices. Default false.

Delay instruction

Recognized *<initlist>/<command>* attributes in delay commands:

delay [0..60000000]

Communication will be suspended by *delay* micro-seconds.

Communication parameter change

Communication parameters may be temporarily changed to perform live setup of Modbus devices to change their own communication parameters. Some devices will start with a fixed rate and must be reprogrammed at start to change to a different rate. The default setup from *<mesamodbus>* must be

restored if one or more parameters were changed or a warning will be emitted.

Recognized `<initlist>/<command>` attributes in communication parameter change commands. Attributes not specified will be taken from the `<mesamodbus>` tag's attributes:

baudrate [1200..1000000]

Communication speed override.

drivedelay [auto, 1..31]

The TX driver delay override.

icdelay [auto, 1..255]

The inter-character delay override.

parity [N, O, E]

Communication parity override.

rxdelay, txdelay [auto, 1..1020]

Inter frame delay override.

stopbits [1, 2]

Communication number of stopbits override.

Initialization data

Recognized `<initlist>/<command>/<data>` attributes:

modbustype [see [MODBUS TYPES](#)]

The destination format and translation of the *value* attribute.

value

The numerical value of the data to send. The format defaults to unsigned 16-bit integer but depends on the *modbustype* attribute and the range of acceptable values depends on the Modbus function.

57.5.7. HAL TYPES

A `<command>` in the `<commands>` section maps to one or more HAL pins with specific type using the *haltype* attribute. Recognized are:

- *HAL_BIT*
 - *HAL_FLOAT*
 - *HAL_S32*
 - *HAL_U32*
 - *HAL_S64*
 - *HAL_U64*
-

The types are also recognized without the `HAL_` prefix. Note that coil and binary input functions `R_COILS` (1), `R_INPUTS` (2), `W_COIL` (5) and `W_COILS` (15) can only map to `HAL_BIT` and do so implicitly.

The `HAL_BIT`, `HAL_U32` and `HAL_U64` types always map to one single HAL pin.

The `HAL_FLOAT`, `HAL_S32` and `HAL_S64` types can generate one single pin or can generate multiple pins with *offset* and *scale*. Output pins with `R_REGISTERS` (3) and `R_INPUTREGS` (4) can add a *scaled* pin to the set.

Mapping HAL pins to commands requires a *modbustype* attribute to encode the format and necessary conversions. Register functions `R_REGISTERS` (3), `R_INPUTREGS` (4), `W_REGISTER` (6) and `W_REGISTERS` (16) may map to `HAL_BIT` only when using unsigned *modbustype* where a value of zero (0) is *false* and any other value is *true* for write functions or one (1) for read functions.

57.5.8. <commands>

The *<commands>* section defines one or more *<command>* tags to describe the Modbus function(s) to execute in a periodical way. Each *<command>* tag maps to one or more HAL pins and specifies data conversion between device data and HAL pin data.

A delay command may be added using the *delay* attribute causing the communication to be suspended for the specified time. This may be required in broadcast situations where the Modbus devices must have time for internal processing before the next data is sent or requested.

The *<command>* entries may include a *<description>* child-tag, which serves as a user's comment. Additionally, the *<command>* tag may have one or more *<pin>* child-tags to create user-defined HAL pin names. Each *<pin>* tag may again include a *<description>* child-tag.

Modbus read functions `R_COILS` (1), `R_INPUTS` (2), `R_REGISTERS` (3) and `R_INPUTREGS` (4) will always be sent at the specified interval. However, the Modbus write functions `W_COIL` (5), `W_REGISTER` (6), `W_COILS` (15) and `W_REGISTERS` (16) are *only* sent when the source data (pin value) changed. You must specify the *resend* attribute to force repeated writes at the specified interval.

```
<commands>
  <command device="wavebox" function="R_COILS" address="0x0000" count="4" name="state" />
    <description>Type is implicit HAL_BIT, will become HAL pins:
      - (out) hm2_modbus.0.wavebox.state-00
      - (out) hm2_modbus.0.wavebox.state-01
      - (out) hm2_modbus.0.wavebox.state-02
      - (out) hm2_modbus.0.wavebox.state-03
    </description>
  </command>
  <command device="scd30" modbustype="F_ABCD" haltype="HAL_FLOAT" function="R_REGISTERS"
    address="0x0028" scale="0">
    <pin name="co2"><description>Too much will kill you...</description></pin>
    <pin name="temperature" />
    <pin name="humidity" />
    <description>Will become HAL pins:
      - (out) hm2_modbus.0.scd30.co2
      - (out) hm2_modbus.0.scd30.temperature
      - (out) hm2_modbus.0.scd30.humidity
```

```

        Count will automatically be calculated (6 Modbus 16-bit registers).
    </description>
</command>
<command device="broadcast" function="W_COILS" address="0x1234" count="2"
        name="anyandall" bcanswer="1">
    <description>Will create HAL_BIT pins:
        - (in) hm2_modbus.0.anyandall-00
        - (in) hm2_modbus.0.anyandall-01
        The bcanswer flag signifies that a device erroneously sends a reply on
        broadcast (oopsie), which needs to be ignored .
    </description>
</command>
<!-- A delay is suggested after a broadcast to allow devices to handle the data -->
<command delay="10000" />
<command device="watcher" function="W_REGISTER" haltype="HAL_U32" modbustype="U_AB"
        address="0x1ee7" noanswer="1" resend="1">
    <pin name="watcher" />
    <description>Will create a HAL_U32 pin
        - (in) hm2_modbus.0.watcher
        The 'count' is implicit 1. The data is mapped to U_AB and is clamped.
        The data is sent every time (resend=1), regardless whether the HAL pin
        changed. No answer is expected to be received (noanswer=1). This
        command generates a (valid) Modbus packet on the bus and nothing more.
        You must be sure that no reply is sent from the device or errors will
        occur (for example silent watchdog).
    </description>
</command>
</commands>

```

Recognized `<commands>`/`<command>` attributes:

address [0..65535]

The Modbus coil/input/register starting address.

bcanswer [Boolean]

Set to true if a device sends an answer on broadcast, which must be ignored. Default false.

clamp [Boolean]

Conversion from larger to smaller types are automatically clamped to their maximum/minimum values. It works in both ways: read \Rightarrow HAL-out and write \Leftarrow HAL-in. Setting this to false can result in truncated values. Default is true.

count [1..2000]/[1..125]/[1..62]/[1..31]

The *count* specifies the number of HAL pins to create. The data from these pins is read from or written to the Modbus device. Alternatively, you can specify the HAL pins using the `<pin>` child-tags. If both *count* and `<pin>` are specified and *count* is larger than the number of `<pin>` tags, then additional HAL pins will be created to match the count.
(the range depends on *haltype* and *modbustype*)

delay [0..60000000]

Suspend activity and delay the next `<command>` by *delay* micro-seconds.

device

The Modbus device to communicate with. The *device* attribute references `<device>[name]`.

The device name *broadcast* will send the command to all devices on the bus.

disabled [Boolean]

Start the command in disabled state when set, preventing it from being executed. Using the *disabled* flag is a fine grain per command control. In contrast, *suspend* works on the entire state machine and controls operation of all commands in an all-or-nothing way. A command in the disabled state can be enabled by toggling the reset pin of the command. Using *disable* can be particularly useful when you need to delay one particular command while others may already be run. The *writeflush* setting is honored when coming out of the disabled state. Default false.

function [see MODBUS FUNCTIONS]

The attribute value is one of the supported Modbus functions.

haltype [see HAL TYPES]

The HAL pin type for interactions. You do not need to specify this attribute for the Modbus functions read/write coil(s) or inputs, *R_COILS* (1), *R_INPUTS* (2), *W_COIL* (5) and *W_COILS* (15), as these always use the *HAL_BIT* type.

interval [once,0..3600000000]

The command repeat interval in micro-seconds. This is the time between repeating this `<command>`. An interval shorter than the time it takes to work through the `<commands>` list will just repeat this `<command>` as fast as possible.

A special value of *once* will run this command only once. However, it will be retried if an error occurred. You normally do not need the value *once* and it may be better to use an entry in the `<initlist>`. But sometimes you need to have other periodic commands before a *once* marked command that cannot be achieved in the `<initlist>` sequence. Default `<mesamodbus>[interval]`.

modbustype [see MODBUS TYPES]

The Modbus data mapping from/to register(s) for Modbus functions read/write register(s) *R_REGISTERS* (3), *R_INPUTREGS* (4), *W_REGISTER* (6) and *W_REGISTERS* (16). The default is U_AB if not specified.

name

The name for HAL pin names.

Example: if `count="2"` and `name="myname"`, then the pins will have names *myname-00* and *myname-01*, unless one or more `<pin>` tags override the name.

noanswer [Boolean]

Set to true if a device does not return a reply to a command. This can be intentional if you send a command to a non-existing device. Default false.

resend [Boolean]

Resend Modbus write command even though no HAL pin change (data to send change) was detected. Normally, only data changes are sent using Modbus write commands. Some devices require a constant "reminder" (like watchdogs) and you need to send the data regularly. Default false.

scale [Boolean]

Add scaling HAL pins. Modbus read functions **R_REGISTERS** (3) and **R_INPUTREGS** (4) add extra HAL pins **pin.name.offset** (in, 64-bit *haltype*), **pin.name.scale** (in, *HAL_FLOAT*) and **pin.name.scaled** (out, *HAL_FLOAT*).

The Modbus write functions **W_REGISTER** (6) and **W_REGISTERS** (16) create extra HAL pins **pin.name.offset** (in, 64-bit *haltype*) and **pin.name.scale** (in, *HAL_FLOAT*).

The *scale* attribute is only supported for *HAL_FLOAT*, *HAL_S32* and *HAL_S64*. Default is true for *HAL_FLOAT* and false for others. The **scale** pin is initialized to one (1.0) and the **offset** pin is initialized to zero (0).

Scaling is always multiplicative to prevent division-by-zero. The offset is always subtracted before scaling. The scaling action performed and subject to clamping is:

- read: **pin.name** = "readvalue"
- read: **pin.name.scaled** = ("readvalue" - pin.name.offset) * pin.name.scale
- write: "sendvalue" = (pin.name - pin.name.offset) * pin.name.scale

timeout [auto, 1..60000000]

The override timeout of `<mesamodbus>[timeout]` for this command in **micro-seconds** (send request plus handling plus receive reply) before the command is deemed lost. See also *timeoutbits* below. Default `<mesamodbus>[timeout]`.

timeoutbits [0..1000000]

The override timeout of `<mesamodbus>[timeout]` for this command in **bit times** (send request plus handling plus receive reply) before the command is deemed lost. The actual timeout is automatically calculated and scaled by the `<mesamodbus>[baudrate]` setting. See also *timeout* above. Default `<mesamodbus>[timeout]`.

timesout [Boolean]

Set to true if the command is known to (periodically) timeout and no error should be emitted when it does. This differs from *noanswer* in that a reply may be expected within the timeout period but not after the timeout expires. This may be required for flaky devices. Default false.

unaligned [Boolean]

Set to true to suppress the alignment warning in multi-register reads or writes where 32-bit or 64-bit values are not aligned to their natural Modbus address boundaries. This is useful for devices that do not care about alignment or do not use Modbus addresses in conventional ways.

Setting *unaligned* is purely a cosmetic attribute to suppress console clutter when compiling the mbccs file. It has no functional effect on the communication with the device. Default false.

writeflush [Boolean]

The override the *writeflush* value. See `<mesamodbus>[writeflush]` for details. Default `<mesamodbus>[writeflush]`.

Pins

Defining `<pin>` tags allows for custom naming schemes and allows reducing read and write function overhead. Using `<pin>` tags enables you to combine different *modbustype* and *haltype* values to be read

or written to or from consecutive addresses. A warning is emitted if 32-bit and 64-bit values are not aligned to their native boundary (it may be an error, depending device). The attributes of the `<command>` tag set the defaults for the `<pin>` tag attributes and can be overridden by adding them to the `<pin>` tag.

```
<command device="booboo"
  function="R_REGISTERS"
  address="0x0240"
  haltype="HAL_FLOAT"
  modbustype="F_ABCD"
  scale="1">
  <!-- addr: 0x0240-0x0241; disable scaling pins -->
  <pin name="speed" scale="0" />
  <!-- addr:0x0242; one register to bit-->
  <pin name="ping" haltype="HAL_BIT" modbustype="U_AB" />
  <!-- Align the next value -->
  <pin skip="1" />
  <!-- addr: 0x0244-0x0245; use defaults from this command -->
  <pin name="afloat" />
<!--
  The above <command><pin> tags read 6 registers and generate pins:
  hm2_modbus.0.speed          HAL_FLOAT (out)
  hm2_modbus.0.ping           HAL_BIT   (out)
  hm2_modbud.0.afloat         HAL_FLOAT (out)
  hm2_modbud.0.afloat.offset  HAL_FLOAT (in)
  hm2_modbud.0.afloat.scale   HAL_FLOAT (in)
  hm2_modbud.0.afloat.scaled  HAL_FLOAT (out)
-->
</command>
```

Recognized `<commands>`/`<command>`/`<pin>` attributes:

clamp [Boolean]

The clamp setting override for this pin.

haltype [see [HAL TYPES](#)]

The HAL type override for this pin.

modbustype [see [MODBUS TYPES](#)]

The Modbus type override for this pin.

name

Specifies the pin name overriding the default `<command>[name]-xx` sequence. This makes the HAL names more human readable.

scale [Boolean]

The scale setting override for this pin.

skip [0..24]

Skip a number of registers ignoring them for read functions and writing zero (0) for write functions. There can not be other attributes if the `skip` attribute is used.

Using a *skip* value larger than 11 will emit a warning. Large skips make the transfers less efficient and skipping 12+ registers may be better off by splitting the function in two commands. An exception may be atomicity where the device allows access to the intermediate (unused) register addresses and only guarantees atomicity in a single read/write transaction.

Beware that the skipped registers **must** be readable or writable (depending function). The skipped values must be transferred in the Modbus transaction and the target device must allow read or write access to the skipped register addresses.

Beware: using *skip* in write commands **writes value zero (0) to the skipped registers**.

57.6. SEE ALSO

`linuxcnc(1)`, `hm2_modbus(9)`.

https://linuxcnc.org/docs/devel/html/drivers/mesa_modbus.html

57.7. AUTHOR

This man page written by B.Stultiens, as part of the LinuxCNC project.

57.8. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>

57.9. COPYRIGHT

Copyright © 2025 B.Stultiens

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 58. milltask(1)

58.1. NAME

milltask - Non-realtime task controller for LinuxCNC

58.2. DESCRIPTION

The internal process **milltask** of LinuxCNC is generally not invoked directly but by an INI file setting: `[TASK]TASK=milltask``. The **milltask** process creates the `ini.*` HAL pins listed below and owned by the **inihal** component. These pins may be modified while LinuxCNC is running to alter values that are typically specified statically in an INI file.

The **inihal** pins are sampled in every task cycle, however, commands affected by their values typically use the value present at the time when the command is processed. Such commands include all codes handled by the interpreter (**G-code** programs and **MDI** commands) and NML **jogging** commands issued by a GUI (including **halui**). **Wheel jogging** is implemented in the realtime motion module so **inihal** pin changes (e.g., `ini.*.max_velocity`, `ini.*.max_acceleration`) may be honored as soon as altered values are propagated to the motion module.

58.3. PINS

58.3.1. Per-joint pins (N == joint number)

ini.N.backlash

Allows adjustment of [JOINT_N]BACKLASH

ini.N.ferror

Allows adjustment of [JOINT_N]FERROR

ini.N.min_ferror

Allows adjustment of [JOINT_N]MIN_FERROR

ini.N.min_limit

Allows adjustment of [JOINT_N]MIN_LIMIT

ini.N.max_limit

Allows adjustment of [JOINT_N]MAX_LIMIT

ini.N.max_velocity

Allows adjustment of [JOINT_N]MAX_VELOCITY

ini.N.max_acceleration

Allows adjustment of [JOINT_N]MAX_ACCELERATION

ini.N.home

Allows adjustment of [JOINT_N]HOME

ini.N.home_offset

Allows adjustment of [JOINT_N]HOME_OFFSET

ini.N.home_offset

Allows adjustment of [JOINT_N]HOME_SEQUENCE

58.3.2. Per-axis pins (L == axis letter)**ini.L.min_limit**

Allows adjustment of [AXIS_L]MIN_LIMIT

ini.L.max_limit

Allows adjustment of [AXIS_L]MAX_LIMIT

ini.L.max_velocity

Allows adjustment of [AXIS_L]MAX_VELOCITY

ini.L.max_acceleration

Allows adjustment of [AXIS_L]MAX_ACCELERATION

58.3.3. Global pins**ini.traj_default_acceleration**

Allows adjustment of [TRAJ]DEFAULT_ACCELERATION

ini.traj_default_velocity

Allows adjustment of [TRAJ]DEFAULT_VELOCITY

ini.traj_max_acceleration

Allows adjustment of [TRAJ]MAX_ACCELERATION

ini.traj_max_velocity

Allows adjustment of [TRAJ]MAX_VELOCITY

58.3.4. Global pins (arc_blend trajectory planner)**ini.traj_arc_blend_enable**

Allows adjustment of [TRAJ]ARC_BLEND_ENABLE

ini.traj_arc_blend_fallback_enable

Allows adjustment of [TRAJ]ARC_BLEND_FALLBACK_ENABLE

ini.traj_arc_blend_gap_cycles

Allows adjustment of [TRAJ]ARC_OPTIMIZATION_DEPTH

ini.traj_arc_blend_optimization_depth

Allows adjustment of [TRAJ]ARC_BLEND_GAP_CYCLES

ini.traj_arc_blend_ramp_freq

Allows adjustment of [TRAJ]ARC_BLEND_RAMP_FREQ

58.4. NOTES

The **inihal** pins cannot be linked or set in a HAL file that is specified by an INI file **[HAL]HALFILE** item because they are not created until **milltask** is started. The **inihal** pin values can be altered by independent halcmd programs specified by **[APPLICATION]APP** items or by GUIs that support a **[HAL]POSTGUI_HALFILE**.

The INI file is not automatically updated with values altered by **inihal** pin settings but can be updated using the calibration program (emccalib.tcl) when using a **[HAL]POSTGUI_HALFILE**.

Chapter 59. millturn(1)

59.1. NAME

millturn, millturngui - Vismach Virtual Machine GUI

59.2. DESCRIPTION

millturngui is one of the sample **Vismach** GUIs for LinuxCNC, simulating a Mill-Turn machine.

See the main LinuxCNC documentation for more details.

<https://linuxcnc.org/docs/html/gui/vismach.html>

59.3. SEE ALSO

linuxcnc(1)

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at /usr/share/doc/LinuxCNC/.

59.4. BUGS

None known at this time.

59.5. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

59.6. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>

59.7. COPYRIGHT

Copyright © 2023 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 60. mitsub_vfd(1)

60.1. NAME

`mitsub_vfd` - HAL non-realtime component for Mitsubishi A500 F500 E500 A500 D700 E700 F700-series VFDs (others may work) This uses the COMPUTER LINK protocol *not* MODBUS. The connection is made through the PU connector.

60.2. SYNOPSIS

loadrt mitsub_vfd [--baud *baudrate*] [--port *devicename*] **name1=number₁**[,**name2=number₂**...]

name1

is user selectable (usually a description of the controlled device).

number1

is the slave number that was set on the VFD. Must be two digits (Parameter 117).

nameN=numberN

can be repeated for multiple VFD's connected together.

--baud *baudrate*

is optional as it defaults to 9600, all networked vfd's must be set to the same baudrate.

--port *devicename*

is optional as it defaults to `ttys0`, a common alternative is `/dev/ttyUSB0`.

60.3. DESCRIPTION

The `mitsub_vfd` component interfaces a Mitsubishi VFD to LinuxCNC. The VFD is connected via RS-485 serial to the computer's USB or serial port using a RS-232/RS-485 converter.

60.4. HARDWARE SETUP

reference manual *communication option reference manual* and A500 technical manual for 500 series. Fr-A700 F700 E700 D700 technical manual for the 700 series.

The inverter must be set manually for communication (you may have to set PR 77 to 1 to unlock PR modification).

You must power cycle the inverter for some of these, e.g. 79.

VFD INTERNAL PARAMETERS:

PARAMETER 79

1 or 0

PARAMETER 117

Station number - 1

(can be optionally set 0 - 31) if component is also set

PARAMETER 118

Communication speed 96

(can be optionally set 48, 96, 192 if component is also set)

PARAMETER 119

Stop bit/data length - 1

(8 bits, two stop - don't change)

PARAMETER 120

Parity - 0

(no parity - don't change)

PARAMETER 121

COM tries - 10

(if maximum 10 COM errors then inverter faults- can change.)

PARAMETER 122

COM check time interval 9999

(never check - if communication is lost inverter will not know (can change))

PARAMETER 123

Wait time - 9999

No wait time is added to the serial data frame (don't change).

PARAMETER 124

CR selection - 0

Don't change.

PARAMETER 549

Communication protocol - 0

Computer link protocol - don't change - (not all VFDs have this)

60.5. NOTES

This driver assumes certain other VFD settings:

- That the motor frequency status is set to show Hertz.
- That the status bit 3 is up to speed.
- That the status bit 7 is alarm.

Some models, e.g. the E500, cannot monitor status.

You must set the monitor pin to false.

In this case pins such as up-to-speed, amps, alarm and status bits are not useful.

60.6. PINS

VFD_NAME.fwd (bit, in)

Forward/reverse pin

VFD_NAME.run (bit, in)

Run/stop pin

VFD_NAME.debug (bit, in)

Set debug mode pin. This will print many messages to the terminal.

VFD_NAME.monitor (bit, in)

Set monitor mode pin. If false, request-status command will not be sent to VFD. Status, amps, power, motor-feedback, and alarm would then not be useful.

VFD_NAME.estop (bit, in)

Set E-stop mode pin. This will stop the VFD. Restarting requires the run pin to cycle.

VFD_NAME.fwd (bit, out)

Up-to-speed status pin. Motor is at requested speed within VFD's settings tolerance.

VFD_NAME.alarm (bit, out)

Alarm status pin

VFD_NAME.motor-cmd (float, in)

The requested motor speed, in Hertz (Hz)

VFD_NAME.motor-fb (float, out)

The motor feedback speed (from VFD) in Hertz (Hz)

VFD_NAME.motor-amps (float, out)

The motor current, in amperes (A)

VFD_NAME.motor-power (float, out)

The motor power

VFD_NAME.scale-cmd (float, in)

Motor command's scale setting defaults to 1

VFD_NAME.scale-cmd (float, in)

Motor command's scale setting defaults to 1

VFD_NAME.scale-cmd (float, in)

Motor command's scale setting defaults to 1

VFD_NAME.stat-bit-0 (bit, out)

Raw status bit

VFD_NAME.stat-bit-1 (bit, out)

Raw status bit

VFD_NAME.stat-bit-2 (bit, out)

Raw status bit

VFD_NAME.stat-bit-3 (bit, out)

Raw status bit. Configure the VFD so that the function *Up to frequency* or *motor-at-speed* is assigned to status bit 3 (parameter 191 for 700 series).

VFD_NAME.stat-bit-4 (bit, out)

Raw status bit

VFD_NAME.stat-bit-5 (bit, out)

Raw status bit

VFD_NAME.stat-bit-6 (bit, out)

Raw status bit

VFD_NAME.stat-bit-7 (bit, out)

Raw status bit. Configure the VFD so that the function *alarm* is assigned to status bit 7 (parameter 195 for 700 series).

60.7. SAMPLE HAL

```
loadusr -Wn coolant mitsub_vfd --port /dev/ttyUSB0 spindle=02 coolant=01
# ***** Spindle VFD setup slave 2 *****
net spindle-vel-cmd spindle.motor-cmd
net spindle-cw spindle.fwd
net spindle-on spindle.run
net spindle-at-speed spindle.up-to-speed
net estop-out spindle.estop
# cmd scaled to RPM (belt/gearbox driven)
setp spindle.scale-cmd .135
# feedback is in rpm (recipicale of command)
setp spindle.scale-fb 7.411
# turn on monitoring so feedback works
setp spindle.monitor 1
net spindle-speed-indicator spindle.motor-fb
# ***** Coolant VFD setup slave 1 *****
net coolant-flood coolant.run
net coolant-is-on coolant.up-to-speed
# cmd and feedback scaled to hertz
setp coolant.scale-cmd 1
setp coolant.scale-fb 1
# command full speed
setp coolant.motor-cmd 60
# allows us to see status
setp coolant.monitor 1
net estop-out coolant.estop
```

60.8. ISSUES

Some models, e.g. E500, cannot monitor status, so set the monitor pin to false. In this case, pins such as up-to-speed, amps, alarm and status bits are not useful.

Chapter 61. modcompile(1)

61.1. NAME

modcompile - Utility for compiling Modbus drivers

61.2. SYNOPSIS

modcompile -h

modcompile [-k] [-n] [-v] all

modcompile [-k] [-n] [-v] module.mod ...

61.3. DESCRIPTION

The **modcompile** utility is used to compile modbus drivers that use the PktUART interface of Mesa cards.

See the main LinuxCNC documentation for more details.

https://linuxcnc.org/docs/devel/html/drivers/mesa_modbus.html

61.4. OPTIONS

-h, --help

Brief help message.

-k, --keep

Keep the temporary files. The program will print a line where these are located. You will be responsible for deleting them.

-n, --noinstall

Do not run the install step for the compiled module. This option is probably only useful if you also use the **--keep** option.

-v, --verbose

Do a verbose build, showing all steps detailed while being performed.

61.5. SEE ALSO

linuxcnc(1)

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at `/usr/share/doc/LinuxCNC/`.

61.6. BUGS

None known at this time.

61.7. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

61.8. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>

61.9. COPYRIGHT

Copyright © 2023 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 62. monitor-xhc-hb04(1)

62.1. NAME

monitor-xhc-hb04 - monitors the XHC-HB04 pendant and warns of disconnection

62.2. SYNOPSIS

monitor-xhc-hb04

62.3. DESCRIPTION

monitor-xhc-hb04 is included to monitor disconnects and reconnects of the pendant. This script runs in the background and will pop up a message when the pendant is disconnected or reconnected.

Usage is optional; if used it is specified with INI file entry:

```
[APPLICATIONS]
APP = monitor-xhc-hb04
```

62.4. SEE ALSO

xhc-hb04(1), linuxcnc(1)

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at /usr/share/doc/LinuxCNC/.

62.5. BUGS

None known at this time.

62.6. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

62.7. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

62.8. COPYRIGHT

Copyright © 2020 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 63. motion-logger(1)

63.1. NAME

motion-logger - log motion commands sent from LinuxCNC's Task module

63.2. SYNOPSIS

motion-logger

63.3. DESCRIPTION

motion-logger is a test program to log motion commands sent from LinuxCNC's Task module to the Motion module.

It is largely used by the regression tests and is poorly documented.

63.4. SEE ALSO

linuxcnc(1)

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at `/usr/share/doc/LinuxCNC/`.

63.5. BUGS

None known at this time.

63.6. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

63.7. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

63.8. COPYRIGHT

Copyright © 2020 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 64. moveoff_gui(1)

64.1. NAME

moveoff_gui - a GUI for the moveoff component

64.2. SYNOPSIS

moveoff_gui [--help | --h | *-?]

moveoff_gui [*options*]

64.3. DESCRIPTION

Moveoff_gui is a sample graphical user interface (GUI) for controlling a HAL moveoff component to implement HAL-only offsets. See the manpage (man moveoff) for **IMPORTANT** limitations and warnings.

Supported configurations must use a known kinematics module with **KINEMATICS_TYPE = KINEMATICS_IDENTITY**. The modules currently supported are: **trivkins**

64.4. OPTIONS

--help | -? | --h

Show options and exit.

-mode onpause | always

onpause: popup GUI to control offsets when program paused

always: show GUI to control offsets always

Default: **onpause**

-axes axis-names

Letters from set of \{x y z a b c u v w\}.

Examples: -axes x, -axes xyz, -axes xz (no spaces)

Default: **xyz**

-inc incrementvalue

Specify one increment value per -inc (up to 4).

Defaults: * 0.001 0.01 0.10 1.0*

-size integer

Overall gui size is based on font size, typically 8 - 20.

Default: **14**

-loc center | +x+y

Initial location on screen.

Examples: -loc center, -loc +20+100

Default: **center**

-autoresume

Resume program when move-enable deasserted.

Default: notused

-delay *delay secs*

Delay for autoresume (allow time to restore spindle speed etc).

Default: 5

64.5. OTHER OPTIONS

These options are available for special cases:

-noentry

Disables creation of entry widgets.

Default: notused

-no_resume_inhibit

Disable use of resume-inhibit to controlling gui.

Default: notused

-no_pause_requirement

Disable check for halui.program.is-paused.

Default: notused

-no_cancel_autoresume

Useful for retracting offsets with simple external controls.

Default: notused

-no_display

Use when both external controls and external displays are in use.

Default: notused

64.6. NOTES

LinuxCNC must be running.

Halui must be loaded, typical INI file setting:

```
[HAL]
HALUI = halui
```

The moveoff component must be loaded with the name *mv* as:

loadrt moveoff names=mv *personality*=_number_of_axes

If the pin `mv.motion-enable` is **not** connected when `moveoff_gui` is started, **controls will be provided** to enable offsets and set offset values. If the pin **is** connected, **only a display** of offsets is shown and control must be made by **external** HAL connections.

If a pin named `*.resume-inhibit` exists and is not connected, it will be set while offsets are applied. This pin may be provided by the controlling LinuxCNC GUI in use. Use of the pin may be disabled with the option `-no_resume_inhibit`.

The `-autoresume` option uses `halui.program.resume` to automatically resume program execution when the move-enable pin is deactivated and all offsets are removed. The resume pin is not activated until an additional interval (`-delay delay_secs`) elapses. This delay interval may be useful for restarting related equipment (a spindle motor for example). While timing the delay, a popup is offered to cancel the automatic program resumption.

64.7. USAGE

The INI file in the configuration directory must provide HALFILES to loadrt the moveoff component, connect its pins, and addf its read and write functions in the proper order. These steps can be done at runtime using an existing configuration INI file and specifying a system library HALFILE **hookup_moveoff.tcl** as illustrated below:

```
[HAL]
HALUI = halui
HALFILE = user_halfile_1
etc ...
HALFILE = user_halfile_n
HALFILE = LIB:hookup_moveoff.tcl
```

The **hookup_moveoff.tcl** HAL file will use INI file settings for the moveoff component control pins:

```
[OFFSET]
EPSILON =
WAYPOINT_SAMPLE_SECS =
WAYPOINT_THRESHOLD =
BACKTRACK_ENABLE =
```

The **hookup_moveoff.tcl** will use INI file settings for the moveoff per-axis limits:

```
[AXIS_m]
OFFSET_MAX_VELOCITY =
OFFSET_MAX_ACCELERATION =
OFFSET_MAX_LIMIT =
OFFSET_MIN_LIMIT =
```

The `moveoff_gui` program should be specified in the APPLICATIONS stanza of the INI file, for example:

```
[APPLICATIONS]
DELAY = delay_in_secs_to_allow_hal_connections
APP = moveoff_gui -option1 -option2 ...
```

64.8. SEE ALSO

Simulation configurations that demonstrate the moveoff_gui and the moveoff component are located in:

configs/sim/axis/moveoff (axis-ui)

configs/sim/touchy/ngcgui (touchy-ui)

See also moveoff(9) for details on the component.

Chapter 65. mqtt-publisher(1)

65.1. NAME

mqtt-publisher - send HAL pin data to MQTT broker periodically

65.2. SYNOPSIS

loadusr -W mqtt-publisher [*options*] **keys=pin1[,pin2...]**

65.3. DESCRIPTION

mqtt-publisher is a non-realtime program that reads HAL values periodically and passes the values to a MQTT broker.

When specifying the MQTT settings in the INI file, this is the recommended setup:

HAL file:

```
loadusr -W mqtt-publisher [MQTT]DRYRUN --mqtt-broker=[MQTT]BROKER \  
--mqtt-user=[MQTT]USERNAME --mqtt-password=[MQTT]PASSWORD keys=halui.estop.is-activated
```

INI file:

```
[MQTT]  
DRYRUN = --dryrun  
BROKER = broker.local  
USERNAME = username  
PASSWORD = password
```

This component need the Paho python library installed to function. On debian this is available from the [python3-paho-mqtt](#) package.

65.4. OPTIONS

keys=pin1[,pin2,...]

The name of HAL pins, signals and other values to publish using MQTT. The names are also used as the JSON keys in the MQTT message published with the broker. If multiple "keys=" options are specified, the lists are merged.

--dryrun

Do not set up MQTT connection, only print message to stdout. Useful for debugging and testing.

--mqtt-broker=FQDN

The fully qualified DNS name of the MQTT broker. The default broker name is "localhost".

--mqtt-port=PORTNUMBER

The port to use of the MQTT broker. The default port is 1883.

--mqtt-user=USERNAME

The user name to use when connecting to the MQTT broker.

--mqtt-password=PASSWORD

The password to use when connecting to the MQTT broker.

--mqtt-prefix=PREFIX

The MQTT prefix/topic to use when publishing to the MQTT broker. The default prefix is "devices/linuxcnc/machine".

65.5. FUNCTIONS

mqtt-publisher

The loop reading HAL values and publishing MQTT messages.

65.6. PINS

mqtt-publisher.enable bit input

When TRUE, publish messages to MQTT broker. When FALSE, do not publish messages. Default is TRUE.

mqtt-publisher.period u32 input

The number of seconds to sleep between publishing MQTT messages to the broker. Default is 10 seconds.

mqtt-publisher.lastpublish u32 output

When the last MQTT publication was published in number of seconds since EPOC. If no publication has taken place, the value is zero.

65.7. EXAMPLE

Any set of HAL pins and signals can be published. This setup might be a useful starting point:

```
loadusr -W mqtt-publisher \  
[MQTT]DRYRUN \  
--mqtt-broker=[MQTT]BROKER \  
--mqtt-user=[MQTT]USERNAME \  
--mqtt-password=[MQTT]PASSWORD \  
keys=halui.axis.a.pos-feedback,halui.axis.b.pos-feedback,\  
halui.axis.c.pos-feedback,halui.axis.u.pos-feedback,\  
halui.axis.v.pos-feedback,halui.axis.w.pos-feedback,\  
halui.axis.x.pos-feedback,halui.axis.y.pos-feedback,\  
halui.axis.z.pos-feedback,halui.estop.is-activated,\  
halui.joint.0.is-homed,halui.joint.1.is-homed,halui.joint.2.is-homed,\  
halui.joint.3.is-homed,halui.joint.4.is-homed,halui.joint.5.is-homed,\  

```

```
halui.joint.6.is-homed,halui.joint.7.is-homed,halui.joint.8.is-homed,\  
halui.machine.is-on,halui.max-velocity.value,halui.mode.is-auto,\  
halui.mode.is-manual,halui.mode.is-mdi,halui.mode.is-teleop,\  
halui.program.is-running
```

Note: It is recommended to use the line continuation character "\" as shown here to improve readability. But note that spaces must be left in to delimit options, and must not be included (including at the beginning of a line) inside a single option.

65.8. SEE ALSO

hal(3)

65.9. AUTHOR

Component and documentation created by Petter Reinholdtsen, as part of the LinuxCNC project.

65.10. COPYRIGHT

Copyright © 2023 Petter Reinholdtsen.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 66. ngcgui(1)

66.1. NAME

ngcgui - a framework for conversational G-code generation on the controller

66.2. SYNOPSIS

ngcgui

66.3. DESCRIPTION

ngcgui details: <https://linuxcnc.org/docs/html/gui/ngcgui.html>

66.4. SEE ALSO

linuxcnc(1)

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at /usr/share/doc/LinuxCNC/.

66.5. BUGS

None known at this time.

66.6. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

66.7. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

66.8. COPYRIGHT

Copyright © 2020 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 67. panelui(1)

67.1. NAME

panelui - interface buttons to LinuxCNC or HAL

67.2. SYNOPSIS

panelui

67.3. DESCRIPTION

The non-realtime component **panelui** interfaces buttons to LinuxCNC or HAL. It decodes MESA 7i73 style key-scan codes and calls the appropriate routine. It gets input from a realtime component - sampler. Sampler gets it's input from either the MESA 7i73 or sim_matrix_kb component. Panelui is configurable using an INI style text file to define button types, HAL pin types, and/or commands.

Full documentation can be found in the HTML or PDF docs: <https://linuxcnc.org/docs/html/gui/panelui.html>

67.4. SEE ALSO

linuxcnc(1)

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at /usr/share/doc/LinuxCNC/.

67.5. BUGS

None known at this time.

67.6. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

67.7. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

67.8. COPYRIGHT

Copyright © 2020 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 68. PI500_VFD(1)

68.1. NAME

pi500_vfd - Powtran PI500 Modbus driver

68.2. SYNOPSIS

pi500_vfd

68.3. PINS

pi500-vfd.N.commanded-frequency float in

Frequency of vfd

pi500-vfd.N.run bit in

run the vfd

pi500-vfd.N.enable bit in

1 to enable the vfd. 0 will remote trip the vfd, thereby disabling it.

pi500-vfd.N.is-running bit out

1 when running

pi500-vfd.N.is-at-speed bit out

1 when running at assigned frequency

pi500-vfd.N.is-ready bit out

1 when vfd is ready to run

pi500-vfd.N.is-alarm bit out

1 when vfd alarm is set

pi500-vfd.N.motor-current float out

Output current in amps

pi500-vfd.N.heatsink-temp float out

Temperature of drive heatsink

pi500-vfd.N.watchdog-out bit out

Alternates between 1 and 0 after every update cycle. Feed into a watchdog component to ensure vfd driver is communicating with the vfd properly.

68.4. PARAMETERS

pi500-vfd.N.mbslaveaddr u32 rw

Modbus slave address

68.5. LICENSE

GPLv2 or greater

Chapter 69. pmx485-test(1)

69.1. NAME

pmx485-test - Modbus communications testing with a Powermax Plasma Cutter

69.2. SYNOPSIS

pmx485-test

69.3. DESCRIPTION

pmx485 is a python script for testing communications with a Hypertherm Powermax plasma cutter using the Modbus ASCII protocol over RS485.

69.4. USAGE

Select the correct port from the list of available ports.

Check RS485 to establish communications.

Changing MODE, CURRENT, or PRESSURE will change the corresponding value on the Powermax and the new value will be reported back to the test panel.

Check PANEL to end communication.

69.5. AUTHOR

Phillip Carter & Gregory D Carl

69.6. LICENSE

GPL

Chapter 70. pmx485(1)

70.1. NAME

pmx485 - Modbus communications with a Powermax Plasma Cutter.

70.2. SYNOPSIS

loadusr -Wn pmx485 pmx485 /dev/ttyUSB0

70.3. DESCRIPTION

pmx485 is a non-realtime HAL component to communicate with a Hypertherm Powermax plasma cutter using the Modbus ASCII protocol over RS485.

70.4. SEE ALSO

See the Drivers section of the LinuxCNC Documentation for more information on pmx485.

70.5. AUTHOR

Phillip Carter & Gregory D Carl

70.6. LICENSE

GPL

Chapter 71. pncconf(1)

71.1. NAME

pncconf - configuration wizard for Mesa cards

71.2. SYNOPSIS

pncconf

71.3. DESCRIPTION

pncconf is used to configure systems that use Mesa cards.

Details: <https://linuxcnc.org/docs/html/config/pncconf.html>

71.4. SEE ALSO

linuxcnc(1)

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at /usr/share/doc/LinuxCNC/.

71.5. BUGS

None known at this time.

71.6. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

71.7. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

71.8. COPYRIGHT

Copyright © 2020 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 72. puma560gui(1)

72.1. NAME

puma560gui - Vismach Virtual Machine GUI

72.2. DESCRIPTION

puma560gui is one of the sample **Vismach** GUIs for LinuxCNC, simulating a Puma 560 robot arm.

See the main LinuxCNC documentation for more details.

<https://linuxcnc.org/docs/html/gui/vismach.html>

72.3. SEE ALSO

linuxcnc(1)

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at /usr/share/doc/LinuxCNC/.

72.4. BUGS

None known at this time.

72.5. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

72.6. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

72.7. COPYRIGHT

Copyright © 2020 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 73. pumagui(1)

73.1. NAME

pumagui - Vismach Virtual Machine GUI

73.2. DESCRIPTION

pumagui is one of the sample **Vismach** GUIs for LinuxCNC, simulating a generic Puma style robot arm.

See the main LinuxCNC documentation for more details.

<https://linuxcnc.org/docs/html/gui/vismach.html>

73.3. SEE ALSO

linuxcnc(1)

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at /usr/share/doc/LinuxCNC/.

73.4. BUGS

None known at this time.

73.5. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

73.6. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

73.7. COPYRIGHT

Copyright © 2020 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 74. pyngcgui(1)

74.1. NAME

pyngcgui - Python implementation of NGCGUI

74.2. SYNOPSIS

pyngcgui

74.3. DESCRIPTION

pyngcgui is an alternative impenlentation of NGCGUI: <https://linuxcnc.org/docs/html/gui/ngcgui.html>

74.4. SEE ALSO

ngcgui(1), linuxcnc(1)

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at /usr/share/doc/LinuxCNC/.

74.5. BUGS

None known at this time.

74.6. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

74.7. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

74.8. COPYRIGHT

Copyright © 2020 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 75. pyui(1)

75.1. NAME

pyui - utility for panelui

75.2. SYNOPSIS

loadusr pyui

75.3. DESCRIPTION

pyui validates panelui.ini files.

This will read, try to correct, then save the panelui.ini file. It will print errors to the terminal if found.

75.4. SEE ALSO

linuxcnc(1)

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at /usr/share/doc/LinuxCNC/.

75.5. BUGS

None known at this time.

75.6. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

75.7. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

75.8. COPYRIGHT

Copyright © 2020 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 76. pyvcp(1)

76.1. NAME

pyvcp - Virtual Control Panel for LinuxCNC

76.2. SYNOPSIS

pyvcp [-g *WxH+X+Y*] [-c *component-name*] *myfile.xml*

76.3. OPTIONS

-g *WxH+X+Y*

This sets the initial geometry of the root window. Use *WxH* for just size, *+X+Y* for just position, or *WxH+X+Y* for both. Size / position use pixel units. Position is referenced from top left.

-c *component-name*

Use *component-name* as the HAL component name. If the component name is not specified, the basename of the XML file is used.

76.4. SEE ALSO

Python Virtual Control Panel in the LinuxCNC documentation for a description of the xml syntax, along with examples.

Chapter 77. pyvcp_demo(1)

77.1. NAME

pyvcp_demo - Python Virtual Control Panel demonstration component

77.2. SYNOPSIS

pyvcp_demo

77.3. DESCRIPTION

pyvcp_demo is mainly used by sample configurations.

77.4. USAGE

pyvcp_demo filename1.xml filename2.hal [compname]

If not provided, use compname == pyvcp

77.5. SEE ALSO

linuxcnc(1)

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at /usr/share/doc/LinuxCNC/.

77.6. BUGS

None known at this time.

77.7. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

77.8. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

77.9. COPYRIGHT

Copyright © 2020 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for

MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 78. qtplasmac-materials(1)

78.1. NAME

qtplasmac-materials - Create a plasma materials file.

78.2. SYNOPSIS

qtplasmac-materials

78.3. DESCRIPTION

qtplasmac-materials is a Python script for creating a materials file.

The file can be created by text entry or by importing text from a CAM tool file.

78.4. SEE ALSO

See the QtPlasmaC section of the LinuxCNC Documentation for more information.

https://linuxcnc.org/docs/devel/html/plasma/qtplasmac.html#_material_converter

78.5. AUTHOR

Phillip Carter & Gregory D Carl

78.6. LICENSE

GPL

Chapter 79. qtplasmac_gcode(1)

79.1. NAME

qtplasmac_gcode - Python script shipping with Plasmac, a Plasma cutting system.

79.2. DESCRIPTION

qtplasmac_gcode is used by qtplasmac and is not intended to be used standalone.

See the QtPlasmaC section of the LinuxCNC Documentation for more information. <https://linuxcnc.org/docs/devel/html/plasma/qtplasmac.html>

79.3. SEE ALSO

linuxcnc(1)

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at /usr/share/doc/LinuxCNC/.

79.4. BUGS

None known at this time.

79.5. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

79.6. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>

79.7. COPYRIGHT

Copyright © 2023 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 80. qtvcp(1)

80.1. NAME

qtvcp - Qt-based virtual control panels

80.2. SYNOPSIS

qtvcp [*OPTIONS*] myfile.ui

80.3. DESCRIPTION

QtVCP is a system for creating user interfaces for LinuxCNC.

Full documentation at <https://linuxcnc.org/docs/html/gui/qtvcp.html>

80.4. OPTIONS

-h, --help

Show this help message and exit.

-c [<NAME>]

Set component name to NAME. Default is basename of UI file.

-a

Set the window to always be on top.

-d

Enable debug output.

-v

Enable verbose debug output.

-q

Enable only error debug output.

-g [<GEOMETRY>]

Set geometry WIDTHxHEIGHT+XOFFSET+YOFFSET. Values are in pixel units, XOFFSET/YOFFSET is referenced from top left of screen. Use -g WIDTHxHEIGHT for just setting size or -g +XOFFSET+YOFFSET for just position. + Example: -g 200x400+0+100

-H [<FILE>]

Execute HAL statements from FILE with halcmd after the component is set up and ready.

-i

Enable info output.

-m

Force panel window to maximize.

-f

Force panel window to fullscreen.

-t [<THEME>]

Set Qt style. Default is system theme.

-x [<XID>]

Reparent QtVCP into an existing window XID instead of creating a new top level window.

--push_xid

Reparent window into a plug add push the plug xid number to standardout.

-u [<USERMOD>]

File path of user defined handler file.

-o [<USEROPTS>]

Pass *USEROPTS* strings to handler under self.w.USEROPTIONS_ list variable.

80.5. SEE ALSO

linuxcnc(1)

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at `/usr/share/doc/LinuxCNC/`.

80.6. BUGS

None known at this time.

80.7. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

80.8. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

80.9. COPYRIGHT

Copyright © 2020 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 81. rotarydelta(1)

81.1. NAME

rotarydelta - Vismach Virtual Machine GUI

81.2. DESCRIPTION

rotarydelta is one of the sample **Vismach** GUIs for LinuxCNC, simulating a delta robot with rotary actuators

See the main LinuxCNC documentation for more details. <https://linuxcnc.org/docs/html/gui/vismach.html>

81.3. SEE ALSO

linuxcnc(1)

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at /usr/share/doc/LinuxCNC/.

81.4. BUGS

None known at this time.

81.5. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

81.6. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

81.7. COPYRIGHT

Copyright © 2020 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 82. rs274(1)

82.1. NAME

rs274 - standalone G-code interpreter

82.2. SYNOPSIS

rs274 [-p interp.so] [-t tool.tbl] [-v var-file.var] [-n 0 | 1 | 2] [-b] [-s] [-g] [*input_file* [*output_file*]]

82.3. DESCRIPTION

rs274 Standalone G-code interpreter interface

Usage: **rs274** [-p interp.so] [-t tool.tbl] [-v var-file.var] [-n 0 | 1 | 2] [-b] [-s] [-g] [input file [output file]]

82.4. OPTIONS

-p

Specify the pluggable interpreter to use

-t

Specify the .tbl (tool table) file to use

-v

Specify the .var (parameter) file to use

-n

Specify the continue mode:

0: continue

1: enter MDI mode

2: stop (default)

-b

Toggle the *block delete* flag (default: OFF)

-s

Toggle the *print stack* flag (default: OFF)

-g

Toggle the *go (batch mode)* flag (default: OFF)

-i

specify the .ini file (default: no ini file)

-T

call task_init()

-l

specify the log_level (default: -1)

82.5. EXAMPLE

To see the output of a loop for example we can run rs274 on the following file and see that the loop never ends. To break out of the loop use Ctrl Z. The following two files are needed to run the example.

FIXME: Some good soul please fix the whitespace for the examples below

test.ngc

```
#<test> = 123.352
o101 while [[#<test> MOD 60 ] NE 0]
(debug,#<test>)
#<test> = [#<test> + 1]
101 endwhile
M2
```

test.tbl

```
T1 P1 Z0.511 D0.125 ;1/8 end mill
T2 P2 Z0.1 D0.0625 ;1/16 end mill
T3 P3 Z1.273 D0.201 ;#7 tap drill
```

command

```
rs274 -g test.ngc -t test.tbl
```

82.6. SEE ALSO

linuxcnc(1)

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at /usr/share/doc/LinuxCNC/.

82.7. BUGS

None known at this time.

82.8. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

82.9. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

82.10. COPYRIGHT

Copyright © 2020 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 83. rtapi_app(1)

83.1. NAME

rtapi_app - creates a simulated real time environment

83.2. SYNOPSIS

rtapi_app

83.3. DESCRIPTION

rtapi_app Creates a simulated real time environment.

Used for loading real time modules on systems without real time (for simulation).

83.4. SEE ALSO

linuxcnc(1)

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at `/usr/share/doc/LinuxCNC/`.

83.5. BUGS

None known at this time.

83.6. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

83.7. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

83.8. COPYRIGHT

Copyright © 2020 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 84. scaragui(1)

84.1. NAME

scaragui - Vismach Virtual Machine GUI

84.2. DESCRIPTION

scaragui is one of the sample **Vismach** GUIs for LinuxCNC, simulating a SCARA style robot arm.

See the main LinuxCNC documentation for more details.

<https://linuxcnc.org/docs/html/gui/vismach.html>

84.3. SEE ALSO

linuxcnc(1)

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at /usr/share/doc/LinuxCNC/.

84.4. BUGS

None known at this time.

84.5. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

84.6. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

84.7. COPYRIGHT

Copyright © 2020 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 85. schedrmt(1)

85.1. NAME

schedrmt - telnet based scheduler for LinuxCNC

85.2. SYNOPSIS

```
schedrmt [--port <port number> --name <server name> --connectpw <password> --enablepw  
<password> --sessions <max sessions> --path <path> -ini <INI file>]
```

85.3. DESCRIPTION

— **--port**

Waits for socket connections (Telnet) on specified socket, without port uses default port 5007.

— **--name <server name>**

Sets the server name to specified name for Hello.

— **--connectpw <password>**

Sets the connection password to *password*. Default *EMC*.

— **--enablepw <password>**

Sets the enable password to *password*. Default *EMCTOO*.

— **--sessions <max sessions>**

Sets the maximum number of simultaneous connexctions to max sessions. Default is no limit (-1).

— **--path**

Sets the base path to program (G-Code) files, default is "../nc_files/". Make sure to include the final slash (/).

— **-ini <INI file>**

Uses specified *INI file* instead of default *emc.ini*.

There are six commands supported, for which the commands set and get contain LinuxCNC-specific sub-commands based on the commands supported by emcsh, but where the "emc_" prefix is omitted. Commands and most parameters are not case-sensitive. The exceptions are passwords, file paths and text strings.

The supported commands are as follows:

=⇒ **HELLO** ⇐=

Hello <password> <client> <version>

If a valid password was entered the server will respond with HELLO ACK <Server Name> <Server Version>, here server name and server version are looked up from the implementation. If an invalid

password or any other syntax error occurs then the server responds with: **HELLO NAK**.

=⇒ Get ⇐=

The get command includes one of the emc sub-commands, described below and zero or more additional parameters.

=⇒ Set ⇐=

The set command includes one of the emc sub-commands, described below and one or more additional parameters.

=⇒ Quit ⇐=

The quit command disconnects the associated socket connection.

=⇒ Shutdown ⇐=

The shutdown command tells EMC to shutdown before quitting the connection. This command may only be issued if the Hello has been successfully negotiated and the connection has control of the CNC (see enable sub-command below). This command has no parameters. **=⇒ Help ⇐=** The help command will return help information in text format over the telnet connection. If no parameters are specified, it will itemize the available commands. If a command is specified, it will provide usage information for the specified command. Help will respond regardless of whether a "Hello" has been successfully negotiated.

EMC sub-commands:

echo on | off

With get will return the current echo state, with set, sets the echo state. When echo is on, all commands will be echoed upon receipt. This state is local to each connection.

verbose on | off

With get will return the current verbose state, with set, sets the verbose state. When in verbose mode is on, all set commands return positive acknowledgement in the form SET <COMMAND> ACK. In addition, text error messages will be issued when in verbose mode. This state is local to each connection.

enable <pwd> | off

With get will return On or Off to indicate whether the current connection is enabled to perform control functions. With set and a valid password, the current connection is enabled for control functions. **OFF** may not be used as a password and disables control functions for this connection.

config

TBD

comm_mode ascii | binary

With get, will return the current communications mode. With set, will set the communications mode to the specified mode. The binary protocol is TBD.

comm_prot <version no>

With get, returns the current protocol version used by the server. With set, sets the server to use the

specified protocol version, provided it is lower than or equal to the highest version number supported by the server implementation.

INIFILE

Returns the path and file name of the current configuration INI file.

plat

Returns the platform for which this was compiled, e.g., linux_2_0_36

ini <var> <section>

Returns the string value of <var> in section <section>, in EMC_INIFILE.

debug {<new value>}

With get, returns the integer value of EMC_DEBUG, in the EMC. Note that it may not be true that the local EMC_DEBUG variable here (in emcsh and the GUIs that use it) is the same as the EMC_DEBUG value in the EMC. This can happen if the EMC is started from one INI file, and the GUI is started with another that has a different value for DEBUG. With set, sends a command to the EMC to set the new debug level, and sets the EMC_DEBUG global here to the same value. This will make the two values the same, since they really ought to be the same.

QMode <mode> stop | run | pause | resume (Set only) | error (Get only)

With no arg, returns the program queue status as "stop", "run", "pause" or "error". Otherwise, sends a command to set the current mode to "stop", "run" or "pause".

QStatus <Queue Size> <First Tag Id> <Last Tag Id> <Queue CRC> (Get only)

Returns then number of programs in queue (Queue Size), the Tag id of the first program in the queue, the Tag id of the last program in the queue, and the CRC of all of the Tag Ids in the queue. The actual calculation of the CRC is not important, the purpose is to be able to compare the current CRC with the previous CRC. If they differ, then there has been a change to the size or order of the programs in queue.

AutoTagId <Start Id>

With get, returns the next autoincremented unique tag id to associate with a queue record. With set, resets auto tag generation to begin at the specified value.

PgmAdd <priority> <tag id> <x> <y> <z> <zone> <file name> <feed override> <spindle override> <tool>

With set, adds a program to the queue with priority of the program, a unique tag identifying the program, the x, y and z offsets or zone for the origin of the program, the path + file name, the feed and spindle overrides to apply, and the default tool to use. If tag id is zero, the tag id will be generated automatically. If zone is zero, then the x, y, and z offsets will be used, otherwise zones 1 to 9 correspond to G54 to G59.3 respectively.

PgmById <tag id> [priority] [tag id] [x] [y] [z] [zone] [file name] [feed override] [spindle override] [tool]

With get, returns the queue entry matching the specified tag id, including the priority, tag id, x, y, and z coordinates, the zone, file name, feed and spindle overrides and the default tool.

PgmByIndex <_index_> [*priority*] [*tag id*] [*x*] [*y*] [*z*] [*zone*] [*file name*] [*feed override*] [*spindle override*] [*tool*]

With get, returns the queue entry matching the specified index into the queue, including the priority, tag id, x, y, and z coordinates, the zone, file name, feed and spindle overrides and the default tool.

PgmAll

With get, performs effectively a PgmByIndex for every entry in the queue. Each result will be returned in the form: "PGMBYINDEX ..." with cr lf at the end of each record.

PriorityById <_tag id_> <_priority_>

With get, returns the priority of the queue entry matching the specified tag. With set, changes the priority of the queue entry to the specified priority.

PriorityByIndex <_tag id_> <_priority_>

With get, returns the priority of the queue entry matching the specified index into the queue. With set, changes the priority of the queue entry to the specified priority.

DeleteById <_tag id_>

With set, deletes the queue entry matching the specified tag id.

DeleteByIndex <_index_>

With set, deletes the queue entry matching the specified index into the queue.

PollRate <_rate_>

With set, sets the rate at which the scheduler polls for information. The default is 1.0 or one second.
With get, returns the current poll rate.

85.4. SEE ALSO

linuxcnc(1)

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at /usr/share/doc/LinuxCNC/.

85.5. BUGS

None known at this time.

85.6. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

85.7. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

85.8. COPYRIGHT

Copyright © 2020 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 86. scorbot-er-3(1)

86.1. NAME

scorbot-er-3 - to link the Intellitek Scorbot educational robot to LinuxCNC

86.2. DESCRIPTION

scorbot-er-3 is a non-realtime component that interfaces the control box of a Scorbot ER-3 robot arm to the LinuxCNC HAL.

Joint 0

rotation around the base

Joint 1

shoulder

Joint 2

elbow

Joint 3

wrist (+ is wrist up & rotate hand)

Joint 4

wrist (+ is wrist down & rotate hand)

Joint 5

unused

Joint 6

unused

Joint 7

hand open/close (+ is close)

86.3. SEE ALSO

linuxcnc(1)

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at `/usr/share/doc/LinuxCNC/`.

86.4. BUGS

None known at this time.

86.5. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

86.6. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

86.7. COPYRIGHT

Copyright © 2020 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 87. sendkeys(1)

87.1. NAME

sendkeys - send input events based on pins or scancodes from HAL

87.2. SYNOPSIS

loadusr sendkeys config=s8t5, 16, t12

87.3. DESCRIPTION

This component is intended as a partner component to `matrix_kb` or the `hostmot2 7i73` driver. It accepts the key-up and key-down event codes from either of these and converts them to keystrokes sent from a virtual keyboard.

It also allows for keystrokes to be generated by individual HAL pins.

The **config** parameter to the **loadusr** HAL command defines how many scancodes will be supported and how many individual pins are created.

config=s16 would support the 16 scancodes of a 4x4 matrix.

config=t10 would create 10 individual HAL pin triggers.

config=s16t10 would create one instance with both the above.

Multiple configs separated by commas will create multiple instances of the component. The accepted codes can be seen in the extract from the linux headers here: <https://wiki.linuxcnc.org/cgi-bin/wiki.pl?Scancodes>

The component requires the user to have write permissions to `/dev/uinput` which is not available by default. To give access perform the following:

1. Create the uinput group and add the LinuxCNC user to it:

```
sudo groupadd -f uinput
sudo gpasswd -a username uinput
```

2. Create a new entry in `.B/etc/udev/rules.d/99-input.rules`

```
sudo echo KERNEL=="uinput", GROUP="uinput", MODE:="0660" | sudo tee
/etc/udev/rules.d/88-input.rules
```

3. Reboot the machine. You can test that it has worked:

```
ls -l /dev/uinput
crw-rw---- 1 root uinput 10, 223 Nov 11 15:35 /dev/uinput
```

It is possible to link the 7i73 codes to both the `matrix_kb` comp and this comp, so that some codes operate

HAL pins and some send keystrokes. Where the option exists it is *MUCH* better to use HAL pins for things like jogging and machine control. This component should really be used only for text entry and GUI operations.

Each key on the matrix is allocated a scan code. The simplest way to configure the component is to load the component and open a halmeter showing `sendkeys.0.current-event`. Note the code for each physical key. (If keys do not give consistent results then you probably need to toggle the value of the `matrix_kb.0.negative-logic` pin and/or invert io pins).

Then edit the HAL file to assign a key event to each scancode. For example:

```
setp sendkeys.0.scan-event-21 34
```

To set a button to type the letter "G". The key events related to each physical key need to be set up prior to the component activating, but after the component is loaded.

To achieve this there is a pin `sendkeys.N.init` which should be set to "true" once the events to be sent for each scancode and pin have been set up.

To generate keystrokes from other sources note that a keydown is simply `0xC0 & keycode` and `keyup` is `0x80 & keycode`.

87.4. PINS

`sendkeys.N.keycode u32 in`

Connect to scancode generator.

`sendkeys.N.current-event s32 out`

Shows the current scancode without keyup / keydown markers.

`sendkeys.N.init bit in`

Set this pin TRUE once all the event parameters have been set.

87.5. PARAMETERS

`sendkeys.N.scan-event-MM u32 in`

Assign the uinput event codes associated with each scancode.

`sendkeys.N.pin-event-MM u32 in`

Assign the uinput codes associated with each HAL bit pin.

87.6. EXAMPLE

```
loadusr -W sendkeys config=16t2
net scancodes hm2_7i73.0.0.keycode => sendkeys.0.keycode

setp sendkeys.0.scan-event-00 34 # Key G
```

```
setp sendkeys.0.scan-event-01 2 # Key 1
setp sendkeys.0.scan-event-02 3 # Key 2
setp sendkeys.0.scan-event-03 4 # Key 3
setp sendkeys.0.scan-event-04 50 # Key M
setp sendkeys.0.scan-event-05 05 # Key 4
setp sendkeys.0.scan-event-06 06 # Key 5
setp sendkeys.0.scan-event-07 07 # Key 6
setp sendkeys.0.scan-event-08 31 # Key S
setp sendkeys.0.scan-event-09 8 # Key 7
setp sendkeys.0.scan-event-10 9 # Key 8
setp sendkeys.0.scan-event-11 10 # Key 9
setp sendkeys.0.scan-event-12 20 # Key T
setp sendkeys.0.scan-event-13 11 # Key 0
setp sendkeys.0.scan-event-14 52 # Key Dot
setp sendkeys.0.scan-event-15 14 # Backspace
setp sendkeys.0.pin-event-00 29 # Left Ctrl
setp sendkeys.0.pin-event-01 57 # Space
setp sendkeys.0.init 1

#Send Ctl + Space from one trigger
net clear-errors parport.0.pin.00.in sendkeys.0.trigger-00 sendkeys.0.trigger-01
```

87.7. AUTHOR

Andy Pugh

87.8. LICENSE

GPL-2.0+

Chapter 88. setup_designer(1)

88.1. NAME

setup_designer - A script to configure the system for use of Qt Designer

88.2. DESCRIPTION

Run the script **setup_designer** to prepare your system for custom GUI creation using the Qt toolset.

See the QtVCP documentation for more details.

88.3. SEE ALSO

linuxcnc(1)

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at `/usr/share/doc/LinuxCNC/`.

88.4. BUGS

None known at this time.

88.5. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

88.6. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>

88.7. COPYRIGHT

Copyright © 2023 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 89. shuttle(1)

89.1. NAME

shuttle - control HAL pins with the ShuttleXpress, ShuttlePRO, and ShuttlePRO2 device made by Contour Design

89.2. SYNOPSIS

loadusr shuttle [*DEVICE* ...]

89.3. DESCRIPTION

Shuttle is a non-realtime HAL component that interfaces Contour Design's ShuttleXpress, ShuttlePRO, and ShuttlePRO2 devices with LinuxCNC's HAL.

If the driver is started without command-line arguments, it will probe all `/dev/hidraw*` device files for Shuttle devices, and use all devices found. If it is started with command-line arguments, it will only probe the devices specified.

The ShuttleXpress has five momentary buttons, a 10 counts/revolution jog wheel with detents, and a 15-position spring-loaded outer wheel that returns to center when released.

The ShuttlePRO has 13 momentary buttons, a 10 counts/revolution jog wheel with detents, and a 15-position spring-loaded outer wheel that returns to center when released.

The ShuttlePRO2 has 15 momentary buttons, a 10 counts/revolution jog wheel with detents, and a 15-position spring-loaded outer wheel that returns to center when released.

89.4. UDEV

The shuttle driver needs read permission to the Shuttle devices' `/dev/hidraw*` device files. This can be accomplished by adding a file `/etc/udev/rules.d/99-shuttle.rules`, with the following contents:

```
SUBSYSTEM=="hidraw", ATTRS\{idVendor}=="0b33",
ATTRS\{idProduct}=="0020", MODE="0444"

SUBSYSTEM=="hidraw", ATTRS\{idVendor}=="05f3",
ATTRS\{idProduct}=="0240", MODE="0444"

SUBSYSTEM=="hidraw", ATTRS\{idVendor}=="0b33",
ATTRS\{idProduct}=="0030", MODE="0444"
```

The LinuxCNC Debian package installs an appropriate udev file automatically, but if you are building LinuxCNC from source and are not using the Debian packaging, you'll need to install this file by hand. If you install the file by hand you'll need to tell udev to reload its rules files by running `udevadm control --reload-rules`.

89.5. A warning about the Jog Wheel

The Shuttle devices have an internal 8-bit counter for the current jog-wheel position. The shuttle driver can not know this value until the Shuttle device sends its first event. When the first event comes into the driver, the driver uses the device's reported jog-wheel position to initialize counts to 0. This means that if the first event is generated by a jog-wheel move, that first move will be lost.

Any user interaction with the Shuttle device will generate an event, informing the driver of the jog-wheel position. So if you (for example) push one of the buttons at startup, the jog-wheel will work fine and notice the first click.

89.6. Pins

All HAL pin names are prefixed with `shuttle` followed by the index of the device (the order in which the driver found them), for example `shuttle.0` or `huttle.2`.

***(prefix).button-(number)* (bit out)**

***(prefix).button-(number)-not* (bit out)**

The momentary buttons. "(number)" identifies which button corresponds to the HAL pin. The "button-(number)" pins are True when the button is pushed, the "button-(number)-not" pins are True when the button is not pushed.

***(prefix).counts* (s32 out)**

Accumulated counts from the jog wheel (the inner wheel).

***(prefix).spring-wheel-s32* (s32 out)**

The current deflection of the spring-wheel (the outer wheel). It's 0 at rest, and ranges from -7 at the counter-clockwise extreme to +7 at the clockwise extreme.

***(prefix).spring-wheel-f* (float out)**

The current deflection of the spring-wheel (the outer wheel). It's 0.0 at rest, -1.0 at the counter-clockwise extreme, and +1.0 at the clockwise extreme. (The Shuttle devices report the spring-wheel position as an integer from -7 to +7, so this pin reports only 15 discrete values in its range.)

Chapter 90. sim-torch(1)

90.1. NAME

sim-torch - A simulated plasma torch

90.2. SYNOPSIS

loadusr Wn sim-torch sim-torch

90.3. DESCRIPTION

A simulated plasma torch for arc-ok testing.

VERSION:

0.1

90.4. PINS

sim-torch-rt.cut-noise-in float in (default: 0.75)

the maximum amount of noise during cutting (volts)

sim-torch-rt.cycles-in s32 in

the number of cycles that the arc voltage overshoots the cut voltage (cycles) (default: 200)

sim-torch-rt.on-delay-in s32 in

the time from turn on until overshoot begins (cycles) (default: 10)

sim-torch-rt.offset-in float in

the cut voltage offset(volts)

sim-torch-rt.overshoot-in s32 in

the percentage of the cut voltage that the arc voltage overshoots (percent) (default: 50)

sim-torch-rt.ramp-noise-in float in (default: 5)

the maximum amount of noise during overshoot (volts)

sim-torch-rt.ramp-up-in s32 in (default: 80)

percent of *cycles_in* that the arc voltage ramps up (percent)

sim-torch-rt.start bit in

start the arc

sim-torch-rt.voltage-in float in

the cut voltage (volts) (default: 100)

sim-torch-rt.voltage-out float out

output voltage (volts)

90.5. AUTHOR

Phillip A Carter & Gregory D Carl

90.6. LICENSE

GPLv2 or greater

Chapter 91. sim_pin(1)

91.1. NAME

sim_pin - GUI for displaying and setting one or more HAL inputs

91.2. SYNOPSIS

sim_pin [*Options*] *name1* [*name2* [*name3* ...]]

Options:

- **--help** (shows help text)
- **--title** *title_string*

For bit items, the name may include a /mode= specifier:

namei/mode=[**pulse** | **toggle** | **hold**] (default is toggle)

91.3. DESCRIPTION

HAL boolean items (bit) and numerical items (u32, s32, float) are supported.

If the named input is a numerical type, the GUI displays:

Entry

Entry widget for value or a valid Tcl expression.

Set

Pushbutton to set new value from Entry (or use <RETURN>).

Reset

Pushbutton to reset to the value present on initiation.

If the input is a **bit** type, the GUI shows a single pushbutton that is controlled by radio-button selectors:

- mode=**pulse** Pulse input to 1 for each pushbutton press.
- mode=**toggle** Toggle input for each pushbutton press.
- mode=**hold** Set input to 1 while pushbutton pressed.

If the bit item mode begins with an uppercase letter, the radio buttons for selecting other modes are not shown

91.4. NOTES

LinuxCNC or a standalone HAL application must be running

A named item can specify a **pin**, **param**, or **signal**. The named item must be writable:

pin IN or I/O (and not connected to a signal with a writer)

param RW

signal connected to a writable pin

91.5. USAGE

sim_pin can be used interactively from a shell command line or started automatically from a configuration INI file.

91.6. EXAMPLE

Example for INI file usage:

```
[APPLICATIONS]
DELAY = 5
APP = sim_pin \
    halui.machine.off/mode=pulse \
    ini.traj_arc_blend_enable \
    motion-command-handler-tmax
```

Chapter 92. simulate_probe(1)

92.1. NAME

simulate_probe - simulate a probe input

92.2. SYNOPSIS

simulate_probe

92.3. DESCRIPTION

simulate_probe Creates an on-screen GUI button to simulate touch probe input. Typically used in sim configs or debugging.

92.4. SEE ALSO

linuxcnc(1)

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at `/usr/share/doc/LinuxCNC/`.

92.5. BUGS

None known at this time.

92.6. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

92.7. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

92.8. COPYRIGHT

Copyright © 2020 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 93. stepconf(1)

93.1. NAME

stepconf - A configuration wizard for parallel-port based machines.

93.2. SYNOPSIS

stepconf

93.3. DESCRIPTION

stepconf aids in the configuration of machines using the parallel port interface.

Detailed docs: <https://linuxcnc.org/docs/html/config/stepconf.html>

93.4. SEE ALSO

linuxcnc(1)

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at `/usr/share/doc/LinuxCNC/`.

93.5. BUGS

None known at this time.

93.6. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

93.7. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

93.8. COPYRIGHT

Copyright © 2020 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 94. svd-ps_vfd(1)

94.1. NAME

svd-ps_vfd - HAL non-realtime component for SVD-P(S) VFDs

94.2. SYNOPSIS

svd-ps_vfd [*OPTIONS*]

94.3. DESCRIPTION

The svd-ps_vfd component interfaces a Soyans Power SVD-P(S) VFD to the LinuxCNC HAL. The VFD is connected via RS-485 to the LinuxCNC computer.

The SVD-P(S) VFDs are also sold under the LAPOND brand.

94.4. Hardware setup

The SVD-P(S) VFDs do not come with a Modbus daughterboard by default, it needs to be purchased separately.

94.5. Firmware setup

The sad-ps_vfd component uses standard Modbus protocol communication, which requires that one parameter be changed from the default settings:

PD-05 = 1 (Standard Modbus protocol)

The following settings have been tested successfully and are the default per Soyans documentation:

PD-00 = 6005 (9600 baud)

PD-01 = 0 (8N2)

PD-02 = 1 (Slave address)

PD-03 = 2 (Response delay)

PD-04 = 0 (Communication timeout)

PD-06 = 0 (Current resolution)

94.6. OPTIONS

-b, --bits *N*

For Modbus communication, set number of data bits to *N*. *N* must be between 5 and 8 inclusive.

(default 8) **-p, --parity** [Even,Odd,None] For Modbus communication, set serial parity to Even, Odd, or None. (default None)

-r, --rate *N*

For Modbus communication, set baud rate to *N*. It is an error if the rate is not one of the following: 1200, 2400, 4800, 9600, 19200, 38400 (default 9600)

-s, --stopbits [1,2]

For Modbus communication set serial stop bits to 1 or 2. (default 2)

-t, --target *N*

For Modbus communication, set Modbus target (slave) number. This must match the device number you set on the Huanyang GT VFD. (default 1)

-d, --device *PATH*

For Modbus communication, set the name of the serial device node to use. (default /dev/ttyS0)

-v, --verbose

Turn on verbose mode.

-S, --motor-max-speed *RPM*

The motor's max speed in RPM.

-F, --max-frequency *HZ*

This is the maximum output frequency of the VFD in Hz.

-f, --min-frequency *HZ*

This is the minimum output frequency of the VFD in Hz.

94.7. PINS

svd-ps_vfd.period (float, in)

The period for the driver's update cycle, in seconds. This is how frequently the driver will wake up, check its HAL pins, and communicate with the VFD. Must be between 0.001 and 2.000 seconds. Default: 0.1 seconds.

svd-ps_vfd.speed-cmd (float, in)

The requested motor speed, in RPM.

svd-ps_vfd.speed-fb (float, out)

The motor's current speed, in RPM, reported by the VFD.

svd-ps_vfd.at-speed (bit, out)

True when the drive is on and at the commanded speed (within 2%), False otherwise.

svd-ps_vfd.freq-cmd (float, out)

The requested output frequency, in Hz. This is set from the `.speed-cmd` value, and is just shown for

debugging purposes.

svd-ps_vfd.freq-fb (float, out)

The current output frequency of the VFD, in Hz. This is reported from the VFD to the driver.

svd-ps_vfd.spindle-on (bit, in)

Set this pin True to command the spindle on, at the speed requested on the `.speed-cmd` pin. Set this pin False to command the spindle off.

svd-ps_vfd.output-voltage (float, out)

The voltage that the VFD is current providing to the motor, in Volts.

svd-ps_vfd.output-current (float, out)

The current that the motor is currently drawing from the VFD, in Amperes.

hsvd-ps_vfd.output-power (float, out)

The power that the motor is currently drawing from the VFD, in Watts.

svd-ps_vfd.dc-bus-voltage (float, out)

The current voltage of the VFD's internal DC power supply, in Volts.

svd-ps_vfd.modbus-errors (u32, out)

A count of the number of modbus communication errors between the driver and the VFD. The driver is resilient against communication errors, but a large or growing number here indicates a problem that should be investigated.

svd-ps_vfd.input-terminal (float, out)

The VFD's input terminal register.

svd-ps_vfd.AI1 (float, out)

The VFD's AI1 register.

svd-ps_vfd.AI2 (float, out)

The VFD's AI2 register.

94.8. AUTHOR

Tinic Uro

94.9. LICENSE

GPL-2.0+

Chapter 95. teach-in(1)

95.1. NAME

teach-in - jog the machine to a position, and record the state

95.2. SYNOPSIS

teach-in [*> outfile*]

95.3. DESCRIPTION

teach-in is a script to learn set positions for later use by a script.

A dialog box is shown with options to choose the coordinate system. Each press of the "Learn" button outputs a line of text to stdout or the file chosen at load time.

Line format: line-no X Y Z flood mist spindle

95.4. SEE ALSO

linuxcnc(1)

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at `/usr/share/doc/LinuxCNC/`.

95.5. BUGS

None known at this time.

95.6. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

95.7. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

95.8. COPYRIGHT

Copyright © 2020 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 96. THERMISTOR(1)

96.1. NAME

thermistor - compute temperature indicated by a thermistor

96.2. SYNOPSIS

thermistor

96.3. DESCRIPTION

This component computes the temperature indicated by a thermistor in a voltage-divider ladder. It uses the Beta-parameter variant of the Steinhart-Hart equation, described here:

```
http://en.wikipedia.org/wiki/Thermistor
```

96.4. PINS

thermistor.N.t0-c float in

Reference temperature of the thermistor, in degrees Celsius (typically 25 C). This must be set before the component can compute the thermistor temperature. The reference temperature information is supplied by the thermistor manufacturer.

thermistor.N.r0 float in

Resistance of the thermistor at the reference temperature. This must be set before the component can compute the thermistor temperature. The reference resistance information is supplied by the thermistor manufacturer.

thermistor.N.beta float in

Beta parameter of the thermistor (sometimes just called B). This must be set before the component can compute the thermistor temperature. The Beta parameter is supplied by the thermistor manufacturer.

thermistor.N.r-other float in

Resistance of the other resistor in the voltage-divider ladder. This must be set before the component can compute the thermistor temperature.

thermistor.N.v-total float in

Supply voltage of the voltage-divider ladder.

thermistor.N.v-thermistor float in

Voltage drop across the thermistor.

thermistor.N.temperature-c float out

Temperature sensed by the thermistor, in degrees Celsius.

thermistor.N.temperature-k float out

Temperature sensed by the thermistor, in Kelvins.

thermistor.N.temperature-f float out

Temperature sensed by the thermistor, in degrees Fahrenheit.

thermistor.N.resistance float out

Computed resistance of the thermistor.

96.5. LICENSE

GPL

Chapter 97. tool_mmap_read(1)

97.1. NAME

tool_mmap_read - A component of the tool database system (an alternative to the classic tooltable)

97.2. DESCRIPTION

tool_mmap_read is not intended to be invoked by the user.

97.3. SEE ALSO

linuxcnc(1)*

See the Tool Database Interface section of the LinuxCNC Documentation for more information at <https://linuxcnc.org/docs/devel/html/tooldatabase/tooldatabase.html>.

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at /usr/share/doc/LinuxCNC/.

97.4. BUGS

None known at this time.

97.5. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

97.6. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

97.7. COPYRIGHT

Copyright © 2023 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 98. tool_watch(1)

98.1. NAME

tool_watch - A component of the tool database system (an alternative to the classic tooltable)

98.2. DESCRIPTION

tool_watch is not intended to be invoked by the user.

See the Tool Database Interface section of the LinuxCNC Documentation for more information.
<https://linuxcnc.org/docs/devel/html/tooldatabase/tooldatabase.html>

98.3. SEE ALSO

linuxcnc(1)*

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at /usr/share/doc/LinuxCNC/.

98.4. BUGS

None known at this time.

98.5. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

98.6. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>

98.7. COPYRIGHT

Copyright © 2023 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 99. tooledit(1)

99.1. NAME

tooledit - tool table editor

99.2. SYNOPSIS

tooledit

99.3. DESCRIPTION

tooledit a graphical tool table editor

99.4. SEE ALSO

linuxcnc(1)

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at `/usr/share/doc/LinuxCNC/`.

99.5. BUGS

None known at this time.

99.6. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

99.7. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

99.8. COPYRIGHT

Copyright © 2020 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 100. touchy(1)

100.1. NAME

touchy - TOUCHY LinuxCNC Graphical User Interface

100.2. SYNOPSIS

touchy -ini <INI file>

100.3. DESCRIPTION

touchy is one of the Graphical User Interfaces (GUI) for LinuxCNC. It gets run by the runscrip usually.

100.4. OPTIONS

INI file

The INI file is the main piece of an LinuxCNC configuration. It is not the entire configuration; there are various other files that go with it (NML files, HAL files, TBL files, VAR files). It is, however, the most important one, because it is the file that holds the configuration together. It can adjust a lot of parameters itself, but it also tells **LinuxCNC** which other files to load and use.

100.5. SEE ALSO

linuxcnc(1)

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at /usr/share/doc/LinuxCNC/.

100.6. BUGS

None known at this time.

100.7. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

100.8. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

100.9. COPYRIGHT

Copyright © 2020 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 101. update_ini(1)

101.1. NAME

update_ini - converts 2.7 format INI files to 2.8 format

101.2. SYNOPSIS

update_ini [-f] [-d] <INI file>_

101.3. DESCRIPTION

update_ini is run automatically by the "linuxcnc" script when an INI file in the pre-joints-axes format is opened.

-d causes a dialog box to be shown asking if the script should be run.

-f is designed for auto-conversion and will not create the backup files.

101.4. SEE ALSO

linuxcnc(1)

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at /usr/share/doc/LinuxCNC/.

101.5. BUGS

None known at this time.

101.6. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

101.7. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

101.8. COPYRIGHT

Copyright © 2020 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 102. vfdb_vfd(1)

102.1. NAME

vfdb_vfd - HAL non-realtime component for Delta VFD-B Variable Frequency Drives

102.2. SYNOPSIS

vfdb_vfd [OPTIONS]

102.3. DESCRIPTION

This manual page explains the **vfdb_vfd** component. This component reads and writes to the VFD-B device via a Modbus connection.

vfdb_vfd is for use with LinuxCNC.

102.4. QUICK START

The VFD-B ships in a configuration that can not talk to this driver. The VFD-B must be reconfigured via the face plate by the integrator before it will work. This section gives a brief description of what changes need to be made, consult your Delta VFD-B manual for more details.

Switch the VFD-B to Modbus RTU frame format

Switch parameter 09-04 from the factory default of 0 (Ascii framing) to 3, 4, or 5 (RTU framing). The setting you choose will determine several serial parameters in addition to the Modbus framing protocol.

Set the frequency control source to be Modbus, not the keypad

Switch parameter 02-00 from factory default of 00 (keypad control) to 5 (control from RS-485).

Set the run/stop control source to be Modbus, not the keypad

Switch parameter 02-01 from the factory default of 0 (control from keypad) to 3 (control from Modbus, with Stop enabled on the keypad).

102.5. OPTIONS

-n --name <halname>

set the HAL component name

-d --debug

Turn on debugging messages. Also toggled by sending a USR1 signal to the vfdb_vfd process.

-m --modbus-debug

Turn on Modbus debugging messages. This will cause all Modbus messages to be printed in hex on the terminal. Also toggled by sending a USR2 signal to the vfdb_vfd process.

-I --ini <INI file>

take configuration from this *INI file*. Defaults to environment variable INI_FILE_NAME. Most vfdb_vfd configuration comes from the INI file, not from command-line arguments.

-S --section <section name>

take configuration from this section in the INI file. Defaults to *VFD-B*.

-r --report-device

report device propertiers on console at startup

102.6. INI CONFIG VARIABLES

DEBUG

Set to a non-zero value to enable general debug output from the VFD-B driver. Optional.

MODBUS_DEBUG

Set to a non-zero value to enable modbus debug output from the VFD-B driver. Optional.

DEVICE

Serial port device file to use for Modbus communication with the VFD-B. Defaults to */dev/ttyS0*.

BAUD

Modbus baud rate. Defaults to 19200.

BITS

Modbus data bits. Defaults to 8.

PARITY

Modbus parity. Defaults to Even. Accepts *Even*, *Odd*, or *None*.

STOPBITS

Modbus stop bits. Defaults to 1.

TARGET

Modbus target number of the VFD-B to speak to. Defaults to 1.

POLLCYCLES

Only read the less important variables from the VFD-B once in this many poll cycles. Defaults to 10.

RECONNECT_DELAY

If the connection to the VFD-B is broken, wait this many seconds before reconnecting. Defaults to 1.

MOTOR_HZ, MOTOR_RPM

The frequency of the motor (in Hz) and the corresponding speed of the motor (in RPM). This information is provided by the motor manufacturer, and is generally printed on the motor's name plate.

102.7. PINS

<name>.at-speed (bit, out)

True when drive is at commanded speed (see *speed-tolerance* below)

<name>.enable (bit, in)

Enable the VFD. If False, all operating parameters are still read but control is released and panel control is enabled (subject to VFD setup).

<name>.frequency-command (float, out)

Current target frequency in HZ as set through speed-command (which is in RPM), from the VFD.

<name>.frequency-out (float, out)

Current output frequency of the VFD.

<name>.inverter-load-percentage (float, out)

Current load report from VFD.

<name>.is-e-stopped (bit, out)

The VFD is in emergency stop status (blinking "E" on panel).

<name>.is-stopped (bit, out)

True when the VFD reports 0 Hz output.

<name>.jog-mode (bit, in)

1 for ON and 0 for OFF, enables the VFD-B *jog mode*. Speed control is disabled. This might be useful for spindle orientation.

<name>.max-rpm (float, out)

Actual RPM limit based on maximum frequency the VFD may generate, and the motors nameplate values. For instance, if *nameplate-HZ* is 50, and *nameplate-RPM* is 1410, but the VFD may generate up to 80Hz, then *max-rpm* would read as 2256 ($80 \times 1410 / 50$). The frequency limit is read from the VFD at startup. To increase the upper frequency limit, the UL and FH parameters must be changed on the panel. See the VFD-B manual for instructions how to set the maximum frequency.

<name>.modbus-ok (bit, out)

True when the Modbus session is successfully established and the last 10 transactions returned without error.

<name>.motor-RPM (float, out)

Estimated current RPM value, from the VFD.

<name>.motor-RPS (float, out)

Estimated current RPS value, from the VFD.

<name>.output-voltage (float, out)

From the VFD.

<name>.output-current (float, out)

From the VFD.

<name>.speed-command (float, in)

Speed sent to VFD in RPM. It is an error to send a speed faster than the Motor Max RPM as set in the VFD.

<name>.spindle-on (bit, in)

1 for ON and 0 for OFF sent to VFD, only on when running.

<name>.max-speed (bit, in)

Ignore the loop-time parameter and run Modbus at maximum speed, at the expense of higher CPU usage. Suggested use during spindle positioning.

<name>.status (s32, out)

Drive Status of the VFD (see the VFD manual). A bitmap.

<name>.error-count (s32, out)

Total number of transactions returning a Modbus error.

<name>.error-code (s32, out)

Most recent Error Code from VFD.

<name>.frequency-limit (float, out)

Upper limit read from VFD setup.

102.8. PARAMETERS

<name>.loop-time (float, RW)

How often the Modbus is polled (default interval 0.1 seconds).

<name>.nameplate-HZ (float, RW)

Nameplate Hz of motor (default 50). Used to calculate target frequency (together with *nameplate-RPM*) for a target RPM value as given by speed-command.

<name>.nameplate-RPM (float, RW)

Nameplate RPM of motor (default 1410)

<name>.rpm-limit (float, RW)

Do-not-exceed soft limit for motor RPM (defaults to *nameplate-RPM*).

<name>.tolerance (float, RW)

Speed tolerance (default 0.01) for determining whether spindle is at speed (0.01 meaning: output frequency is within 1% of target frequency).

102.9. USAGE

The vfdb_vfd driver takes precedence over panel control while it is enabled (see **.enable** pin), effectively disabling the panel. Clearing the **.enable** pin re-enables the panel. Pins and parameters can still be set, but will not be written to the VFD until the **.enable** pin is set. Operating parameters are still read while bus control is disabled.

Exiting the vfdb_vfd driver in a controlled way will release the VFD from the bus and restore panel control.

See the LinuxCNC Integrators Manual for more information. For a detailed register description of the Delta VFD-B, see the VFD manual.

102.10. AUTHOR

Yishin Li; based on vfd11_vfd by Michael Haberler.

102.11. LICENSE

GPL

Chapter 103. vfs11_vfd(1)

103.1. NAME

vfs11_vfd - HAL non-realtime component for Toshiba-Schneider VF-S11 Variable Frequency Drives

103.2. SYNOPSIS

vfs11_vfd [OPTIONS]

103.3. DESCRIPTION

This manual page explains the **vfs11_vfd** component. This component reads and writes to the vfs11 via a Modbus connection.

vfs11_vfd is for use with LinuxCNC.

103.4. OPTIONS

-n --name <halname>

set the HAL component name

-d --debug

Turn on debugging messages. Also toggled by sending a USR1 signal to the vfs11_vfd process.

-m --modbus-debug

Turn on Modbus debugging messages. This will cause all Modbus messages to be printed in hex on the terminal. Also toggled by sending a USR2 signal to the vfs11_vfd process.

-I --ini <INI file>

takes configuration from this INI file. Defaults to environment variable INI_FILE_NAME.

-S --section <section name>

take configuration from this section in the INI file. Defaults to *VFS11*.

-r --report-device

Reports device propertiers on console at startup.

103.5. PINS

<name>.acceleration-pattern (bit, in)

when true, set acceleration and deceleration times as defined in registers F500 and F501 respectively. Used in PID loops to choose shorter ramp times to avoid oscillation.

<name>.alarm-code (s32, out)

non-zero if drive is in alarmed state. Bitmap describing alarm information (see register FC91 description). Use *err-reset* (see below) to clear the alarm.

<name>.at-speed (bit, out)

when drive is at commanded speed (see *speed-tolerance* below)

<name>.current-load-percentage (float, out)

Reported from the VFD.

<name>.dc-brake (bit, in)

Engage the DC brake. Also turns off spindle-on.

<name>.enable (bit, in)

Enable the VFD. If false, all operating parameters are still read but control is released and panel control is enabled (subject to VFD setup).

<name>.err-reset (bit, in)

Reset errors (alarms a.k.a Trip and e-stop status). Resetting the VFD may cause a 2-second delay until it's rebooted and Modbus is up again.

<name>.estop (bit, in)

Put the VFD into emergency-stopped status. No operation possible until cleared with *err-reset* or powercycling.

<name>.frequency-command (float, out)

Current target frequency in Hz as set through speed-command (which is in RPM), from the VFD.

<name>.frequency-out (float, out)

Current output frequency of the VFD.

<name>.inverter-load-percentage (float, out)

Current load report from VFD.

<name>.is-e-stopped (bit, out)

The VFD is in emergency stop status (blinking "E" on panel). Use *err-reset* to reboot the VFD and clear the e-stop status.

<name>.is-stopped (bit, out)

True when the VFD reports 0 Hz output

<name>.jog-mode (bit, in)

1 for ON and 0 for OFF, enables the VF-S11 *jog mode*. Speed control is disabled, and the output frequency is determined by register F262 (preset to 5 Hz). This might be useful for spindle orientation.

<name>.max-rpm (float, R)

Actual RPM limit based on maximum frequency the VFD may generate, and the motors nameplate values. For instance, if *nameplate-HZ* is 50, and *nameplate-RPM_* is 1410, but the VFD may generate up to 80Hz, then *max-rpm* would read as 2256 ($80 \times 1410 / 50$). The frequency limit is read from the VFD at startup. To increase the upper frequency limit, the UL and FH parameters must be changed on the panel. See the VF-S11 manual for instructions how to set the maximum frequency.

<name>.modbus-ok (bit, out)

True when the Modbus session is successfully established and the last 10 transactions returned without error.

<name>.motor-RPM (float, out)

Estimated current RPM value, from the VFD.

<name>.output-current-percentage (float, out)

from the VFD

<name>.output-voltage-percentage (float, out)

from the VFD

<name>.output-voltage (float, out)

from the VFD

<name>.speed-command (float, in)

Speed sent to VFD in RPM. It is an error to send a speed faster than the Motor Max RPM as set in the VFD.

<name>.spindle-fwd (bit, in)

1 for FWD and 0 for REV, sent to VFD.

<name>.spindle-on (bit, in)

1 for ON and 0 for OFF sent to VFD, only on when running.

<name>.spindle-rev (bit, in)

1 for ON and 0 for OFF, only on when running.

<name>.max-speed (bit, in)

Ignore the loop-time parameter and run Modbus at maximum speed, at the expense of higher CPU usage. Suggested use during spindle positioning.

<name>.status (s32, out)

Drive Status of the VFD (see the TOSVERT VF-S11 Communications Function Instruction Manual, register FD01). A bitmap.

<name>.trip-code (s32, out)

Trip code if VF-S11 is in tripped state.

<name>.error-count (s32, RW)

Total number of transactions returning a Modbus error.

103.6. PARAMETERS

<name>.frequency-limit (float, RO)

Upper limit read from VFD setup.

<name>.loop-time (float, RW)

How often the Modbus is polled (default interval 0.1 seconds)

<name>.nameplate-HZ (float, RW)

Nameplate Hz of motor (default 50). Used to calculate target frequency (together with *nameplate-RPM*) for a target RPM value as given by speed-command.

<name>.nameplate-RPM (float, RW)

Nameplate RPM of motor (default 1410)

<name>.rpm-limit (float, RW)

Do-not-exceed soft limit for motor RPM (defaults to *nameplate-RPM*).

<name>.tolerance (float, RW)

Speed tolerance (default 0.01) for determining whether spindle is at speed (0.01 meaning: output frequency is within 1% of target frequency).

103.7. USAGE

The `vfs11_vfd` driver takes precedence over panel control while it is enabled (see `_.enable`` pin), effectively disabling the panel. Clearing the `.enable` pin re-enables the panel. Pins and parameters can still be set, but will not be written to the VFD until the `.enable` pin is set. Operating parameters are still read while bus control is disabled.

Exiting the `vfs11_vfd` driver in a controlled will release the VFD from the bus and restore panel control.

See the LinuxCNC Integrators Manual for more information. For a detailed register description of the Toshiba VFDs, see the "TOSVERT VF-S11 Communications Function Instruction Manual" (Toshiba document number E6581222) and the "TOSVERT VF-S11 Instruction manual" (Toshiba document number E6581158).

103.8. AUTHOR

Michael Haberler; based on `gs2_vfd` by Steve Padnos and John Thornton.

103.9. LICENSE

GPL

Chapter 104. WJ200_VFD(1)

104.1. NAME

wj200_vfd - Hitachi wj200 modbus driver

104.2. SYNOPSIS

wj200_vfd

104.3. PINS

wj200-vfd.N.commanded-frequency float in

Frequency of vfd (scaled to RPM)

wj200-vfd.N.motor-frequency float out

Motor's actual frequency (scaled to RPM)

wj200-vfd.N.motor-reverse bit out

1 when actually turning in reverse

wj200-vfd.N.reverse bit in

1 when reverse 0 when forward

wj200-vfd.N.run bit in

run the vfd

wj200-vfd.N.enable bit in

1 to enable the vfd. 0 will remote trip the vfd, thereby disabling it.

wj200-vfd.N.is-running bit out

1 when running

wj200-vfd.N.is-at-speed bit out

1 when running at assigned frequency

wj200-vfd.N.is-stopped bit out

1 when stopped

wj200-vfd.N.is-ready bit out

1 when vfd is ready to run

wj200-vfd.N.is-alarm bit out

1 when vfd alarm is set

wj200-vfd.N.motor-current float out

Output current in amps

wj200-vfd.N.heatsink-temp float out

Temperature of drive heatsink

wj200-vfd.N.watchdog-out bit out

Alternates between 1 and 0 after every update cycle. Feed into a watchdog component to ensure vfd driver is communicating with the vfd properly.

104.4. PARAMETERS

wj200-vfd.N.mbslaveaddr u32 rw

Modbus slave address

wj200-vfd.N.frequency-scale float rw (default: 1)

RPM / frequency, default 1

104.5. LICENSE

GPLv2 or greater

Chapter 105. xhc-hb04-accels(1)

105.1. NAME

xhc-hb04-accels - Obsolete script for jogging wheel

105.2. SYNOPSIS

xhc-hb04-accels

105.3. DESCRIPTION

xhc-hb04-accels Obsolete script, xhc-hb04.tcl now controls reduced wheel jogging accels.

105.4. SEE ALSO

linuxcnc(1)

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at `/usr/share/doc/LinuxCNC/`.

105.5. BUGS

None known at this time.

105.6. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

105.7. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

105.8. COPYRIGHT

Copyright © 2020 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 106. xhc-hb04(1)

106.1. NAME

xhc-hb04 - HAL non-realtime component for the xhc-hb04 pendant.

106.2. DESCRIPTION

The xhc-hb04 component supports a common USB pendant that provides a number of pushbuttons, a manual pulse generator (mpg or jog wheel), and a selector switch for the wheel.

There are at least two hardware versions—one with 16 buttons and a more common one with 18 buttons. The information herein is based on the 18 button device with a USB Vendor:Product code of 10CE:EB70.

In addition to buttons, the pendant provides an LCD display for the current stepsize multiplier (from a set of available integer values), position (absolute and relative, labeled MC and WC respectively), feedrate (override percent and value in units per minute), and spindle speed (override percent and value in revolutions per minute (RPM)). The display is managed by a rotary switch that selects one of four axes for wheel positioning, feed override, spindle override, or OFF.

The pendant display, its rotary selector switch, and the component pin names use designators x,y,z,a. While this arrangement presumes a machine configured as XYZA, the pins can be assigned independently as required in a HAL configuration.

106.3. UDEV

The xhc-hb04 executable needs permission for reading the pendant's USB device. Debian package installs (debs) handle this automatically but Run-In-Place (RIP) builds may need a udev rules file. This file should be created (using sudo and a text editor) as:

```
/etc/udev/rules.d/99-xhc-hb04.rules with the single line:
```

```
ATTR{idProduct}=="eb70", ATTR{idVendor}=="10ce", MODE="0666", OWNER="root",  
GROUP="plugdev"
```

106.4. Standalone Usage

The xhc-hb04 program can be run from the command line without LinuxCNC to test a pendant in a simulation mode. This standalone mode is used to identify the button codes produced for each button press and to verify proper counting of the jog wheel. The identified button codes can be used to create a **button-cfg-file**. When a **button-cfg-file** exists, pendant operation can be verified using the -I option to specify the file.

Usage:

xhc -hb04 [*options*]

106.5. Options

-h

list command line options and exit

-I button-cfg-file

see below for file format

-H

run in real-time HAL mode (simulation mode is default)

-x

wait for pendant detection before creating HAL pins.

-s *n*

n is one of the following stepsize sequences

1: 1,10,100,1000 (default) 2: 1,5,10,20 3: 1,10,100 4: 1,5,10,20,50,100 5: 1,10,50,100,1000

The stepsize selected is always multiplied by 0.001.

106.6. button-cfg-file format

Standard configuration files are provided in the distribution for known button configurations:

```
/usr/share/linuxcnc/hallib/xhc-hb04-layout1.cfg
/usr/share/linuxcnc/hallib/xhc-hb04-layout2.cfg
or for a RIP build:
rip_base_dir/lib/hallib/xhc-hb04-layout1.cfg
rip_base_dir/lib/hallib/xhc-hb04-layout2.cfg
```

layout1 describes the 16 button pendant, layout2 describes the more common 18 button pendant.

The button configuration file follows the same format as INI files but should use a file suffix of .cfg.

```
File format:
[XHC-HB04]
BUTTON=X1:button-thename1
BUTTON=X2:button-thename2
BUTTON=X3:button-thename3
etc.
```

XN is the code reported for a button press and button-thenameN is the name to be assigned to the pin created for the button.

106.7. HAL Usage

Use the -H option to specify HAL mode and other options as required:

```
loadusr -W xhc-hb04 -H [options]
```

```
Example: loadusr -W xhc-hb04 -H -I path_to_cfg_file -s 2
```

106.8. Input Pins (Control)

xhc-hb04.stepsize-up (bit in)

A 1 pulse on this pin changes the stepsize to the next higher stepsize in the stepsize sequence specified in the xhc-hb04 (loadusr) command.

xhc-hb04.stepsize-down (bit in)

A 1 pulse on this pin changes the stepsize to the next lower stepsize in the stepsize sequence specified in the xhc-hb04 (loadusr) command.

106.9. Input Pins (to the pendant LCD display)

xhc-hb04.[xyza].pos-absolute (float in)

Absolute position display. The LCD display for pos-absolute is fixed format with a sign, 4 number digits and 3 fraction digits (+XXXX.XXX), require: $-9999.999 \leq \text{value} \leq 9999.999$ (typically connect to: `halui.axis.N.pos-feedback`).

xhc-hb04.[xyza].pos-relative (float in)

Relative position display (typically connect to: `halui.axis.N.pos-relative`). The LCD display for pos-relative is fixed format with a sign, 4 number digits and 3 fraction digits (+XXXX.XXX), require: $-9999.999 \leq \text{value} \leq 9999.999$.

xhc-hb04.feed-override (float in)

Feed-override value. The float value is converted to a 16 bit integer and multiplied by 100 in order to display as percent, require: $0 \leq \text{pinvalue} \leq 655$ (typically connect to: `halui.feed-override.value`).

xhc-hb04.feed-value (float in)

Current Feed-value (units/sec). The float value is converted to a 16 bit integer and multiplied by 60 in order to display as units-per-minute, require: $0 \leq \text{pinvalue} \leq 1092$ (65520 units-per-minute) (typically connect to: `motion.current-vel`).

xhc-hb04.spindle-override (float in)

Spindle-override value. The float value is converted to a 16 bit integer and multiplied by 100 in order to display as percent, require: $0 \leq \text{pinvalue} \leq 655$ (typically connect to: `halui.spindle-override.value`).

xhc-hb04.spindle-rps (float in)

Spindle speed in RPS (revolutions per second). The float value is converted to a 16 bit integer and multiplied by 60 in order to display as RPMs, require: $0 \leq \text{pinvalue} \leq 1092$ (65520 RPM) (typically connect to: `spindle.N.speed-out-rps-abs`).

xhc-hb04.inch-icon (bit in)

Use inch icon (default is mm):

106.10. Output Pins (Status)

xhc-hb04.sleeping (bit out)

True when the driver receives a pendant inactive (sleeping) message.

xhc-hb04.jog.enable-off (bit out)

True when the pendant rotary selector switch is in the OFF position or when the pendant is sleeping.

xhc-hb04.enable-[xyza] (bit out)

True when the pendant rotary selector switch is in the [xyza] position and not sleeping.

xhc-hb04.enable-spindle-override (bit out)

True when the pendant rotary selector switch is in the Spindle position and not sleeping (typically connect to: halui.spindle-override-count-enable).

xhc-hb04.enable-feed-override (bit out)

True when the pendant rotary selector switch is in the feed position and not sleeping (typically connect to: halui.feed-override-count-enable).

xhc-hb04.connected (bit out)

True when connection to the pendant is established over the USB interface.

xhc-hb04.require_pendant (bit out)

True if driver started with the -x option.

xhc-hb04.stepsize (s32 out)

Current stepsize in the stepsize sequence as controlled by the stepsize-up and/or stepsize-down pins.

106.11. Output Pins (for jogging using axis.N.jog-counts)

xhc-hb04.jog.counts (s32 out)

Number of counts of the wheel since start-up (50 counts per wheel revolution) (typically connect to **axis.N.jog-counts** (lowpass filtering may be helpful)).

xhc-hb04.jog.counts-neg (s32 out)

The value of the **xhc-hb04.jog.counts** multiplied by -1.

xhc-hb04.jog.scale (float out)

Value is the current stepsize multiplied by 0.001 (typically connect to **axis.N.jog-scale**).

106.12. Experimental: Pins for halui plus/minus jogging.

These pins provide some support for non-trivkins, world mode jogging.

xhc-hb04.jog.max-velocity (float in)

Connect to halui.max-velocity.value.

xhc-hb04.jog.velocity (float out)

Connect to halui.jog-speed.

xhc-hb04.jog.plus-[xyza] (bit out)

Connect to halui.jog.N.plus.

xhc-hb04.jog.minus-[xyza] (bit out)

Connect to halui.jog.N.minus.

xhc-hb04.jog.increment (float out)

Debug pin — abs(delta_pos).

106.13. Button output pins (for the 18 button, layout2 pendant)

The output bit type pins are TRUE when the button is pressed.

```
ROW 1
  (bit out) xhc-hb04.button-reset
  (bit out) xhc-hb04.button-stop

ROW 2
  (bit out) xhc-hb04.button-goto-zero
  (bit out) xhc-hb04.button-rewind
  (bit out) xhc-hb04.button-start-pause
  (bit out) xhc-hb04.button-probe-z

ROW 3
  (bit out) xhc-hb04.button-spindle
  (bit out) xhc-hb04.button-half
  (bit out) xhc-hb04.button-zero
  (bit out) xhc-hb04.button-safe-z

ROW 4
  (bit out) xhc-hb04.button-home
  (bit out) xhc-hb04.button-macro-1
  (bit out) xhc-hb04.button-macro-2
  (bit out) xhc-hb04.button-macro-3

ROW 5
  (bit out) xhc-hb04.button-step
  (bit out) xhc-hb04.button-mode
  (bit out) xhc-hb04.button-macro-6
  (bit out) xhc-hb04.button-macro-7
```

106.14. Synthesized button pins

Additional buttons are synthesized for buttons named **zero**, **goto-zero**, and **half**. These synthesized

buttons are active when the button is pressed AND the selector-switch is set to the corresponding axis [xyza].

```
(bit out) xhc-hb04.button-zero-[xyza]
(bit out) xhc-hb04.button-goto-zero-[xyza]
(bit out) xhc-hb04.button-half-[xyza]
```

106.15. DEBUGGING

For debugging USB activity, use environmental variable LIBUSB_DEBUG:

export LIBUSB_DEBUG=[2 | 3 | 4]; xhc-hb04 [options]

2:warning, 3:info, 4:debug

106.16. Sim Configs

The distribution includes several simulation configurations in the directory:

```
/usr/share/doc/linuxcnc/examples/sample-configs/sim/axis/xhc-hb04/
or for a RIP build:
rip_base_dir/configs/sim/axis/xhc-hb04/
```

These configurations use a distribution-provided script (xhc-hb04.tcl) to configure the pendant and make necessary HAL connections according to a number of INI file settings. The script uses an additional HAL component (xhc_hb04_util) to provide common functionality and includes support for a standard method for the start-pause button.

The settings available include: * Specify button-cfg-file for standard layout1 or layout2, * select axes (up to 4 axes from set of x y z a b c u v w), * implement per-axis filtering coefficients, * implement per-axis acceleration for mpg jogging, * implement per-axis scale settings, * select normal or velocity based jog modes, * select stepsize sequence, * option to initialize pin for inch or mm display icon, * option to require pendant on startup.

The sim configs illustrate button connections that: * Connect pendant stepsize-up button to the step input pin, * connect buttons to halui.* pins, * connect buttons to motion.* pins.

Another script is included to monitor the pendant and report loss of USB connectivity. See the README and .txt files in the above directory for usage.

106.16.1. Note

The sim configs use the AXIS GUI but the scripts are available with any HAL configuration or GUI. The same scripts can be used to adapt the xhc-hb04 to existing configurations provided that the halui, motion, and axis.N pins needed are not otherwise claimed. Instructions are included in README file in the directory named above.

Use halcmd to display the pins and signals used by the xhc-hb04.tcl script:

```
halcmd show pin xhc-hb04      (show all xhc-hb04 pins)
halcmd show pin pendant_util  (show all pendant_util pins)
halcmd show sig pendant:      (show all pendant signals)
```

106.17. AUTHOR

Frederick Rible (frible@teaser.fr)

Chapter 107. xhc-whb04b-6(1)

107.1. NAME

xhc-whb04b-6 - Non-realtime jog dial HAL component for the wireless XHC WHB04B-6 USB device.

107.2. SYNOPSIS

xhc-whb04b-6 [-h] | [-H] [OPTIONS]

107.3. DESCRIPTION

The xhc-whb04b-6 HAL component supports the XHC WHB04B-6, a 6-axis wireless USB pendant. It provides a number of push-buttons, a jogwheel, two rotary buttons for axis and speed / step selection and an ordinary LCD display.

The LCD display, having a very simple firmware interface, indicates the following listed information only. No other information, such as custom data, can be printed.

- Activated axis (X, Y, Z, A, B or C)
- Current axis position of X, Y, Z and separately of A, B, C.
- Whether machine (X, Y, Z, A, B or C) or relative (X1, Y1, Z1, A1, B1 or C1) coordinates are displayed.
- Step size or velocity depending on the operating mode (MPG or Step or Continuous).
- Feedrate override
- Spindle Feedrate override
- Machine state such as reset.
- Battery level
- Wireless signal strength

The pendant display, its rotary selector switch, and the component pin names use designators x, y, z, a, b and c. While this arrangement presumes a machine configured as X, Y, Z, A, B and C, the pins can be assigned independently as required in a HAL configuration.

107.4. OPTIONS

-h, --help

Prints the synopsis and the most commonly used commands.

-H

Run xhc-whb04b-6 in HAL-mode instead of interactive mode. When in HAL mode commands from device will be exposed to HAL's shared memory. Interactive mode is useful for testing device connectivity and debugging.

-s

Lead + jogwheel changes the spindle override speed. Each tick will increase/decrease the spindle override.

-f

MPG + jogwheel changes the feed override. Each tick will increment/decrement the feed override.

-B

Add 5 mm and 10 mm to Step feedrate output

-t

Wait with timeout for USB device then proceed, exit otherwise. Without -t the timeout is implicitly infinite.

-u, -U

Show received data from device. With -U received and transmitted data will be printed. Output is prefixed with "usb".

-p

Show HAL pins and HAL related messages. Output is prefixed with "hal".

-e

Show captured events such as button pressed/released, jog dial, axis rotary button, and feed rotary button event. Output is prefixed with "event".

-a

Enable all logging facilities without explicitly specifying each.

-c

Enable checksum output which is necessary for debugging the checksum generator function. Do not rely on this feature since it will be removed once the generator is implemented.

-n

Force being silent and not printing any output except of errors. This will also inhibit messages prefixed with "init".

107.5. UDEV

The `xhc-whb04b-6` executable needs permission for reading the pendant's USB device. There may be the need for additional udev rules. If so, this file

`/etc/udev/rules.d/99-xhc-whb04b-6.rules`

should be created with the single line

```
ATTR{idProduct}=="eb93", ATTR{idVendor}=="10ce", MODE="0666", OWNER="root",  
GROUP="plugdev".
```

107.6. Standalone Usage

The **xhc-whb04b-6** program can be run from the command line without LinuxCNC to test a pendant. This standalone mode is used to identify the button codes produced for each button press and debug transmitted USB data.

107.6.1. EXAMPLES

xhc-whb04b-6 -ue

Start in simulation mode and prints incoming USB data transfer and generated key pressed/released events.

xhc-whb04b-6 -p

Start in simulation mode and prints HAL pin names and events distributed to HAL memory.

xhc-whb04b-6 -H

Start in HAL mode (Normal mode for real machine use).

xhc-whb04b-6 -HsfB

Start in HAL mode + Spindle Override + Feedrate Override + Big step (5/10 mm).

107.7. HAL Usage

Use the -H option to specify HAL mode and other options as required:

```
loadusr -W xhc-whb04b-6 -HsfB
```

107.7.1. Input/Output Signals

Note: For each button an output pin is provided even if no functionality is realized with that signal. For example, to stop a running program the Stop button pin may be directly connected to **halui.program.stop**. However, to start/pause/resume a program, the corresponding button toggles besides **whb.button.start-pause** also the ```whb.halui.program.``{run,pause,resume}` signals accordingly.

Note: The Spindle+/Spindle- buttons do manipulate the spindle override. The spindle speed is set with the respective combos Fn + Spindle⁻ and FN + Spindle⁺.

The following tables list all in-/output pins and state which signals they are meant to be connected to.

Axis and Stepgen

Signals utilized for moving axis.

<N> ... denotes the axis number, which is of {x, y, z, a, b, c}.

whb.halui.home-all (bit,out)

connect to **halui.home-all**, driven by M-Home. Pin for requesting all axis to home. See also

`whb.button.m-home.`

`whb.halui.axis._<N>_select (bit,out)`

connect to `halui.axis._<N>_select`. Pin to select axis.

`whb.axis._<N>_jog-counts (s32,out)`

connect to `axis._<N>_jog-counts`. The count pin of the jogwheel.

`whb.axis._<N>_jog-enable (bit,out)`

connect to `axis._<N>_jog-enable`. If true (and in manual mode), any change to "jog-counts" will result in motion. If false, "jog-counts" is ignored.

`whb.axis._<N>_jog-scale (float,out)`

connect to `axis._<N>_jog-scale`. The distance to move for each count on "jog-counts", in machine units.

`whb.axis._<N>_jog-vel-mode (bit,out)`

connect to `axis._<N>_jog-jog-vel-mode`. If false the jogwheel operates in position mode. The axis will move exactly jog-scale units for each count, regardless of how long that might take. If true, the jogwheel operates in velocity mode - motion stops when the wheel stops, even if that means the commanded motion is not completed.

`whb.halui.max-velocity.value (float,in)`

connect to `halui.max-velocity.value`. The maximum allowable velocity, in units per second (<N> is two digit 0-padded).

`whb.halui.feed-override.scale (float,in)`

connect to `halui.feed-override.scale`. The scaling for feed override value.

`whb.halui.axis._<N>_pos-feedback` (float,in)`

connect to `halui.axis._<N>_pos-feedback`. Feedback axis position in machine coordinates to be displayed.

`whb.halui.axis._<N>_pos-relative (float,in)`

connect to `halui.axis._<N>_pos-relative`. Commanded axis position in relative coordinates to be displayed.

Machine

Signals utilized for toggling machine status.

`whb.halui.machine.on (bit,out)`

Connect to `halui.machine.on`. Pin for requesting machine on.

`whb.halui.machine.is-on (bit,in)`

Connect to `halui.machine.is-on`. Pin that indicates machine is on.

whb.halui.machine.off (bit,out)

Connect to `halui.machine.off`. Pin for requesting machine off.

Spindle

Signals utilized for operating a spindle.

whb.halui.spindle.start (bit,out)

Connect to `halui.spindle.0.start`. Pin to start the spindle.

whb.halui.spindle.is-on (bit,in)

Connect to `halui.spindle.0.on`. Pin to indicate spindle is on (either direction).

whb.halui.spindle.stop (bit,out)

Connect to `halui.spindle.0.stop`. Pin to stop the spindle.

whb.halui.spindle.forward (bit,out)

Connect to `halui.spindle.0.forward`. Pin to make the spindle go forward.

whb.halui.spindle.reverse (bit,out)

Connect to `halui.spindle.0.reverse`. Pin to make the spindle go reverse.

whb.halui.spindle.decrease (bit,out)

Connect to `halui.spindle.0.decrease`. Pin to decrease the spindle speed.

whb.halui.spindle.increase (bit,out)

Connect to `halui.spindle.0.increase`. Pin to increase the spindle speed.

whb.halui.spindle-override.increase (bit,out)

Connect to `halui.spindle.0.override.increase`. Pin for increasing the spindle override by the amount of scale.

whb.halui.spindle-override.decrease (bit,out)

Connect to `halui.spindle.0.override.decrease`. Pin for decreasing the spindle override by the amount of scale.

whb.halui.spindle-override.value (float,in)

Connect to `halui.spindle.0.override.value`. The current spindle override value.

whb.halui.spindle-override.scale (float,in)

Connect to `halui.spindle.0.override.scale`. The current spindle scaling override value.

Feed

Signals utilized for operating spindle and feed override. The feed rotary button can serve in

- Continuous move x% from max velocity
 - Step move x mm
-

- MPG override feed/spindle
- The special position Lead.

Continuous: In this mode jogging is performed at the selected feed rate. As long the jogwheel turns, the selected axis moves.

Step: In this mode the machine moves steps * wheel_counts at the currently selected step size and the current set feed rate in machine units. If the commanded position is not reached the machine keeps moving even the jogwheel is not turning.

Lead: Manipulates the spindle override.

MPG: Manipulates the feedrate override.

Note: As a consequence of 3 modes from manufacturer, switching the feed rotary button back from Lead revert to MPG mode, MPG mode is default mode at startup. Depending on the mode before turning the rotary button, the feed override results in different values. In MPG/CON the feed rate will change to 100%, 60%, ... and so forth. In Step mode the feed rate is specified in mm.

whb.halui.feed-override.value (float,in)

Connect to `halui.feed-override.value`. The current feed override value.

whb.halui.feed-override.decrease (bit,out)

Connect to `halui.feed-override.decrease`. Pin for decreasing the feed override by amount of scale.

whb.halui.feed-override.increase (bit,out)

Connect to `halui.feed-override.increase`. Pin for increasing the feed override by amount of scale.

whb.halui.feed-override.scale (float,out)

Connect to `halui.feed-override.scale`. Pin for setting the scale on changing the feed override.

whb.halui.max-velocity.value (float,out)

Connect to `halui.max-velocity.value`.

Program

Signals for operating program and MDI mode.

whb.halui.program.run (bit,out)

Connect to `halui.program.run` in for running a program.

whb.halui.program.is-running (bit,in)

Connect to `halui.program.is-running` in indicating a program is running.

whb.halui.program.pause (bit,out)

Connect to `halui.program.pause`. Pin for pausing a program.

whb.halui.program.is-paused (bit,in)

Connect to `halui.program.is-paused`. Pin indicating a program is pausing.

whb.halui.program.resume (bit,out)

Connect to `halui.program.resume`. Pin for resuming a program.

whb.halui.program.stop (bit,out)

Connect to `program.stop`. Pin for stopping a program.

whb.halui.program.is-idle (bit,in)

Connect to `halui.program.is-idle`. Pin indicating no program is running.

whb.halui.mode.auto (bit,out)

Connect to `halui.mode.auto`. Pin for requesting auto mode.

whb.halui.mode.is-auto (bit,in)

Connect to `halui.mode.is-auto`. Pin for indicating auto mode is on.

whb.halui.mode.joint (bit,out)

Connect to `halui.mode.joint` Pin for requesting joint by joint mode.

whb.halui.mode.is-joint (bit,in)

Connect to `halui.mode.is-joint`. Pin indicating joint by joint mode is on.

whb.halui.mode.manual (bit,out)

Connect to `halui.mode.manual`. Pin for requesting manual mode.

whb.halui.mode.is-manual (bit,in)

Connect to `halui.mode.is-manual`. Pin indicating manual mode is on.

whb.halui.mode.mdi (bit,out)

Connect to `halui.mode.mdi`. Pin for requesting MDI mode.

whb.halui.mode.is-mdi (bit,in)

Connect to `halui.mode.is-mdi`. Pin indicating MDI mode is on.

whb.halui.mode.teleop (bit,out)

Connect to `halui.mode.teleop`. Pin for requesting axis by axis mode.

whb.halui.mode.is-teleop (bit,in)

Connect to `halui.mode.is-teleop`. Pin indicating axis by axis mode is on.

Buttons

For flexibility reasons each button provides an output pin even if no functionality is realized directly with that signal. The Fn button can be combined with each other push-button. This includes also RESET, Stop, Start/Pause, Macro-10, and Step|Continuous. By default the more frequent used orange buttons are executed, whereas blue ones (` whb.button.macro-` <M>) by combining them with Fn (press Fn first then button).

Button macro needs to be added to your INI and needs to be edited for your own use:

```
[HALUI]
MDI_COMMAND=(debug,macro0) # this one is for numbering but not used by pendant (need 1
to 16)
MDI_COMMAND=(debug,macro1)
MDI_COMMAND=(debug,macro2)
MDI_COMMAND=(debug,macro3)
MDI_COMMAND=(debug,macro4)
MDI_COMMAND=(debug,macro5)
MDI_COMMAND=(debug,macro6)
MDI_COMMAND=(debug,macro7)
MDI_COMMAND=(debug,macro8)
MDI_COMMAND=(debug,macro9)
MDI_COMMAND=(debug,macro10)
MDI_COMMAND=(debug,macro11)
MDI_COMMAND=(debug,macro12)
MDI_COMMAND=(debug,macro13)
MDI_COMMAND=(debug,macro14)
MDI_COMMAND=(debug,macro15)
MDI_COMMAND=(debug,macro16)
```

<M> ... denotes an arbitrary macro number which is of {1, 2, ..., 16}

whb.button.reset (bit,out)

See **whb.halui.estop**.{**activate**, **reset**} True one Reset button down, false otherwise. For toggling E-stop use **whb.halui.estop** .**active** and .**reset**.

whb.button.stop (bit,out)

See **whb.halui.program.stop**. True on Stop button down, false otherwise. For stopping a program use **whb.halui.program.stop**.

whb.button.start-pause (bit,out)

See **whb.halui.program**.{**run**, **pause**, **resume**}. True on Start-Pause button down, false otherwise. For toggling start-pause use **`whb.halui.program.run**, .**pause**, and .**resume**.

whb.button.feed-plus (bit,out)

True on Feed+ button down, false otherwise.

whb.button.feed-minus (bit,out)

True on Feed- button down, false otherwise.

whb.button.spindle-plus (bit,out)

See **halui.spindle.0.override.increase**. True on Spindle+ button down, false otherwise. This button is meant to manipulate the spindle override. For increasing the spindle override use **halui.spindle.0.override.increase**.

whb.button.spindle-minus (bit,out)

See **halui.spindle.0.override.decrease**. True on Spindle- button down, false otherwise. This button is meant to manipulate the spindle override. For decreasing the spindle override use **halui.spindle.0.override.decrease**.

whb.button.m-home (bit,out)

Connect to `halui.home-all`. True on M-Home button down, false otherwise. Requests MDI mode before button pin is set. See also `whb.halui.mode.mdi`.

whb.button.safe-z (bit,out)

Connect to `halui.mdi-command-`__<M>__` True on Safe-Z button down, false otherwise. Requests MDI mode before button pin is set. See also ``whb.halui.mode.mdi`.

whb.button.w-home (bit,out)

Connect to `halui.mdi-command-`__<M>__` True on W-Home button down, false otherwise. Requests MDI mode before button pin is set. See also ``whb.halui.mode.mdi`.

whb.button.s-on-off (bit,out)

See ``whb.halui.spindle.``{``start``, ``stop``}` True on S-ON/OFF button down, false otherwise. For toggling spindle on-off use `halui.spindle.0.start`. For toggling spindle on-off use `halui.spindle.0.stop`.

whb.button.fn (bit,out)

True on Fn button down, false otherwise.

whb.button.probe-z (bit,out)

Connect to `halui.mdi-command-`__<M>__` True on Probe-Z button down, false otherwise. Requests MDI mode before button pin is set. See also ``whb.halui.mode.mdi`.

whb.button.macro-1 (bit,out)

Connect to ``halui.mdi-command-`<M>` True on Macro-1 button (Fn + Feed+) down, false otherwise.

whb.button.macro-2 (bit,out)

Connect to ``halui.mdi-command-`<M>` True on Macro-2 button (Fn + Feed-) down, false otherwise.

whb.button.macro-3 (bit,out)

See `whb.halui.spindle.increase` True on Macro-3 button (Fn + Spindle+) down, false otherwise. This button is meant to manipulate the spindle speed. For decreasing the spindle speed use `whb.halui.spindle.increase`.

whb.button.macro-4 (bit,out)

See `whb.halui.spindle.decrease` True on Macro-4 button down (Fn + Spindle-), false otherwise. This button is meant to manipulate the spindle speed. For decreasing the spindle speed use `whb.halui.spindle.decrease`.

whb.button.macro-5 (bit,out)

Connect to ``halui.mdi-command-`<M>` True on Macro-5 button down (Fn + M-HOME), false otherwise.

whb.button.macro-6 (bit,out)

Connect to ``halui.mdi-command-`<M>` True on Macro-6 button down (Fn + Safe-Z), false otherwise.

whb.button.macro-7 (bit,out)

Connect to `halui.mdi-command-`<M> True on Macro-7 button down (Fn + W-HOME), false otherwise.

whb.button.macro-8 (bit,out)

Reserved for Spindle Direction True on Macro-8 button down (Fn + S-ON/OFF), false otherwise.

whb.button.macro-9 (bit,out)

Connect to `halui.mdi-command-`<M> True on Macro-9 button down (Fn + Probe-Z), false otherwise.

whb.button.macro-10 (bit,out)

Reserved for toggle DRO Abs/rel. True on Macro-10 button down, false otherwise. Switches the display coordinates to relative coordinates. On display the axis are denoted then as X1, Y1, Z1, A1, B1 and C1. See also `whb.halui.axis.`__<N>__.pos-relative``.

whb.button.macro-11 (bit,out)

Connect to `halui.mdi-command-`<M> True on Macro-11 button down (Fn + RESET), false otherwise.

whb.button.macro-12 (bit,out)

Connect to `halui.mdi-command-`<M> True on Macro-12 button (Fn + Stop) down, false otherwise.

whb.button.macro-13 (bit,out)

Connect to `halui.mdi-command-`<M> True on Macro-13 button (Fn + Start/Pause) down, false otherwise.

whb.button.macro-14 (bit,out)

Connect to `halui.mdi-command-`<M> True on Macro-14 button (Fn + Macro-10) down, false otherwise.

whb.button.macro-15 (bit,out)

Connect to `halui.mdi-command-`<M> True on Macro-15 button down (Fn + MPG), false otherwise.

whb.button.macro-16 (bit,out)

Connect to `halui.mdi-command-`<M> True on Macro-16 button (Fn + Step) down, false otherwise.

whb.button.mode-continuous (bit,out)

True on Continuous mode button down, false otherwise.

whb.button.mode-step (bit,out)

True on Step mode button down, false otherwise.

Pendant**whb.pendant.is-sleeping (bit,out)**

True as long pendant is in sleep mode (usually a few seconds after turned off), false otherwise.

whb.pendant.is-connected (bit,out)

True as long pendant is not in sleep mode (turned on), false otherwise.

107.8. HAL Configuration Example

Exercise caution if using copy and paste of this example code from the online web docs. Certain characters are incompatibly encoded by the web site (minus becomes em-dash). It is safer to copy and paste from https://raw.githubusercontent.com/LinuxCNC/linuxcnc/devel/src/hal/user_comps/xhc-whb04b-6/example-configuration.md.

```
#
### Hal File xhc_whb04b_6.hal Example
#
# #####
# load pendant components
# #####

loadusr -W xhc-whb04b-6 -HsfB

# #####
# pendant signal configuration
# #####

# On/Off signals
net machine.is-on                halui.machine.is-on
whb.halui.machine.is-on
net pdnt.machine.on              whb.halui.machine.on
halui.machine.on
net pdnt.machine.off             whb.halui.machine.off
halui.machine.off

# program related signals
net pdnt.program.is-idle         whb.halui.program.is-idle
halui.program.is-idle
net pdnt.program.is-paused       whb.halui.program.is-paused
halui.program.is-paused
net pdnt.program.is-running      whb.halui.program.is-running
halui.program.is-running
net pdnt.program.resume          whb.halui.program.resume
halui.program.resume
net pdnt.program.pause           whb.halui.program.pause
halui.program.pause
net pdnt.program.run             whb.halui.program.run
halui.program.run
net pdnt.program.stop            whb.halui.program.stop
halui.program.stop

# machine mode related signals
net pdnt.mode.auto               whb.halui.mode.auto
halui.mode.auto
net pdnt.mode.manual             whb.halui.mode.manual
halui.mode.manual
net pdnt.mode.mdi                whb.halui.mode.mdi
halui.mode.mdi
```

```
net pdnt.mode.joint                whb.halui.mode.joint
halui.mode.joint
net pdnt.mode.teleop              whb.halui.mode.teleop
halui.mode.teleop
net pdnt.mode.is-auto             halui.mode.is-auto
whb.halui.mode.is-auto
net pdnt.mode.is-manual           halui.mode.is-manual
whb.halui.mode.is-manual
net pdnt.mode.is-mdi              halui.mode.is-mdi
whb.halui.mode.is-mdi
net pdnt.mode.is-joint            halui.mode.is-joint
whb.halui.mode.is-joint
net pdnt.mode.is-teleop           halui.mode.is-teleop
whb.halui.mode.is-teleop

# "is-homed" axis signal for allowing pendant when machine is not homed
net pdnt.axis.X.is-homed          halui.joint.0.is-homed
whb.halui.joint.x.is-homed
net pdnt.axis.Y.is-homed          halui.joint.1.is-homed
whb.halui.joint.y.is-homed
net pdnt.axis.Z.is-homed          halui.joint.2.is-homed
whb.halui.joint.z.is-homed

# "selected axis" signals
net pdnt.axis.X.select            whb.halui.axis.x.select
halui.axis.x.select
net pdnt.axis.y.select            whb.halui.axis.y.select
halui.axis.y.select
net pdnt.axis.Z.select            whb.halui.axis.z.select
halui.axis.z.select

net pdnt.axis.x.jog-scale         whb.axis.x.jog-scale
axis.x.jog-scale
net pdnt.axis.y.jog-scale         whb.axis.y.jog-scale
axis.y.jog-scale
net pdnt.axis.z.jog-scale         whb.axis.z.jog-scale
axis.z.jog-scale

net pdnt.axis.x.jog-counts        whb.axis.x.jog-counts
axis.x.jog-counts
net pdnt.axis.y.jog-counts        whb.axis.y.jog-counts
axis.y.jog-counts
net pdnt.axis.z.jog-counts        whb.axis.z.jog-counts
axis.z.jog-counts

net pdnt.axis.x.jog-enable        whb.axis.x.jog-enable
axis.x.jog-enable
net pdnt.axis.y.jog-enable        whb.axis.y.jog-enable
axis.y.jog-enable
net pdnt.axis.z.jog-enable        whb.axis.z.jog-enable
axis.z.jog-enable

net pdnt.axis.x.jog-vel-mode      whb.axis.x.jog-vel-mode
axis.x.jog-vel-mode
net pdnt.axis.y.jog-vel-mode      whb.axis.y.jog-vel-mode
axis.y.jog-vel-mode
```



```
net pdnt.axis.z.jog-vel-mode          whb.axis.z.jog-vel-mode
axis.z.jog-vel-mode

# macro buttons to MDI commands
net pdnt.macro-1                      whb.button.macro-1
halui.mdi-command-01                 # use MDI command from main.ini
net pdnt.macro-2                      whb.button.macro-2
halui.mdi-command-02                 # use MDI command from main.ini
net pdnt.reserved.for.spindle+        whb.button.macro-3
# Hardcoded for spindle+ whb.halui.spindle.increase
net pdnt.reserved.for.spindle-        whb.button.macro-4
# Hardcoded for spindle- whb.halui.spindle.decrease
net pdnt.macro-5                      whb.button.macro-5
halui.mdi-command-05                 # use MDI command from main.ini
net pdnt.macro-6                      whb.button.macro-6
halui.mdi-command-06                 # use MDI command from main.ini
net pdnt.macro-7                      whb.button.macro-7
halui.mdi-command-07                 # use MDI command from main.ini
net pdnt.reserved.for.spindle.dir     whb.button.macro-8
# Hardcoded for spindle direction inside pendant
net pdnt.macro-9                      whb.button.macro-9
halui.mdi-command-09                 # use MDI command from main.ini
net pdnt.reserved.for.ABS-REL         whb.button.macro-10
# Hardcoded for swap Dro  Relative/Absolute
net pdnt.macro-14                     whb.button.macro-14
halui.mdi-command-14                 # use MDI command from main.ini
net pdnt.reserved.for.flood           whb.button.macro-15
# Hardcoded for halui.flood on/off
net pdnt.reserved.for.mist            whb.button.macro-16
# Hardcoded for halui.mist on/off

net pdnt.macro.11                     whb.button.macro-11
halui.mdi-command-11                 # use MDI command from main.ini
net pdnt.macro.12                     whb.button.macro-12
halui.mdi-command-12                 # use MDI command from main.ini
net pdnt.macro.13                     whb.button.macro-13
halui.mdi-command-13                 # use MDI command from main.ini

# flood and mist toggle signals
net pdnt.flood.is-on                 whb.halui.flood.is-on
halui.flood.is-on                    #return signal is on or off
net pdnt.flood.off                   whb.halui.flood.off
halui.flood.off                      #reserved whb.button.macro-15
net pdnt.flood.on                    whb.halui.flood.on
halui.flood.on                       #reserved whb.button.macro-15

net pdnt.mist.is-on                  whb.halui.mist.is-on
halui.mist.is-on                     #return signal is on or off
net pdnt.mist.off                    whb.halui.mist.off
halui.mist.off                       #reserved whb.button.macro-16
net pdnt.mist.on                     whb.halui.mist.on
halui.mist.on                        #reserved whb.button.macro-16

# default function button signals
```

```

net pdnt.button.m-home                whb.button.m-home
halui.home-all                        # Homeing use built-in halui home all
net pdnt.button.safe-z                whb.button.safe-z
halui.mdi-command-03                 # Safe-z use MDI command from main.ini
net pdnt.button.w-home                whb.button.w-home
halui.mdi-command-04                 # Unpark use MDI command from main.ini
net pdnt.button.probe-z              whb.button.probe-z
halui.mdi-command-08                 # Probe-Z use MDI command from main.ini

# unused, just exposes pendant internal status or as basic button
#net pdnt.mode-lead                  whb.halui.feed.selected-lead
#net pdnt.mode-mpg-feed              whb.halui.feed.selected-mpg-feed
#net pdnt.mode-continuous            whb.halui.feed.selected-continuous
#net pdnt.mode-step                  whb.halui.feed.selected-step

#net pdnt.button.mode-mpg            whb.button.mode-continuous
#net pdnt.button.mode-step           whb.button.mode-step
#net pdnt.button.fn                  whb.button.fn
#net pdnt.button.reset               whb.button.reset
#net pdnt.button.stop                whb.button.stop
#net pdnt.button.start-pause         whb.button.start-pause
#net pdnt.button.s-on-off            whb.button.s-on-off
#net pdnt.button.spindle-plus        whb.button.spindle-plus
#net pdnt.button.spindle-minus       whb.button.spindle-minus
#net pdnt.button.feed-plus           whb.button.feed-plus
#net pdnt.button.feed-minus          whb.button.feed-minus

# spindle related signals
net pdnt.spindle.is-on                whb.halui.spindle.is-on
spindle.0.on
net pdnt.spindle.start                whb.halui.spindle.start
halui.spindle.0.start
net pdnt.spindle.stop                whb.halui.spindle.stop
halui.spindle.0.stop
net pdnt.spindle.forward              whb.halui.spindle.forward
halui.spindle.0.forward
net pdnt.spindle.reverse              whb.halui.spindle.reverse
halui.spindle.0.reverse
net pdnt.spindle.increase             whb.halui.spindle.increase
halui.spindle.0.increase              # reserved whb.button.macro-3
net pdnt.spindle.decrease             whb.halui.spindle.decrease
halui.spindle.0.decrease              # reserved whb.button.macro-4
net pdnt.spindle-speed-abs            whb.halui.spindle-speed-cmd
spindle.0.speed-out-abs               # speed cmd from motion in rpm absolute

# spindle speed override signals
net pdnt.spindle-override.scale        whb.halui.spindle-override.scale
halui.spindle.0.override.scale        # needed for both spindle+/- and spindleoverride+/-
button
net pdnt.spindle.override.value        halui.spindle.0.override.value
whb.halui.spindle-override.value      # GUI feed rate related signals
net pdnt.spindle.override.increase    whb.halui.spindle-override.increase
halui.spindle.0.override.increase

```

```
net pdnt.spindle.override.decrease      whb.halui.spindle-override.decrease
halui.spindle.0.override.decrease

# GUI feed rate related signals can be used when program is running moving GUI slider
net pdnt.feed-override.scale            whb.halui.feed-override.scale
halui.feed-override.scale               # needed for both FeedOverride+/- and rotary knob button
net pdnt.max-velocity.value             whb.halui.max-velocity.value
halui.max-velocity.value                # needed for Mpg mode : button feed position% * max-
velocity = Mpg feedrate

# take feed override min/max values from/to the GUI
net pdnt.feed-override.value            halui.feed-override.value
whb.halui.feed-override.value           # GUI feed rate related signals
net pdnt.feed-override.increase         whb.halui.feed-override.increase
halui.feed-override.increase
net pdnt.feed-override.decrease         whb.halui.feed-override.decrease
halui.feed-override.decrease

# axis position related signals feedback
net pdnt.axis.x.pos-feedback            halui.axis.x.pos-feedback
whb.halui.axis.x.pos-feedback
net pdnt.axis.y.pos-feedback            halui.axis.y.pos-feedback
whb.halui.axis.y.pos-feedback
net pdnt.axis.z.pos-feedback            halui.axis.z.pos-feedback
whb.halui.axis.z.pos-feedback

# axis position related signals relative
net pdnt.axis.x.pos-relative            halui.axis.x.pos-relative
whb.halui.axis.x.pos-relative
net pdnt.axis.y.pos-relative            halui.axis.y.pos-relative
whb.halui.axis.y.pos-relative
net pdnt.axis.z.pos-relative            halui.axis.z.pos-relative
whb.halui.axis.z.pos-relative
```

107.9. SEE ALSO

[xhc-whb04b-6 developer documentation on GitHub](#)

107.10. NOTES

The CRC code function is not disclosed by the manufacturer. Thus the CRC value transmitted with each package is not checked yet. Feel free to help us enhance the component.

107.11. AUTHOR

This component was started by Raoul Rubien based on predecessor device component [xhc-hb04.cc](#). <https://github.com/machinekit/machinekit/graphs/contributors> gives you a more complete list of contributors.

107.12. HISTORY

The component was developed accidentally as leisure project. The development started with the xhc-whb04 (4-axis wireless pendant) implementation as reference. 73 & many thanks to the developers who delivered provided an excellent preparatory work!

107.13. COPYRIGHT

Copyright © 2018 Raoul Rubien (github.com/rubienr) Updated for Linuxcnc 2020 by [alkabal_free.fr](https://alkabal.free.fr).

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 108. xyzab-tdr-gui(1)

108.1. NAME

xyzab-tdr-gui - Vismach Virtual Machine GUI

108.2. DESCRIPTION

xyzab-tdr-gui is one of the sample **Vismach** GUIs for LinuxCNC, simulating a dual-rotary machine with switchable kinematics.

108.3. SEE ALSO

linuxcnc(1)*

See the main LinuxCNC documentation for more details: <https://linuxcnc.org/docs/html/gui/vismach.html>

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at /usr/share/doc/LinuxCNC/.

108.4. BUGS

None known at this time.

108.5. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

108.6. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>

108.7. COPYRIGHT

Copyright © 2023 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 109. xyzac-trt-gui(1)

109.1. NAME

xyzac-trt-gui - Vismach Virtual Machine GUI

109.2. DESCRIPTION

xyzac-trt-gui is one of the sample **Vismach** GUIs for LinuxCNC, simulating a 5-axis milling machine with tool-point kinematics.

See the main LinuxCNC documentation for more details.

109.3. SEE ALSO

linuxcnc(1)

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at `/usr/share/doc/LinuxCNC/`.

109.4. BUGS

None known at this time.

109.5. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

109.6. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

109.7. COPYRIGHT

Copyright © 2020 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 110. xyzbc-trt-gui(1)

110.1. NAME

xyzbc-trt-gui - Vismach Virtual Machine GUI

110.2. DESCRIPTION

xyzbc-trt-gui is one of the sample **Vismach** GUIs for LinuxCNC, simulating a 5-axis milling machine with tool-point kinematics.

See the main LinuxCNC documentation for more details.

110.3. SEE ALSO

linuxcnc(1)

Much more information about LinuxCNC and HAL is available in the LinuxCNC and HAL User Manuals, found at `/usr/share/doc/LinuxCNC/`.

110.4. BUGS

None known at this time.

110.5. AUTHOR

This man page written by Andy Pugh, as part of the LinuxCNC project.

110.6. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

110.7. COPYRIGHT

Copyright © 2020 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 111. hal(3)

111.1. NAME

hal - Introduction to the HAL API

111.2. DESCRIPTION

HAL stands for Hardware Abstraction Layer, and is used by LinuxCNC to transfer realtime data to and from I/O devices and other low-level modules.

hal.h defines the API and data structures used by the HAL. This file is included in both realtime and non-realtime HAL components. HAL uses the RTPAI real-time interface, and the `#define` symbols `RTAPI` and `ULAPI` are used to distinguish between realtime and non-realtime code. The API defined in this file is implemented in `hal_lib.c` and can be compiled for linking to either realtime or non-realtime HAL components.

The HAL is a very modular approach to the low level parts of a motion control system. The goal of the HAL is to allow a systems integrator to connect a group of software components together to meet whatever I/O requirements he (or she) needs. This includes realtime and non-realtime I/O, as well as basic motor control up to and including a PID position loop. What these functions have in common is that they all process signals. In general, a signal is a data item that is updated at regular intervals. For example, a PID loop gets position command and feedback signals, and produces a velocity command signal.

HAL is based on the approach used to design electronic circuits. In electronics, off-the-shelf components like integrated circuits are placed on a circuit board and their pins are interconnected to build whatever overall function is needed. The individual components may be as simple as an op-amp, or as complex as a digital signal processor. Each component can be individually tested, to make sure it works as designed. After the components are placed in a larger circuit, the signals connecting them can still be monitored for testing and troubleshooting.

Like electronic components, HAL components have pins, and the pins can be interconnected by signals.

In the HAL, a *signal* contains the actual data value that passes from one pin to another. When a signal is created, space is allocated for the data value. A *pin* on the other hand, is a pointer, not a data value. When a pin is connected to a signal, the pin's pointer is set to point at the signal's data value. This allows the component to access the signal with very little run-time overhead. (If a pin is not linked to any signal, the pointer points to a dummy location, so the realtime code doesn't have to deal with null pointers or treat unlinked variables as a special case in any way.)

There are three approaches to writing a HAL component. Those that do not require hard realtime performance can be written as a regular non-realtime process. Components that need hard realtime performance but have simple configuration and init requirements can be done as a single realtime component, using either pre-defined init info, or load-time parameters. Finally, complex components may use both a realtime component for the realtime part, and a non-realtime process to handle INI file access, user interface (possibly including GUI features), and other details.

HAL uses the RTAPI/ULAPI interface. If RTAPI is #defined, hal_lib.c generates a realtime-capable library (to be insmoded into the kernel or linked to a realtime process) that provides the functions for all realtime components. The same source file compiled with the ULAPI #define would make a non-realtime library that would be linked to non-realtime code to make non-realtime executables. The variable lists and link information are stored in a block of shared memory and protected with mutexes, so that realtime components and non-realtime programs can access the data.

111.3. REALTIME CONSIDERATIONS

For an explanation of realtime considerations, see **rtapi(3)**.

111.4. HAL STATUS CODES

Except as noted in specific manual pages, HAL returns negative errno values for errors, and non-negative values for success.

111.5. SEE ALSO

rtapi(3)

Chapter 112. hal_add_func_to_thread(3)

112.1. NAME

hal_add_func_to_thread, hal_del_func_from_thread - cause a function to be executed at regular intervals

112.2. SYNTAX

```
int hal_add_func_to_thread(const char* func_name, const char* thread_name, int
position)
int hal_del_func_from_thread(const char* func_name, const char* thread_name)
```

112.3. ARGUMENTS

func_name

The name of the function.

thread_name

The name of the thread.

position

The desired location within the thread. This determines when the function will run, in relation to other functions in the thread. A positive number indicates the desired location as measured from the beginning of the thread, and a negative is measured from the end. So +1 means this function will become the first one to run, +5 means it will be the fifth one to run, -2 means it will be next to last, and -1 means it will be last. Zero is illegal.

112.4. DESCRIPTION

The function **hal_add_func_to_thread** adds another function that is exported by a realtime HAL component to a realtime thread. This determines how often and in what order functions are executed.

The function **hal_del_func_from_thread** removes a function from a thread.

112.5. RETURN VALUE

Returns a HAL status code.

112.6. REALTIME CONSIDERATIONS

Call only from realtime init code, not from other realtime or non-realtime code.

112.7. SEE ALSO

hal_thread_new(3), hal_export_func(3)

Chapter 113. hal_create_thread(3)

113.1. NAME

hal_create_thread - Create a HAL thread

113.2. SYNTAX

```
int hal_create_thread(const char* name, unsigned long period, int uses_fp)
```

```
int hal_thread_delete(const char* name)
```

113.3. ARGUMENTS

name

The name of the thread.

period

The interval, in nanoseconds, between iterations of the thread.

uses_fp

Deprecated and ignored. All threads now unconditionally save and restore floating point state. This parameter will be removed in a future version.

113.4. DESCRIPTION

hal_create_thread establishes a realtime thread that will execute one or more HAL functions periodically.

All thread periods are rounded to integer multiples of the hardware timer period, and the timer period is based on the first thread created. Threads must be created in order, from the fastest to the slowest. HAL assigns decreasing priorities to threads that are created later, so creating them from fastest to slowest results in rate monotonic priority scheduling.

hal_delete_thread deletes a previously created thread.

113.5. REALTIME CONSIDERATIONS

Call only from realtime init code, not from other realtime or non-realtime code.

113.6. RETURN VALUE

Returns a HAL status code.

113.7. SEE ALSO

hal_export_funct(3)

Chapter 114. hal_exit(3)

114.1. NAME

hal_exit - Shut down HAL

114.2. SYNTAX

```
int hal_exit(int comp_id)
```

114.3. ARGUMENTS

comp_id

A HAL component identifier returned by an earlier call to **hal_init**.

114.4. DESCRIPTION

The function **hal_exit** shuts down and cleans up HAL and RTAPI. It must be called prior to exit by any module that called **hal_init**.

114.5. REALTIME CONSIDERATIONS

Call only from within non-realtime or init/cleanup code, not from realtime tasks.

114.6. RETURN VALUE

Returns a HAL status code.

Chapter 115. hal_export_func(3)

115.1. NAME

hal_export_func, hal_export_funcf - create a realtime function callable from a thread

115.2. SYNTAX

```
typedef void(hal_func_t)(void arg, long period)
```

```
int hal_export_func(const char* name, hal_func_t func, void* arg, int uses_fp, int reentrant, int comp_id)
```

115.3. ARGUMENTS

name

The name of the function.

func

The pointer to the function.

arg

The argument to be passed as the first parameter of *func*.

uses_fp

Deprecated and ignored. All threads now unconditionally save and restore floating point state. This parameter will be removed in a future version.

reentrant

If *reentrant* is non-zero, the function may be preempted and called again before the first call completes. Otherwise, it may only be added to one thread.

comp_id

A HAL component identifier returned by an earlier call to **hal_init**.

115.4. DESCRIPTION

hal_export_func makes a realtime function provided by a component available to the system. A subsequent call to **hal_add_func_to_thread** can be used to schedule the execution of the function as needed by the system.

When this function is placed on a HAL thread, and HAL threads are started, *func* is called repeatedly with two arguments: void **arg** is the same value that was given to *hal_export_func*, and *long period* is the interval between calls in nanoseconds.

Each call to the function should do a small amount of work and return.

115.5. RETURN VALUE

Returns a HAL status code.

115.6. SEE ALSO

hal_create_thread(3), hal_add_func_to_thread(3)

Chapter 116. hal_init(3)

116.1. NAME

hal_init - Sets up HAL and RTAPI

116.2. SYNTAX

```
int hal_init(const char* modname)
```

116.3. ARGUMENTS

modname

The name of this HAL module.

116.4. DESCRIPTION

hal_init sets up HAL and RTAPI. It must be called by any module that intends to use the API, before any other RTAPI calls.

modname must point to a string that identifies the module. The string may be no longer than **HAL_NAME_LEN** characters.

116.5. REALTIME CONSIDERATIONS

Call only from within non-realtime or init/cleanup code, not from realtime tasks.

116.6. RETURN VALUE

On success, returns a positive integer module ID, which is used for subsequent calls to HAL and rtapi APIs. On failure, returns a HAL error code.

Chapter 117. hal_malloc(3)

117.1. NAME

hal_malloc - Allocate space in the HAL shared memory area

117.2. SYNTAX

```
void *hal_malloc(long int size)
```

117.3. ARGUMENTS

size

Gives the size, in bytes, of the block.

117.4. DESCRIPTION

hal_malloc allocates a block of memory from the main HAL shared memory area. It should be used by all components to allocate memory for HAL pins and parameters. It allocates 'size' bytes, and returns a pointer to the allocated space, or NULL (0) on error. The returned pointer will be properly aligned for any type HAL supports. A component should allocate during initialization all the memory it needs.

The allocator is very simple, and there is no 'free'. The entire HAL shared memory area is freed when the last component calls **hal_exit**. This means that if you continuously install and remove one component while other components are present, you eventually will fill up the shared memory and an install will fail. Removing all components completely clears memory and you start fresh.

117.5. RETURN VALUE

A pointer to the allocated space, which is properly aligned for any variable HAL supports. Returns NULL on error.

Chapter 118. hal_param_alias(3)

118.1. NAME

hal_param_alias - create an alternate name for a param

118.2. SYNTAX

```
int hal_param_alias(const char original_name*, const char alias*);
```

118.3. ARGUMENTS

original_name

The original name of the param

alias

The alternate name that may be used to refer to the param, or NULL to remove any alternate name.

118.4. DESCRIPTION

A param may have two names: the original name (the one that was passed to a **hal_param_new** function) and an alias.

Usually, aliases are for the convenience of users and should be created and destroyed via halcmd. However, in some cases it is sensible to create aliases directly in a component. These cases include the case where a param is renamed, to preserve compatibility with old versions.

118.5. RETURN VALUE

Returns a HAL status code.

118.6. SEE ALSO

hal_pin_alias(3)

Chapter 119. hal_param_new(3)

119.1. NAME

hal_param_new, hal_param_bit_new, hal_param_float_new, hal_param_u32_new, hal_param_s32_new, hal_param_bit_newf, hal_param_float_newf, hal_param_u32_newf, hal_param_s32_newf - creates a HAL parameter

119.2. SYNTAX

```
int hal_param_bit_new(const char* name, hal_param_dir_t dir, hal_bit_t* data_addr, int comp_id)
```

```
int hal_param_float_new(const char* name, hal_param_dir_t dir, hal_float_t* data_addr, int comp_id)
```

```
int hal_param_u32_new(const char* name, hal_param_dir_t dir, hal_u32_t* data_addr, int comp_id)
```

```
int hal_param_s32_new(const char* name, hal_param_dir_t dir, hal_s32_t* data_addr, int comp_id)
```

```
int hal_param_bit_newf(hal_param_dir_t dir, hal_bit_t* data_addr, int comp_id, const char* fmt, ...)
```

```
int hal_param_float_newf(hal_param_dir_t dir, hal_float_t* data_addr, int comp_id, const char* fmt, ...)
```

```
int hal_param_u32_newf(hal_param_dir_t dir, hal_u32_t* data_addr, int comp_id, const char* fmt, ...)
```

```
int hal_param_s32_newf(hal_param_dir_t dir, hal_s32_t* data_addr, int comp_id, const char* fmt, ...)
```

```
int hal_param_new(const char* name, hal_type_t type, hal_param_dir_t dir, void* data_addr, int comp_id)
```

119.3. ARGUMENTS

name

The name to give to the created parameter.

dir

The direction of the parameter, from the viewpoint of the component. It may be one of **HAL_RO**, or **HAL_RW**. A component may assign a value to any parameter, but other programs (such as halcmd) may only assign a value to a parameter that is **HAL_RW**.

data_addr

The address of the data, which must lie within memory allocated by **hal_malloc**.

comp_id

A HAL component identifier returned by an earlier call to **hal_init**.

fmt, ...

A printf-style format string and arguments.

type

The type of the parameter, as specified in **hal_type_t(3)**.

119.4. DESCRIPTION

The **hal_param_new** family of functions create a new *param* object.

There are functions for each of the data types that the HAL supports. Pins may only be linked to signals of the same type.

119.5. RETURN VALUE

Returns a HAL status code.

119.6. SEE ALSO

hal_type_t(3)

Chapter 120. hal_parport(3)

120.1. NAME

hal_parport - portable access to PC-style parallel ports

120.2. SYNTAX

```
#include "hal_parport.h"
int hal_parport_get(int _comp_id_, hal_parport_t* _port_, unsigned short _base_, unsigned
short _base_hi_, unsigned int _modes_)
void hal_parport_release(hal_parport_t* _port_)
```

120.3. ARGUMENTS

comp_id

A HAL component identifier returned by an earlier call to **hal_init**.

port

A pointer to a hal_parport_t structure.

base

The base address of the port (if port >= 16) or the linux port number of the port (if port < 16)

base_hi

The "high" address of the port (location of the ECP registers), 0 to use a probed high address, or -1 to disable the high address

modes

Advise the driver of the desired port modes, from <linux/parport.h>. If a linux-detected port does not provide the requested modes, a warning is printed with rtapi_print_msg. This does not make the port request fail, because unfortunately, many systems that have working EPP parports are not detected as such by Linux.

120.4. DESCRIPTION

hal_parport_get allocates a parallel port for exclusive use of the named HAL component. The port must be released with **hal_parport_release** before the component exits with **hal_exit**.

120.5. HIGH ADDRESS PROBING

If the port is a parallel port known to Linux, and Linux detected a high I/O address, this value is used. Otherwise, if base+0x400 is not registered to any device, it is used. Otherwise, no address is used. If no high address is detected, port → base_hi is 0.

120.6. PARPORT STRUCTURE

```
typedef struct
{
    unsigned short base;
    unsigned short base_hi;
    .... // and further unspecified fields
} hal_parport_t;
```

120.7. RETURN VALUE

hal_parport_get returns a HAL status code. On success, *port* is filled out with information about the allocated port. On failure, the contents of *port* are undefined except that it is safe (but not required) to pass this port to **hal_parport_release**.

hal_parport_release does not return a value. It always succeeds.

120.8. NOTES

In new code, prefer use of `rtapi_parport` to `hal_parport`.

Chapter 121. hal_pin_alias(3)

121.1. NAME

hal_pin_alias - creates an alternate name for a pin

121.2. SYNTAX

```
int hal_pin_alias(const char* original_name, const char* alias);
```

121.3. ARGUMENTS

original_name

The original name of the pin.

alias

The alternate name that may be used to refer to the pin, or NULL to remove any alternate name.

121.4. DESCRIPTION

A pin may have two names: the original name (the one that was passed to a **hal_pin_new** function) and an alias.

Usually, aliases are for the convenience of users and should be created and destroyed via halcmd. However, in some cases it is sensible to create aliases directly in a component. These cases include the case where a pin is renamed, to preserve compatibility with old versions.

121.5. RETURN VALUE

Returns a HAL status code.

121.6. SEE ALSO

hal_param_alias(3)

Chapter 122. hal_pin_new(3)

122.1. NAME

hal_pin_new, hal_pin_bit_new, hal_pin_float_new, hal_pin_u32_new, hal_pin_s32_new, hal_pin_port_new, hal_pin_bit_newf, hal_pin_float_newf, hal_pin_u32_newf, hal_pin_s32_newf, hal_pin_port_newf - creates a HAL pin

122.2. SYNTAX

```
int hal_pin_bit_new(const char* name, hal_pin_dir_t dir, hal_bit_t** data_ptr_addr, int comp_id)
```

```
int hal_pin_float_new(const char* name, hal_pin_dir_t dir, hal_float_t** data_ptr_addr, int comp_id)
```

```
int hal_pin_u32_new(const char* name, hal_pin_dir_t dir, hal_u32_t** data_ptr_addr, int comp_id)
```

```
int hal_pin_s32_new(const char* name, hal_pin_dir_t dir, hal_s32_t** data_ptr_addr, int comp_id)
```

```
int hal_pin_port_new(const char* name, hal_pin_dir_t dir, hal_port_t** data_ptr_addr, int comp_id)
```

```
int hal_pin_bit_newf(hal_pin_dir_t dir, hal_bit_t** data_ptr_addr, int comp_id, const char* fmt, ...)
```

```
int hal_pin_float_newf(hal_pin_dir_t dir, hal_float_t** data_ptr_addr, int comp_id, const char* fmt, ...)
```

```
int hal_pin_u32_newf(hal_pin_dir_t dir, hal_u32_t** data_ptr_addr, int comp_id, const char* fmt, ...)
```

```
int hal_pin_s32_newf(hal_pin_dir_t dir, hal_s32_t** data_ptr_addr, int comp_id, const char* fmt, ...)
```

```
int hal_pin_port_newf(hal_pin_dir_t dir, hal_port_t** data_ptr_addr, int comp_id, const char* fmt, ...)
```

```
int hal_pin_new(const char* name, hal_type_t type, hal_pin_dir_t dir, void** data_ptr_addr, int comp_id)
```

122.3. ARGUMENTS

name

Name of the pin.

dir

The direction of the pin, from the viewpoint of the component. It may be one of **HAL_IN**, **HAL_OUT**, or **HAL_IO**. Any number of **HAL_IN** or **HAL_IO** pins may be connected to the same signal, but at most one **HAL_OUT** pin is permitted. A component may assign a value to a pin that is **HAL_OUT** or **HAL_IO**, but may not assign a value to a pin that is **HAL_IN**.

data_ptr_addr

The address of the pointer-to-data, which must lie within memory allocated by **hal_malloc**.

comp_id

HAL component identifier returned by an earlier call to **hal_init**.

fmt,

printf-style format string and arguments

type

The type of the param, as specified in **hal_type_t(3)**.

122.4. DESCRIPTION

The **hal_pin_new** family of functions create a new *pin* object. Once a pin has been created, it can be linked to a signal object using **hal_link**. A pin contains a pointer, and the component that owns the pin can dereference the pointer to access whatever signal is linked to the pin. (If no signal is linked, it points to a dummy signal.)

There are functions for each of the data types that the HAL supports. Pins may only be linked to signals of the same type.

122.5. RETURN VALUE

Returns 0 on success, or a negative errno value on failure.

122.6. SEE ALSO

hal_type_t(3), hal_link(3)

Chapter 123. hal_port(3)

123.1. NAME

hal_port - a HAL pin type that acts as an asynchronous one way byte stream

123.2. SYNOPSIS

```
#include <hal.h>
bool hal_port_read(hal_port_t port, char* dest, unsigned count);
bool hal_port_peek(hal_port_t port, char* dest, unsigned count);
bool hal_port_peek_commit(hal_port_t port, unsigned count);
unsigned hal_port_readable(hal_port_t port);
void hal_port_clear(hal_port_t port);

bool hal_port_write(hal_port_t port, const char* src, unsigned count);
unsigned hal_port_writable(hal_port_t port);

unsigned hal_port_buffer_size(hal_port_t port);

#ifdef ULAPI
void hal_port_wait_readable(hal_port_t** port, unsigned count, sig_atomic_t* stop);
void hal_port_wait_writable(hal_port_t** port, unsigned count, sig_atomic_t* stop);
#endif
```

123.3. DESCRIPTION

A HAL port pin is a HAL pin that acts as a one way byte oriented data stream in real-time. An output port on any component may be connected to an input port on any other component via a signal. Data written on the output pin becomes accessible to the input pin. A HAL port signal may link only a single writer and a single reader.

A port also buffers data. Users should determine the proper buffer size based upon their intended application.

123.3.1. hal_port_read

Reads *count* bytes from the port into destination buffer *dest*. `hal_port_read` will read *count* bytes if and only if *count* bytes are available for reading and otherwise it will leave the port unaffected. Returns true if *count* bytes were read and false otherwise. This function should only be called by the component that owns the IN PORT pin.

123.3.2. hal_port_peek

Behaves the same as `hal_port_read`, however it does not consume bytes from the HAL port. Repeated calls to `hal_port_peek` will return the same data. Returns true if *count* bytes were read and false otherwise. This function should only be called by the component that owns the IN PORT pin.

123.3.3. hal_port_peek_commit

Advances the read position in the port buffer by count bytes. A `hal_port_peek` followed by a `hal_port_peek_commit` would function equivalently to `hal_port_read` given the same count value. Returns true if count readable bytes were skipped and are no longer accessible and false if no bytes were skipped. This function should only be called by the component that owns the IN PORT pin.

123.3.4. hal_port_readable

Returns the number of bytes available for reading from port. It is safe to call this function from any component.

123.3.5. hal_port_clear

Emptys a given port of all data. `hal_port_clear` should only be called by the component that owns the IN PORT pin.

123.3.6. hal_port_write

Writes count bytes from src into the port. Returns true if count bytes were written and false otherwise. This function should only be called by the component that owns the OUT PORT pin.

123.3.7. hal_port_writable

Returns the number of bytes that can be written into the port. It is safe to call this function from any component.

123.3.8. hal_port_buffer_size

Returns the maximum number of bytes that a port can buffer. It is safe to call this function from any component.

123.3.9. hal_port_wait_readable

Waits until the port has count bytes or more available for reading or the stop flag is set.

123.3.10. hal_port_wait_writable

Waits until the port has count bytes or more available for writing or the stop flag is set.

123.4. ARGUMENTS

hal_port_t

A handle to a port object. Created by `hal_pin_new`.

dest

An array of bytes that `hal_port_read` and `hal_port_peek` will copy data into. This must be allocated by the caller and be at least `count` bytes long.

count

The number of bytes that `hal_port_read`, `hal_port_peek`, and `hal_port_write` will copy in to `dest` or out from `src`.

src

An array of bytes that `hal_port_write` will copy data from into the port buffer. This must be of size `count` bytes or larger.

stop

A pointer to a value which is monitored while waiting. If it is nonzero, the wait operation returns early. This allows a wait call to be safely terminated in the case of a signal.

123.5. SAMPLE CODE

In the source tree under `src/hal/components/raster.comp` is a realtime component intended for laser control. `src/tests/raster` is a test program that also programs the raster component from Python.

123.6. REALTIME CONSIDERATIONS

`hal_port_read`, `hal_port_peek`, `hal_port_peek_commit`, `hal_port_readable`, `hal_port_clear`, `hal_port_write`, `hal_port_writable`, `hal_port_buffer_size` may be called from realtime code.

`hal_port_wait_writable`, `hal_port_wait_readable` may be called from ULAPI code.

123.7. SEE ALSO

`raster(9)`

Chapter 124. hal_ready(3)

124.1. NAME

hal_ready - indicates that this component is ready

124.2. SYNTAX

hal_ready(int *comp_id*)

124.3. ARGUMENTS

comp_id

A HAL component identifier returned by an earlier call to **hal_init**.

124.4. DESCRIPTION

hal_ready indicates that this component is ready (has created all its pins, parameters, and functions). This must be called in any realtime HAL component before its **rtapi_app_init** exits, and in any non-realtime component before it enters its main loop.

124.5. RETURN VALUE

Returns a HAL status code.

Chapter 125. hal_set_constructor(3)

125.1. NAME

hal_set_constructor - sets the constructor function for this component

125.2. SYNTAX

```
typedef int (hal_constructor_t)(const char prefix, const char* arg); int hal_set_constructor(int comp_id,  
hal_constructor_t constructor)
```

125.3. ARGUMENTS

comp_id

A HAL component identifier returned by an earlier call to **hal_init**.

prefix

The prefix to be given to the pins, parameters, and functions in the new instance.

arg

An argument that may be used by the component to customize this instance.

125.4. DESCRIPTION

As an experimental feature in HAL 2.1, components may be *constructable*. Such a component may create pins and parameters not only at the time the module is loaded, but it may create additional pins and parameters, and functions on demand.

125.5. RETURN VALUE

Returns a HAL status code.

125.6. SEE ALSO

halcmd(1)

Chapter 126. hal_set_lock(3)

126.1. NAME

hal_set_lock, hal_get_lock - Set or get the HAL lock level

126.2. SYNTAX

```
int hal_set_lock(unsigned char lock_type)
```

```
int hal_get_lock()
```

126.3. ARGUMENTS

lock_type

The desired lock type, which may be a bitwise combination of: **HAL_LOCK_LOAD**, **HAL_LOCK_CONFIG**, **HAL_LOCK_PARAMS**, or **HAL_LOCK_PARAMS**. **HAL_LOCK_NONE** or 0 locks nothing, and **HAL_LOCK_ALL** locks everything.

126.4. RETURN VALUE

hal_set_lock returns a HAL status code. **hal_get_lock** returns the current HAL lock level or a HAL status code.

Chapter 127. hal_signal_new(3)

127.1. NAME

hal_signal_new, hal_signal_delete, hal_link, hal_unlink - Manipulate HAL signals

127.2. SYNTAX

```
int hal_signal_new(const char* signal_name, hal_type_t type)
```

```
int hal_signal_delete(const char* signal_name)
```

```
int hal_link(const char* pin_name, const char* signal_name)
```

```
int hal_unlink(const char* pin_name)
```

127.3. ARGUMENTS

signal_name

The name of the signal.

pin_name

The name of the pin.

type

The type of the signal, as specified in **hal_type_t(3)**.

127.4. DESCRIPTION

hal_signal_new creates a new signal object. Once a signal has been created, pins can be linked to it with **hal_link**. The signal object contains the actual storage for the signal data. Pin objects linked to the signal have pointers that point to the data. *name* is the name of the new signal. It may be no longer than HAL_NAME_LEN characters. If there is already a signal with the same name the call will fail.

hal_link links a pin to a signal. If the pin is already linked to the desired signal, the command succeeds. If the pin is already linked to some other signal, it is an error. In either case, the existing connection is not modified. (Use *hal_unlink* to break an existing connection.) If the signal already has other pins linked to it, they are unaffected - one signal can be linked to many pins, but a pin can be linked to only one signal.

hal_unlink unlinks any signal from the specified pin.

hal_signal_delete deletes a signal object. Any pins linked to the object are unlinked.

127.5. RETURN VALUE

Returns a HAL status code.

127.6. SEE ALSO

hal_type_t(3)

Chapter 128. hal_start_threads(3)

128.1. NAME

hal_start_threads - Allow HAL threads to begin executing

128.2. SYNTAX

int hal_start_threads()

int hal_stop_threads()

128.3. DESCRIPTION

hal_start_threads starts all threads that have been created. This is the point at which realtime functions start being called.

hal_stop_threads stops all threads that were previously started by **hal_start_threads**. It should be called before any component that is part of a system exits.

128.4. RETURN VALUE

Returns a HAL status code.

128.5. SEE ALSO

hal_export_funct(3), hal_create_thread(3), hal_add_funct_to_thread(3)

Chapter 129. hal_stream(3)

129.1. NAME

hal_stream - non-blocking realtime streams

129.2. SYNOPSIS

```
#include <hal.h>

int hal_stream_create(hal_stream_t* stream, int comp_id, int key, int depth, const char*
typestring);
void hal_stream_destroy(hal_stream_t* stream);
int hal_stream_attach(hal_stream_t* stream, int comp_id, int key, const char*
typestring);
int hal_stream_detach(hal_stream_t* stream);

int hal_stream_element_count(hal_stream_t* stream);
hal_type_t hal_stream_element_type(hal_stream_t* stream, int idx);
int hal_stream_depth(hal_stream_t* stream);
int hal_stream_maxdepth(hal_stream_t* stream);
int hal_stream_num_underruns(hal_stream_t* stream);
int hal_stream_num_overruns(hal_stream_t* stream);

int hal_stream_read(hal_stream_t* stream, hal_stream_data_u *buf, unsigned* sampleno);
bool hal_stream_readable(hal_stream_t* stream);

int hal_stream_write(hal_stream_t* stream, hal_stream_data_u *buf);
bool hal_stream_writable(hal_stream_t* stream);

#ifdef ULAPI
void hal_stream_wait_writable(hal_stream_t* stream, sig_atomic_t* stop);
void hal_stream_wait_readable(hal_stream_t* stream, sig_atomic_t* stop);
#endif
```

129.3. DESCRIPTION

A HAL stream provides a limited ability for two components to communicate data which does not fit within the model of HAL pins. A reader and a writer must agree on a *key* (32-bit integer identifier) and a data structure specified by *typestring*. They must also agree which component (the first one loaded) will **hal_stream_create** the stream, and which component (the second one loaded) will **hal_stream_attach** to the already-created stream.

The non-realtime part can be **halstreamer** or **halsampler**. In the case of **halstreamer** the key is 0x48535430 plus the channel number. In the case of **halsampler** the key is 0x48534130 plus the channel number.

hal_stream_create

Create the given stream, initializing the *stream* which is passed by reference. It is an undiagnosed error if a stream has already been created with the same *key*.

hal_stream_destroy

Destroy the given stream. It is an undiagnosed error if the stream is still attached by another component. It is an undiagnosed error if the stream was attached with **hal_stream_attach** rather than created with **hal_stream_create**. It is an undiagnosed error if the call to **hal_stream_destroy** is omitted.

hal_stream_attach

Attach the given stream, which was already created by **hal_stream_create**. If the typestring is specified, this call fails if it does not match the typestring the stream was created with. If the typestring argument is NULL, then any typestring is accepted.

hal_stream_detach

Detach the given stream. It is an undiagnosed error if the stream was created with **hal_stream_create** rather than attached with **hal_stream_attach**. It is an undiagnosed error if the call to **hal_stream_detach** is omitted.

hal_stream_element_count

Returns the number of pins.

hal_stream_element_type

Returns the type of the given pin number.

hal_stream_readable

Returns true if the stream has at least one sample to read

hal_stream_read

If the stream has one sample to read, stores it in buf.

hal_stream_writable

Returns true if the stream has room for at least one sample to be written.

hal_stream_depth

Returns the number of samples waiting to be read.

hal_stream_maxdepth

Returns the **depth** argument that the stream was created with.

hal_stream_num_overruns

Returns a number which is incremented each time **hal_stream_write** is called without space available.

hal_stream_num_underruns

Returns a number which is incremented each time **hal_stream_read** is called without a sample available.

hal_stream_wait_readable

Waits until the stream is readable or the stop flag is set.

hal_stream_wait_writable

Waits until the stream is writable or the stop flag is set.

hal_stream_read

Reads a record from stream. If successful, it is stored in the given buffer. Optionally, the sample number can be retrieved. If no sample is available, *num_underruns* is incremented. It is an undetected error if more than one component or real-time function calls **hal_stream_read** concurrently.

hal_stream_write

Writes a record to the stream. If successful, it copied from the given buffer. If no room is available, *num_overruns* is incremented. In either case, the internal *sampleno* value is incremented. It is an undetected error if more than one component or real-time function calls **hal_stream_write** concurrently.

129.4. ARGUMENTS

stream

A pointer to a stream object. In the case of **hal_stream_create** and **hal_stream_attach** this is an uninitialized stream; in other cases, it must be a stream created or attached by an earlier call and not yet detached or destroyed.

hal_id

An HAL component identifier returned by an earlier call to **hal_init**.

key

The key for the shared memory segment.

depth

The number of samples that can be unread before any samples are lost (overrun)

typestring

A typestring is limited to 20 characters. A typestring is a case-insensitive string which consists of one or more of the following type characters: +

- B for bool / *hal_bit_t*
- S for *rtapi_s32* / *hal_s32_t*
- U for *rtapi_u32* / *hal_u32_t*
- F for *real_t* / *hal_float_t*
- L for *rtapi_s64* / *hal_s64_t*
- K for *rtapi_u64* / *hal_u64_t*

buf

A buffer big enough to hold all the data in one sample.

sampleno

If non-NULL, the last sample number is stored here. Gaps in this sequence indicate that an overrun occurred between the previous read and this one. May be NULL, in which case the sample number is not retrieved.

stop

A pointer to a value which is monitored while waiting. If it is nonzero, the wait operation returns early. This allows a wait call to be safely terminated in the case of a signal.

129.5. SAMPLE CODE

In the source tree under `src/hal/components`, `sampler.c` and `streamer.c` are realtime components that read and write HAL streams.

129.6. REALTIME CONSIDERATIONS

`hal_stream_read`, `hal_stream_readable`, `hal_stream_write`, `hal_stream_writable`, `hal_stream_element_count`, `hal_tream_pin_type`, `hal_stream_depth`, `hal_stream_maxdepth`, `hal_stream_num_underruns`, `hal_stream_number_overruns` may be called from realtime code.

`hal_stream_wait_writable`, `hal_stream_wait_writable` may be called from ULAPI code.

Other functions may be called in any context, including realtime contexts.

129.7. RETURN VALUE

The functions `hal_stream_create`, `hal_stream_attach`, `hal_stream_read`, `hal_stream_write`, `hal_stream_detach` and `hal_stream_destroy` return an RTAPI status code. Other functions' return values are explained above.

129.8. BUGS

The memory overhead of a stream can be large. Each element in a record uses 8 bytes, and the implicit sample number also uses 8 bytes. As a result, a stream which is used to transport 8-bit values uses 94% of its memory as overhead. However, for modest stream sizes this overhead is not important. (This memory is part of its own shared memory region and does not count against the HAL shared memory region used for pins, parameters and signals.)

129.9. SEE ALSO

`sampler(9)`, `streamer(9)`, `halsampler(1)`, `halstreamer(1)`

Chapter 130. hal_type_t(3)

130.1. NAME

hal_type_t, hal_bool, hal_bit_t, hal_s32_t, hal_u32_t, hal_port_t, hal_float_t, real_t, ireal_t - typedefs for HAL datatypes

130.2. DESCRIPTION

typedef ... hal_bool;

A type which may have a value of 0 or nonzero.

typedef ... hal_bit_t;

A volatile type which may have a value of 0 or nonzero.

typedef ... hal_s32_t;

A volatile type which may have a value from -2147483648 to 2147483647.

typedef ... hal_u32_t;

A volatile type which may have a value from 0 to 4294967295.

typedef ... hal_port_t;

A volatile handle to a port object. Used with hal_port* functions.

typedef ... hal_float_t;

A volatile floating-point type, which typically has the same precision and range as the C type **double**.

typedef ... real_t;

A nonvolatile floating-point type with at least as much precision as **hal_float_t**.

typedef ... ireal_t;

A nonvolatile unsigned integral type the same size as **hal_float_t**.

typedef enum hal_type_t;

+

HAL_BIT

Corresponds to the type **hal_bit_t**.

HAL_FLOAT

Corresponds to the type **hal_float_t**.

HAL_S32

Corresponds to the type **hal_s32_t**.

HAL_U32

Corresponds to the type **hal_u32_t**.

130.3. NOTES

hal_bit_t is typically a typedef to an integer type whose range is larger than just 0 and 1. When testing the value of a **hal_bit_t**, never compare it to 1. Prefer one of the following:

- `if(b)`
- `if(b != 0)`

It is often useful to refer to a type that can represent all the values as a HAL type, but without the volatile qualifier. The following types correspond with the HAL types:

hal_bit_t

`int`

hal_s32_t

`__s32`

hal_u32_t

`__u32`

hal_float_t

`hal_real_t`

hal_port_t

`int`

Take care not to use the types **s32** and **u32**. These will compile in kernel modules but not in userspace, and not for realtime components when using uspace realtime.

130.4. SEE ALSO

`hal_pin_new(3)`, `hal_param_new(3)`

Chapter 131. rtapi(3)

131.1. NAME

rtapi - Introduction to the RTAPI API

131.2. DESCRIPTION

RTAPI is a library providing a uniform API for several real time operating systems. As of LinuxCNC 2.7, POSIX threads and RTAI are supported.

131.3. HEADER FILES

131.3.1. rtapi.h

The file **rtapi.h** defines the RTAPI for both realtime and non-realtime code. This is a change from Rev 2, where the non-realtime API was defined in `ulapi.h` and used different function names. The symbols RTAPI and ULAPI are used to determine which mode is being compiled, RTAPI for realtime and ULAPI for non-realtime.

131.3.2. rtapi_math.h

The file `rtapi_math.h` defines floating-point functions and constants. It should be used instead of `<math.h>` in rtapi real-time components.

131.3.3. rtapi_string.h

The file `rtapi_string.h` defines string-related functions. It should be used instead of `<string.h>` in rtapi real-time components.

131.3.4. rtapi_byteorder.h

This file defines the preprocessor macros RTAPI_BIG_ENDIAN, RTAPI_LITTLE_ENDIAN, and RTAPI_FLOAT_BIG_ENDIAN as true or false depending on the characteristics of the target system. It should be used instead of `<endian.h>` (userspace) or `<linux/byteorder.h>` (kernel space).

131.3.5. rtapi_limits.h

This file defines the minimum and maximum value of some fundamental integral types, such as INT_MIN and INT_MAX. This should be used instead of `<limits.h>` because that header file is not available to kernel modules.

131.4. REALTIME CONSIDERATIONS

131.4.1. Non-realtime code

Certain functions are not available in non-realtime code. This includes functions that perform direct device access such as **rtapi_inb(3)**.

131.4.2. Init/cleanup code

Certain functions may only be called from realtime init/cleanup code. This includes functions that perform memory allocation, such as **rtapi_shmem_new(3)**.

131.4.3. Realtime code

Only a few functions may be called from realtime code. This includes functions that perform direct device access such as **rtapi_inb(3)**. It excludes most Linux kernel APIs such as **do_gettimeofday(3)** and many rtapi APIs such as **rtapi_shmem_new(3)**.

131.4.4. Simulator

For an RTAPI module to be buildable in the "sim" environment (fake realtime system without special privileges), it must not use **any** linux kernel APIs, and must not use the RTAPI APIs for direct device access such as **rtapi_inb(3)**. This automatically includes any hardware device drivers, and also devices which use Linux kernel APIs to do things like create special devices or entries in the **/proc** filesystem.

131.5. RTAPI STATUS CODES

Except as noted in specific manual pages, RTAPI returns negative **errno** values for errors, and nonnegative values for success.

Chapter 132. rtapi_app_exit(3)

132.1. NAME

rtapi_app_exit - User-provided function to shut down a component

132.2. SYNTAX

```
#include <rtapi_app.h>
void rtapi_app_exit(void);
```

132.3. ARGUMENTS

None

132.4. DESCRIPTION

The body of **rtapi_app_exit**, which is provided by the component author, generally consists of a call to `rtapi_exit` or `hal_exit`, preceded by other component-specific shutdown code.

This code is called when unloading a component which successfully initialized (i.e., returned zero from its **rtapi_app_main**). It is not called when the component did not successfully initialize.

132.5. RETURN VALUE

None.

132.6. REALTIME CONSIDERATIONS

Called automatically by the rtapi infrastructure in an initialization (not realtime) context.

132.7. SEE ALSO

rtapi_app_main(3), rtapi_exit(3), hal_exit(3)

Chapter 133. rtapi_app_main(3)

133.1. NAME

rtapi_app_main - User-provided function to initialize a component

133.2. SYNTAX

```
#include <rtapi_app.h>
int rtapi_app_main(void);
```

133.3. ARGUMENTS

None

133.4. DESCRIPTION

The body of **rtapi_app_main**, which is provided by the component author, generally consists of a call to `rtapi_init` or `hal_init`, followed by other component-specific initialization code.

133.5. RETURN VALUE

Return 0 for success. Return a negative `errno` value (e.g., `-EINVAL`) on error. Existing code also returns RTAPI or HAL error values, but using negative `errno` values gives better diagnostics from `insmod`.

133.6. REALTIME CONSIDERATIONS

Called automatically by the `rtapi` infrastructure in an initialization (not realtime) context.

133.7. SEE ALSO

`rtapi_app_exit(3)`, `rtapi_init(3)`, `hal_init(3)`

Chapter 134. rtapi_atomic(3)

134.1. NAME

rtapi_atomic - subset of C11 stdatomic.h

134.2. SYNTAX

```
#include <rtapi_atomic.h>
enum memory_order { ... };
#define atomic_store(obj, desired)...
#define atomic_store_explicit(obj, desired, order)...
#define atomic_load(obj)...
#define atomic_load_explicit(obj, order)...
```

134.3. ARGUMENTS

volatile A* obj

A pointer to a volatile object that is the destination of the store or the source of the load. The pointer must have an appropriate type and alignment such that the underlying store or load operation itself is atomic; at a minimum, a properly aligned "int" may be assumed to be such a type. Improper size or alignment are undiagnosed errors.

C desired

The value to be stored in the object. `"*obj = desired"` must be well-formed.

memory_order order

The required memory ordering semantic.

134.4. DESCRIPTION

This header provides at least the subset of C11's `<stdatomic.h>` given above. When there is an ordering requirement for multiple values read or written in RTAPI shared memory areas by other threads of execution, including the values of HAL pins and parameters, these functions (or function-like macros) are the only way to ensure the ordering requirement is obeyed. Otherwise, according to architecture-specific rules, loads and stores may be reordered from their normal source code order.

For example, to leave a message in a shared memory area from one thread and retrieve it from another, the writer must use an atomic store for the "message is complete" variable, and the reader must use an atomic load when checking that variable:

```
// producer
*message = 42;
atomic_store_explicit(message_ready, 1, memory_order_release);

// consumer
while(atomic_load_explicit(message_ready, memory_order_acquire) == 0) sched_yield();
```

```
printf("message was %d\n", *message); // must print 42
```

134.5. REALTIME CONSIDERATIONS

May be called from any code.

134.6. RETURN VALUE

atomic_load and **atomic_load_explicit** return the value pointed to by the *obj* argument.

atomic_store and **atomic_store_explicit** have no return value.

134.7. SEE ALSO

<stdatomic.h> (C11), <rtapi_bitops.h> (for other atomic memory operations supported by rtapi)

Chapter 135. rtapi_bool(3)

135.1. NAME

rtapi_bool - RTAPI wrappers for linux kernel functionality

135.2. SYNTAX

```
#include <rtapi_bool.h>
```

135.3. DESCRIPTION

Includes either <stdbool.h> or <linux/types.h> as appropriate, to obtain suitable declarations of "bool", "true" and "false".

135.4. REALTIME CONSIDERATIONS

None.

135.5. NOTES

Also permitted in C++ programs, where including it has no effect.

Chapter 136. rtapi_byteorder(3)

136.1. NAME

rtapi_byteorder - RTAPI wrappers for linux kernel functionality

136.2. SYNTAX

```
#include <rtapi_byteorder.h>
```

RTAPI_BIG_ENDIAN

Defined to 1 if the platform is big-endian, 0 otherwise.

RTAPI_LITTLE_ENDIAN

Defined to 1 if the platform is little-endian, 0 otherwise.

RTAPI_FLOAT_BIG_ENDIAN

Defined to 1 if the platform double-precision value is big-endian, 0 otherwise.

136.3. DESCRIPTION

In kernel space, each `rtapi_xxx` or `RTAPI_XXX` identifier is mapped to the underlying kernel functionality, if available.

In userspace, or in kernels where the underlying functionality is not provided by a kernel, generally another implementation—possibly with reduced functionality—is provided. (For example, the userspace implementation for `rtapi_byteorder_register` always succeeds)

136.4. REALTIME CONSIDERATIONS

May be used at any time.

136.5. RETURN VALUE

As in Linux.

Chapter 137. rtapi_clock_set_period(3)

137.1. NAME

rtapi_clock_set_period - set the basic time interval for realtime tasks

137.2. SYNTAX

```
rtapi_clock_set_period(long int nsec);
```

137.3. ARGUMENTS

nsec

The desired basic time interval for realtime tasks.

137.4. DESCRIPTION

rtapi_clock_set_period sets the basic time interval for realtime tasks. All periodic tasks will run at an integer multiple of this period. The first call to **rtapi_clock_set_period** with *nsec* greater than zero will start the clock, using *nsec* as the clock period in nano-seconds. Due to hardware and RTOS limitations, the actual period may not be exactly what was requested. On success, the function will return the actual clock period if it is available, otherwise it returns the requested period. If the requested period is outside the limits imposed by the hardware or RTOS, it returns **-EINVAL** and does not start the clock. Once the clock is started, subsequent calls with non-zero *nsec* return **-EINVAL** and have no effect. Calling **rtapi_clock_set_period** with *nsec* set to zero queries the clock, returning the current clock period, or zero if the clock has not yet been started.

137.5. REALTIME CONSIDERATIONS

Call only from within init/cleanup code, not from realtime tasks. This function is not available from non-realtime code.

137.6. RETURN VALUE

The actual period provided by the RTOS, which may be different than the requested period, or a RTAPI status code.

Chapter 138. rtapi_delay(3)

138.1. NAME

rtapi_delay, rtapi_delay_max - Busy-loop for short delays

138.2. SYNTAX

```
void rtapi_delay(long int _nsec_);  
void rtapi_delay_max();
```

138.3. ARGUMENTS

nsec

The desired delay length in nanoseconds.

138.4. DESCRIPTION

rtapi_delay is a simple delay. It is intended only for short delays, since it simply loops, wasting CPU cycles.

rtapi_delay_max returns the max delay permitted (usually approximately 1/4 of the clock period). Any call to **rtapi_delay** requesting a delay longer than the max will delay for the max time only.

rtapi_delay_max should be called before using **rtapi_delay** to make sure the required delays can be achieved. The actual resolution of the delay may be as good as one nano-second, or as bad as a several microseconds.

138.5. REALTIME CONSIDERATIONS

May be called from init/cleanup code, and from within realtime tasks.

138.6. RETURN VALUE

rtapi_delay_max returns the maximum delay permitted.

138.7. SEE ALSO

rtapi_clock_set_period(3)

Chapter 139. rtapi_device(3)

139.1. NAME

rtapi_device - RTAPI wrappers for linux kernel functionality

139.2. SYNTAX

```
#include <rtapi_device.h>
struct rtapi_device;
int rtapi_dev_set_name(struct rtapi_device* dev, const char* name, ...);
int rtapi_device_register(struct rtapi_device* dev);
int rtapi_device_unregister(struct rtapi_device* dev);
```

139.3. DESCRIPTION

In kernel space, each ``rtapi_`xxx` or ``RTAPI_`XXX` identifier is mapped to the underlying kernel functionality, if available.

In userspace, or in kernels where the underlying functionality is not provided by a kernel, generally another implementation—possibly with reduced functionality—is provided. (For example, the userspace implementation for `rtapi_device_register` always succeeds)

139.4. REALTIME CONSIDERATIONS

Typically, these functions may be called from realtime init/cleanup code.

139.5. RETURN VALUE

As in Linux.

Chapter 140. rtapi_div_u64(3)

140.1. NAME

rtapi_div_u64, rtapi_div_u64_rem, rtapi_div_s64, rtapi_div_s64_rem - unsigned division of a 64-bit number by a 32-bit number

140.2. SYNTAX

```
__u64 rtapi_div_u64_rem(__u64 dividend, __u32 divisor, __u32* remainder);
__u64 rtapi_div_u64(__u64 dividend, __u32 divisor);
__s64 rtapi_div_s64(__s64 dividend, __s32 divisor);
__s64 rtapi_div_s64_rem(__s64 dividend, __s32 divisor, __s32* remainder);
```

140.3. ARGUMENTS

dividend

The value to be divided.

divisor

The value to divide by.

remainder

Pointer to the location to store the remainder. This may not be a NULL pointer. If the remainder is not desired, call **rtapi_div_u64** or **rtapi_div_s64**.

140.4. DESCRIPTION

Perform integer division (and optionally compute the remainder) with a 64-bit dividend and 32-bit divisor.

140.5. RETURN VALUE

The result of integer division of *dividend* / *divisor*. In versions with the *remainder* argument, the remainder is stored in the pointed-to location.

140.6. NOTES

If the result of the division does not fit in the return type, the result is undefined.

This function exists because in kernel space the use of the division operator on a 64-bit type can lead to an undefined symbol such as `__umoddi3` when the module is loaded.

140.7. REALTIME CONSIDERATIONS

May be called from init/cleanup code and from within realtime tasks. Available in non-realtime components.

Chapter 141. rtapi_exit(3)

141.1. NAME

rtapi_exit - Shut down RTAPI

141.2. SYNTAX

```
int rtapi_exit(int module_id);
```

141.3. ARGUMENTS

module_id

An rtapi module identifier returned by an earlier call to **rtapi_init**.

141.4. DESCRIPTION

rtapi_exit shuts down and cleans up the RTAPI. It must be called prior to exit by any module that called **rtapi_init**.

141.5. REALTIME CONSIDERATIONS

Call only from within non-realtime or realtime init/cleanup code, not from realtime tasks.

141.6. RETURN VALUE

Returns a RTAPI status code.

Chapter 142. rtapi_firmware(3)

142.1. NAME

rtapi_firmware - RTAPI wrappers for linux kernel functionality

142.2. SYNTAX

```
#include <rtapi_firmware.h>
struct rtapi_firmware;
int rtapi_request_firmware(const struct rtapi_firmware **fw,
                          const char* name, struct rtapi_device* device);
void rtapi_release_firmware(const struct rtapi_firmware *fw);
```

142.3. DESCRIPTION

In kernel space, each `rtapi_xxx` or `RTAPI_XXX` identifier is mapped to the underlying kernel functionality, if available.

In userspace, or in kernels where the underlying functionality is not provided by a kernel, generally another implementation—possibly with reduced functionality—is provided. (For example, the userspace implementation for `rtapi_device_register` always succeeds)

142.4. REALTIME CONSIDERATIONS

Typically, these functions may be called from realtime init/cleanup code.

142.5. RETURN VALUE

As in Linux.

Chapter 143. rtapi_get_msg_level(3)

143.1. NAME

rtapi_get_msg_level, rtapi_set_msg_level - Get or set the logging level

143.2. SYNTAX

```
int rtapi_set_msg_level(int level);  
int rtapi_get_msg_level();
```

143.3. ARGUMENTS

level

The desired logging level.

143.4. DESCRIPTION

Get or set the RTAPI message level used by **rtapi_print_msg**. Depending on the RTOS, this level may apply to a single RTAPI module, or it may apply to a group of modules.

143.5. REALTIME CONSIDERATIONS

May be called from non-realtime, init/cleanup, and realtime code.

143.6. RETURN VALUE

rtapi_set_msg_level returns a status code, and **rtapi_get_msg_level** returns the current level. RTAPI_MSG_NONE = 0, RTAPI_MSG_ERR = 1, RTAPI_MSG_WARN = 2, RTAPI_MSG_INFO = 3, RTAPI_MSG_DBG = 4, RTAPI_MSG_ALL = 5

143.7. SEE ALSO

rtapi_print_msg(3)

Chapter 144. rtapi_get_time(3)

144.1. NAME

rtapi_get_time, rtapi_get_clocks - get the current time

144.2. SYNTAX

```
long long rtapi_get_time();  
long long rtapi_get_clocks();
```

144.3. DESCRIPTION

rtapi_get_time returns the current time in nanoseconds. Depending on the RTOS, this may be time since boot, or time since the clock period was set, or some other time. Its absolute value means nothing, but it is monotonically increasing and can be used to schedule future events, or to time the duration of some activity. Returns a 64 bit value. The resolution of the returned value may be as good as one nano-second, or as poor as several microseconds. May be called from init/cleanup code, and from within realtime tasks.

rtapi_get_clocks returns the current time in CPU clocks. It is fast, since it just reads the TSC in the CPU instead of calling a kernel or RTOS function. Of course, times measured in CPU clocks are not as convenient, but for relative measurements this works fine. Its absolute value means nothing, but it is monotonically increasing and can be used to schedule future events, or to time the duration of some activity. (On SMP machines, the two TSC's may get out of sync, so if a task reads the TSC, gets swapped to the other CPU, and reads again, the value may decrease. RTAPI tries to force all RT tasks to run on one CPU.) Returns a 64 bit value. The resolution of the returned value is one CPU clock, which is usually a few nanoseconds to a fraction of a nanosecond. Note that *long long* math may be poorly supported on some platforms, especially in kernel space. Also note that `rtapi_print()` will NOT print *long longs*. Most time measurements are relative, and should be done like this:

```
deltat = (long int)(end_time - start_time);
```

where `end_time` and `start_time` are `longlong` values returned from `rtapi_get_time`, and `deltat` is an ordinary `long int` (32 bits). This will work for times up to a second or so, depending on the CPU clock frequency. It is best used for millisecond and microsecond scale measurements though.

144.4. RETURN VALUE

Returns the current time in nanoseconds or CPU clocks.

144.5. NOTES

Certain versions of the Linux kernel provide a global variable **cpu_khz**. Computing

```
deltat = (end_clocks - start_clocks) / cpu_khz:
```

gives the duration measured in milliseconds. Computing

```
deltat = (end_clocks - start_clocks) * 1000000 / cpu_khz:
```

gives the duration measured in nanoseconds for deltas less than about 9 trillion clocks (e.g., 3000 seconds at 3 GHz).

144.6. REALTIME CONSIDERATIONS

May be called from init/cleanup code and from within realtime tasks. Not available in non-realtime components.

Chapter 145. rtapi_gfp(3)

145.1. NAME

rtapi_gfp - RTAPI wrappers for linux kernel functionality

145.2. SYNTAX

```
#include <rtapi_gfp.h>
enum rtapi_gfp_e;
RTAPI_GFP_xxx
typedef ... rtapi_gfp_t;
```

145.3. DESCRIPTION

In kernel space, each `rtapi_xxx` or `RTAPI_XXX` identifier is mapped to the underlying kernel functionality, if available.

In userspace, or in kernels where the underlying functionality is not provided by a kernel, generally another implementation—possibly with reduced functionality—is provided. (For example, the userspace implementation for `rtapi_device_register` always succeeds)

145.4. REALTIME CONSIDERATIONS

Typically, these functions may be called from realtime init/cleanup code.

145.5. RETURN VALUE

As in Linux.

Chapter 146. rtapi_init(3)

146.1. NAME

rtapi_init - Sets up RTAPI

146.2. SYNTAX

```
int rtapi_init(const char *_modname_);
```

146.3. ARGUMENTS

modname

The name of this RTAPI module.

146.4. DESCRIPTION

rtapi_init sets up the RTAPI. It must be called by any module that intends to use the API, before any other RTAPI calls.

modname can optionally point to a string that identifies the module. The string will be truncated at **RTAPI_NAME_LEN** characters. If *modname* is **NULL**, the system will assign a name.

146.5. REALTIME CONSIDERATIONS

Call only from within non-realtime or realtime init/cleanup code, not from realtime tasks.

146.6. RETURN VALUE

On success, returns a positive integer module ID, which is used for subsequent calls to **rtapi_xxx_new**, **rtapi_xxx_delete**, and **rtapi_exit**. On failure, returns an RTAPI error code.

Chapter 147. rtapi_io(3)

147.1. NAME

rtapi_io - RTAPI wrappers for linux kernel functionality

147.2. SYNTAX

```
#include <rtapi_io.h>
unsigned char rtapi_inb(unsigned short int port);
unsigned short rtapi_inw(unsigned short int port);
unsigned int rtapi_inl(unsigned short int port);
unsigned void rtapi_outb(unsigned char value, unsigned short int port);
unsigned void rtapi_outw(unsigned short value, unsigned short int port);
unsigned void rtapi_inl(unsigned int value, unsigned short int port);
int rtapi_ioperm(unsigned long from, unsigned long num, int turn_on);
unsigned void rtapi_outl(unsigned int value, unsigned short int port);
```

147.3. DESCRIPTION

In kernel space, each rtapi_xxx or RTAPI_XXX identifier is mapped to the underlying kernel functionality, if available.

In userspace, or in kernels where the underlying functionality is not provided by a kernel, generally another implementation—possibly with reduced functionality—is provided. (For example, the userspace implementation for rtapi_device_register and the kernel space implementation of rtapi_ioperm always succeeds)

147.4. REALTIME CONSIDERATIONS

Call from init/cleanup code and from realtime tasks. These functions will cause illegal instruction exceptions in non-realtime components, as well as in uspace rtapi_app when it is not setuid root.

147.5. RETURN VALUE

As in Linux.

147.6. SEE ALSO

inb(3), inw(3), inl(3), outb(3), outw(3), outl(3), ioperm(3)

147.7. AUTHOR

Jeff Epler

Chapter 148. rtapi_is(3)

148.1. NAME

rtapi_is - details of rtapi configuration

148.2. SYNTAX

```
int rtapi_is_kernelspace();
int rtapi_is_realtime();
```

148.3. DESCRIPTION

rtapi_is_kernelspace() returns nonzero when rtapi modules run in kernel space (e.g., under RTAI) and zero when they run in userspace (e.g., under uspace).

rtapi_is_realtime() returns nonzero when capable of running with realtime guarantees. For rtai, this always returns nonzero (but actually loading realtime modules will fail if not running under the appropriate kernel). For uspace, this returns nonzero when the running kernel indicates it is capable of realtime performance. If **rtapi_app** is not setuid root, this returns nonzero even though **rtapi_app** will not be able to obtain realtime scheduling or hardware access, so e.g., attempting to **loadrt** a hardware driver will fail.

148.4. REALTIME CONSIDERATIONS

May be called from non-realtime or from realtime setup code. **rtapi_is_realtime()** may perform filesystem I/O.

148.5. RETURN VALUE

Zero for false, nonzero for true.

Chapter 149. rtapi_list(3)

149.1. NAME

rtapi_list - RTAPI wrappers for linux kernel functionality

149.2. SYNTAX

```
#include <rtapi_list.h>
struct rtapi_list_head;
void rtapi_list_add(struct rtapi_list_head*new_,
                   struct rtapi_list_head* head);
void rtapi_list_add_tail(struct rtapi_list_head* new_,
                        struct rtapi_list_head* head);
void rtapi_list_del(struct rtapi_list_head* entry);
void RTAPI_INIT_LIST_HEAD(struct rtapi_list_head* entry);
rtapi_list_for_each(pos, head) { ... }
rtapi_list_entry(ptr, type, member)
```

149.3. DESCRIPTION

In kernel space, each `rtapi_xxx` or `RTAPI_XXX` identifier is mapped to the underlying kernel functionality, if available.

In userspace, or in kernels where the underlying functionality is not provided by a kernel, generally another implementation—possibly with reduced functionality—is provided. (For example, the userspace implementation for `rtapi_device_register` always succeeds)

149.4. REALTIME CONSIDERATIONS

Call from init/cleanup code and from realtime tasks. These functions will cause illegal instruction exceptions in non-realtime components, as well as in uspace `rtapi_app` when it is not `setuid root`.

149.5. RETURN VALUE

As in Linux.

Chapter 150. rtapi_module_param(3)

150.1. NAME

rtapi_module_param, EXPORT_FUNCTION, RTAPI_MP_INT, RTAPI_MP_LONG, RTAPI_MP_STRING, RTAPI_MP_ARRAY_INT, RTAPI_MP_ARRAY_LONG, RTAPI_MP_ARRAY_STRING, MODULE_LICENSE, MODULE_AUTHOR, MODULE_DESCRIPTION - Specifying module parameters

150.2. SYNTAX

```
RTAPI_MP_INT(_var_, _description_);
RTAPI_MP_LONG(_var_, _description_);
RTAPI_MP_STRING(_var_, _description_);
RTAPI_MP_ARRAY_INT(_var_, _num_, _description_);
RTAPI_MP_ARRAY_LONG(_var_, _num_, _description_);
RTAPI_MP_ARRAY_STRING(_var_, _num_, _description_);
MODULE_LICENSE(_license_);
MODULE_AUTHOR(_author_);
MODULE_DESCRIPTION(_description_);
EXPORT_FUNCTION(_function_);
```

150.3. ARGUMENTS

var

The variable where the parameter should be stored

description

A short description of the parameter or module

num

The maximum number of values for an array parameter

license

The license of the module, for instance "GPL"

author

The author of the module

function

The pointer to the function to be exported

150.4. DESCRIPTION

These macros are portable ways to declare kernel module parameters. They must be used in the global scope, and are not followed by a terminating semicolon. They must be used after the associated variable or function has been defined.

150.5. NOTES

EXPORT_FUNCTION makes a symbol available for use by a subsequently loaded component. It is unrelated to HAL functions, which are described in hal_export_funct(3)

150.6. Interpretation of license strings

MODULE_LICENSE follows the kernel's definition of license strings. Notably, "GPL" indicates "GNU General Public License v2 *or later*". (emphasis ours).

"GPL"

GNU General Public License v2 or later

"GPL v2"

GNU General Public License v2

"GPL and additional rights"

GNU General Public License v2 rights and more

"Dual BSD/GPL"

GNU General Public License v2 or BSD license choice

"Dual MIT/GPL"

GNU General Public License v2 or MIT license choice

"Dual MPL/GPL"

GNU General Public License v2 or Mozilla license choice

"Proprietary"

Non-free products

It is still good practice to include a license block which indicates the author, copyright date, and disclaimer of warranty as recommended by the GNU GPL.

150.7. REALTIME CONSIDERATIONS

Not available in userspace code.

Chapter 151. rtapi_mutex(3)

151.1. NAME

rtapi_mutex - Mutex-related functions

151.2. SYNTAX

```
#include <rtapi_mutex.h>

int rtapi_mutex_try(unsigned long* _mutex_);
int rtapi_mutex_get(unsigned long* _mutex_);
int rtapi_mutex_give(unsigned long* _mutex_);
```

151.3. ARGUMENTS

mutex

A pointer to the mutex.

151.4. DESCRIPTION

rtapi_mutex_try makes a non-blocking attempt to get the mutex. If the mutex is available, it returns 0, and the mutex is no longer available. Otherwise, it returns a nonzero value.

rtapi_mutex_get blocks until the mutex is available.

rtapi_mutex_give releases a mutex acquired by **rtapi_mutex_try** or **rtapi_mutex_get**.

151.5. REALTIME CONSIDERATIONS

rtapi_mutex_give and **rtapi_mutex_try** may be used from non-realtime, init/cleanup, and realtime code.

rtapi_mutex_get may not be used from realtime code.

151.6. RETURN VALUE

rtapi_mutex_try returns 0 for if the mutex was claimed, and nonzero otherwise.

rtapi_mutex_get and **rtapi_mutex_gif** have no return value.

Chapter 152. rtapi_open_as_root(3)

152.1. NAME

rtapi_open_as_root - Open a file with "root" privilege

152.2. SYNTAX

```
#include <rtapi.h>
int rtapi_open_as_root(const char *filename, int flags);
```

152.3. ARGUMENTS

filename

The filename to open, as in **open(2)**. Note that rtapi has no well-defined "current directory", so this should be an absolute path, but this is not enforced.

flags

The open flags, as in **open(2)**. Should never include bits that open or create files (e.g., O_CREAT, O_APPEND, etc) as this API is not intended for creating or writing files, but this is not enforced.

152.4. DESCRIPTION

In "uspace" realtime, root privileges are dropped whenever possible. This API temporarily switches on root privileges to open a file, and switches them off before returning. This can be useful for example when accessing device nodes or memory-mapped I/O.

In the case of PCI devices on x86 and x86-64 systems, prefer the linux-style PCI interfaces provided in **<rtapi_pci.h>**.

152.5. RETURN VALUE

In case of success, the nonnegative file descriptor opened. If the caller does not close it, it remains open until rtapi_app exits.

In case of failure, a negative errno value.

152.6. REALTIME CONSIDERATIONS

Call only from realtime initcode in "uspace" realtime.

152.7. SEE ALSO

open(2), rtapi_pci(3)

Chapter 153. rtapi_outb(3)

153.1. NAME

rtapi_outb, rtapi_inb - Perform hardware I/O

153.2. SYNTAX

```
void rtapi_outb(unsigned char _byte_, unsigned int _port_);  
unsigned char rtapi_inb(unsigned int _port_);
```

153.3. ARGUMENTS

port

The address of the I/O port

byte

The byte to be written to the port

153.4. DESCRIPTION

rtapi_outb writes a byte to a hardware I/O port. **rtapi_inb** reads a byte from a hardware I/O port.

153.5. REALTIME CONSIDERATIONS

May be called from init/cleanup code and from within realtime tasks. Not available in non-realtime components.

153.6. RETURN VALUE

rtapi_inb returns the byte read from the given I/O port

153.7. NOTES

The I/O address should be within a region previously allocated by **rtapi_request_region**. Otherwise, another real-time module or the Linux kernel might attempt to access the I/O region at the same time.

153.8. SEE ALSO

rtapi_region(3)

Chapter 154. rtapi_parport(3)

154.1. NAME

rtapi_parport - portable access to PC-style parallel ports

154.2. SYNTAX

```
#include "rtapi_parport.h"

int rtapi_parport_get(const char* _module_name_, rtapi_parport_t* _port_,
                     short _base_, unsigned short _base_hi_,
                     int _modes_);
void rtapi_parport_release(rtapi_parport_t* _port_);
```

154.3. ARGUMENTS

module_name

By convention, the name of the RTAPI module or HAL component using the parport.

port

A pointer to a `rtapi_parport_t` structure.

base

The base address of the port (if `port >= 16`) or the linux port number of the port (if `port < 16`).

base_hi

The "high" address of the port (location of the ECP registers), 0 to use a probed high address, or -1 to disable the high address.

modes

Advise the driver of the desired port modes, from `<linux/parport.h>`. If a linux-detected port does not provide the requested modes, a warning is printed with `rtapi_print_msg`. This does not make the port request fail, because unfortunately, many systems that have working EPP parports are not detected as such by Linux.

154.4. DESCRIPTION

rtapi_parport_get allocates a parallel port for exclusive use of the named hal component. If successful, access the port with I/O calls such as `rtapi_inb` at address based at the **base** or **base_hi** addresses. The port must be released with **rtapi_parport_release** before the component exits with **rtapi_exit**.

154.5. HIGH ADDRESS PROBING

If the port is a parallel port known to Linux, and Linux detected a high I/O address, this value is used.

Otherwise, if `base+0x400` is not registered to any device, it is used. Otherwise, no address is used. If no high address is detected, `port→base_hi` is 0.

154.6. PARPORT STRUCTURE

```
typedef struct
{
    unsigned short base;
    unsigned short base_hi;
    .... // and further unspecified fields
} rtapi_parport_t;
```

154.7. RETURN VALUE

rtapi_parport_get returns a HAL status code. On success, *port* is filled out with information about the allocated port. On failure, the contents of *port* are undefined except that it is safe (but not required) to pass this port to **rtapi_parport_release**.

rtapi_parport_release does not return a value. It always succeeds.

154.8. NOTES

In new code, prefer use of `rtapi_parport` to `rtapi_parport`.

Chapter 155. rtapi_pci(3)

155.1. NAME

rtapi_pci - RTAPI wrappers for linux kernel functionality

155.2. SYNTAX

```
#include <rtapi_pci.h>

struct rtapi_pci_device_id { ... };
struct rtapi_pci_resource { ... };
struct rtapi_pci_dev { ... };
struct rtapi_pci_driver { ... };
const char *rtapi_pci_name(const struct rtapi_pci_dev *pdev);
int rtapi_pci_enable_device(struct rtapi_pci_dev *dev);
void rtapi_iomem *rtapi_pci_ioremap_bar(struct rtapi_pci_dev *pdev, int bar);
int rtapi_pci_register_driver(struct rtapi_pci_driver *driver);
void rtapi_pci_unregister_driver(struct rtapi_pci_driver *driver);
int rtapi_pci_enable_device(struct rtapi_pci_dev *dev);
int rtapi_pci_disable_device(struct rtapi_pci_dev *dev);
#define rtapi_pci_resource_start(dev, bar) ...
#define rtapi_pci_resource_end(dev, bar) ...
#define rtapi_pci_resource_flags(dev, bar) ...
#define rtapi_pci_resource_len(dev, bar) ....
void rtapi_pci_set_drvdata(struct rtapi_pci_dev *pdev, void *data)
void rtapi_pci_set_drvdata(struct rtapi_pci_dev *pdev, void *data)
void rtapi_iounmap(volatile void *addr);
struct rtapi_pci;
```

155.3. DESCRIPTION

In kernel space, each `rtapi_xxx` or `RTAPI_XXX` identifier is mapped to the underlying kernel functionality, if available.

In userspace, or in kernels where the underlying functionality is not provided by a kernel, generally another implementation—possibly with reduced functionality—is provided. (For example, the userspace implementation for `rtapi_pci_register` always succeeds)

155.4. REALTIME CONSIDERATIONS

Typically, these functions may be called from realtime init/cleanup code.

155.5. RETURN VALUE

As in Linux.

Chapter 156. rtapi_print(3)

156.1. NAME

rtapi_print, rtapi_print_msg - print diagnostic messages

156.2. SYNTAX

```
void rtapi_print(const char* _fmt_, ...)
void rtapi_print_msg(int level, const char* _fmt_, ...)
typedef void(**rtapi_msg_handler_t*)(msg_level_t _level_, const char* _msg_);
void rtapi_set_msg_handler(rtapi_msg_handler_t _handler_);
rtapi_msg_handler_t rtapi_get_msg_handler(void);
```

156.3. ARGUMENTS

level

A message level: One of **RTAPI_MSG_ERR**, **RTAPI_MSG_WARN**, **RTAPI_MSG_INFO**, or **RTAPI_MSG_DBG**.

handler

A function to call from **rtapi_print** or **rtapi_print_msg** to actually output the message.

fmt, ...

Other arguments are as for *rtapi_vsnprintf(3)*.

156.4. DESCRIPTION

rtapi_print and **rtapi_print_msg** work like the standard C printf functions, except that a reduced set of formatting operations are supported. Notably, formatting long-long values is not supported, and formatting floating-point values has different behavior than standard printf.

Depending on the RTOS, the default may be to print the message to stdout, stderr, a kernel log, etc. In RTAPI code, the action may be changed by a call to **rtapi_set_msg_handler**. A **NULL** argument to **rtapi_set_msg_handler** restores the default handler. **rtapi_get_msg_handler** returns the current handler. When the message came from **rtapi_print**, *level* is **RTAPI_MSG_ALL**.

rtapi_print_msg works like **rtapi_print** but only prints if *level* is less than or equal to the current message level.

156.5. REALTIME CONSIDERATIONS

rtapi_print and **rtapi_print_msg** May be called from non-realtime, init/cleanup, and realtime code. **rtapi_get_msg_handler** and **rtapi_set_msg_handler** may be called from realtime init/cleanup code. A message handler passed to **rtapi_set_msg_handler** may only call functions that can be called from

realtime code.

156.6. RETURN VALUE

None.

156.7. SEE ALSO

rtapi_set_msg_level(3), rtapi_get_msg_level(3), rtapi_vsnprintf(3)

Chapter 157. rtapi_prio(3)

157.1. NAME

rtapi_prio, rtapi_prio_highest, rtapi_prio_lowest, rtapi_prio_next_higher, rtapi_prio_next_lower - thread priority functions

157.2. SYNTAX

```
int rtapi_prio_highest();
int rtapi_prio_lowest();
int rtapi_prio_next_higher(int _prio_);
int rtapi_prio_next_lower(int _prio_);
```

157.3. ARGUMENTS

prio

A value returned by a prior **rtapi_prio_xxx** call

157.4. DESCRIPTION

The **rtapi_prio_xxxx** functions provide a portable way to set task priority. The mapping of actual priority to priority number depends on the RTOS. Priorities range from **rtapi_prio_lowest** to **rtapi_prio_highest**, inclusive. To use this API, use one of two methods:

1. Set your lowest priority task to **rtapi_prio_lowest**, and for each task of the next lowest priority, set their priorities to **rtapi_prio_next_higher**(previous).
2. Set your highest priority task to **rtapi_prio_highest**, and for each task of the next highest priority, set their priorities to **rtapi_prio_next_lower**(previous).

N.B.: A high priority task will preempt or interrupt a lower priority task. Linux is always the lowest priority!

157.5. REALTIME CONSIDERATIONS

Call these functions only from within init/cleanup code, not from realtime tasks.

157.6. RETURN VALUE

Returns an opaque real-time priority number.

157.7. SEE ALSO

rtapi_task_new(3)

Chapter 158. rtapi_region(3)

158.1. NAME

rtapi_region, rtapi_request_region, rtapi_release_region - functions to manage I/O memory regions

158.2. SYNTAX

```
void *rtapi_request_region(unsigned long _base_, unsigned long int _size_, const char*  
_name_)  
void rtapi_release_region(unsigned long _base_, unsigned long int _size_)
```

158.3. ARGUMENTS

base

The base address of the I/O region

size

The size of the I/O region

name

The name to be shown in /proc/ioproports

158.4. DESCRIPTION

rtapi_request_region reserves I/O memory starting at *base* and going for *size* bytes.

158.5. REALTIME CONSIDERATIONS

May be called from realtime init/cleanup code only.

158.6. RETURN VALUE

rtapi_request_region returns NULL if the allocation fails, and a non-NULL value otherwise.

rtapi_release_region has no return value.

Chapter 159. rtapi_shmem(3)

159.1. NAME

rtapi_shmem, rtapi_shmem_new, rtapi_shmem_delete, rtapi_shmem_getptr - Functions for managing shared memory blocks

159.2. SYNTAX

```
int rtapi_shmem_new(int _key_, int _module_id_, unsigned long int _size_);
int rtapi_shmem_delete(int _shmem_id_, int _module_id_);
int rtapi_shmem_getptr(int _shmem_id_, void ** _ptr_);
```

159.3. ARGUMENTS

key

Identifies the memory block. Key must be nonzero. All modules wishing to use the same memory must use the same key.

module_id

Module identifier returned by a prior call to **rtapi_init**.

size

The desired size of the shared memory block, in bytes

ptr

The pointer to the shared memory block. Note that the block may be mapped at a different address for different modules.

159.4. DESCRIPTION

rtapi_shmem_new allocates a block of shared memory. *key* identifies the memory block, and must be non-zero. All modules wishing to access the same memory must use the same key. *module_id* is the ID of the module that is making the call (see **rtapi_init**). The block will be at least *size* bytes, and may be rounded up. Allocating many small blocks may be very wasteful. When a particular block is allocated for the first time, the contents are zeroed. Subsequent allocations of the same block by other modules or processes will not touch the contents of the block. Applications can use those bytes to see if they need to initialize the block, or if another module already did so. On success, it returns a positive integer ID, which is used for all subsequent calls dealing with the block. On failure it returns a negative error code.

rtapi_shmem_delete frees the shared memory block associated with *shmem_id*. *module_id* is the ID of the calling module. Returns a status code.

rtapi_shmem_getptr sets **ptr* to point to shared memory block associated with *shmem_id*.

159.5. REALTIME CONSIDERATIONS

rtapi_shmem_getptr may be called from non-realtime code, init/cleanup code, or realtime tasks.

rtapi_shmem_new and **rtapi_shmem_dete** may not be called from realtime tasks.

Chapter 160. rtapi_slab(3)

160.1. NAME

rtapi_slab - RTAPI wrappers for linux kernel functionality

160.2. SYNTAX

```
#include <rtapi_slab.h>

void *rtapi_kmalloc(size_t size, gfp_t g);
void *rtapi_kzalloc(size_t size, gfp_t g);
void *rtapi_krealloc(size_t size, gfp_t g);
void rtapi_kfree(void*);
```

160.3. DESCRIPTION

In kernel space, each `rtapi_xxx` or `RTAPI_XXX` identifier is mapped to the underlying kernel functionality, if available.

In userspace, or in kernels where the underlying functionality is not provided by a kernel, generally another implementation—possibly with reduced functionality—is provided. (For example, the userspace implementation for `rtapi_device_register` always succeeds)

160.4. REALTIME CONSIDERATIONS

Call only from within init/cleanup code, not from realtime tasks. This function is not available from non-realtime code.

160.5. RETURN VALUE

As in Linux.

Chapter 161. rtapi_snprintf(3)

161.1. NAME

rtapi_snprintf, rtapi_vsnprintf - Perform snprintf-like string formatting

161.2. SYNTAX

```
int rtapi_snprintf(char* _buf_, unsigned long int _size_, const char* _fmt_, ...);  
int rtapi_vsnprintf(char* _buf_, unsigned long int _size_, const char* _fmt_, va_list  
_apf);
```

161.3. ARGUMENTS

As for *snprintf(3)* or *vsnprintf(3)*.

161.4. DESCRIPTION

These functions work like the standard C printf functions, except that a reduced set of formatting operations are supported.

In particular: formatting of long long values is not supported. Formatting of floating-point values is done as though with %A even when other formats like %f are specified.

161.5. REALTIME CONSIDERATIONS

May be called from non-realtime, init/cleanup, and realtime code.

161.6. RETURN VALUE

The number of characters written to *buf*.

161.7. SEE ALSO

printf(3)

Chapter 162. rtapi_stdint(3)

162.1. NAME

rtapi_stdint - RTAPI wrappers for linux kernel functionality

162.2. SYNTAX

```
#include <rtapi_stdint.h>

typedef ... rtapi_s8;
typedef ... rtapi_s16;
typedef ... rtapi_s32;
typedef ... rtapi_s64;
typedef ... rtapi_intptr_t;
typedef ... rtapi_u8;
typedef ... rtapi_u16;
typedef ... rtapi_u32;
typedef ... rtapi_u64;
typedef ... rtapi_uintptr_t;
#define RTAPI_INT__xx__MIN ...
#define RTAPI_INT__xx__MAX ...
#define RTAPI_UINT__xx__MAX ...
```

162.3. DESCRIPTION

In kernel space, each `rtapi_xxx` or `RTAPI_XXX` identifier is mapped to the underlying kernel functionality, if available.

In userspace, or in kernels where the underlying functionality is not provided by a kernel, generally another implementation—possibly with reduced functionality—is provided. (For example, the userspace implementation for `rtapi_device_register` always succeeds)

162.4. REALTIME CONSIDERATIONS

None.

162.5. RETURN VALUE

As in Linux.

Chapter 163. rtapi_string(3)

163.1. NAME

rtapi_string - RTAPI wrappers for linux kernel functionality

163.2. SYNTAX

```
#include <rtapi_string.h>
char** rtapi_argv_split(rtapi_gfp_t g, const char* argstr, int* argc);
void rtapi_argv_free(char** argv);
char* rtapi_kstrdup(const char* s, rtapi_gfp_t t);
```

163.3. DESCRIPTION

In kernel space, each `rtapi_xxx` or `RTAPI_XXX` identifier is mapped to the underlying kernel functionality, if available.

In userspace, or in kernels where the underlying functionality is not provided by a kernel, generally another implementation—possibly with reduced functionality—is provided. (For example, the userspace implementation for `rtapi_device_register` always succeeds)

163.4. REALTIME CONSIDERATIONS

Call only from within init/cleanup code, not from realtime tasks. This function is not available from non-realtime code.

163.5. RETURN VALUE

As in Linux.

Chapter 164. rtapi_strlcpy(3)

164.1. NAME

rtapi_strlcpy - RTAPI string manipulation functions

164.2. SYNTAX

```
#include <rtapi_string.h>

size_t rtapi_strlcpy(char *dst, const char *src, size_t sz);
#define rtapi_strxcpy(dst, src) ...
size_t rtapi_strlcat(char *dst, const char *src, size_t sz);
#define rtapi_strxcat(dst, src) ...
```

164.3. DESCRIPTION

rtapi_strlcpy will copy at most *sz* chars from *src* to *dst*. Always leaves *dst* NUL-terminated except if *sz* is 0.

rtapi_strxcpy(*dst*, *src*) checks that *dst* is an array with known size, and calls rtapi_strlcpy(*dst*, *src*, sizeof(*dst*)). If it is not an array with a known size, it is a (possibly cryptic!) syntax error.

rtapi_strlcat will append characters from *src* to *dst*, stopping when the end of *src* is reached, or *dst* uses *sz*-many bytes of storage including the trailing null.

rtapi_strxcat(*dst*, *src*) checks that *dst* is an array with known size, and calls rtapi_strlcat(*dst*, *src*, sizeof(*dst*)). If it is not an array with a known size, it is a (possibly cryptic!) syntax error.

164.4. RETURN VALUE

The total length of the string strlcpy or strlcat tried to create. For strlcpy() that means the length of *src*. If the return value is greater than or equal to *sz*, the result was truncated.

164.5. SEE ALSO

strlcpy(3bsd), strlcat(3bsd)

Chapter 165. rtapi_task_new(3)

165.1. NAME

rtapi_task_new, rtapi_task_delete - create a realtime task

165.2. SYNTAX

```
int rtapi_task_new(void (*_taskcode_)(void*), void *_arg_, int _prio_,
                  unsigned long _stacksize_, int _uses_fp_);
int rtapi_task_delete(int _task_id_);
```

165.3. ARGUMENTS

taskcode

A pointer to the function to be called when the task is started

arg

An argument to be passed to the *taskcode* function when the task is started

prio

A task priority value returned by **rtapi_prio_xxxx**

uses_fp

Deprecated and ignored. All tasks now unconditionally save and restore floating point state. This parameter will be removed in a future version.

task_id

A task ID returned by a previous call to **rtapi_task_new**

165.4. DESCRIPTION

rtapi_task_new creates but does not start a realtime task. The task is created in the "paused" state. To start it, call either **rtapi_task_start** for periodic tasks, or **rtapi_task_resume** for free-running tasks.

165.5. REALTIME CONSIDERATIONS

Call only from within init/cleanup code, not from realtime tasks.

165.6. RETURN VALUE

On success, returns a positive integer task ID. This ID is used for all subsequent calls that need to act on the task. On failure, returns an RTAPI status code.

165.7. SEE ALSO

rtapi_prio(3), rtapi_task_start(3), rtapi_task_wait(3), rtapi_task_resume(3)

Chapter 166. rtapi_task_pause(3)

166.1. NAME

rtapi_task_pause, rtapi_task_resume - pause and resume real-time tasks

166.2. SYNTAX

```
void rtapi_task_pause(int _task_id_);  
void rtapi_task_resume(int _task_id_);
```

166.3. ARGUMENTS

task_id

An RTAPI task identifier returned by an earlier call to **rtapi_task_new**.

166.4. DESCRIPTION

rtapi_task_resume starts a task in free-running mode. The task must be in the "paused" state.

A free running task runs continuously until either:

1. It is preempted by a higher priority task. It will resume as soon as the higher priority task releases the CPU.
2. It calls a blocking function, like **rtapi_sem_take**. It will resume when the function unblocks.
3. It is returned to the "paused" state by **rtapi_task_pause**. May be called from init/cleanup code, and from within realtime tasks.

rtapi_task_pause causes a task to stop execution and change to the "paused" state. The task can be free-running or periodic. Note that **rtapi_task_pause** may called from any task, or from init or cleanup code, not just from the task that is to be paused. The task will resume execution when either **rtapi_task_resume** or **rtapi_task_start** (depending on whether this is a free-running or periodic task) is called.

166.5. REALTIME CONSIDERATIONS

May be called from init/cleanup code, and from within realtime tasks.

166.6. RETURN VALUE

An RTAPI status code.

166.7. SEE ALSO

rtapi_task_new(3), rtapi_task_start(3)

Chapter 167. rtapi_task_self(3)

167.1. NAME

rtapi_task_self - Retrieve ID of current task

167.2. SYNTAX

```
void rtapi_task_self();
```

167.3. DESCRIPTION

rtapi_task_self retrieves the current task, or -EINVAL if not in a realtime task (e.g., in startup or shutdown code).

167.4. REALTIME CONSIDERATIONS

May be called from init/cleanup code, and from within realtime tasks.

167.5. RETURN VALUE

The task number previously returned by **rtapi_task_new** or -EINVAL.

167.6. SEE ALSO

rtapi_task_new(3)

Chapter 168. rtapi_task_start(3)

168.1. NAME

rtapi_task_start - start a realtime task in periodic mode

168.2. SYNTAX

```
int rtapi_task_start(int task_id, unsigned long period_nsec);
```

168.3. ARGUMENTS

task_id

A task ID returned by a previous call to **rtapi_task_new**

period_nsec

The clock period in nanoseconds between iterations of a periodic task

168.4. DESCRIPTION

rtapi_task_start starts a task in periodic mode. The task must be in the *paused* state.

168.5. REALTIME CONSIDERATIONS

Call only from within init/cleanup code, not from realtime tasks.

168.6. RETURN VALUE

Returns an RTAPI status code.

168.7. SEE ALSO

rtapi_task_new(3), rtapi_task_pause(3), rtapi_task_resume(3)

Chapter 169. rtapi_task_wait(3)

169.1. NAME

rtapi_task_wait - suspend execution of this periodic task

169.2. SYNTAX

```
void rtapi_task_wait();
```

169.3. DESCRIPTION

rtapi_task_wait suspends execution of the current task until the next period. The task must be periodic. If not, the result is undefined.

169.4. REALTIME CONSIDERATIONS

Call only from within a periodic realtime task.

169.5. RETURN VALUE

None

169.6. SEE ALSO

rtapi_task_start(3), rtapi_task_pause(3)

Chapter 170. hm2_allocate_bsp_i_tram(3)

170.1. NAME

hm2_allocate_bsp_i_tram - Allocate the TRAM regions for a BSP_I channel

170.2. SYNTAX

```
#include <hostmot2-serial.h>
hm2_allocate_bsp_i_tram(char* name)
```

170.3. DESCRIPTION

hm2_allocate_bsp_i_tram Allocate the TRAM memory for bspi instance "name". "name" is a unique string given to each bspi channel during hostmot2 setup. The names of the available channels are printed to standard output during the driver loading process and take the form: hm2_<board name>.<board index>.bsp_i.<index>, for example: hm2_5i23.0.bspi.0 .

This function allocates the TRAM memory and sets up the regular data transfers. It should be called only when all the frames have been defined by calls to hm2_tram_add_bsp_i_frame().

170.4. REALTIME CONSIDERATIONS

Call only from realtime init code, not from other realtime code or non-realtime components.

170.5. RETURN VALUE

Returns 0 on success and -1 on failure.

170.6. SEE ALSO

hm2_bsp_i_set_read_function(3), hm2_bsp_i_setup_chan(3), hm2_bsp_i_set_write_function(3),
hm2_bsp_i_write_chan(3), hm2_tram_add_bsp_i_frame(3)

See src/hal/drivers mesa_7i65.comp for an example usage.

Chapter 171. hm2_bspi_set_read_function(3)

171.1. NAME

hm2_bspi_set_read_function - Register a function to handle the tram write phase of a hostmot2 buffered SPI driver.

171.2. SYNTAX

```
#include <hostmot2-serial.h>
int hm2_bspi_set_read_function(char *name, void *func, void *subdata)
```

171.3. DESCRIPTION

hm2_bspi_set_read_function registers a function in an external driver to be called every time that the main Hostmot2 driver calls the generic "process_tram_read" function. The names of the available channels are printed with `rtapi_print_msg` during the driver loading process and take the form:

```
hm2_<board name>.<board index>.bspi.<index>
```

For example `hm2_5i23.0.bspi.0`.

"func" should be a pointer to a function in the sub driver which is to be called to process the results of the BSPI TRAM read phase. The function must take a single argument, a pointer to an individual instance of the internal driver. If defined in comp then the function must **not** use the `FUNCTION()` convenience macro, and the argument to the function in the definition must **always** be (struct state *inst).

"subdata" is a pointer to the driver instance internal data. In the case of a driver written in comp this will always be "inst" in the function call and the call should be anywhere in the `EXTRA_SETUP` code.

171.4. REALTIME CONSIDERATIONS

Call only from realtime init code, not from other realtime code or non-realtime components.

171.5. RETURN VALUE

Returns 0 on success and -1 on failure.

171.6. SEE ALSO

hm2_allocate_bspi_tram(3), hm2_bspi_setup_chan(3), hm2_bspi_set_write_function(3),
hm2_bspi_write_chan(3), hm2_tram_add_bspi_frame(3), `src/hal/drivers mesa_7i65.comp` in the
LinuxCNC source distribution.

Chapter 172. hm2_bspi_set_write_function(3)

172.1. NAME

hm2_bspi_set_write_function - Register a function to handle the tram write phase of a hostmot2 buffered SPI driver.

172.2. SYNTAX

```
#include <hostmot2-serial.h>
int hm2_bspi_set_write_function(char *name, void *func, void *subdata)
```

172.3. DESCRIPTION

hm2_bspi_set_write_function registers a function in an external driver to be called every time that the main Hostmot2 driver calls the generic "prepare_tram_write" functions. The names of the available channels are printed with `rtapi_print_msg` during the driver loading process and take the form:

hm2_<board name>.<board index>.bspi.<index>

For example `hm2_5i23.0.bspi.0`.

"func" should be a pointer to a function in the sub driver which is to be called to process the pins into BSPI write registers prior to the regular TRAM write phase. The function must take a single argument, a pointer to an individual instance of the internal driver. If defined in comp then the function must **not** use the `FUNCTION()` convenience macro, and the argument to the function in the definition must **always** be (struct state *inst).

"subdata" is a pointer to the driver instance internal data. In the case of a driver written in comp this will always be "inst" in the function call.

If using comp then the call to this function should be anywhere in the `EXTRA_SETUP` code.

172.4. REALTIME CONSIDERATIONS

Call only from realtime init code, not from other realtime code or non-realtime components.

172.5. RETURN VALUE

Returns 0 on success and -1 on failure.

172.6. SEE ALSO

hm2_allocate_bspi_tram(3), hm2_bspi_set_read_function(3), hm2_bspi_setup_chan(3),
hm2_bspi_write_chan(3), hm2_tram_add_bspi_frame(3), src/hal/drivers mesa_7i65.comp in the

LinuxCNC source distribution.

Chapter 173. hm2_bspi_setup_chan(3)

173.1. NAME

hm2_bspi_setup_chan - setup a Hostmot2 bspi channel

173.2. SYNTAX

```
#include <hostmot2-serial.h>
int hm2_bspi_setup_chan(char* name, int chan, int cs, int bits, float mhz,
                        int delay, int cpol, int cpha, int noclear, int noecho)
```

173.3. DESCRIPTION

hm2_bspi_setup_chan allows a realtime component to claim and configure a BSPI channel on a previously configured hostmot2 board.

name

A unique string given to the BSPI channel during hostmot2 setup. The names of the available channels are printed to standard output during the driver loading process and take the form **hm2_board-name.board-index.bspi.bspi-index**. For example, the first index on the first hm2_5i23 board would be called **hm2_5i23.0.bspi.0**.

chan

Channels are numbered 0 to 15. The value on the chip-select lines is set by cs and need not match the channel number.

cs

The chip select line(s) to assert when accessing this channel. BSPI supports 4 chip select lines, so the valid range for cs is 0-15.

bits

sets the bit-length of the SPI packet. The maximum supported length is 64 bits but this will span two read FIFO entries and will need special handling (values 32 and below require no special handling).

mhz

sets the chip communication rate. The maximum value for this is half the FPGA base frequency, so for example with a 48 MHz 5I23 the max SPI frequency is 24 MHz. Values in excess of the max supported will be silently rounded down.

delay

sets the chip select valid delay (in ns)

cpha and cpol

Set the clock phase and polarity (according to the device datasheet).

noclear

Controls whether the frame clear bit is set after the 32 bit buffer transfer. This parameter should be set to 1 when the frame length is greater than 32 bits and the next data in the FIFO contains the other bits.

noecho

Set to 1 for devices which do not return data (such as DACs).

samplelate

Set to 1 to sample the received SPI data 1/2 SPI clock later than normal. This is useful when high clock rates or isolation cause significant delays from clock to received data.

173.4. REALTIME CONSIDERATIONS

Call only from within realtime init/cleanup code or non-realtime components, not from realtime tasks.

173.5. RETURN VALUE

Returns 0 on success and -1 on failure.

173.6. SEE ALSO

hm2_allocate_bspi_tram(3), hm2_bspi_set_read_function(3), hm2_bspi_set_write_function(3),
hm2_bspi_write_chan(3), hm2_tram_add_bspi_frame(3)

See src/hal/drivers mesa_7i65.comp for an example usage.

Chapter 174. hm2_bspi_write_chan(3)

174.1. NAME

hm2_bspi_write_chan - write data to a Hostmot2 Buffered SPI channel

174.2. SYNTAX

```
#include <hostmot2-serial.h>
hm2_bspi_write_chan(char* name, int chan, u32 val)
```

174.3. DESCRIPTION

hm2_bspi_write_chan write one-time data to the bspi channel "chan" on the bspi instance "name". "name" is a unique string given to each bspi channel during hostmot2 setup. The names of the available channels are printed to standard output during the driver loading process and take the form: hm2_<board name>.<board index>.bspi.<index>. For example: **hm2_5i23.0.bspi.0**.

This function performs a one-time write of data to the specified channel. It is typically used for setup and chip enabling purposes. It should not be used in the main loop for regular data transfers (but is appropriate to use for on-the-fly setup changes).

174.4. REALTIME CONSIDERATIONS

May be called from init/cleanup code and from within realtime tasks. Not available in non-realtime components.

174.5. RETURN VALUE

Returns 0 on success and -1 on failure.

174.6. SEE ALSO

hm2_allocate_bspi_tram(3), hm2_bspi_set_read_function(3), hm2_bspi_setup_chan(3),
hm2_bspi_set_write_function(3), hm2_tram_add_bspi_frame(3)

See src/hal/drivers mesa_7i65.comp for an example usage.

Chapter 175. hm2_pktuart(3)

175.1. NAME

hm2_pktuart - functions to access the Mesa FPGA card packeted UARTs

175.2. SYNOPSIS

```
#include <hostmot2-serial.h>
int hm2_pktuart_setup(char* name, int bitrate, rtapi_s32 tx_mode, rtapi_s32 rx_mode, int
txclear, int rxclear);
int hm2_pktuart_send(char* name, unsigned char data[], rtapi_u8* num_frames, rtapi_u16
frame_sizes[]);
int hm2_pktuart_read(char* name, unsigned char data[], rtapi_u8* num_frames, rtapi_u16
*max_frame_length, rtapi_u16 frame_sizes[]);
int hm2_pktuart_queue_get_frame_sizes(char *name, rtapi_u32 fsizes[]);
int hm2_pktuart_queue_read_data(char* name, rtapi_u32* data, int bytes);
int hm2_pktuart_get_clock(char* name);
int hm2_pktuart_get_version(char* name);
rtapi_u32 hm2_pktuart_get_rx_status(char* name);
rtapi_u32 hm2_pktuart_get_tx_status(char* name);
```

175.3. DESCRIPTION

In this context a "Packeted UART" sends data as a burst of bytes separated by blank space, and receives packets of bytes similarly delimited. Each "packet" of N bytes is sent from, or stored in 32-bit "frames" inside 16-deep FIFOs in the FPGA code.

Unlike the other hostmot2 functions, the hostmot2 uart and pktuart do not create any HAL pins or usable driver code when hostmot2 is loaded. Instead interfaxes are created to allow secondary drivers to use them.

In LinuxCNC v2.8 and earlier the PktUART driver was entirely inactive. In LinuxCNC v2.9 onwards the driver polls the Rx and Tx status registers every servo thread, and these can be read with the functions `rtapi_u32 hm2_pktuart_get_rx_status()` and `rtapi_u32 hm2_pktuart_get_tx_status()`.

175.3.1. Accessing the UARTs

The UART functions above can be included in your driver code by ```#include "hostmot2-serial.h"```. This will make the functions above available for use in your own C code.

The UARTs are accessed by name, and the names will be printed to the terminal (or `dmesg` in the case of RTAI kernel realtime) when the board driver (`hm2_eth`, `hm2_pci` etc) is loaded. Internally the UARTs are addressed by index, but the indices are per-card so not unambiguous. Internally the functions all use the private `hm2_get_pktuart` function which returns the index of the UART *and* the low level driver instance it belongs to. These functions are not hard- private, you can `#include "hostmot2.h"` if you need the lower-level functions, but then need to track the board instances yourself.

175.3.2. Configuring the UART

You should refer to the Hostmot2 "regmap" file for up-to-date register setup information. The latest version will normally be found at <https://freeby.mesanet.com/regmap>.

You should use the function **hm2_pktuart_get_version()** to check the module version loaded to the FPGA board. This documentation is valid for Rx v0 / v1 and Tx v0. The return value of the function is 16 * Tx + Rx. If viewed in Hex then 0x01 would indicate Tx v0 and Rx v1. (The latest at the time of writing.)

When reading the Regmap file it should be considered that to an FPGA read and write addresses are not the same. You will see that there are overlaps, in that some bits in the registers have different functions when read or written.

To configure the UART use

int hm2_pktuart_setup(name, bitrate, tx_mode, rx_mode, txclear, rxclear)

bitrate is simply the bitrate (e.g. 9600, 115200 etc).

txmode is built up from the following bits (directly copied from the regmap).

Bit 17	Parity enable W0
Bit 18	Odd Parity W0 (1=odd, 0=even)
Bits 15..8	InterFrame delay in bit times RW
Bit 6	Drive Enable bit (enables external RS-422/485 Driver when set) RW
Bit 5	Drive enable Auto (Automatic external drive enable) RW
	Drive Enable Auto has priority over Drive Enable (bit 6 is a no-op if bit 5 is set)
Bits 3..0	Drive enable delay (delay from asserting drive enable to start of data transmit.
	In Clock Low periods RW Drive enable delay is important to avoid start bit timing errors at high baud rates in RS-485 (half duplex) modes.

A reasonable starting value for txmode is **0x00000A20**

rxmode is built from the following:

Bits 29..22	RX data digital filter (in ClockLow periods)
	Should be set to 1/2 bit time (or max=255 if it cannot be set long enough)
Bit 17	Parity enable W0
Bit 18	Odd Parity W0 (1=odd, 0=even)
Bits 15..8	InterFrame delay in bit times RW
Bit 6	RXMask R0
Bit 3	RXEnable (must be set to receive packets) RW
Bit 2	RXMask Enable (enables input data masking when transmitting) RW

For low baud rates **0x3FC0140C** will generally work, but the filter bits should really be set according to the actual baud rate.

The function **int hm2_pktuart_get_clock(name)** is provided to enable calculation of the required filter period. It returns units of Hz.

[Note] It is expected that v2 of Rx will extend the number of bits in the filter definition for better behaviour at low bitrates.

175.3.3. Direct reads and writes

The function:

int hm2_pktuart_send()

Will always use the hm2_llio_queue_write function where available.

However:

int hm2_pktuart_read()

Will force an immediate read transaction. It may be used in setup and teardown code, but should not be called in the realtime functions as this will cause extra packets to be transmitted. This may be acceptable for PCI cards, but should otherwise be avoided.

175.3.4. Queued Reads and Writes

In the realtime threads the queued reads and writes should be used. This means that most transactions will be spread over more than one thread period.

rtapi_u32 hm2_pktuart_get_rx_status(name)

rtapi_u32 hm2_pktuart_get_tx_status(name)

These functions will always return the latest status from the most recent data packet from the FPGA. The status should be used to check if any new data has been received, or if the UART has completed the recent transmissions.

The Tx status is encoded as:

Bit 21	FrameBuffer Has Data R0
Bits 20..16	Frames to send R0
Bit 7	Send busy R0
Bit 4	SCFIFO Error R0

The Rx status is:

Bit 21	FrameBuffer has data R0
Bits 20..16	Frames received R0
Bit 7	Buffer error (RX idle but data in RX data FIFO) R0
Bit 6	RXMask R0
Bit 5	Parity Error RW
Bit 4	RCFIFO Error RW
Bit 1	Overrun error (no stop bit when expected) (sticky) RW
Bit 0	False Start bit error (sticky) RW

Based on the status of the Rx and Tx components reads or writes from the FPGA can then be set up. This is typically a multi-step process:

1. rxstatus indicates that there are packets of data, but at this point we need to know how big each packet is (and reading too much or too little data from the FIFOs will cause problems).
2. Queue a read of the frame sizes. **hm2_pktuart_queue_get_frame_sizes(name, fsizes[])** On return, the fsizes[] array will have been loaded with the frame sizes (size in bytes). If fsizes are [8] [7] [6] and you only read 1 frame from the data FIFO then on the next call to get_frame_sizes the returned array would be [7] [6].
3. Wait one thread cycle to get the data. Note that there is no serial latency here, the data is already on the FPGA but we can only know how much data to request once we know the packet size
4. Queue enough data reads to get all the data frames that the packet is spread over. int **hm2_pktuart_queue_read_data(name, data, bytes)** On return the data[] array will have been loaded with enough 32-bit frames to include "bytes" bytes.
5. Parse the data.

175.3.5. Data Formats

Both the Tx and Rx pack the bytes that are to be read or written in 32-bit "frames" stored in a 16-deep FIFO.

To send the sequence 01, 02, 03, 04, 05, 06 followed by the sequence F1, F2, F3, F3, F5, F6, F7 the registers would be loaded with:

```
0x04030201
0xFFFF0605
0xF4F3F2F1
0xFF7F6F5
```

(Where X indicates data that will be ignored).

I.e., the data is filled right-to-left and right-justified with consecutive packets not sharing a 32-bit frame.

175.3.6. Typical Usage

Because the transactions are necessarily split over multiple reads, and some steps will have serial-port latency delays it is recommended to use a state machine in the realtime code where waiting on input is not possible.

```
int process(void *arg, long period) {
    static int state = START;

    switch (state) {
        case START:
            // Check for received data
            if (rxstatus & 0x200000) {
                state = WAIT_FOR_DATA_FRAME;
                break;
            }
    }
```

```

    }

    // No incoming data, so service the outputs
    if (time to send data){
        hm2_pktuart_send(pktUART_name, some_data);
        state = WAIT_FOR_SEND_COMPLETE;
        break;

case WAIT_FOR_SEND_COMPLETE:
    if ( ! (txstatus & 0x80)){ // i.e. the Tx is not busy
        state = WAIT_FOR_DATA_FRAME;
    }
    break;

case WAIT_FOR_DATA_FRAME:
    if ( ! ( rxstatus & 0x1F0000)) { // no data yet
        break;
    }
    // find the frame size
    hm2_pktuart_queue_get_frame_sizes(pktUART_name, fsizes);
    state = WAIT_FOR_FRAME_SIZES;
    frame_inde = 0;
    break;

case WAIT_FOR_FRAME_SIZES:
case FETCH_MORE_DATA:
    // This step may need to be iterated if there are multiple frames
    r = hm2_pktuart_queue_read_data(pktUART_name, rxdata, fsizes[frame_index]);
    state = WAIT_FOR_DATA; // Just a one-cycle delay, the data is on the FPGA
    break;

case WAIT_FOR_DATA:
    parse_data(rxdata);
    if ((fsizes[++frame_index] & 0x3FF) > 0){
        state = FETCH_MORE_DATA;
    } else {
        state = WAIT_FOR_RX_CLEAR;
    }
    break;

case WAIT_FOR_RX_CLEAR:
    if (rxstatus & 0x200000) break;
    state = START;
    break;
}
}
}

```

175.4. PINS

The functions / hostmot2 component do not create any HAL pins.

175.5. EXAMPLE

See `inuxcnc-dev/src/hal/components/mesa_pktgyro_test.comp` for a simple example (which might not work, and uses the deprecated direct reads and writes. **mesa_modbus** is a better example, but significantly more complex and less instructive because of that.

175.6. Testing

The PktUART can be tested using low-level register writes outside the realtime context using `mesaflash`. Here is an example bash script:

```
# First setup the DDR and Alt Source regs for the 7I96
mesaflash --device 7i96 --addr 10.10.10.10 --wpo 0x1100=0x1F800
mesaflash --device 7i96 --addr 10.10.10.10 --wpo 0x1104=0x1C3FF
mesaflash --device 7i96 --addr 10.10.10.10 --wpo 0x1200=0x1F800
mesaflash --device 7i96 --addr 10.10.10.10 --wpo 0x1204=0x1C3FF
# Next set the baud rate DDS's for 9600 baud
mesaflash --device 7i96 --addr 10.10.10.10 --wpo 0x6300=0x65
mesaflash --device 7i96 --addr 10.10.10.10 --wpo 0x6700=0x65
# setup the TX and RX mode registers
mesaflash --device 7i96 --addr 10.10.10.10 --wpo 0x6400=0x00062840
mesaflash --device 7i96 --addr 10.10.10.10 --wpo 0x6800=0x3FC61408
# Reset the TX and RX UARTS
mesaflash --device 7i96 --addr 10.10.10.10 --wpo 0x6400=0x80010000
mesaflash --device 7i96 --addr 10.10.10.10 --wpo 0x6800=0x80010000
# load 7 bytes of data into the TX UART
mesaflash --device 7i96 --addr 10.10.10.10 --wpo 0x6100=0x54535251
mesaflash --device 7i96 --addr 10.10.10.10 --wpo 0x6100=0x58575655
mesaflash --device 7i96 --addr 10.10.10.10 --wpo 0x6100=0x64636261
mesaflash --device 7i96 --addr 10.10.10.10 --wpo 0x6100=0x68676665
# Command the TX UART to send 8 bytes twice
mesaflash --device 7i96 --addr 10.10.10.10 --wpo 0x6200=0x08
mesaflash --device 7i96 --addr 10.10.10.10 --wpo 0x6200=0x08
sleep .1
# display the RX mode reg, RX count, and the data
mesaflash --device 7i96 --addr 10.10.10.10 --rpo 0x6800
mesaflash --device 7i96 --addr 10.10.10.10 --rpo 0x6600
mesaflash --device 7i96 --addr 10.10.10.10 --rpo 0x6500
mesaflash --device 7i96 --addr 10.10.10.10 --rpo 0x6500
mesaflash --device 7i96 --addr 10.10.10.10 --rpo 0x6800
mesaflash --device 7i96 --addr 10.10.10.10 --rpo 0x6600
mesaflash --device 7i96 --addr 10.10.10.10 --rpo 0x6500
mesaflash --device 7i96 --addr 10.10.10.10 --rpo 0x6500
```

175.7. AUTHOR

Andy Pugh

175.8. LICENSE

GPL-2.0+

Chapter 176. hm2_pktuart_read(3)

176.1. NAME

hm2_pktuart_read - read data from a Hostmot2 UART buffer

176.2. SYNTAX

```
#include <hostmot2-serial.h>
int hm2_pktuart_read(char* name, unsigned char data[], rtapi_u8* num_frames,
                    rtapi_u16* max_frame_length, rtapi_u16 frame_sizes[]);
```

176.3. DESCRIPTION

hm2_pktuart_read reads data from the PktUART "name".

DEPRECATED except in setup code.

Please see the combined document hm2_pktuart.3

Chapter 177. hm2_pktuart_send(3)

177.1. NAME

hm2_pktuart_send - write data to a Hostmot2 PktUART

177.2. SYNTAX

```
#include <hostmot2-serial.h>
int hm2_uart_send(char* name, unsigned char data[], rtapi_u8* num_frames,
                  rtapi_u16 frame_sizes[]);
```

177.3. DESCRIPTION

hm2_pktuart_send writes "num_frames" of data to the PktUART "name" from the buffer "data" with frame sizes preset in "frame_sizes[]" array.

Please see the combined document hm2_pktuart.3 for how to use this function.

Chapter 178. hm2_pktuart_setup(3)

178.1. NAME

hm2_pktuart_setup - setup a Hostmot2 PktUART instance

178.2. SYNTAX

```
#include <hostmot2-serial.h>
int hm2_pktuart_setup(char* name, int bitrate, rtapi_s32 tx_mode,
                    rtapi_s32 rx_mode, int txclear, int rxclear)
```

178.3. DESCRIPTION

hm2_pktuart_setup

Please see the combined document hm2_pktuart.3 for how to use this function.

Chapter 179. hm2_tram_add_bspi_frame(3)

179.1. NAME

hm2_tram_add_bspi_frame - add a register-write to the Hostmot2 TRAM

179.2. SYNTAX

```
#include <hostmot2-serial.h>
hm2_tram_add_bspi_frame(char* name, int chan, u32** wbuff, u32** rbuff);
```

179.3. DESCRIPTION

hm2_tram_add_bspi_frame Add a regular (every thread) write event to the Hostmot2 tram for bspi instance "name". "name" is a unique string given to each bspi channel during hostmot2 setup. The names of the available channels are printed to standard output during the driver loading process and take the form: hm2_<board name>.<board index>.bspi.<index> For example hm2_5i23.0.bspi.0

This function is used to add a regular, every thread, write or write-read transaction to the Translation RAM system. A write need not have a read (use 0 for *rbuff*) but it is an error to have a read without a write. Note that the TRAM list is not actioned until the `hm2_allocate_bspi_tram` function is called. The read and write parameters must be pointers to pointers, as TRAM re-maps the buffers into contiguous memory.

179.4. REALTIME CONSIDERATIONS

Call only from realtime init code, not from other realtime code or non-realtime components.

179.5. RETURN VALUE

Returns 0 on success and -1 on failure.

179.6. SEE ALSO

hm2_allocate_bspi_tram(3), hm2_bspi_set_read_function(3), hm2_bspi_setup_chan(3),
hm2_bspi_set_write_function(3), hm2_bspi_write_chan(3)

See src/hal/drivers mesa_7i65.comp for an example usage.

Chapter 180. hm2_uart_read(3)

180.1. NAME

hm2_uart_read - read data from a Hostmot2 UART buffer

180.2. SYNTAX

```
#include <hostmot2-serial.h>
int hm2_uart_read(char *name, unsigned char *data);
```

180.3. DESCRIPTION

hm2_uart_read read data from the UART "name". "name" is a unique string given to each UART during hostmot2 setup. The names of the available channels are printed to standard output during the driver loading process and take the form: hm2_<board name>.<board index>.uart.<index> For example: **hm2_5i23.0.uart.0.**

This function reads a variable number of bytes from the the specified channel. It should be used inside a realtime HAL component registered with the main hostmot2 driver using the function **hm2_uart_set_read_function** in the setup code.

Note that the UART Receive FIFO is only 16 bytes deep,(the transmit FIFO is 64 bytes) and "data" needs to be at least that large or undefined mayhem will ensue.

180.4. RETURN VALUE

Returns the number of bytes read on success and -1 on failure.

180.5. SEE ALSO

hm2_uart_setup(3), hm2_uart_send(3)

See src/hal/drivers mesa_uart.comp for an example usage.

Chapter 181. hm2_uart_send(3)

181.1. NAME

hm2_uart_send - write data to a Hostmot2 UART

181.2. SYNTAX

```
#include <hostmot2-serial.h>
int hm2_uart_send(char* name, unsigned char data[], int count);
```

181.3. DESCRIPTION

hm2_uart_send write *count* bytes of data to the UART "name" from the buffer *data*.

The UART FIFO is 64 bytes deep, attempts to transmit more than 64 bytes may have unexpected effects.

"name" is a unique string given to each UART during hostmot2 setup. The names of the available channels are printed to standard output during the driver loading process and take the form: hm2_<board name>.<board index>.uart.<index>, for example **hm2_5i23.0.uart.0**.

This function performs writes of data to the specified UART. It should be used inside a function in a realtime or non-realtime HAL component.

181.4. RETURN VALUE

Returns the number of bytes sent on success and -1 on failure.

181.5. SEE ALSO

hm2_uart_setup(3), hm2_uart_read(3)

See src/hal/drivers mesa_uart.comp for an example usage.

Chapter 182. hm2_uart_setup(3)

182.1. NAME

hm2_uart_setup - setup a Hostmot2 UART

182.2. SYNTAX

```
#include <hostmot2-serial.h>
int hm2_uart_setup(char* name, int bitrate, s32 tx_mode, s32 rx_mode);
```

182.3. DESCRIPTION

hm2_uart_setup Setup the bitrate for the UART named "name". "name" is a unique string given to each UART during hostmot2 setup. The names of the available UARTs are printed to standard output during the driver loading process and take the form: hm2_<board name>.<board index>.uart.<index>, for example **hm2_5i23.0.uart.0**. The minimum bitrate is approximately 50 bps, and the maximum around the FPGA frequency, 48 MHz for a 5I23. The UART function allows different RX and TX bitrates, but that is not currently supported by this driver.

tx_mode is bit mask defined in the Hostmot2 regmap: Bit 0..3:: TXEnable delay. TXEnable delay specifies the transmit data holdoff time from the TXenable signal valid state. This is used for RS-485 (half duplex) operation, to delay transmit data until the driver is enabled, allowing for driver enable delays, isolation barrier delays, etc. Delay is in units of ClockLow period. Bit 4:: FIFOError, it indicates that a host push has overflowed the FIFO (Mainly for driver debugging). Bit 5:: DriveEnableAuto, When set, enables Drive when any data is in FIFO or Xmit Shift register, removes drive when FIFO and Xmit shift register are empty. Bit 6:: DriveEnableBit, If DriveEnableAuto is 0, controls Drive (for software control of Xmit drive).

rx_mode is bit mask defined in the Hostmot2 regmap: Bit 0:: FalseStart bit Status, 1 = false start bit detected Bit 1 = OverRun Status, 1 = overrun condition detected (no valid stop bit) Bit 2:: RXMaskEnable, 1= enable RXMask for half duplex operation, 0 = ignore RXMask Bit 4 = FIFOError, indicates that a host read has attempted to read more data than available. (mainly for driver debugging) Bit 5:: LostDataError, indicates that data was received with no room in FIFO, therefore lost Bit 6:: RXMask, RO RXMASK status Bit 7:: FIFO Has Data

rx_mode and tx_mode registers are currently write-only. There should possibly be a get-status function.

To write only to the tx_mode DriveEnable bit call this function with the bitrate unchanged and -1 as the rx_mode. To change bitrate without altering mode settings send -1 to both modes.

182.4. RETURN VALUE

Returns 0 on success and -1 on failure.

182.5. SEE ALSO

hm2_uart_send(3), hm2_uart_read(3)

See src/hal/drivers mesa_uart.comp for an example usage.

Chapter 183. ABS(9)

183.1. NAME

abs - Compute the absolute value and sign of a float input signal

183.2. SYNOPSIS

loadrt abs [**count**=*N*|**names**=*name1*[,*name2*...]]

183.3. FUNCTIONS

abs.*N*

183.4. PINS

abs.*N*.in float in

Analog input value

abs.*N*.out float out

Analog output value, always positive

abs.*N*.sign bit out

Sign of input, false for positive, true for negative

abs.*N*.is-positive bit out

TRUE if input is positive, FALSE if input is 0 or negative

abs.*N*.is-negative bit out

TRUE if input is negative, FALSE if input is 0 or positive

183.5. AUTHOR

John Kasunich

183.6. LICENSE

GPL

Chapter 184. ABS_S32(9)

184.1. NAME

`abs_s32` - Compute the absolute value and sign of a integer input signal

184.2. SYNOPSIS

loadrt abs_s32 [count=*N* | names=*name1*[,*name2*...]]

184.3. FUNCTIONS

abs-s32.*N*

184.4. PINS

abs-s32.*N*.in s32 in

input value

abs-s32.*N*.out s32 out

output value, always non-negative

abs-s32.*N*.sign bit out

Sign of input, false for positive, true for negative

abs-s32.*N*.is-positive bit out

TRUE if input is positive, FALSE if input is 0 or negative

abs-s32.*N*.is-negative bit out

TRUE if input is negative, FALSE if input is 0 or positive

184.5. AUTHOR

Sebastian Kuzminsky

184.6. LICENSE

GPL

Chapter 185. ABS_S64(9)

185.1. NAME

`abs_s64` - Computes the absolute value and sign of a 64 bit integer input signal

185.2. SYNOPSIS

loadrt abs_s64 [count=*N* | names=*name1*[,*name2*...]]

185.3. FUNCTIONS

abs-s64.*N*

185.4. PINS

abs-s64.*N*.in s64 in

input value

abs-s64.*N*.out s64 out

output value, always non-negative

abs-s64.*N*.sign bit out

Sign of input, false for positive, true for negative

abs-s64.*N*.is-positive bit out

true if input is positive, false if input is 0 or negative

abs-s64.*N*.is-negative bit out

true if input is negative, false if input is 0 or positive

185.5. AUTHOR

ArcEye based on code from Sebastian Kuzminsky

185.6. LICENSE

GPL

Chapter 186. AND2(9)

186.1. NAME

and2 - Two-input AND gate

186.2. SYNOPSIS

loadrt and2 [**count**=*N* | **names**=*name1*[,*name2*...]]

186.3. DESCRIPTION

The **out** pin is computed from the value of the **in0** and **in1** pins according to the following truth table:

in1	in0	out
0	0	0
0	1	0
1	0	0
1	1	1

186.4. FUNCTIONS

and2.N

186.5. PINS

and2.N.in0 bit in

First input

and2.N.in1 bit in

Second input

and2.N.out bit out

Output

186.6. SEE ALSO

logic(9), **lut5(9)**, **not(9)**, **or2(9)**, **xor2(9)**.

186.7. AUTHOR

Jeff Epler

186.8. LICENSE

GPL

Chapter 187. ANGLEJOG(9)

187.1. NAME

anglejog - Jog two axes (or joints) at an angle

187.2. SYNOPSIS

loadrt anglejog [count=N | names=name1[,name2...]]

187.3. DESCRIPTION

The anglejog component accepts a dynamic counts-in input (typically from a manual pulse generator (MPG)) and static angle and scale factor settings. It computes the counts and scale values required to jog two (M,N) axes (or joints) at an angle. The corresponding output pins must be connected to the candidate **axis.[MN].jog** (or **joint.[MN].jog**) pins to create motion at the current angle. HAL pins are provided to set the vector velocity and acceleration and to enable the computations.

Notes:

1. The max-vel, max-accel settings should be **less than or equal** to the smallest settings for both of the target axes.
2. The scale-in pin is sampled only when the enable-in pin is false. The value in use is output on the current-scale pin.
3. The angle-degrees-in pin is sampled only when the enable-in pin is false. The value in use is output on the current-angle-degrees pin.
4. The value of the iscale-factor pin multiplies counts-in internally to support integer (s32) calculations for counting. The current-scale-out is divided by the same amount. The pin is sampled only when the enable-in pin is false. The default value should work in most applications.
5. For identity kins machines that support both world jogging (axis letter) and joint jogging (joint number), connections are needed for both the axis pins: **axis.[MN].jog-enable, jog-scale, jog-counts** and the corresponding joint pins: **joint.[mn].jog-enable, jog-scale, jog-counts** where **[mn]** are the joint numbers corresponding to the [MN] axis letters.
6. The current-scale pin is for information, the required output scaling pin is current-scale-out as it depends on the iscale-factor setting.

Simulation Config: [configs/sim/axis/anglejog/anglejog.in](#)

187.4. FUNCTIONS

anglejog.N

187.5. PINS

anglejog.N.enable-in bit in

enables motion (disables alteration of angle and scale)

anglejog.N.counts-in s32 in

MPG (wheel) counts

anglejog.N.angle-degrees-in float in

vector angle

anglejog.N.iscale-factor s32 in (default: 10000)

integer scaling factor (>1)

anglejog.N.scale-in float in

magnitude units/count ($\text{mag} = \text{counts} * \text{scale}$)

anglejog.N.max-vel float in

vector max velocity magnitude

anglejog.N.max-accel float in

vector max acceleration magnitude

anglejog.N.accel-fraction-in float in (default: 1)

acceleration fraction input

anglejog.N.enable-out bit out

to: axis.M.jog-enable AND axis.N.jog-enable

anglejog.N.current-scale float out

effective scale (informational)

anglejog.N.current-scale-out float out

to: axis.M.jog-scale AND axis.N.jog-scale

anglejog.N.coscounts s32 out

to: axis.M.jog-counts (cosine counts)

anglejog.N.sincounts s32 out

to: axis.N.jog-counts (sine counts)

anglejog.N.cos-accel-fraction float out

to: axis.M.jog-accel-fraction

anglejog.N.sin-accel-fraction float out

to: axis.N.jog-accel-fraction

anglejog.N.active bit out

angle jog move in progress

anglejog.N.current-angle-degrees float out

current angle

anglejog.N.current-mag float out

current vector magnitude

anglejog.N.current-vel float out

current vector speed

187.6. AUTHOR

Dewey Garrett

187.7. LICENSE

GPL

Chapter 188. at_pid(9)

188.1. NAME

at_pid - obsolete pid HAL component

188.2. DESCRIPTION

The functionality of the at_pid component has been merged into the pid component.

188.3. SEE ALSO

pid(9)

Chapter 189. AXISTEST(9)

189.1. NAME

axistest - Used to allow testing of an axis. Used IN PnCconf.

189.2. SYNOPSIS

loadrt axistest [count=*N* | names=*name1*[,*name2*...]]

189.3. FUNCTIONS

axistest.*N*.update

189.4. PINS

axistest.*N*.jog-minus bit in

Drive TRUE to jog the axis in its negative (*minus*) direction.

axistest.*N*.jog-plus bit in

Drive TRUE to jog the axis in its positive direction.

axistest.*N*.run bit in

Drive TRUE to run the axis near its current position_fb with a trapezoidal velocity profile.

axistest.*N*.maxvel float in

Maximum velocity

axistest.*N*.amplitude float in

Approximate amplitude of positions to command during *run*

axistest.*N*.dir s32 in

Direction from central point to test: 0 = both, 1 = positive, 2 = negative

axistest.*N*.position-cmd float out

axistest.*N*.position-fb float in

axistest.*N*.running bit out

axistest.*N*.run-target float out

axistest.*N*.run-start float out

axistest.*N*.run-low float out

axistest.*N*.run-high float out

axistest.*N*.pause s32 in (default: 0)

Pause time for each end of run in seconds

189.5. PARAMETERS

axistest.N.epsilon float rw (default: *.001*)

axistest.N.elapsed float r

Current value of the internal timer

189.6. AUTHOR

Chris S. Morley

189.7. LICENSE

GPL

Chapter 190. BIN2GRAY(9)

190.1. NAME

`bin2gray` - convert a number to the gray-code representation

190.2. SYNOPSIS

loadrt bin2gray [**count**=*N* | **names**=*name1* [, *name2* ...]]

190.3. DESCRIPTION

Converts a number into gray-code

190.4. FUNCTIONS

bin2gray.N

190.5. PINS

bin2gray.N.in u32 in
binary code in

bin2gray.N.out u32 out
gray code out

190.6. AUTHOR

Andy Pugh

190.7. LICENSE

GPL

Chapter 191. BIQUAD(9)

191.1. NAME

biquad - Biquad IIR filter

191.2. SYNOPSIS

loadrt biquad [**count**=*N* | **names**=*name1*[,*name2*...]]

191.3. DESCRIPTION

Biquad IIR filter. Implements the following transfer function: $H(z) = (n_0 + n_1z^{-1} + n_2z^{-2}) / (1 + d_1z^{-1} + d_2z^{-2})$

191.4. FUNCTIONS

biquad.N

191.5. PINS

biquad.N.in float in

Filter input.

biquad.N.out float out

Filter output.

biquad.N.enable bit in (default: 0)

Filter enable. When false, the **in** pin is passed to the **out** pin without any filtering. A **transition from false to true** causes filter coefficients to be calculated according to the current **type** and the describing pin and parameter settings

biquad.N.valid bit out (default: 0)

When false, indicates an error occurred when calculating filter coefficients (require $2 > Q > 0.5$ and $f_0 > \text{sampleRate}/2$)

biquad.N.type- u32 in (default: 0)

Filter type determines the type of filter coefficients calculated. When 0, coefficients must be loaded directly from the **n0,n1,n2,d1** params. When 1, a low pass filter is created specified by the **f0,Q** pins. When 2, a notch filter is created specified by the **f0,Q** pins.

biquad.N.f0 float in (default: 250.0)

The corner frequency of the filter.

biquad.N.Q float in (default: 0.7071)

The Q of the filter.

biquad.N.s1 float out (default: 0.0)

1st-delayed internal state (for debug only)

biquad.N.s2 float out (default: 0.0)

2nd-delayed internal state (for debug only)

191.6. PARAMETERS

biquad.N.d1 float rw (default: 0.0)

1st-delayed denominator coef

biquad.N.d2 float rw (default: 0.0)

2nd-delayed denominator coef

biquad.N.n0 float rw (default: 1.0)

non-delayed numerator coef

biquad.N.n1 float rw (default: 0.0)

1st-delayed numerator coef

biquad.N.n2 float rw (default: 0.0)

2nd-delayed numerator coef

191.7. AUTHOR

Peter G. Vavaroutsos

191.8. LICENSE

GPL

Chapter 192. BITMERGE(9)

192.1. NAME

bitmerge - Converts individual bits into an unsigned-32

192.2. SYNOPSIS

loadrt bitmerge [count=*N* | names=*name1*[,*name2*...]] [personality=*P1*[,*P2*...]]

192.3. DESCRIPTION

This component creates a compound unsigned-32 from individual bit-inputs for each bit of an unsigned-32 output. The number of bits can be limited by the "personality" modparam. The inverse process can be performed by the bitslice HAL component.

192.4. FUNCTIONS

bitmerge.*N*

192.5. PINS

bitmerge.*N*.out u32 out

The output value

bitmerge.*N*.in-*MM* bit in (MM=00..*personality*)

192.6. AUTHOR

Andy Pugh

192.7. LICENSE

GPL2+

Chapter 193. BITSLICE(9)

193.1. NAME

bitslice - Converts an unsigned-32 input into individual bits

193.2. SYNOPSIS

loadrt bitslice [**count**=*N* | **names**=*name1*[,*name2*...]] [**personality**=*P1*[,*P2*...]]

193.3. DESCRIPTION

This component creates individual bit-outputs for each bit of an unsigned-32 input. The number of bits can be limited by the "personality" modparam. The inverse process can be performed by the bitmerge HAL component.

193.4. FUNCTIONS

bitslice.N

193.5. PINS

bitslice.N.in u32 in

The input value

bitslice.N.out-MM bit out (MM=00..personality)

193.6. AUTHOR

Andy Pugh

193.7. LICENSE

GPL2+

Chapter 194. BITWISE(9)

194.1. NAME

bitwise - Computes various bitwise operations on the two input values

194.2. SYNOPSIS

loadrt bitwise [**count**=*N* | **names**=*name1* [, *name2* ...]]

194.3. FUNCTIONS

bitwise.N

194.4. PINS

bitwise.N.in0 u32 in

First input value

bitwise.N.in1 u32 in

Second input value

bitwise.N.out-and u32 out

The bitwise AND of the two inputs

bitwise.N.out-or u32 out

The bitwise OR of the two inputs

bitwise.N.out-xor u32 out

The bitwise XOR of the two inputs

bitwise.N.out-nand u32 out

The inverse of the bitwise AND

bitwise.N.out-nor u32 out

The inverse of the bitwise OR

bitwise.N.out-xnor u32 out

The inverse of the bitwise XOR

194.5. AUTHOR

Andy Pugh

194.6. LICENSE

GPL 2+

Chapter 195. BLDC(9)

195.1. NAME

`bldc` - BLDC and AC-servo control component

195.2. SYNOPSIS

`loadrt bldc cfg=qi6,aH`

195.3. DESCRIPTION

This component is designed as an interface between the most common forms of three-phase motor feedback devices and the corresponding types of drive. However, there is no requirement that the motor and drive should necessarily be of inherently compatible types.

Each instance of the component is defined by a group of letters describing the input and output types. A comma separates individual instances of the component. For example `loadrt bldc cfg=qi6,aH`.

195.3.1. TAGS

Input type definitions are all lower-case:

- **n**: No motor feedback.
This mode could be used to drive AC induction motors, but is also potentially useful for creating free-running motor simulators for drive testing.
- **h**: Hall sensor input. Brushless DC motors (electronically commutated permanent magnet 3-phase motors) typically use a set of three Hall sensors to measure the angular position of the rotor.
A lower-case **h** in the `cfg` string indicates that these should be used.
- **a**: Absolute encoder input (also possibly used by some forms of Resolver conversion hardware). The presence of this tag over-rides all other inputs.
Note that the component still requires to be connected to the **rawcounts** encoder pin to prevent loss of commutation on index-reset.
- **q**: Incremental (quadrature) encoder input. If this input is used then the rotor will need to be homed before the motor can be run.
- **i**: Use the index of an incremental encoder as a home reference.
- **f**: Use a 4-bit Gray-scale pattern to determine rotor alignment.
This scheme is only used on the Fanuc "Red Cap" motors. This mode could be used to control one of these motors using a non-Fanuc drive.

Output type descriptions are all upper-case:

Defaults: The component will always calculate rotor angle, phase angle and the absolute value of the input **value** for interfacing with drives such as the Mesa 8I20. It will also default to three individual, bipolar phase output values if no other output type modifiers are used.

- **B**: Bit level outputs. Either 3 or 6 logic-level outputs indicating which high or low gate drivers on an external drive should be used.
- **6**: Create 6 rather than the default 3 outputs.
In the case of numeric value outputs these are separate positive and negative drive amplitudes. Both have positive magnitude.
- **H**: Emulated Hall sensor output. This mode can be used to control a drive which expects 3x Hall signals, or to convert between a motor with one hall pattern and a drive which expects a different one.
- **F**: Emulated Fanuc Red Cap Gray-code encoder output. This mode might be used to drive a non-Fanuc motor using a Fanuc drive intended for the "Red-Cap" motors.
- **T**: Force Trapezoidal mode.

195.3.2. OPERATING MODES

The component can control a drive in either Trapezoidal or Sinusoidal mode, but will always default to sinusoidal if the input and output modes allow it. This can be over-ridden by the **T** tag. Sinusoidal commutation is significantly smoother (trapezoidal commutation induces 13% torque ripple).

195.3.3. ROTOR HOMING.

To use an encoder for commutation a reference 0-degrees point must be found. The component uses the convention that motor zero is the point that an unloaded motor aligns to with a positive voltage on the A (or U) terminal and the B & C (or V and W) terminals connected together and to -ve voltage. There will be two such positions on a 4-pole motor, 3 on a 6-pole and so on. They are all functionally equivalent as far as driving the motor is concerned. If the motor has Hall sensors then the motor can be started in trapezoidal commutation mode, and will switch to sinusoidal commutation when an alignment is found. If the mode is **qh** then the first Hall state-transition will be used. If the mode is **qhi** then the encoder index will be used. This gives a more accurate homing position if the distance in encoder counts between motor zero and encoder index is known. To force homing to the Hall edges instead simply omit the **i**.

Motors without Hall sensors may be homed in synchronous/direct mode. The better of these options is to home to the encoder zero using the **iq** config parameter. When the **init** pin goes high the motor will rotate (in a direction determined by the **rev** pin) until the encoder indicates an index-latch (the servo thread runs too slowly to rely on detecting an encoder index directly).

If there is no encoder index or its location relative to motor zero can not be found, then an alternative is to use *magnetic* homing using the **q** config. In this mode the motor will go through an alignment sequence ending at motor zero when the init pin goes high. It will then set the final position as motor zero. Unfortunately the motor is rather *springy* in this mode and so alignment is likely to be fairly sensitive to load.

195.4. FUNCTIONS

bldc.N

195.5. PINS

bldc.N.hall1 bit in [if personality & 0x01]

Hall sensor signal 1

bldc.N.hall2 bit in [if personality & 0x01]

Hall sensor signal 2

bldc.N.hall3 bit in [if personality & 0x01]

Hall sensor signal 3

bldc.N.hall-error bit out [if personality & 0x01]

Indicates that the selected hall pattern gives inconsistent rotor position data. This can be due to the pattern being wrong for the motor, or one or more sensors being unconnected or broken. A consistent pattern is not necessarily valid, but an inconsistent one can never be valid.

bldc.N.C1 bit in [if (personality & 0x10)]

Fanuc Gray-code bit 0 input

bldc.N.C2 bit in [if (personality & 0x10)]

Fanuc Gray-code bit 1 input

bldc.N.C4 bit in [if (personality & 0x10)]

Fanuc Gray-code bit 2 input

bldc.N.C8 bit in [if (personality & 0x10)]

Fanuc Gray-code bit 3 input

bldc.N.value float in

PWM master amplitude input

bldc.N.lead-angle float in [if personality & 0x06] (default: 90)

The phase lead between the electrical vector and the rotor position in degrees

bldc.N.rev bit in

Set this pin true to reverse the motor. Negative PWM amplitudes will also reverse the motor and there will generally be a Hall pattern that runs the motor in each direction too.

bldc.N.frequency float in [if (personality & 0x0F) == 0]

Frequency input for motors with no feedback at all, or those with only an index (which is ignored)

bldc.N.initvalue float in [if personality & 0x04] (default: 0.2)

The current to be used for the homing sequence in applications where an incremental encoder is used with no hall-sensor feedback

bldc.N.rawcounts s32 in [if personality & 0x06] (default: 0)

Encoder counts input. This must be linked to the encoder rawcounts pin or encoder index resets will cause the motor commutation to fail.

bldc.N.index-enable bit io [if personality & 0x08]

This pin should be connected to the associated encoder index-enable pin to zero the encoder when it passes index. This is only used indicate to the bldc control component that an index has been seen.

bldc.N.init bit in [if (personality & 0x05) == 4]

A rising edge on this pin starts the motor alignment sequence. This pin should be connected in such a way that the motors re-align any time that encoder monitoring has been interrupted. Typically this will only be at machine power-off.

The alignment process involves powering the motor phases in such a way as to put the motor in a known position. The encoder counts are then stored in the **offset** parameter. The alignment process will tend to cause a following error if it is triggered while the axis is enabled, so should be set before the matching axis.N.enable pin.

The complementary **init-done** pin can be used to handle the required sequencing.

Both pins can be ignored if the encoder offset is known explicitly, such as is the case with an absolute encoder. In that case the **offset** parameter can be set directly in the HAL file.

bldc.N.init-done bit out [if (personality & 0x05) == 4] (default: 0)

Indicates homing sequence complete.

bldc.N.A-value float out [if (personality & 0xF00) == 0]

Output amplitude for phase A

bldc.N.B-value float out [if (personality & 0xF00) == 0]

Output amplitude for phase B

bldc.N.C-value float out [if (personality & 0xF00) == 0]

Output amplitude for phase C

bldc.N.A-on bit out [if (personality & 0xF00) == 0x100]

Output bit for phase A

bldc.N.B-on bit out [if (personality & 0xF00) == 0x100]

Output bit for phase B

bldc.N.C-on bit out [if (personality & 0xF00) == 0x100]

Output bit for phase C

bldc.N.A-high float out [if (personality & 0xF00) == 0x200]

High-side driver for phase A

bldc.N.B-high float out [if (personality & 0xF00) == 0x200]

High-side driver for phase B

bldc.N.C-high float out [if (personality & 0xF00) == 0x200]

High-side driver for phase C

bldc.N.A-low float out [if (personality & 0xF00) == 0x200]

Low-side driver for phase A

bldc.N.B-low float out [if (personality & 0xF00) == 0x200]

Low-side driver for phase B

bldc.N.C-low float out [if (personality & 0xF00) == 0x200]

Low-side driver for phase C

bldc.N.A-high-on bit out [if (personality & 0xF00) == 0x300]

High-side driver for phase A

bldc.N.B-high-on bit out [if (personality & 0xF00) == 0x300]

High-side driver for phase B

bldc.N.C-high-on bit out [if (personality & 0xF00) == 0x300]

High-side driver for phase C

bldc.N.A-low-on bit out [if (personality & 0xF00) == 0x300]

Low-side driver for phase A

bldc.N.B-low-on bit out [if (personality & 0xF00) == 0x300]

Low-side driver for phase B

bldc.N.C-low-on bit out [if (personality & 0xF00) == 0x300]

Low-side driver for phase C

bldc.N.hall1-out bit out [if (personality & 0x400)]

Hall 1 output

bldc.N.hall2-out bit out [if (personality & 0x400)]

Hall 2 output

bldc.N.hall3-out bit out [if (personality & 0x400)]

Hall 3 output

bldc.N.C1-out bit out [if (personality & 0x800)]

Fanuc Gray-code bit 0 output

bldc.N.C2-out bit out [if (personality & 0x800)]

Fanuc Gray-code bit 1 output

bldc.N.C4-out bit out [if (personality & 0x800)]

Fanuc Gray-code bit 2 output

bldc.N.C8-out bit out [if (personality & 0x800)]

Fanuc Gray-code bit 3 output

bldc.N.phase-angle float out (default: 0)

Phase angle including lead/lag angle after encoder zeroing, etc. Useful for angle/current drives. This value has a range of 0 to 1 and measures electrical revolutions. It will have two zeros for a 4 pole motor, three for a 6-pole, etc.

bldc.N.rotor-angle float out (default: 0)

Rotor angle after encoder zeroing etc. Useful for angle/current drives which add their own phase offset such as the 8I20. This value has a range of 0 to 1 and measures electrical revolutions. It will have two zeros for a 4 pole motor, three for a 6-pole, etc.

bldc.N.out float out

Current output, including the effect of the dir pin and the alignment sequence.

bldc.N.out-dir bit out

Direction output, high if **value** is negative XOR **rev** is true.

bldc.N.out-abs float out

Absolute value of the input value

195.6. PARAMETERS

bldc.N.in-type s32 r (default: -1)

state machine output, will probably hide after debug

bldc.N.out-type s32 r (default: -1)

state machine output, will probably hide after debug

bldc.N.scale s32 rw [if personality & 0x06] (default: 512)

The number of encoder counts per rotor revolution.

bldc.N.poles s32 rw [if personality & 0x06] (default: 4)

The number of motor poles. The encoder scale will be divided by this value to determine the number of encoder counts per electrical revolution.

bldc.N.encoder-offset s32 rw [if personality & 0x0A] (default: 0)

The offset, in encoder counts, between the motor electrical zero and the encoder zero modulo the number of counts per electrical revolution

bldc.N.offset-measured s32 r [if personality & 0x04] (default: 0)

The encoder offset measured by the homing sequence (in certain modes)

bldc.N.drive-offset float rw (default: 0)

The angle, in degrees, applied to the commanded angle by the drive in degrees. This value is only used during the homing sequence of drives with incremental encoder feedback. It is used to back-calculate from commanded angle to actual phase angle. It is only relevant to drives which expect rotor-angle input rather than phase-angle demand. Should be 0 for most drives.

bldc.N.output-pattern u32 rw [if personality & 0x400] (default: 25)

Commutation pattern to be output in Hall Signal translation mode. See the description of **pattern** for details.

bldc.N.pattern u32 rw [if personality & 0x01] (default: 25)

Commutation pattern to use, from 0 to 47. Default is type 25. Every plausible combination is included. The table below shows the excitation pattern along the top, and the pattern code on the left hand side. The table entries are the hall patterns in H1, H2, H3 order. Common patterns are:

+ 0 (30 degree commutation) and 26, its reverse.

+ 17 (120 degree)

+ 18 (alternate 60 degree)

+ 21 (300 degree, Bodine)

+ 22 (240 degree)

+ 25 (60 degree commutation)

Note that a number of incorrect commutations will have non-zero net torque which might look as if they work, but don't really.

If your motor lacks documentation it might be worth trying every pattern.

Pattern	Phases, Source - Sink					
	B-A	C-A	C-B	A-B	A-C	B-C
0	000	001	011	111	110	100
1	001	000	010	110	111	101
2	000	010	011	111	101	100
3	001	011	010	110	100	101
4	010	011	001	101	100	110
5	011	010	000	100	101	111
6	010	000	001	101	111	110
7	011	001	000	100	110	111
8	000	001	101	111	110	010
9	001	000	100	110	111	011
10	000	010	110	111	101	001
11	001	011	111	110	100	000
12	010	011	111	101	100	000
13	011	010	110	100	101	001
14	010	000	100	101	111	011
15	011	001	101	100	110	010
16	000	100	101	111	011	010

17	001	101	100	110	010	011
18	000	100	110	111	011	001
19	001	101	111	110	010	000
20	010	110	111	101	001	000
21	011	111	110	100	000	001
22	010	110	100	101	001	011
23	011	111	101	100	000	010
24	100	101	111	011	010	000
25	101	100	110	010	011	001
26	100	110	111	011	001	000
27	101	111	110	010	000	001
28	110	111	101	001	000	010
29	111	110	100	000	001	011
30	110	100	101	001	011	010
31	111	101	100	000	010	011
32	100	101	001	011	010	110
33	101	100	000	010	011	111
34	100	110	010	011	001	101
35	101	111	011	010	000	100
36	110	111	011	001	000	100
37	111	110	010	000	001	101
38	110	100	000	001	011	111
39	111	101	001	000	010	110
40	100	000	001	011	111	110
41	101	001	000	010	110	111
42	100	000	010	011	111	101
43	101	001	011	010	110	100
44	110	010	011	001	101	100
45	111	011	010	000	100	101
46	110	010	000	001	101	111
47	111	011	001	000	100	110

195.7. AUTHOR

Andy Pugh

195.8. LICENSE

GPL

Chapter 196. BLEND(9)

196.1. NAME

blend - Perform linear interpolation between two values

196.2. SYNOPSIS

loadrt blend [**count**=*N*|**names**=*name1*[,*name2*...]]

196.3. FUNCTIONS

blend.N

196.4. PINS

blend.N.in1 float in

First input. If select is equal to 1.0, the output is equal to in1

blend.N.in2 float in

Second input. If select is equal to 0.0, the output is equal to in2

blend.N.select float in

Select input. For values between 0.0 and 1.0, the output changes linearly from in2 to in1

blend.N.out float out

Output value.

196.5. PARAMETERS

blend.N.open bit rw

If true, select values outside the range 0.0 to 1.0 give values outside the range in2 to in1. If false, outputs are clamped to the the range in2 to in1

196.6. AUTHOR

Jeff Epler

196.7. LICENSE

GPL

Chapter 197. CAROUSEL(9)

197.1. NAME

carousel - Orient a toolchanger carousel using various encoding schemes

197.2. SYNOPSIS

loadrt carousel pockets=N[,N] encoding=ssss[,sss] num_sense=N[,N] dir=N[,N]

pockets The number of pockets in each toolchanger

Use up to 8 numbers separated by commas to create multiple carousel components.

encoding

The position encoding. One of **gray**, **binary**, **bcd**, **index**, **edge**, **counts** or **single**. Default = **gray**.

num_sense

The number of position sense pins. Default = 4.

dir

Set to 1 for unidirectional or 2 for bidirectional operation. Default = bidirectional

parity

Set to 1 for odd parity, 0 for even parity checking. Default = 0 (even)

197.3. DESCRIPTION

This component is intended to help operate various types of carousel-type toolchangers.

The component can be configured to operate with binary, binary-coded decimal (BCD) or gray-coded position feedback (*binary*;; *bcd* and *gray* modes) It can alternatively work with an individual sensor for each tool position (*single* mode) or with a sensor at each tool position and a separate index (*index* mode). Systems using a stepper motor or quadrature encoder are also supported (*counts* mode). **edge** is a special case of index mode for tool changers with pockets on both the rising and falling edges of the position sensor. (Seen on at least one Denford Orac.)

Both unidirectional and bidirectional systems are supported and those that reverse against a stop when in position.

The number of carousel component instances created depends on the number of entries in the *pockets* modparam. For example

B loadrt carousel pockets=10,10,8

Would create 3 carousel instances with 10, 10 and 8 pockets. The other parameters are optional. If absent then defaults will be used. Any missing entry will assume the previous value.

When the enable pin is set to true the component will immediately set the "active" pin to true and then

(for a bidirectional instance) calculate the shortest path to the requested pocket number. The appropriate motor direction output pins will then be set. Bit outputs for forward and reverse are provided as well as a three-state velocity output for driving a DC motor PWM or a velocity-mode stepgen.

The component will monitor the carousel position and, when the correct position is reached, set the motor-control pins to 0, set "active" to 0 and set "ready" to 1.

In index, edge or counts mode there is a need to find the initial home position of the carousel. The first time that the "enable" pin is set; the carousel will rotate forwards searching for a home signal. In 'index and edge mode this is when both the index and pulse inputs are true. In counts mode only the index input needs to be set to set home. Additionally in counts mode the usual index-enable logic of the encoder counters is supported.

With some carousel designs the carousel will not stop immediately. To allow for this set the **align-dc** pin to a low velocity to be used for a final latching move, and set the **decel-time** to a suitable value. Once the decel-time has expired the carousel will, if it was moving forwards, reverse back on to the position marker, off of the marker and then back on to the FWD edge. If moving in reverse it will continue off the marker and then reverse slowly on to the FWD edge. This alignment is only possible with a motor-vel controlled bidirectional carousel, Other combinations will be accepted but probably will not have the desired behaviour. Some tuning will be needed of align-dc and decel-time to achieve reliable operation.

In the unusual case that the index and pulse signals do not align it is possible to use HAL logic to achieve the desired pin switching during homing.

Setting "enable" low does not halt the homing move, so if homing on first tool change is not needed then the enable pin can be toggled by an axis homing pin or a script and the homing process will continue even if that driving signal resets during the carousel homing move.

To operate the component with an encoder or stepgen use mode "C". The **scale** pin should be the number of steps or encoder counts between pocket centres. The **width** pin can be used to stop the motor some distance before the centre of the pocket to allow the motor time to decelerate. In mode "C" it is possible to use either the speed/direction control used in other modes or to use direct position mode using the counts-target pin. The internal scaling of the encoder or stepgen should be set to 1.0. A PID hal component will be needed for encoder applications whereas stepgen configurations can use a stepgen in position control mode or in velocity control mode with a PID.

For tool changers which lock the carousel against a stop the **rev-pulse** pin can be set to a non-zero value. The motor-rev pin will then be set for this many seconds at the completion of the tool search and at the same time the reverse duty/cycle velocity value will be sent to the motor-vel pin.

197.4. FUNCTIONS

carousel.N

197.5. PINS

carousel.N.pocket-number s32 in

The pocket to move to when the .enable pin goes high. If the value passed is higher than the number

of pockets specified in the "pockets" modparam then modulo arithmetic is used. This is intended to allow the use of multiple tools in the same holder, as is sometimes useful with lathes.

carousel.N.enable bit in

Set this pin high to start movement. Setting it low will stop movement

carousel.N.active bit out

indicates that the component is active

carousel.N.ready bit out

This pin goes high when the carousel is in-position

carousel.N.strobe bit in (default: 1)

Use this pin to indicate that the position feedback is valid. Often provided by binary encoders

carousel.N.parity- bit in

Some encoders supply a parity bit, if this is connected then the parity-error output bit will indicate parity errors

carousel.N.sense-M bit in (M=0..personality)

Carousel position feedback pins. In *index* mode there will be only 2 pins. sense-0 is the index and sense-1 is the pocket sensor.

carousel.N.rev-pulse float in

The duration in seconds for which a ratchet changer (Boxford, Emco) should pulse the reverse pin to lock the holder

carousel.N.fwd-dc float in

Velocity or duty cycle when forwards rotation is desired

carousel.N.rev-dc float in

Velocity or duty cycle when reverse rotation is desired

carousel.N.hold-dc float in

Duty cycle when carousel is in-position (to hold against stop)

carousel.N.align-dc float in

Use this pin to set the speed of a slower alignment move once the changer is in position. Such a system almost certainly needs decel-time setting too

carousel.N.decel-time float in

Time to wait for carousel to stop before final alignment and position check

carousel.N.counts s32 in

Connect to the rawcounts of an encoder or a stepgen in *counts* mode

carousel.N.scale s32 in (default: 100)

The number of stepgen or encoder counts between successive pockets

carousel.N.width s32 in (default: 10)

How far each side of the exact scale to signal a new pocket

carousel.N.home-offset s32 in (default: 0)

The offset (in counts) between the index and pocket 1

carousel.N.index-enable bit io

Used to home to an encoder index

carousel.N.jog-fwd bit in

Jog the carousel forwards one tool position

carousel.N.jog-rev bit in

Jog the carousel in reverse (only if dir = 2). It is very important that these pins should be debounced and should probably also be interlocked to only operate when the machine is idle.

carousel.N.motor-fwd bit out

Indicates the motor should run forwards (bigger numbers)

carousel.N.motor-rev bit out

Indicates the motor should run reverse.

carousel.N.parity-error bit out

Indicates a parity error

carousel.N.current-position s32 out

This pin indicates the current position feedback

carousel.N.motor-vel float out

The duty-cycle or velocity to drive a DC motor or stepgen

carousel.N.homed bit out (default: 0)

Shows that homing is complete. Only used in index and edge modes

carousel.N.unhome bit in (default: 0)

Should only really be necessary for testing

carousel.N.counts-target float out

Target position for a stepgen or external PID controller

197.6. PARAMETERS

carousel.N.state s32 r (default: 0)

Current component state

carousel.N.homing bit r (default: 0)

Shows that homing is in progress. Only used for index mode

carousel.N.timer float r

Shows the value of the internal timer

carousel.N.motor-dir s32 r

Internal tag for search direction

carousel.N.counts-offset s32 r

Internal offset of index pin

carousel.N.debounce u32 rw

How many thread cycles to wait for the position to stabilise

carousel.N.target s32 r

Current target pocket, debug

carousel.N.base-counts s32 r (default: 0)

197.7. AUTHOR

Andy Pugh

197.8. LICENSE

GPL

Chapter 198. CHARGE_PUMP(9)

198.1. NAME

`charge_pump` - Create a square-wave for the *charge pump* input of some controller boards

198.2. SYNOPSIS

loadrt charge_pump

198.3. DESCRIPTION

The *Charge Pump* should be added to the base thread function. When enabled the output is on for one period and off for one period. To calculate the frequency of the output $1/(\text{period time in seconds} \times 2) = \text{Hz}$. For example if you have a base period of 100,000ns that is 0.0001 seconds and the formula would be $1/(0.0001 \times 2) = 5,000 \text{ Hz}$ or 5 kHz. Two additional outputs are provided that run a factor of 2 and 4 slower for hardware that requires a lower frequency.

198.4. FUNCTIONS

charge-pump.-

Toggle the output bit (if enabled)

198.5. PINS

charge-pump.out bit out

Square wave if *enable* is TRUE or unconnected, low if *enable* is FALSE

charge-pump.out-2 bit out

Square wave at half the frequency of *out*

charge-pump.out-4 bit out

Square wave at a quarter of the frequency of *out*

charge-pump.enable bit in (default: TRUE)

If FALSE, forces all *out* pins to be low

198.6. AUTHOR

Jeff Epler

198.7. LICENSE

GPL

Chapter 199. CLARKE2(9)

199.1. NAME

clarke2 - Two input version of Clarke transform

199.2. SYNOPSIS

loadrt clarke2 [**count**=*N* | **names**=*name1*[,*name2*...]]

199.3. DESCRIPTION

The Clarke transform can be used to translate a vector quantity from a three phase system (three components 120 degrees apart) to a two phase Cartesian system.

clarke2 implements a special case of the Clarke transform, which only needs two of the three input phases. In a three wire three phase system, the sum of the three phase currents or voltages must always be zero. As a result only two of the three are needed to completely define the current or voltage. **clarke2** assumes that the sum is zero, so it only uses phases A and B of the input. Since the H (homopolar) output will always be zero in this case, it is not generated.

199.4. FUNCTIONS

clarke2.N

199.5. PINS

clarke2.N.a float in

clarke2.N.b float in

first two phases of three phase input

clarke2.N.x float out

clarke2.N.y float out

cartesian components of output

199.6. SEE ALSO

clarke3(9) for the general case, **clarkeinv**(9) for the inverse transform.

199.7. AUTHOR

John Kasunich

199.8. LICENSE

GPL

Chapter 200. CLARKE3(9)

200.1. NAME

clarke3 - Clarke (3 phase to cartesian) transform

200.2. SYNOPSIS

loadrt clarke3 [**count**=*N* | **names**=*name1* [, *name2* ...]]

200.3. DESCRIPTION

The Clarke transform can be used to translate a vector quantity from a three phase system (three components 120 degrees apart) to a two phase Cartesian system (plus a homopolar component if the three phases don't sum to zero).

clarke3 implements the general case of the transform, using all three phases. If the three phases are known to sum to zero, see **clarke2** for a simpler version.

200.4. FUNCTIONS

clarke3.N

200.5. PINS

clarke3.N.a float in

clarke3.N.b float in

clarke3.N.c float in

three phase input vector

clarke3.N.x float out

clarke3.N.y float out

cartesian components of output

clarke3.N.h float out

homopolar component of output

200.6. SEE ALSO

clarke2(9) for the $a+b+c=0$ case, **clarkeinv**(9) for the inverse transform.

200.7. AUTHOR

John Kasunich

200.8. LICENSE

GPL

Chapter 201. CLARKEINV(9)

201.1. NAME

clarkeinv - Inverse Clarke transform

201.2. SYNOPSIS

loadrt clarkeinv [**count**=*N* | **names**=*name1*[,*name2*...]]

201.3. DESCRIPTION

The inverse Clarke transform can be used rotate a vector quantity and then translate it from Cartesian coordinate system to a three phase system (three components 120 degrees apart).

201.4. FUNCTIONS

clarkeinv.N

201.5. PINS

clarkeinv.N.x float in

clarkeinv.N.y float in

cartesian components of input

clarkeinv.N.h float in

homopolar component of input (usually zero)

clarkeinv.N.theta float in

rotation angle: 0.00 to 1.00 = 0 to 360 degrees

clarkeinv.N.a float out

clarkeinv.N.b float out

clarkeinv.N.c float out

three phase output vector

201.6. SEE ALSO

clarke2(9) and **clarke3**(9) for the forward transform.

201.7. AUTHOR

John Kasunich

201.8. LICENSE

GPL

Chapter 202. classicladder(9)

202.1. NAME

classicladder - realtime software plc based on ladder logic

202.2. SYNOPSIS

```
loadrt classicladder_rt [numRungs=N] [numBits=N] [numWords=N] [numTimers=N]
[numMonostables=N] [numCounters=N] [numPhysInputs=N] [numPhysOutputs=N]
[numArithmExpr=N] [numSections=N] [numSymbols=N] [numS32in=N] [numS32out=N]
[numFloatIn=N] [numFloatOut=N]
```

```
loadusr classicladder <file name> [--nogui]
```

202.3. DESCRIPTION

This component consist of a realtime part and a non-realtime part. The non-realtime part loads the programmable ladder description, while the realtime part provides the pins. The file name of the configuration can be changed using an argument to the non-realtime part. By default the non-realtime part provides a graphical visualisation of the loaded ladder, which can be disabled using the *--nogui* option to the non-realtime part.

These pins and parameters are created by the realtime **classicladder_rt** module. Each period (minimum 1000000 ns), ClassicLadder reads the inputs, evaluates the ladder logic defined in the GUI, and then writes the outputs.

202.4. PINS

classicladder.0.in-NN IN bit

These bit signal pins map to %INN variables in ClassicLadder.

classicladder.0.out-NN OUT bit

These bit signal pins map to %QNN variables in ClassicLadder. Output from ClassicLadder.

classicladder.0.s32in-NN IN s32

Integer input from ClassicLadder. These s32 signal pins map to %IWNN variables in ClassicLadder.

classicladder.0.s32out-NN OUT s32

Integer output from ClassicLadder. These s32 signal pins map to %QWNN variables in ClassicLadder.

classicladder.0.floatin-NN IN float

Integer input from ClassicLadder. These float signal pins map to %IFNN variables in ClassicLadder. These are truncated to S32 values internally, e.g. 7.5 will be 7.

classicladder.0.floatout-NN OUT float

Float output from ClassicLadder. These float signal pins map to %QFNN variables in ClassicLadder.

classicladder.0.hide_gui IN bit

This bit pin hides the ClassicLadder window, while still having the non-realtime code run. This is usually desirable when modbus is used, as modbus requires the non-realtime code to run.

202.5. PARAMETERS

classicladder.0.refresh.time RO s32

Tells you how long the last refresh took.

classicladder.0.refresh.tmax RW s32

Tells you how long the longest refresh took.

classicladder.0.ladder-state RO s32

Tells you if the program is running or not

202.6. FUNCTIONS

classicladder.0.refresh FP

The rung update rate. Add this to the servo thread. You can added it to a faster thread but it. Will update no faster than once every 1 millisecond (1000000 ns).

202.7. BUGS

See https://wiki.linuxcnc.org/cgi-bin/wiki.pl?ClassicLadder_Ver_7.124 for the latest.

202.8. SEE ALSO

ClassicLadder chapters in the LinuxCNC documentation for a full description of the **ClassicLadder** syntax and examples.

https://wiki.linuxcnc.org/cgi-bin/wiki.pl?ClassicLadder_Ver_7.124

Chapter 203. COMP(9)

203.1. NAME

comp - Two input comparator with hysteresis

203.2. SYNOPSIS

loadrt comp [count=*N* | names=*name1*[,*name2*...]]

203.3. FUNCTIONS

comp.*N*

Update the comparator

203.4. PINS

comp.*N*.in0 float in

Inverting input to the comparator

comp.*N*.in1 float in

Non-inverting input to the comparator

comp.*N*.out bit out

Normal output. True when **in1** > **in0** (see parameter **hyst** for details)

comp.*N*.equal bit out

Match output. True when difference between **in1** and **in0** is less than **hyst**/2

203.5. PARAMETERS

comp.*N*.hyst float rw (default: 0.0)

Hysteresis of the comparator (default 0.0)

With zero hysteresis, the output is true when **in1** > **in0**. With nonzero hysteresis, the output switches on and off at two different values, separated by distance **hyst** around the point where **in1** = **in0**. Keep in mind that floating point calculations are never absolute and it is wise to always set **hyst** if you intend to use equal

203.6. AUTHOR

Jeff Epler

203.7. LICENSE

GPL

Chapter 204. CONV_BIT_FLOAT(9)

204.1. NAME

`conv_bit_float` - Convert a value from bit to float

204.2. SYNOPSIS

loadrt conv_bit_float [count=*N* | names=*name1* [, *name2* ...]]

204.3. FUNCTIONS

conv-bit-float.*N*

Update *out* based on *in*

204.4. PINS

conv-bit-float.*N*.in bit in

conv-bit-float.*N*.out float out

204.5. AUTHOR

Jeff Epler

204.6. LICENSE

GPL

Chapter 205. CONV_BIT_S32(9)

205.1. NAME

conv_bit_s32 - Convert a value from bit to s32

205.2. SYNOPSIS

loadrt conv_bit_s32 [count=*N* | names=*name1* [, *name2* ...]]

205.3. FUNCTIONS

conv-bit-s32.*N*

Update *out* based on *in*

205.4. PINS

conv-bit-s32.*N*.in bit in

conv-bit-s32.*N*.out s32 out

205.5. AUTHOR

Jeff Epler

205.6. LICENSE

GPL

Chapter 206. CONV_BIT_S64(9)

206.1. NAME

conv_bit_s64 - Convert a value from bit to s64

206.2. SYNOPSIS

loadrt conv_bit_s64 [count=*N* | names=*name1* [, *name2* ...]]

206.3. FUNCTIONS

conv-bit-s64.*N*

Update *out* based on *in*

206.4. PINS

conv-bit-s64.*N*.in bit in

conv-bit-s64.*N*.out s64 out

206.5. AUTHOR

Jeff Epler

206.6. LICENSE

GPL

Chapter 207. CONV_BIT_U32(9)

207.1. NAME

conv_bit_u32 - Convert a value from bit to u32

207.2. SYNOPSIS

loadrt conv_bit_u32 [count=*N* | names=*name1* [, *name2* ...]]

207.3. FUNCTIONS

conv-bit-u32.*N*

Update *out* based on *in*

207.4. PINS

conv-bit-u32.*N*.in bit in

conv-bit-u32.*N*.out u32 out

207.5. AUTHOR

Jeff Epler

207.6. LICENSE

GPL

Chapter 208. CONV_BIT_U64(9)

208.1. NAME

conv_bit_u64 - Convert a value from bit to u64

208.2. SYNOPSIS

loadrt conv_bit_u64 [**count**=*N* | **names**=*name1* [, *name2* ...]]

208.3. FUNCTIONS

conv-bit-u64.N

Update *out* based on *in*

208.4. PINS

conv-bit-u64.N.in bit in

conv-bit-u64.N.out u64 out

208.5. AUTHOR

Jeff Epler

208.6. LICENSE

GPL

Chapter 209. CONV_FLOAT_S32(9)

209.1. NAME

`conv_float_s32` - Convert a value from float to s32

209.2. SYNOPSIS

loadrt `conv_float_s32` [**count**=*N* | **names**=*name1* [, *name2* ...]]

209.3. FUNCTIONS

conv-float-s32.N

Update *out* based on *in*

209.4. PINS

conv-float-s32.N.in float *in*

conv-float-s32.N.out s32 *out*

conv-float-s32.N.out-of-range bit *out*

TRUE when *in* is not in the range of s32

209.5. PARAMETERS

conv-float-s32.N.clamp bit *rw*

If TRUE, then clamp to the range of s32. If FALSE, then allow the value to "wrap around".

209.6. AUTHOR

Jeff Epler

209.7. LICENSE

GPL

Chapter 210. CONV_FLOAT_S64(9)

210.1. NAME

`conv_float_s64` - Convert a value from float to s64

210.2. SYNOPSIS

loadrt conv_float_s64 [count=*N* | names=*name1*[,*name2*...]]

210.3. FUNCTIONS

conv-float-s64.*N*

Update *out* based on *in*

210.4. PINS

conv-float-s64.*N*.in float in

conv-float-s64.*N*.out s64 out

conv-float-s64.*N*.out-of-range bit out

TRUE when *in* is not in the range of s64

210.5. PARAMETERS

conv-float-s64.*N*.clamp bit rw

If TRUE, then clamp to the range of s64. If FALSE, then allow the value to "wrap around".

210.6. AUTHOR

Jeff Epler

210.7. LICENSE

GPL

Chapter 211. CONV_FLOAT_U32(9)

211.1. NAME

conv_float_u32 - Convert a value from float to u32

211.2. SYNOPSIS

loadrt conv_float_u32 [count=*N* | names=*name1* [, *name2* ...]]

211.3. FUNCTIONS

conv-float-u32.*N*

Update *out* based on *in*

211.4. PINS

conv-float-u32.*N*.in float in

conv-float-u32.*N*.out u32 out

conv-float-u32.*N*.out-of-range bit out

TRUE when *in* is not in the range of u32

211.5. PARAMETERS

conv-float-u32.*N*.clamp bit rw

If TRUE, then clamp to the range of u32. If FALSE, then allow the value to "wrap around".

211.6. AUTHOR

Jeff Epler

211.7. LICENSE

GPL

Chapter 212. CONV_FLOAT_U64(9)

212.1. NAME

conv_float_u64 - Convert a value from float to u64

212.2. SYNOPSIS

loadrt conv_float_u64 [count=*N* | names=*name1* [, *name2* ...]]

212.3. FUNCTIONS

conv-float-u64.*N*

Update *out* based on *in*

212.4. PINS

conv-float-u64.*N*.in float in

conv-float-u64.*N*.out u64 out

conv-float-u64.*N*.out-of-range bit out

TRUE when *in* is not in the range of u64

212.5. PARAMETERS

conv-float-u64.*N*.clamp bit rw

If TRUE, then clamp to the range of u64. If FALSE, then allow the value to "wrap around".

212.6. AUTHOR

Jeff Epler

212.7. LICENSE

GPL

Chapter 213. CONV_S32_BIT(9)

213.1. NAME

conv_s32_bit - Convert a value from s32 to bit

213.2. SYNOPSIS

loadrt conv_s32_bit [count=*N* | names=*name1*[,*name2*...]]

213.3. FUNCTIONS

conv-s32-bit.*N*

Update *out* based on *in*

213.4. PINS

conv-s32-bit.*N*.in s32 in

conv-s32-bit.*N*.out bit out

conv-s32-bit.*N*.out-of-range bit out

TRUE when *in* is not in the range of bit

213.5. PARAMETERS

conv-s32-bit.*N*.clamp bit rw

If TRUE, then clamp to the range of bit. If FALSE, then allow the value to "wrap around".

213.6. AUTHOR

Jeff Epler

213.7. LICENSE

GPL

Chapter 214. CONV_S32_FLOAT(9)

214.1. NAME

`conv_s32_float` - Convert a value from s32 to float

214.2. SYNOPSIS

loadrt `conv_s32_float` [**count**=*N* | **names**=*name1*[,*name2*...]]

214.3. FUNCTIONS

conv-s32-float.N

Update *out* based on *in*

214.4. PINS

conv-s32-float.N.in s32 in

conv-s32-float.N.out float out

214.5. AUTHOR

Jeff Epler

214.6. LICENSE

GPL

Chapter 215. CONV_S32_S64(9)

215.1. NAME

conv_s32_s64 - Convert a value from s32 to s64

215.2. SYNOPSIS

loadrt conv_s32_s64 [**count**=*N* | **names**=*name1* [, *name2* ...]]

215.3. FUNCTIONS

conv-s32-s64.N

Update *out* based on *in*

215.4. PINS

conv-s32-s64.N.in s32 in

conv-s32-s64.N.out s64 out

215.5. AUTHOR

Jeff Epler

215.6. LICENSE

GPL

Chapter 216. CONV_S32_U32(9)

216.1. NAME

conv_s32_u32 - Convert a value from s32 to u32

216.2. SYNOPSIS

loadrt conv_s32_u32 [count=*N* | names=*name1*[,*name2*...]]

216.3. FUNCTIONS

conv-s32-u32.*N*

Update *out* based on *in*

216.4. PINS

conv-s32-u32.*N*.in s32 in

conv-s32-u32.*N*.out u32 out

conv-s32-u32.*N*.out-of-range bit out

TRUE when *in* is not in the range of u32

216.5. PARAMETERS

conv-s32-u32.*N*.clamp bit rw

If TRUE, then clamp to the range of u32. If FALSE, then allow the value to "wrap around".

216.6. AUTHOR

Jeff Epler

216.7. LICENSE

GPL

Chapter 217. CONV_S32_U64(9)

217.1. NAME

conv_s32_u64 - Convert a value from s32 to u64

217.2. SYNOPSIS

loadrt conv_s32_u64 [count=*N* | names=*name1*[,*name2*...]]

217.3. FUNCTIONS

conv-s32-u64.*N*

Update *out* based on *in*

217.4. PINS

conv-s32-u64.*N*.in s32 in

conv-s32-u64.*N*.out u64 out

conv-s32-u64.*N*.out-of-range bit out

TRUE when *in* is not in the range of u64

217.5. PARAMETERS

conv-s32-u64.*N*.clamp bit rw

If TRUE, then clamp to the range of u64. If FALSE, then allow the value to "wrap around".

217.6. AUTHOR

Jeff Epler

217.7. LICENSE

GPL

Chapter 218. CONV_S64_BIT(9)

218.1. NAME

conv_s64_bit - Convert a value from s64 to bit

218.2. SYNOPSIS

loadrt conv_s64_bit [count=*N* | names=*name1*[,*name2*...]]

218.3. FUNCTIONS

conv-s64-bit.*N*

Update *out* based on *in*

218.4. PINS

conv-s64-bit.*N*.in s64 in

conv-s64-bit.*N*.out bit out

conv-s64-bit.*N*.out-of-range bit out

TRUE when *in* is not in the range of bit

218.5. PARAMETERS

conv-s64-bit.*N*.clamp bit rw

If TRUE, then clamp to the range of bit. If FALSE, then allow the value to "wrap around".

218.6. AUTHOR

Jeff Epler

218.7. LICENSE

GPL

Chapter 219. CONV_S64_FLOAT(9)

219.1. NAME

`conv_s64_float` - Convert a value from s64 to float

219.2. SYNOPSIS

loadrt conv_s64_float [count=*N* | names=*name1*[,*name2*...]]

219.3. FUNCTIONS

conv-s64-float.*N*

Update *out* based on *in*

219.4. PINS

conv-s64-float.*N*.in s64 in

conv-s64-float.*N*.out float out

219.5. AUTHOR

Jeff Epler

219.6. LICENSE

GPL

Chapter 220. CONV_S64_S32(9)

220.1. NAME

conv_s64_s32 - Convert a value from s64 to s32

220.2. SYNOPSIS

loadrt conv_s64_s32 [count=*N* | names=*name1*[,*name2*...]]

220.3. FUNCTIONS

conv-s64-s32.*N*

Update *out* based on *in*

220.4. PINS

conv-s64-s32.*N*.in s64 in

conv-s64-s32.*N*.out s32 out

conv-s64-s32.*N*.out-of-range bit out

TRUE when *in* is not in the range of s32

220.5. PARAMETERS

conv-s64-s32.*N*.clamp bit rw

If TRUE, then clamp to the range of s32. If FALSE, then allow the value to "wrap around".

220.6. AUTHOR

Jeff Epler

220.7. LICENSE

GPL

Chapter 221. CONV_S64_U32(9)

221.1. NAME

conv_s64_u32 - Convert a value from s64 to u32

221.2. SYNOPSIS

loadrt conv_s64_u32 [count=*N* | names=*name1*[,*name2*...]]

221.3. FUNCTIONS

conv-s64-u32.*N*

Update *out* based on *in*

221.4. PINS

conv-s64-u32.*N*.in s64 in

conv-s64-u32.*N*.out u32 out

conv-s64-u32.*N*.out-of-range bit out

TRUE when *in* is not in the range of u32

221.5. PARAMETERS

conv-s64-u32.*N*.clamp bit rw

If TRUE, then clamp to the range of u32. If FALSE, then allow the value to "wrap around".

221.6. AUTHOR

Jeff Epler

221.7. LICENSE

GPL

Chapter 222. CONV_S64_U64(9)

222.1. NAME

conv_s64_u64 - Convert a value from s64 to u64

222.2. SYNOPSIS

loadrt conv_s64_u64 [count=*N* | names=*name1*[,*name2*...]]

222.3. FUNCTIONS

conv-s64-u64.*N*

Update *out* based on *in*

222.4. PINS

conv-s64-u64.*N*.in s64 in

conv-s64-u64.*N*.out u64 out

conv-s64-u64.*N*.out-of-range bit out

TRUE when *in* is not in the range of u64

222.5. PARAMETERS

conv-s64-u64.*N*.clamp bit rw

If TRUE, then clamp to the range of u64. If FALSE, then allow the value to "wrap around".

222.6. AUTHOR

Jeff Epler

222.7. LICENSE

GPL

Chapter 223. CONV_U32_BIT(9)

223.1. NAME

conv_u32_bit - Convert a value from u32 to bit

223.2. SYNOPSIS

loadrt conv_u32_bit [count=*N* | names=*name1* [, *name2* ...]]

223.3. FUNCTIONS

conv-u32-bit.*N*

Update *out* based on *in*

223.4. PINS

conv-u32-bit.*N*.in u32 in

conv-u32-bit.*N*.out bit out

conv-u32-bit.*N*.out-of-range bit out

TRUE when *in* is not in the range of bit

223.5. PARAMETERS

conv-u32-bit.*N*.clamp bit rw

If TRUE, then clamp to the range of bit. If FALSE, then allow the value to "wrap around".

223.6. AUTHOR

Jeff Epler

223.7. LICENSE

GPL

Chapter 224. CONV_U32_FLOAT(9)

224.1. NAME

`conv_u32_float` - Convert a value from u32 to float

224.2. SYNOPSIS

loadrt `conv_u32_float` [**count**=*N* | **names**=*name1* [, *name2* ...]]

224.3. FUNCTIONS

conv-u32-float.N

Update *out* based on *in*

224.4. PINS

conv-u32-float.N.in u32 in

conv-u32-float.N.out float out

224.5. AUTHOR

Jeff Epler

224.6. LICENSE

GPL

Chapter 225. CONV_U32_S32(9)

225.1. NAME

conv_u32_s32 - Convert a value from u32 to s32

225.2. SYNOPSIS

loadrt conv_u32_s32 [count=*N* | names=*name1*[,*name2*...]]

225.3. FUNCTIONS

conv-u32-s32.*N*

Update *out* based on *in*

225.4. PINS

conv-u32-s32.*N*.in u32 in

conv-u32-s32.*N*.out s32 out

conv-u32-s32.*N*.out-of-range bit out

TRUE when *in* is not in the range of s32

225.5. PARAMETERS

conv-u32-s32.*N*.clamp bit rw

If TRUE, then clamp to the range of s32. If FALSE, then allow the value to "wrap around".

225.6. AUTHOR

Jeff Epler

225.7. LICENSE

GPL

Chapter 226. CONV_U32_S64(9)

226.1. NAME

conv_u32_s64 - Convert a value from u32 to s64

226.2. SYNOPSIS

loadrt conv_u32_s64 [count=*N* | names=*name1*[,*name2*...]]

226.3. FUNCTIONS

conv-u32-s64.*N*

Update *out* based on *in*

226.4. PINS

conv-u32-s64.*N*.in u32 in

conv-u32-s64.*N*.out s64 out

226.5. AUTHOR

Jeff Epler

226.6. LICENSE

GPL

Chapter 227. CONV_U32_U64(9)

227.1. NAME

conv_u32_u64 - Convert a value from u32 to u64

227.2. SYNOPSIS

loadrt conv_u32_u64 [count=*N* | names=*name1* [, *name2* ...]]

227.3. FUNCTIONS

conv-u32-u64.*N*

Update *out* based on *in*

227.4. PINS

conv-u32-u64.*N*.in u32 in

conv-u32-u64.*N*.out u64 out

227.5. AUTHOR

Jeff Epler

227.6. LICENSE

GPL

Chapter 228. CONV_U64_BIT(9)

228.1. NAME

conv_u64_bit - Convert a value from u64 to bit

228.2. SYNOPSIS

loadrt conv_u64_bit [count=*N* | names=*name1* [, *name2* ...]]

228.3. FUNCTIONS

conv-u64-bit.*N*

Update *out* based on *in*

228.4. PINS

conv-u64-bit.*N*.in u64 in

conv-u64-bit.*N*.out bit out

conv-u64-bit.*N*.out-of-range bit out

TRUE when *in* is not in the range of bit

228.5. PARAMETERS

conv-u64-bit.*N*.clamp bit rw

If TRUE, then clamp to the range of bit. If FALSE, then allow the value to "wrap around".

228.6. AUTHOR

Jeff Epler

228.7. LICENSE

GPL

Chapter 229. CONV_U64_FLOAT(9)

229.1. NAME

`conv_u64_float` - Convert a value from u64 to float

229.2. SYNOPSIS

loadrt `conv_u64_float` [**count**=*N*|**names**=*name1*[,*name2*...]]

229.3. FUNCTIONS

conv-u64-float.N

Update *out* based on *in*

229.4. PINS

conv-u64-float.N.in u64 in

conv-u64-float.N.out float out

229.5. AUTHOR

Jeff Epler

229.6. LICENSE

GPL

Chapter 230. CONV_U64_S32(9)

230.1. NAME

conv_u64_s32 - Convert a value from u64 to s32

230.2. SYNOPSIS

loadrt conv_u64_s32 [count=*N* | names=*name1*[,*name2*...]]

230.3. FUNCTIONS

conv-u64-s32.*N*

Update *out* based on *in*

230.4. PINS

conv-u64-s32.*N*.in u64 in

conv-u64-s32.*N*.out s32 out

conv-u64-s32.*N*.out-of-range bit out

TRUE when *in* is not in the range of s32

230.5. PARAMETERS

conv-u64-s32.*N*.clamp bit rw

If TRUE, then clamp to the range of s32. If FALSE, then allow the value to "wrap around".

230.6. AUTHOR

Jeff Epler

230.7. LICENSE

GPL

Chapter 231. CONV_U64_S64(9)

231.1. NAME

conv_u64_s64 - Convert a value from u64 to s64

231.2. SYNOPSIS

loadrt conv_u64_s64 [count=*N* | names=*name1*[,*name2*...]]

231.3. FUNCTIONS

conv-u64-s64.*N*

Update *out* based on *in*

231.4. PINS

conv-u64-s64.*N*.in u64 in

conv-u64-s64.*N*.out s64 out

conv-u64-s64.*N*.out-of-range bit out

TRUE when *in* is not in the range of s64

231.5. PARAMETERS

conv-u64-s64.*N*.clamp bit rw

If TRUE, then clamp to the range of s64. If FALSE, then allow the value to "wrap around".

231.6. AUTHOR

Jeff Epler

231.7. LICENSE

GPL

Chapter 232. CONV_U64_U32(9)

232.1. NAME

conv_u64_u32 - Convert a value from u64 to u32

232.2. SYNOPSIS

loadrt conv_u64_u32 [count=*N* | names=*name1*[,*name2*...]]

232.3. FUNCTIONS

conv-u64-u32.*N*

Update *out* based on *in*

232.4. PINS

conv-u64-u32.*N*.in u64 in

conv-u64-u32.*N*.out u32 out

conv-u64-u32.*N*.out-of-range bit out

TRUE when *in* is not in the range of u32

232.5. PARAMETERS

conv-u64-u32.*N*.clamp bit rw

If TRUE, then clamp to the range of u32. If FALSE, then allow the value to "wrap around".

232.6. AUTHOR

Jeff Epler

232.7. LICENSE

GPL

Chapter 233. COREXY_BY_HAL(9)

233.1. NAME

corexy_by_hal - CoreXY kinematics

233.2. SYNOPSIS

loadrt corexy_by_hal [**count**=*N* | **names**=*name1* [, *name2* ...]]

233.3. DESCRIPTION

Implement **CoreXY** forward and inverse transformations **in HAL**. This component provides an alternative method for implementing **CoreXY** kinematics.

In the INI file, use:

```
[KINS]
KINEMATICS=trivkins
coordinates=xyz
kinstype=both
```

This component accepts two joint (**j0**, **j1**) motor position commands for a trivkins coordinates=xyz configuration and computes equivalent **CoreXY** motor commands for two motors identified as **alpha**, **beta**. Similarly, the component accepts feedback values for the **alpha,beta** motor controllers and converts to equivalent joint (**j0**, **j1**) motor position feedback values.

Notes:

1. Using **trivkins** with this module allows home switches to trigger according to the **Cartesian x,y** positions
2. Joint pin names are based on **coordinates=xyz** and the corresponding joint number assignments used by **trivkins** so **j0==x**, **j1==y** (see **trivkins(9)**).
3. **CoreXY** kinematics can also be implemented using the kinematics module named **corexykins** with home switches triggered by the **j0,j1 motor** positions (see **kins(9)**).

233.4. FUNCTIONS

corexy-by-hal.N

233.5. PINS

corexy-by-hal.N.alpha-fb float in

typ: feedback from alpha motor controller

corexy-by-hal.N.beta-fb float in

typ: feedback from beta motor controller

corexy-by-hal.N.j0-motor-pos-cmd float in

typ: from joint.0.motor-pos-cmd

corexy-by-hal.N.j1-motor-pos-cmd float in

typ: from joint.1.motor-pos-cmd

corexy-by-hal.N.j0-motor-pos-fb float out

typ: to joint.0.motor-pos-fb

corexy-by-hal.N.j1-motor-pos-fb float out

typ: to joint.1.motor-pos-fb

corexy-by-hal.N.alpha-cmd float out

typ: command to alpha motor

corexy-by-hal.N.beta-cmd float out

typ: command to beta ts motor

233.6. AUTHOR

Dewey Garrett based on forum post from nbremond

233.7. LICENSE

GPL

Chapter 234. counter(9)

234.1. NAME

counter - counts input pulses (DEPRECATED)

234.2. SYNOPSIS

loadrt counter [num_chan=*N*]

234.3. DESCRIPTION

counter is a deprecated HAL component and will be removed in a future release. Use the **encoder** component with encoder.X.counter-mode set to TRUE.

counter is a HAL component that provides software- based counting that is useful for spindle position sensing and maybe other things. Instead of using a real encoder that outputs quadrature, some lathes have a sensor that generates a simple pulse stream as the spindle turns and an index pulse once per revolution. This component simply counts up when a "count" pulse (phase-A) is received, and if reset is enabled, resets when the "index" (phase-Z) pulse is received.

This is of course only useful for a unidirectional spindle, as it is not possible to sense the direction of rotation.

counter conforms to the "canonical encoder" interface described in the HAL manual.

234.4. FUNCTIONS

counter.capture-position (uses floating-point)

Updates the counts, position and velocity outputs based on internal counters.

counter.update-counters

Samples the phase-A and phase-Z inputs and updates internal counters.

234.5. PINS

counter.N.phase-A bit in

The primary input signal. The internal counter is incremented on each rising edge.

counter.N.phase-Z bit in

The index input signal. When the **index-enable** pin is TRUE and a rising edge on **phase-Z** is seen, **index-enable** is set to FALSE and the internal counter is reset to zero.

counter.N.index-enable bit io

+

counter.N.reset bit io

+

counter.N.counts signed out

+

counter.N.position float out

+

counter.N.velocity float out

These pins function according to the canonical digital encoder interface.

counter.N.position-scale float rw

This parameter functions according to the canonical digital encoder interface.

counter.N.rawcounts signed ro

The internal counts value, updated from **update-counters** and reflected in the output pins at the next call to **capture-position**.

234.6. SEE ALSO

encoder(9)

Chapter 235. DBOUNCE(9)

235.1. NAME

dbounce - alternative debounce component

235.2. SYNOPSIS

loadrt dbounce [**count**=*N* | **names**=*name1* [, *name2* ...]]

235.3. DESCRIPTION

This component is similar to the **debounce**(9) component but uses settable delay pins for each instance and supports **count**= or **names**= parameters (groups are not used)

235.4. FUNCTIONS

dbounce.N

235.5. PINS

dbounce.N.in bit in

dbounce.N.out bit out

dbounce.N.delay u32 in (default: 5)

235.6. AUTHOR

Dewey Garrett

235.7. LICENSE

GPL

Chapter 236. DDT(9)

236.1. NAME

ddt - Compute the derivative of the input function

236.2. SYNOPSIS

loadrt ddt [**count**=*N*|**names**=*name1*[,*name2*...]]

236.3. DESCRIPTION

For every function call from the real time thread, calculate the difference between the old and current input value divided by the timer elapsed since the last call.

236.4. FUNCTIONS

ddt.N

236.5. PINS

ddt.N.in float in

ddt.N.out float out

236.6. NOTES

As this only work on two consecutive input values, it will only work well if the input change every function call, and not work so well if the rate of change is very low and the input change do not happen every time the real time function is called.

236.7. AUTHOR

Jeff Epler

236.8. LICENSE

GPL

Chapter 237. DEADZONE(9)

237.1. NAME

deadzone - Return the center if within the threshold

237.2. SYNOPSIS

loadrt deadzone [**count**=*N* | **names**=*name1*[,*name2*...]]

237.3. FUNCTIONS

deadzone.N

Update **out** based on **in** and the parameters.

237.4. PINS

deadzone.N.in float in

deadzone.N.out float out

237.5. PARAMETERS

deadzone.N.center float rw (default: *0.0*)

The center of the dead zone

deadzone.N.threshold float rw (default: *1.0*)

The dead zone is **center** \pm (**threshold**/2)

237.6. AUTHOR

Jeff Epler

237.7. LICENSE

GPL

Chapter 238. debounce(9)

238.1. NAME

debounce - filter noisy digital inputs

238.2. SYNOPSIS

loadrt debounce cfg=size[,size,...]

Creates debounce groups with the number of filters specified by (*size*). Every filter in the same group has the same sample rate and delay. For example `cfg=2,3` creates two filter groups with 2 filters in the first group and 3 filters in the second group.

238.3. SEE ALSO

An alternate component named **dbounce** implements similar functionality using conventional `count=` and `names=` parameters. Delay settings are implemented by a delay pin for each instance instead of using filter groups.

238.4. DESCRIPTION

The debounce filter works by incrementing a counter whenever the input is true, and decrementing the counter when it is false. If the counter decrements to zero, the output is set false and the counter ignores further decrements. If the counter increments up to a threshold, the output is set true and the counter ignores further increments. If the counter is between zero and the threshold, the output retains its previous state. The threshold determines the amount of filtering: A threshold of 1 does no filtering at all, and a threshold of *N* requires a signal to be present for *N* samples before the output changes state.

238.5. FUNCTIONS

debounce.G

Sample all the input pins in group *G* and update the output pins.

238.6. PINS

debounce.G.F.in bit in

The *F*'th input pin in group *G*.

debounce.G.F.out bit out

The *F*'th output pin in group *G*. Reflects the last "stable" input seen on the corresponding input pin.

debounce.G.delay signed rw

Sets the amount of filtering for all pins in group *G*.

Chapter 239. DEMUX(9)

239.1. NAME

demux - Select one of several output pins by integer and/or or individual bits.

239.2. SYNOPSIS

loadrt demux [**count**=*N* | **names**=*name1* [, *name2* ...]] [**personality**=*P1* [, *P2* ...]]

239.3. DESCRIPTION

This component creates a number of output bits defined by the "personality" command-line parameter. One of these bits will be set based on interpreting the bit-inputs as a binary number and then adding on the integer input. Most uses will use only one or the other, but it is possible to use the bits as a ""shift"" if required. An optional operating mode is enabled by setting the "bargraph" parameter to true, in this case all bits up to the selected bit will be set, as might be required for an LED bargraph display.

239.4. FUNCTIONS

demux.N

239.5. PINS

demux.N.sel-bit-MM bit in (MM=00..04)

Binary-number bit selectors

demux.N.sel-u32 u32 in

Integer selection input

demux.N.out-MM bit out (MM=00..personality)

The set of output bits

239.6. PARAMETERS

demux.N.bargraph bit rw (default: 0)

239.7. SEE ALSO

select8(9)

239.8. AUTHOR

Andy Pugh

239.9. LICENSE

GPL 2+

Chapter 240. demux_generic(9)

240.1. NAME

demux_generic - routes a single input signal to one of multiple outputs

240.2. SYNOPSIS

loadrt demux_generic config="<input_type><output_type><size>[,<input_type><output_type><size>],..."


Types: **b** = bit, **f** = float, **s** = signed integer, **u** = unsigned integer

Example: **loadrt demux_generic config="bb8,fu12"**

240.3. FUNCTIONS

demux-gen.NN Depending on the data types can run in either a floating point or non-floating point thread.

240.4. PINS



demux-gen.N.suppress-no-input bit in

This suppresses changing the output if all select lines are false. This stops unwanted jumps in output between transitions of input but makes in00 unavailable.

demux-gen.N.debounce-us unsigned in

sets debounce time in microseconds, e.g. 100000 = a tenth of a second. The selection inputs must be stable this long before the output changes. This helps to ignore *noisy* switches.

demux-gen.N.sel-bit-BB bit in (BB=0..bit width of size)

demux-gen.N.sel-int unsigned in

The sel-bit pins are only created when the size of the demux_gen component is an integer power of two. Together, these determine to which **out-MM** the **in** value is forwarded. The bit pins are

interpreted as binary bits, and the result is simply added on to the integer pin input. It is expected that either one or the other would normally be used. However, the possibility exists to use a higher-order bit to "shift" the values set by the integer pin.

demux-gen.N.in-[bit/float/s32/u32] variable-type in

The input value which is routed to an output depending on the selection pins.

demux-gen.N.out--MM variable-type out (M=0..size-1)

According to the selection bits and/or the selection number, the selected output follows the **in** value. The other outputs retain the values they had before resp. zero if they have not been selected yet. Values will be converted/truncated according to standard C rules. This means, for example that a float input greater than 2147483647 will give an S32 output of -2147483648.

240.5. PARAMETERS

demux-gen.N.elapsed float r

Current value of the internal debounce timer for debugging.

demux-gen.N.selected s32 r

Current value of the internal selection variable after conversion for debugging. Possibly useful for setting up gray-code switches.

240.6. DESCRIPTION

This component is a general demultiplexer component. It allows the creation of arbitrary-size demultiplexers (up to 1024 entries) and also supports differing data types on the input and output pins. The configuration string is a comma-separated list of code-letters and numbers, such as "bb4,fu12". This would create a 4-element bit-to-bit demux and a 12-element float-to-unsigned demux. The code letters are:

b = bit, **f** = float, **s** = signed integer and **u** = unsigned integer.

The first letter code is the input type, the second is the output type. The codes are not case-sensitive. The order of the letters is significant but the position in the string is not. Do not insert any spaces in the config string. Any non-zero float value will be converted to a "true" output in bit form. Be wary that float datatypes can be very, very, close to zero and not actually be equal to zero.

Each demux has its own HAL function and must be added to a thread separately. If neither input nor output is of type float then the function is base-thread (non floating-point) safe. Any demux_generic with a floating point input or output can only be added to a floating-point thread.

240.7. SEE ALSO

mux_generic(9)

240.8. AUTHOR

Hans Unzner

240.9. LICENSE

GPL

Chapter 241. DIFFERENTIAL(9)

241.1. NAME

differential - kinematics for a differential transmission

241.2. SYNOPSIS

loadrt differential [count=*N* | names=*name1* [, *name2* ...]]

241.3. FUNCTIONS

differential.*N*

241.4. PINS

differential.*N*.roll-cmd float in

position command for roll (in degrees)

differential.*N*.pitch-cmd float in

position command for pitch (in degrees)

differential.*N*.roll-fb float out

position feedback for roll (in degrees)

differential.*N*.pitch-fb float out

position feedback for pitch (in degrees)

differential.*N*.motor0-cmd float out

position command to motor0 (based on roll & pitch inputs)

differential.*N*.motor1-cmd float out

position command to motor1 (based on roll & pitch inputs)

differential.*N*.motor0-fb float in

position feedback from motor0

differential.*N*.motor1-fb float in

position feedback from motor1

241.5. AUTHOR

Sebastian Kuzminsky

241.6. LICENSE

GPL

Chapter 242. DIV2(9)

242.1. NAME

div2 - Quotient of two floating point inputs

242.2. SYNOPSIS

loadrt div2 [count=*N* | names=*name1*[,*name2*...]]

242.3. DESCRIPTION

A very simple comp to divide a floating point number by another floating point number, to get a floating point result. Remember, not to use a zero divisor. A zero divisor creates an indefinite result. This is simple mathematics.

242.4. FUNCTIONS

div2.*N*

242.5. PINS

div2.*N*.in0 float in

the Dividend

div2.*N*.in1 float in

the Divisor

div2.*N*.out float out

the Quotient out = in0 / in1

242.6. PARAMETERS

div2.*N*.deadband float rw

The **out** will be zero if **in** is between **-deadband** and **+deadband**

242.7. SEE ALSO

mult2(9), invert(9)

242.8. AUTHOR

Noel Rhodes

242.9. LICENSE

GPL

Chapter 243. EDGE(9)

243.1. NAME

edge - Edge detector

243.2. SYNOPSIS

loadrt edge [count=*N* | names=*name1* [,*name2*...]]

243.3. FUNCTIONS

edge.*N*

Produce output pulses from input edges

243.4. PINS

edge.*N*.in bit in

edge.*N*.out bit out

Goes high when the desired edge is seen on *in*

edge.*N*.out-invert bit out

Goes low when the desired edge is seen on *in*

243.5. PARAMETERS

edge.*N*.both bit rw (default: *FALSE*)

If TRUE, selects both edges. Otherwise, selects one edge according to in-edge

edge.*N*.in-edge bit rw (default: *TRUE*)

If both is FALSE, selects the one desired edge: TRUE means falling, FALSE means rising

edge.*N*.out-width-ns s32 rw (default: *0*)

Time in nanoseconds of the output pulse

edge.*N*.time-left-ns s32 r

Time left in this output pulse

edge.*N*.last-in bit r

Previous input value

243.6. AUTHOR

Jeff Epler

243.7. LICENSE

GPL

Chapter 244. encoder(9)

244.1. NAME

encoder - software counting of quadrature encoder signals

244.2. SYNOPSIS

loadrt encoder [**num_chan**=*num* | **names**=*name1*[,*name2*...]]

244.3. DESCRIPTION

encoder is used to measure position by counting the pulses generated by a quadrature encoder. As a software-based implementation it is much less expensive than hardware, but has a limited maximum count rate. The limit is in the range of 10 kHz to 50 kHz, depending on the computer speed and other factors. If better performance is needed, a hardware encoder counter is a better choice. Some hardware-based systems can count at MHz rates.

encoder supports a maximum of eight channels. The number of channels actually loaded is set by the **num_chan** argument when the module is loaded. Alternatively, specify **names=** and unique names separated by commas.

The **num_chan=** and **names=** specifiers are mutually exclusive. If neither **num_chan=** nor **names=** are specified, or if **num_chan=0** is specified, the default value is three.

encoder has a one-phase, unidirectional mode called *counter*. In this mode, the **phase-B** input is ignored; the counts increase on each rising edge of **phase-A**. This mode may be useful for counting a unidirectional spindle with a single input line, though the noise-resistant characteristics of quadrature are lost.

If used in counter-mode it is also possible to enable the missing-teeth index mode, where a gap in the pulse train of one or more teeth is used as in index marker. This system is used extensively for automotive crank position sensors.

244.4. FUNCTIONS

encoder.update-counters (no floating-point)

Does the actual counting, by sampling the encoder signals and decoding the quadrature waveforms. Must be called as frequently as possible, preferably twice as fast as the maximum desired count rate. Operates on all channels at once.

encoder.capture-position (uses floating point)

Captures the raw counts from **update-counters** and performs scaling and other necessary conversion, handles counter rollover, etc. Can (and should) be called less frequently than **update-counters**. Operates on all channels at once.

244.5. NAMING

The names for pins and parameters are prefixed as: **encoder.N.** for $N=0,1,\dots,\text{num}-1$ when using **num_chan=num** **nameN.** for $\text{nameN}=\text{name1},\text{name2},\dots$ when using **names=name1,name2,**...

The **encoder.N.** format is shown in the following descriptions.

244.6. PINS

encoder.N.counter-mode bit i/o

Enables counter mode. When true, the counter counts each rising edge of the phase-A input, ignoring the value on phase-B. This is useful for counting the output of a single channel (non-quadrature) sensor. When false (the default), it counts in quadrature mode.

encoder.N.counts s32 out

Position in encoder counts.

encoder.N.index-enable bit i/o

When true, **counts** and **position** are reset to zero on the next rising edge of **Phase-Z**. At the same time, **index-enable** is reset to zero to indicate that the rising edge has occurred.

encoder.N.min-speed-estimate float in (default: 1.0)

Determine the minimum speed at which **velocity** will be estimated as nonzero and **position-interpolated** will be interpolated. The units of **min-speed-estimate** are the same as the units of **velocity**. Setting this parameter too low will cause it to take a long time for **velocity** to go to 0 after encoder pulses have stopped arriving.

encoder.N.phase-A bit in

Quadrature input for encoder channel N .

encoder.N.phase-B bit in

Quadrature input.

encoder.N.phase-Z bit in

Index pulse input.

encoder.N.position float out

Position in scaled units (see **position-scale**)

encoder.N.position-interpolated float out

Position in scaled units, interpolated between encoder counts. Only valid when velocity is approximately constant and above **min-speed-estimate**. Do not use for position control.

encoder.N.position-scale float i/o

Scale factor, in counts per length unit. For example, if **position-scale** is 500, then 1000 counts of the encoder will be reported as a position of 2.0 units.

encoder.N.missing-teeth s32 in

The number of teeth missing from the index gap. For example a 60 tooth gear with two teeth shortened to form an index so that there are 58 pulses per revolution would use a position-scale of 60 and a missing-teeth of 2.

encoder.N.rawcounts s32 out

The raw count, as determined by **update-counters**. This value is updated more frequently than **counts** and **position**. It is also unaffected by **reset** or the index pulse.

encoder.N.reset bit in

When true, **counts** and **position** are reset to zero immediately.

encoder.N.velocity float out

Velocity in scaled units per second. **encoder** uses an algorithm that greatly reduces quantization noise as compared to simply differentiating the **position** output. When the magnitude of the true velocity is below min-speed-estimate, the velocity output is 0.

encoder.N.velocity-rpm float out

Velocity in scaled units per minute. Simply **encoder.N.velocity** scaled by a factor of 60 for convenience.

encoder.N.x4-mode bit i/o

Enables times-4 mode. When true (the default), the counter counts each edge of the quadrature waveform (four counts per full cycle). When false, it only counts once per full cycle. In **counter-mode**, this parameter is ignored.

encoder.N.latch-input bit in

+

encoder.N.latch-falling bit in (default: TRUE)

+

encoder.N.latch-rising bit in (default: TRUE)

+

encoder.N.counts-latched s32 out

+

encoder.N.position-latched float out

Update **counts-latched** and **position-latched** on the rising and/or falling edges of **latch-input** as indicated by **latch-rising** and **latch-falling**.

encoder.N.counter-mode bit rw

Enables counter mode. When true, the counter counts each rising edge of the phase-A input, ignoring the value on phase-B. This is useful for counting the output of a single channel (non-quadrature) sensor. When false (the default), it counts in quadrature mode.

encoder.N.capture-position.tmax s32 rw

Maximum number of CPU cycles it took to execute this function.

244.7. PARAMETERS

The encoder component has no HAL Parameters.

Chapter 245. encoder_ratio(9)

245.1. NAME

encoder_ratio - an electronic gear to synchronize two axes

245.2. SYNOPSIS

loadrt encoder_ratio [num_chan=num | names=name1[,name2...]]

245.3. DESCRIPTION

encoder_ratio can be used to synchronize two axes (like an "electronic gear"). It counts encoder pulses from both axes in software, and produces an error value that can be used with a PID loop to make the slave encoder track the master encoder with a specific ratio.

This module supports up to eight axis pairs. The number of pairs is set by the module parameter **num_chan**. Alternatively, specify **names=** and unique names separated by commas.

The **num_chan=** and **names=** specifiers are mutually exclusive. If neither **num_chan=** nor **names=** are specified, the default value is one.

245.4. FUNCTIONS

encoder-ratio.sample

Read all input pins. Must be called at twice the maximum desired count rate.

encoder-ratio.update (uses floating-point)

Updates all output pins. May be called from a slower thread.

245.5. NAMING

The names for pins and parameters are prefixed as: **encoder-ratio.N.** for $N=0,1,\dots,num-1$ when using **num_chan=num** **nameN.** for **nameN=name1,name2,...** when using ***names=name1,name2,...**.

The **encoder-ratio.N.** format is shown in the following descriptions.

245.6. PINS

encoder-ratio.N.master-A bit in

+

encoder-ratio.N.master-B bit in

+

encoder-ratio.N.slave-A bit in

+

encoder-ratio.N.slave-B bit in

The encoder channels of the master and slave axes.

encoder-ratio.N.enable bit in

When the enable pin is FALSE, the error pin simply reports the slave axis position, in revolutions. As such, it would normally be connected to the feedback pin of a PID block for closed loop control of the slave axis. Normally the command input of the PID block is left unconnected (zero), so the slave axis simply sits still. However when the enable input goes TRUE, the error pin becomes the slave position minus the scaled master position. The scale factor is the ratio of master teeth to slave teeth. As the master moves, error becomes non-zero, and the PID loop will drive the slave axis to track the master.

encoder-ratio.N.error float out

The error in the position of the slave (in revolutions).

245.7. PARAMETERS

encoder-ratio.N.master-ppr unsigned rw**encoder-ratio.N.slave-ppr unsigned rw**

The number of pulses per revolution of the master and slave axes.

encoder-ratio.N.master-teeth unsigned rw**encoder-ratio.N.slave-teeth unsigned rw**

The number of "teeth" on the master and slave gears.

245.8. SEE ALSO

encoder(9)

Chapter 246. enum(9)

246.1. NAME

enum - enumerate integer values into bits

246.2. SYNOPSIS

loadrt enum enums=E;enum1pin1;enum1pin2;;;enum1pin3,D;;;enum2pin1;enum2pin2 [names=name1,name2]

246.3. DESCRIPTION

enum converts integer values into bits and vice versa.

The component is especially suitable for encoding and decoding register values for modbus devices, where control commands and status are frequently encoded as enumerations rather than bits. For example, 0 = stop, 1 = forwards, 2 = backwards, 3 = jog-forwards etc.

The pins created and the behaviour of the component are controlled by the load-time modparams "enums=" and "names="

The **enums=** parameter should be a comma-separated list of semicolon-separated pin labels. The enumerated values will increase in sequence starting at zero. To skip a value use a zero-length label, i.e. two consecutive semicolons, as shown in the examples.

There should be no spaces in the "enums=" list.

"names=" is an optional list of component instance names. If "names=" is omitted the functions and pins will be named "enum-decode...." or "enum-encode...."

Taking the example configuration above, if **enum-decode.01.enum2pin1-in** is set to **TRUE** then the output pin **enum-decode.01.output** will be set to the value 2. If **enum-decode.01.enum2pin2-in** is set to true then the output would be 3.

Conversely, if **enum-encode.00.input** is set to 4 then the pin **enum-encode.00.enum1pin3-out** will be set to **TRUE**.

246.4. OPTIONS

Preceding the list of labels should be the control-codes "D" for decode or "E" for encode. A D-type enum will set the value of HAL bit pins in response to changes to the enum-decode.NN.input value, whereas an E-type enum will set the value of the enum-encode.NN.output integer depending on which enum-encode.NN.label-bit value is set.

If more than one label-bit input pin is set the output value will correspond to the pin label later in the list.

E and D-type enumerations may be freely mixed in separate instances.

246.5. FUNCTIONS

enum-decode.NN

if instance type = "D"

enum-encode.NN

if instance type = "E"

246.6. PINS

enum-decode.NN.input

The integer value to be decoded

enum-decode.NN.label-out

Output bits of a decode instance

enum-decode.NN.label-val

The enumeration value corresponding to each specific bit output. These are populated in sequence during loading but may be over-ridden in HAL if convenient.

enum-encode.NN.label-in

input bits of a decode instance

enum-encode.NN.label-val

The enumeration value corresponding to each specified bit input. These are populated in sequence during loading but may be over-ridden in HAL if convenient.

enum-decode.NN.output

The integer value corresponding to the set bit input.

246.7. BUGS

If no bits are set the output value will be zero even if zero is a defined enumeration.

246.8. AUTHOR

Andy Pugh

246.9. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

246.10. COPYRIGHT

Copyright © 2023 Andy Pugh.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 247. EOFFSET_PER_ANGLE(9)

247.1. NAME

`offset_per_angle` - Compute External Offset Per Angle

247.2. SYNOPSIS

loadrt offset_per_angle [**count**=*N*|**names**=*name1*[,*name2*...]]

247.3. DESCRIPTION

An offset is computed (from one of several functions) based on an input angle in degrees. The angle could be a rotary coordinate value or a spindle angle.

The computed offset is represented as an s32 **kcounts** output pin that is a compatible input to external offset pins like **axis.L.offset-counts** where **L** is the coordinate letter. Scaling of the s32 **kcounts** is controlled by the input (**k**)—its reciprocal value is presented on an output pin **kreciprocal** for connection to **axis.L.offset-scale**. The default value for **k** should be suitable for most uses.

The built-in functions use pins **fmult** and **rfraction** to control the output frequency (or number of polygon sides) and amplitude respectively. The **rfraction** pin controls the offset amplitude as a fraction of the **radius-ref** pin.

One of the four built-in functions is specified by the **fnum** pin:

- 0: f0 inside polygon (requires **fmult** == nsides ≥ 3)
- 1: f1 outside polygon (requires **fmult** == nsides ≥ 3)
- 2: f2 sinusoid
- 3: f3 square wave

Unsupported **fnum** values default to use function f0.

247.4. FUNCTIONS

offset-per-angle.N

247.5. PINS

offset-per-angle.N.active bit in (default: 0)

From: motion.offset-active

offset-per-angle.N.is-on bit in (default: 0)

From: halui.machine.is-on

offset-per-angle.N.enable-in bit in (default: 0)

Enable Input

offset-per-angle.N.radius-ref float in (default: 1)

Radius reference (see notes)

offset-per-angle.N.angle float in (default: 0)

Input angle (in degrees)

offset-per-angle.N.start-angle float in (default: 0)

Start angle (in degrees)

offset-per-angle.N.fnum s32 in (default: 0)

Function selector (default 0)

offset-per-angle.N.rfraction float in (default: 0.1)

Offset amplitude (+/- fraction of radius_ref)

offset-per-angle.N.fmult float in (default: 6)

Offset frequency multiplier

offset-per-angle.N.k u32 in (default: 10000)

Scaling Factor (if 0, use 10000)

offset-per-angle.N.is-off bit out

invert is_on (for convenience)

offset-per-angle.N.enable-out bit out

To: axis.L.offset-enable

offset-per-angle.N.clear bit out

To: axis.L.offset-clear

offset-per-angle.N.kcounts s32 out

To: axis.L.offset-counts

offset-per-angle.N.kreciprocal float out

To: axis.L.offset-scale (1/k)

offset-per-angle.N.offset-dbg float out

offset (debug pin—use kcounts & kreciprocal)

offset-per-angle.N.state-dbg u32 out

state (debug pin)

247.6. EXAMPLES

An example simulation configuration is provided at: [configs/sim/axis/external_offsets/opa.ini](#).

A simulated XZC machine uses the **C** coordinate angle to offset the transverse **X** coordinate according to the selected **fnum** function.

247.7. NOTES

radius-ref

The computed offsets are based on the **radius-ref** pin value. This pin may be set to a constant radius value or controlled by a user interface or by g code program (using **M68** and a **motion.analog-out-NN** pin for instance).

Stopping

When the **enable-in** pin is deasserted, the offset is returned to zero respecting the allocated acceleration and velocity limits. The allocations for coordinate **L** are typically controlled by an ini file setting:

```
[AXIS_L]  
OFFSET_AV_RATIO=...
```

If unsupported parameters are supplied to a function (for instance a polygon with fewer than three sides), the current offset will be returned to zero (respecting velocity and acceleration constraints). After correcting the offending parameter, the **enable-in** pin must be toggled to resume offset computations.

247.8. AUTHOR

Dewey Garrett

247.9. LICENSE

GPL

Chapter 248. ESTOP_LATCH(9)

248.1. NAME

estop_latch - Software ESTOP latch

248.2. SYNOPSIS

loadrt estop_latch [count=*N* | names=*name1* [, *name2* ...]]

248.3. DESCRIPTION

This component can be used as a part of a simple software ESTOP chain.

It has two states: "OK" and "Faulted".

The initial state is "Faulted". When faulted, the **out-ok** output is false, the **fault-out** output is true, and the **watchdog** output is unchanging.

The state changes from "Faulted" to "OK" when **all** these conditions are true:

- **fault-in** is false
- **ok-in** is true
- **reset** changes from false to true

When "OK", the **out-ok** output is true, the **fault-out** output is false, and the **watchdog** output is toggling.

The state changes from "OK" to "Faulted" when **any** of the following are true:

- **fault-in** is true
- **ok-in** is false

To facilitate using only a single fault source, **ok-in** and **fault-en** are both set to the non-fault-causing value when no signal is connected. For estop-latch to ever be able to signal a fault, at least one of these inputs must be connected.

Typically, an external fault or estop input is connected to **fault-in**, **iocontrol.0.user-request-enable** is connected to **reset**, and **ok-out** is connected to **iocontrol.0.emc-enable-in**.

In more complex systems, it may be more appropriate to use classicladder to manage the software portion of the estop chain.

248.4. FUNCTIONS

estop-latch.N

248.5. PINS

estop-latch.N.ok-in bit in (default: *true*)

estop-latch.N.fault-in bit in (default: *false*)

estop-latch.N.reset bit in

estop-latch.N.ok-out bit out (default: *false*)

estop-latch.N.fault-out bit out (default: *true*)

estop-latch.N.watchdog bit out

248.6. AUTHOR

John Kasunich

248.7. LICENSE

GPL

Chapter 249. FEEDCOMP(9)

249.1. NAME

feedcomp - Multiply the input by the ratio of current velocity to the feed rate.

249.2. SYNOPSIS

loadrt feedcomp [count=*N* | names=*name1*[,*name2*...]]

249.3. FUNCTIONS

feedcomp.*N*

249.4. PINS

feedcomp.*N*.out float out

Proportionate output value

feedcomp.*N*.in float in

Reference value

feedcomp.*N*.enable bit in

Turn compensation on or off.

feedcomp.*N*.vel float in

Current velocity

249.5. PARAMETERS

feedcomp.*N*.feed float rw

Feed rate reference value

249.6. NOTES

Note that if enable is false, out = in.

249.7. AUTHOR

Eric H. Johnson

249.8. LICENSE

GPL

Chapter 250. FILTER_KALMAN(9)

250.1. NAME

`filter_kalman` - Unidimensional Kalman filter, also known as linear quadratic estimation (LQE)

250.2. SYNOPSIS

loadrt filter_kalman [**count**=*N* | **names**=*name1*[,*name2*...]]

250.3. DESCRIPTION

Useful for reducing input signal noise (e.g. from the voltage or temperature sensor).

More information can be found at https://en.wikipedia.org/wiki/Kalman_filter.

Adjusting **Qr** and **Qk** covariances:

Default values of **Rk** and **Qk** are given for informational purpose only. The nature of the filter requires the parameters to be individually computed.

One of the possible and quite practical method (probably far from being the best) of estimating the **Rk** covariance is to collect the raw data from the sensor by either asserting the **debug** pin or using **halscope** and then compute the covariance using **cov()** function from **Octave** package. Ready to use script can be found at <https://github.com/dwrobel/TrivialKalmanFilter/blob/master/examples/DS18B20Test/covariance.m>.

Adjusting **Qk** covariance mostly depends on the required response time of the filter. There is a relationship between **Qk** and response time of the filter that the lower the **Qk** covariance is the slower the response of the filter is.

Common practice is also to conservatively set **Rk** and **Qk** slightly larger then computed ones to get robustness.

250.4. FUNCTIONS

filter-kalman.N

Update **xk-out** based on **zk** input.

250.5. PINS

filter-kalman.N.debug bit in (default: *FALSE*)

When asserted, prints out measured and estimated values.

filter-kalman.N.passthrough bit in (default: *FALSE*)

When asserted, copies measured value into estimated value.

filter-kalman.N.reset bit in (default: *FALSE*)

When asserted, resets filter to its initial state and returns 0 as an estimated value (**reset** pin has higher priority than **passthrough** pin).

filter-kalman.N.zk float in

Measured value.

filter-kalman.N.xk-out float out

Estimated value.

250.6. PARAMETERS

filter-kalman.N.Rk float rw (default: *1.17549e-38*)

Estimation of the noise covariances (process).

filter-kalman.N.Qk float rw (default: *1.17549e-38*)

Estimation of the noise covariances (observation).

250.7. AUTHOR

Dmian Wrobel dwrobel.AT.ertelnet.rybnik.pl

250.8. LICENSE

GPL-2.0-or-later

Chapter 251. FLIPFLOP(9)

251.1. NAME

flipflop - D type flip-flop

251.2. SYNOPSIS

loadrt flipflop [**count**=*N* | **names**=*name1* [, *name2* ...]]

251.3. FUNCTIONS

flipflop.N

251.4. PINS

flipflop.N.data- bit in

data input

flipflop.N.clk bit in

clock, rising edge writes data to out

flipflop.N.set bit in

when true, force out true

flipflop.N.reset bit in

when true, force out false; overrides set

flipflop.N.out bit io

output

flipflop.N.out-not bit io

inverted output

251.5. AUTHOR

John Kasunich

251.6. LICENSE

GPL

Chapter 252. GANTRY(9)

252.1. NAME

gantry - LinuxCNC HAL component for driving multiple joints from a single axis.

252.2. SYNOPSIS

loadrt gantry [count=*N* | names=*name1*[,*name2*...]] [personality=*P1*[,*P2*...]]

252.3. DESCRIPTION

--- Deprecation Notice

gantry - Superseded by the general purpose *trivkins* kinematics module.

To specify a gantry with non-identity kinematics: use *trivkins* with the *kinstype* parameter set for *KINEMATICS_BOTH*. Example:

loadrt trivkins coordinates=xyz kinstypes=BOTH Drives multiple physical motors (joints) from a single axis input

--- End deprecation notice Drives multiple physical motors (joints) from a single axis input

The ‘personality’ value is the number of joints to control. Two is typical, but up to seven is supported (a three joint setup has been tested with hardware).

All controlled joints track the commanded position (with a per-joint offset) unless in the process of homing. Homing is when the commanded position is moving towards the homing switches (as determined by the sign of *search-vel*) and the joint home switches are not all in the same state. When the system is homing and a joint home switch activates, the command value sent to that joint is "frozen" and the joint offset value is updated instead. Once all home switches are active, there are no more adjustments made to the offset values and all joints run in lock-step once more.

For best results, set *HOME_SEARCH_VEL* and *HOME_LATCH_VEL* to the same direction and as slow as practical. When a joint home switch trips, the commanded velocity will drop immediately from *HOME_SEARCH_VEL* to zero, with no limit on acceleration.

252.4. FUNCTIONS

gantry.*N*.read

Update position-fb and home/limit outputs based on joint values.

gantry.*N*.write

Update joint pos-cmd outputs based on position-cmd in.

252.5. PINS

gantry.N.joint.MM.pos-cmd float out (MM=00..personality)

Per-joint commanded position

gantry.N.joint.MM.pos-fb float in (MM=00..personality)

Per-joint position feedback

gantry.N.joint.MM.home bit in (MM=00..personality)

Per-joint home switch

gantry.N.joint.MM.offset float out (MM=00..personality)

(debugging) Per-joint offset value, updated when homing.

gantry.N.position-cmd float in

Commanded position from motion

gantry.N.position-fb float out

Position feedback to motion

gantry.N.home bit out

Combined home signal, true if all joint home inputs are true.

gantry.N.limit bit out

Combined limit signal, true if any joint home input is true.

gantry.N.search-vel float in

HOME_SEARCH_VEL from INI file

252.6. AUTHOR

Charles Steinkuehler

252.7. LICENSE

GPL

Chapter 253. gantrykins(9)

253.1. NAME

gantrykins - Superseded by the general purpose *trivkins* kinematics module.

253.2. SYNOPSIS

To specify a gantry with non-identity kinematics: use *trivkins* with the *kinstype* parameter set for *KINEMATICS_BOTH*. Example:

```
loadrt trivkins coordinates=xyzz kinstypes=BOTH
```

253.3. SEE ALSO

trivkins(9)

Chapter 254. GEARCHANGE(9)

254.1. NAME

gearchange - Select from one two speed ranges

254.2. SYNOPSIS

The output will be a value scaled for the selected gear, and clamped to the min/max values for that gear. The scale of gear 1 is assumed to be 1, so the output device scale should be chosen accordingly. The scale of gear 2 is relative to gear 1, so if gear 2 runs the spindle 2.5 times as fast as gear 1, scale2 should be set to 2.5.

254.3. FUNCTIONS

gearchange.N

254.4. PINS

gearchange.N.sel bit in

Gear selection input

gearchange.N.speed-in float in

Speed command input

gearchange.N.speed-out float out

Speed command to DAC/PWM

gearchange.N.dir-in bit in

Direction command input

gearchange.N.dir-out bit out

Direction output - possibly inverted for second gear

254.5. PARAMETERS

gearchange.N.min1 float rw (default: 0)

Minimum allowed speed in gear range 1

gearchange.N.max1 float rw (default: 100000)

Maximum allowed speed in gear range 1

gearchange.N.min2 float rw (default: 0)

Minimum allowed speed in gear range 2

gearchange.N.max2 float rw (default: 100000)

Maximum allowed speed in gear range 2

gearchange.N.scale2 float rw (default: 1.0)

Relative scale of gear 2 vs. gear 1. Since it is assumed that gear 2 is "high gear", **scale2** must be greater than 1, and will be reset to 1 if set lower.

gearchange.N.reverse bit rw (default: 0)

Set to 1 to reverse the spindle in second gear.

254.6. AUTHOR

Stephen Wille Padnos

254.7. LICENSE

GPL

Chapter 255. gentrivkins(9)

255.1. NAME

gentrivkins - Superseded by the general purpose *trivkins* kinematics module.

255.2. SEE ALSO

trivkins(9)

Chapter 256. gladevcp(9)

256.1. NAME

gladevcp - displays Virtual control Panels built with GTK / GLADE

256.2. SYNOPSIS

loadusr gladevcp [-c **componentname0xN**] [-g **WxH+Xoffset+Yoffset0xN**] [-H *halcmdfile*] [-x *windowid*] **gladefile.glade**

256.3. DESCRIPTION

GladeVCP parses a glade file and displays the widgets in a window. Then calls gladevcp_makepins which again parses the gladefile looking for specific HAL widgets then makes HAL pins and sets up updating for them. The HAL component name defaults to the basename of the glade file. The -x option directs GladeVCP to reparent itself under this X window id instead of creating its own toplevel window. The -H option passes an input file for halcmd to be run after the GladeVCP component is initialized. This is used in Axis when running GladeVCP under a tab with the `EMBED_TAB_NAME/EMBED_TAB_COMMAND` INI file feature.

GladeVCP supports GtkBuilder or libglade files though some widgets are not fully supported in GtkBuilder yet.

256.4. ISSUES

For now, system links need to be added in the glade library folders to point to our new widgets and catalog files. Look in `lib/python/gladevcp/README` for details.

Chapter 257. GRAY2BIN(9)

257.1. NAME

gray2bin - convert a gray-code input to binary

257.2. SYNOPSIS

loadrt gray2bin [count=*N* | names=*name1*[,*name2*...]]

257.3. DESCRIPTION

Converts a gray-coded number into the corresponding binary value

257.4. FUNCTIONS

gray2bin.*N*

257.5. PINS

gray2bin.*N*.in u32 in

gray code in

gray2bin.*N*.out u32 out

binary code out

257.6. AUTHOR

Andy Pugh

257.7. LICENSE

GPL

Chapter 258. hal_bb_gpio(9)

258.1. NAME

hal_bb_gpio - Driver for beaglebone GPIO pins

258.2. SYNOPSIS

loadrt hal_bb_gpio user_leds=,... input_pins=,... output_pins=#,...

258.3. USER LEDS

The *user_leds* loadrt parameter controls which LEDs are available to HAL. Valid range: 0..3. These LEDs are next to the ethernet jack and the LinuxCNC numbers match the silkscreen on beaglebone black. Empirically, these seem to be OR'd with whatever function is assigned to the LED in Linux.

258.3.1. PINS

bb_gpio.userledN bit in

+

bb_gpio.userledN-invert bit in

The associated LED is lit if **userledN** xor **userledN-invert** is TRUE.

258.4. INPUT PINS

The *input_pins* loadrt parameter controls which physical I/O pins are available to HAL as input pins. The numbering is "800+N" for pin N on connector P8, and "900+N" for pin N on connector P9. For example, "803" means connector P8 pin 3, which is also described in BeagleBone documentation as "gpmc_ad6".

Specifying pins that are otherwise in use by the system may have undesirable side effects, such as crashing rtapi_app or the whole system.

258.4.1. PINS

bb_gpio.pN.in-NN bit out

+

bb_gpio.pN.in-NN-invert bit in

in-NN is a snapshot of the value of the corresponding physical pin XOR the value of the corresponding **in-NN-invert** pin.

258.5. OUTPUT PINS

The *input_pins* loadrt parameter controls which physical I/O pins are available to HAL as input pins. The numbering is "800+N" for pin N on connector P8, and "900+N" for pin N on connector P9.

Specifying pins that are otherwise in use by the system may have undesirable side effects, such as crashing rtapi_app or the whole system.

258.5.1. PINS

bb_gpio.pN.out-NN bit out

+

bb_gpio.pN.out-NN-invert bit in

The corresponding physical pin is driven with the result of **in-NN** xor **in-NN-invert**.

258.6. PARAMETERS

None

258.7. FUNCTIONS

bb_gpio.read

Update HAL pins from physical pins.

bb_gpio.write

Update physical pins from HAL pins.

258.8. LICENSE

GPL

Chapter 259. hal_parport(9)

259.1. NAME

hal_parport - Realtime HAL component to communicate with one or more pc parallel ports.

259.2. SYNOPSIS

loadrt hal_parport cfg="port_addr [type] [[port_addr [type] .. .]"

259.3. DESCRIPTION

The hal_parport component is a realtime component that provides connections from HAL via halpins to the physical pins of one or more parallel ports. It provides a read and write function to send and receive data to the attached parallel port(s).

The hal_parport component supports up to **8** physical parallel ports.

259.4. OPTIONS

cfg="port_addr [type] [[port_addr [type] ...]"

The cfg string tells hal_parport the address(es) of the parallel port(s) and whether the port(s) is/are used as an input or output port(s). Up to eight parallel ports are supported by the component.

The **port_addr** parameter of the configuration string may be either the physical base address of a parallel port or specified as the detected parallel port via Linux parport_pc driver. In which case, a **port_addr** of *0* is the first parallel port detected on the system, *1* is the next, and so on.

The **type** parameter of the configuration string determines how the I/O bits of the port are used. There are four possible options and if none is specified will default to out.

in

Sets the 8 bits of the data port to input. In this mode the parallel port has a total of 13 input pins and 4 output pins.

out

Sets the 8 bits of the data port to output. In this mode the parallel port has a total of 5 input pins and 12 output pins.

epp

This option is the same as setting to out, but can cause the computer to change the electrical characteristics of the port, see USAGE below.

x

The option allows ports with open collectorts on the control group pins to be configured as inputs resulting in 8 output pins and 9 input pins, see USAGE below.

259.5. PINS

The pins created by the `hal_parport` component depends on how it is configured in the `cfg=""` string passed to it, see `OPTIONS`.

parport.p.pin-n-out (bit)

Drives a physical output pin.

parport.p.pin-n-in (bit)

Tracks a physical input pin.

parport.p.pin-n-in-not (bit)

Tracks a physical input pin, but inverted.

For each pin created, *p* is the port number, and *n* is the physical pin number in the 25 pin D-shell connector.

For each physical output pin, the driver creates a single HAL pin, for example: `parport.0.pin-14-out`.

For each physical input pin, the driver creates two HAL pins, for example: `parport.0.pin-12-in` and `parport.0.pin-12-in-not`.

The `-in` HAL pin is TRUE if the physical pin is high, and FALSE if the physical pin is low. The `-in-not` HAL pin is inverted and is FALSE if the physical pin is high.

The following lists the input and output pins by the type setting used in the `cfg=""` string.

in: Pins 2,3,4,5,6,7,8,9,10,11,12,13,15 are input pins and pins 1,14,16 and 17 are output pins.

out/epp: Pins 10,11,12,13 and 15 are input pins and pins 1,2,3,4,5,6,7,8,9,14,16 and 17 are output pins.

x: Pins 1,10,11,12,13,14,15,16 and 17 are input pins and pins 2,3,4,5,6,7,8,9 are output pins. (See *USAGE section*.)

259.6. PARAMETERS

parport.p.pin-<n>-out-invert (bit)

Inverts an output pin.

parport.p.pin-<n>-out-reset (bit)

(only for out pins) TRUE if this pin should be reset when the `.reset` function is executed.

parport.p.reset-time (u32)

The time (in nanoseconds) between a pin is set by write and reset by the reset function if it is enabled.

259.7. FUNCTIONS

parport.p.read (funct)

Reads physical input pins of port <portnum> and updates HAL -in and -in-not pins.

parport.read-all (funct)

Reads physical input pins of all ports and updates HAL -in and -in-not pins.

parport.p.write (funct)

Reads HAL -out pins of port *p* and updates that port's physical output pins.

parport.write-all (funct)

Reads HAL -out pins of all ports and updates all physical output pins.

parport.p.reset (funct)

Waits until *reset-time* has elapsed since the associated write, then resets pins to values indicated by *-out-reset* and *-out-invert* settings. Reset must be later in the same thread as write. If *-out-reset* is TRUE, then the reset function will set the pin to the value of *_out-invert_*. This can be used in conjunction with stepgen's *doublefreq* to produce one step per period. The stepgen *stepspace* for that pin must be set to 0 to enable *doublefreq*.

259.8. USAGE

The *hal_parport* component is a driver for the traditional PC parallel port. The port has a total of 25 physical pins of which 17 are used for signals. The original parallel port divided those pins into three groups: data, control, and status. The data group consists of 8 output pins, the control group consists of 4 output pins, and the status group consists of 5 input pins.

In the early 1990s, the bidirectional parallel port was introduced, which allows the data group to be used for output or input. The HAL driver supports the bidirectional port, and allows the user to set the data group as either input or output. If configured as "out", a port provides a total of 12 outputs and 5 inputs. If configured as "in", it provides 4 outputs and 13 inputs.

In some parallel ports, the control group pins are open collectors, which may also be driven low by an external gate. On a board with open collector control pins, if configured as "x", it provides 8 outputs, and 9 inputs.

In some parallel ports, the control group has push-pull drivers and cannot be used as an input.

Note: HAL and Open Collectors

HAL cannot automatically determine if the x mode bidirectional pins are actually open collectors (OC). If they are not, they cannot be used as inputs, and attempting to drive them LOW from an external source can damage the hardware.

To determine whether your port has open collector pins, load *hal_parport* in x mode. With no device attached, HAL should read the pin as TRUE. Next, insert a 470 ohm resistor from one of the control pins to GND. If the resulting voltage on the control pin is close to 0V, and HAL now reads the pin as FALSE, then you have an OC port. If the resulting voltage is far from 0V, or HAL does not read the pin as FALSE,

then your port cannot be used in x mode.

The external hardware that drives the control pins should also use open collector gates (e.g., 74LS05).

On some computers, BIOS settings may affect whether x mode can be used. SPP mode is most likely to work.

No other combinations are supported, and a port cannot be changed from input to output once the driver is installed.

The parport driver can control up to 8 ports (defined by MAX_PORTS in hal_parport.c). The ports are numbered starting at zero.

Loading the hal_parport component

The hal_parport driver is a real time component so it must be loaded into the real time thread with loadrt. The configuration string describes the parallel ports to be used, and (optionally) their types. If the configuration string does not describe at least one port, it is an error.

loadrt hal_parport cfg="port [type] [port [type] ...]"

Specifying the Port

Numbers below 16 refer to parallel ports detected by the system. This is the simplest way to configure the hal_parport driver, and cooperates with the Linux parport_pc driver if it is loaded. A port of 0 is the first parallel port detected on the system, 1 is the next, and so on.

Basic configuration

This will use the first parallel port Linux detects:

loadrt hal_parport cfg="0"

Using the Port Address

Instead, the port address may be specified using the hex notation 0x then the address.+ **loadrt hal_parport cfg="0x378"**

Specifying a port Type

For each parallel port handled by the hal_parport driver, a type can optionally be specified. The type is one of in, out, epp, or x.

If the type is not specified, the default is out.

A type of epp is the same as out, but the hal_parport driver requests that the port switch into EPP mode. The hal_parport driver does not use the EPP bus protocol, but on some systems EPP mode changes the electrical characteristics of the port in a way that may make some marginal hardware work better. The Gecko G540's charge pump is known to require this on some parallel ports.

See the Note above about mode x.

Example with two parallel ports

This will enable two system-detected parallel ports, the first in output mode and the second in input mode:

loadrt hal_parport cfg="0 out 1 in"

Functions single port

You must also direct LinuxCNC to run the read and write functions.

addf parport.read-all base-thread + addf parport.write-all base-thread

Functions multiple ports

You can direct LinuxCNC to run the read and write functions for all the attached ports.

addf parport.0.read base-thread + addf parport.0.write base-thread

The individual functions are provided for situations where one port needs to be updated in a very fast thread, but other ports can be updated in a slower thread to save CPU time. It is probably not a good idea to use both an -all function and an individual function at the same time.

259.9. SEE ALSO

Parallel Port Driver (Hardware Drivers Section of LinuxCNC Docs), PCI Parallel Port Example (Hardware Examples Section of LinuxCNC Docs)

259.10. AUTHOR

This man page written by Joe Hildreth as part of the LinuxCNC project. Most of this information was taken from the parallel-port docs located in the Hardware Drivers section of the documentation. To the best of our knowledge that documentation was written by Sebastian Kuzminsky and Chris Radek.

Chapter 260. HISTOBINS(9)

260.1. NAME

histobins - histogram bins utility for scripts/hal-histogram

260.2. SYNOPSIS

loadrt histobins [**count**=*N* | **names**=*name1* [, *name2* ...]]

260.3. DESCRIPTION

Read **availablebins** pin for the number of bins available. Set the **minvalue**, **binsize**, and **nbins** pins and ensure **nbins** ≤ **availablebins**.

For **nbins** = *N*, the bins are numbered: 0 ... *N*-1

Iterate:

- Set **index** pin to a bin number: $0 \leq \text{index} < \text{nbins}$.
- Read check pin and verify that check pin == index pin.
- Read outputs: binvalue, pextra, nextra pins.
(**binvalue** is count for the indexed bin)
(**pextra** is count for all inputs > maxvalue)
(**nextra** is count for all bins < minvalue)

If **index** is out of range (**index** < 0 or **index** > **maxbinnumber** then binvalue == -1. The **input-error** pin is set when input rules are violated and updates cease. The reset pin may be used to restart.

The input used is selected based on pintype:

pintype	inputpin
0	input
1	input-s32
2	input-u32
3	input-bit

Additional output statistics pins:

- **input-min**
- **input-max**
- **nsamples**
- **variance**

- **mean**

The method input pin selects an alternate variance calculation.

Maintainers note: hardcoded for MAXBINNUMBER==200

260.4. FUNCTIONS

histobins.N

260.5. PINS

histobins.N.pintype u32 in

histobins.N.input float in

histobins.N.input-s32 s32 in

histobins.N.input-u32 u32 in

histobins.N.input-bit bit in

histobins.N.nbins u32 in (default: 20)

histobins.N.binsize float in (default: 1)

histobins.N.minvalue float in (default: 0)

histobins.N.index s32 in

histobins.N.check s32 out

histobins.N.reset bit in

histobins.N.method bit in

histobins.N.input-error bit out

histobins.N.binvalue float out

histobins.N.pextra float out

histobins.N.nextra float out

histobins.N.input-min float out

histobins.N.input-max float out

histobins.N.nsamples u32 out

histobins.N.variance float out

histobins.N.mean float out

histobins.N.availablebins s32 out (default: 200)

260.6. AUTHOR

Dewey Garrett

260.7. LICENSE

GPL

Chapter 261. HISTOBINSTREAM(9)

261.1. NAME

histobinstream - histogram bins utility for scripts/hal-histogram

261.2. SYNOPSIS

loadrt histobinstream [**count**=*N* | **names**=*name1*[,*name2*...]] [**keys**=*value*[,*value*...]]

keys

Stream shmem unique key for each instance

261.3. DESCRIPTION

Calculates a histogram of an input pin's value. The histogram data is sent in a HAL stream for maximum transfer speed and to prevent any RT to non-RT data race conditions. This is the streaming counterpart to the **histobins** component.

Read the **availablebins** pin for the number of bins available. Set the **minvalue**, **binsize** and **nbins** pins and ensure **nbins** ≤ **availablebins**.

For **nbins** = *N*, the bins are numbered 0 ... *N*-1. The value range covered is [**minvalue** ... **minvalue** + *N* * **binsize**). Any input below **minvalue** is counted in the negative overflow (**ntail**). Any input at or above the upper edge is counted in the positive overflow (**ptail**).

The input used is selected based on pintype:

pintype	inputpin
0	input
1	input-s32
2	input-u32
3	input-bit

Stream format and how to obtain the histogram data:

- Set the **stream** pin to high.
- Read the fifo data when it becomes available. The data streamed has the following sequence:
 - *ntail bin[0] ... bin[*N*-1] ptail*
 - This gives *nbins* + 2 values streamed (all unsigned counts).
- Read the statistics pins (**input-min**, **input-max**, **mean**, **variance**, **nsamples**) that reflect the values at the time when **stream** was asserted.
- Set the **stream** pin to low.

The reset pin may be used to restart. Note that the reset pin is set to high at startup. You must set it to low before data collection begins.

The **method** input pin selects an alternate variance calculation (0: Welford incremental, 1: sum / sum-of-squares).

Maintainers note: hardcoded for MAXBINNUMBER==200

261.4. FUNCTIONS

histobinstream.N

261.5. PINS

histobinstream.N.pintype u32 in

Select the input pin (0:input 1:input-s32 2:input-u32 3:input-bit).

histobinstream.N.input float in

Floating point input value (pintype 0).

histobinstream.N.input-s32 s32 in

Signed input value (pintype 1).

histobinstream.N.input-u32 u32 in

Unsigned input value (pintype 2).

histobinstream.N.input-bit bit in

Bit input value (pintype 3).

histobinstream.N.nbins u32 in (default: 20)

Number of active bins N (0 ... N-1).

histobinstream.N.binsize float in (default: 1)

Width of one bin in input units.

histobinstream.N.minvalue float in (default: 0)

Lower edge of bin 0.

histobinstream.N.reset bit in (default: 1)

Reset state and bins.

histobinstream.N.stream bit in (default: 0)

Set to high to stream all bins and tails on rising edge.

histobinstream.N.method bit in (default: 0)

Variance method (0:Welford incremental, 1:sum of squares).

histobinstream.N.stream-error bit out

Set if the data stream did not fit and was never sent.

histobinstream.N.input-error bit out

Set when input rules are violated; updates are invalid until fixed and a reset.

histobinstream.N.input-min float out

Minimum input value seen (latched on stream rising edge).

histobinstream.N.input-max float out

Maximum input value seen (latched on stream rising edge).

histobinstream.N.nsamples u32 out

Number of samples accumulated (latched on stream rising edge).

histobinstream.N.variance float out

Variance of the input (latched on stream rising edge).

histobinstream.N.mean float out

Mean of the input (latched on stream rising edge).

histobinstream.N.stream-time s64 out

The time it took for the stream data to be pushed out in nanoseconds (ns).

histobinstream.N.availablebins s32 out (default: 200)

261.6. AUTHOR

Dewey Garrett, B.Stultiens, LinuxCNC contributors

261.7. LICENSE

GPL

Chapter 262. hm2_7i43(9)

262.1. NAME

hm2_7i43 - LinuxCNC HAL driver for the Mesa Electronics 7i43 EPP Anything IO board with HostMot2 firmware.

262.2. SYNOPSIS

```
loadrt hm2_7i43 [ ioaddr=N[,N...] ] [ ioaddr_hi=N[,N...] ] [ epp_wide=N[,N...] ] [ config="str[,str...]" ]  
[debug_epp=N_[,N...]]
```

ioaddr [default: 0 (parport0)]

The base address of the parallel port.

The number of ioaddr indexes/addresses given is used by the driver to determine how many boards to search for.

ioaddr_hi [default: 0]

The secondary address of the parallel port, used to set EPP mode. 0 means to use ioaddr + 0x400.

epp_wide [default: 1]

Set to zero to disable the "wide EPP mode". "Wide" mode allows a 16- and 32-bit EPP transfers, which can reduce the time spent in the read and write functions. However, this may not work on all EPP parallel ports.

config [default: ""]

HostMot2 config strings, described in the hostmot2(9) manpage.

debug_epp [default: 0]

Developer/debug use only! Enable debug logging of most EPP transfers.

262.3. DESCRIPTION

hm2_7i43 is a device driver that interfaces the Mesa 7i43 board with the HostMot2 firmware to the LinuxCNC HAL. Both the 200K and the 400K FPGAs are supported.

The driver talks with the 7i43 over the parallel port, not over USB. USB can be used to power the 7i43, but not to talk to it. USB communication with the 7i43 will not be supported any time soon, since USB has poor real-time qualities.

The driver programs the board's FPGA with firmware when it registers the board with the hostmot2 driver. The firmware to load is specified in the **config** modparam, as described in the hostmot2(9) manpage, in the *config modparam* section.

262.4. Jumper settings

To send the FPGA configuration from the PC, the board must be configured to get its firmware from the EPP port. To do this, jumpers W4 and W5 must both be down, ie toward the USB connector.

The board must be configured to power on whether or not the USB interface is active. This is done by setting jumper W7 up, ie away from the edge of the board.

262.5. Communicating with the board

The 7i43 communicates with the LinuxCNC computer over EPP, the Enhanced Parallel Port. This provides about 1 Mbps of throughput, and the communication latency is very predictable and reasonably low.

The parallel port must support EPP 1.7 or EPP 1.9. EPP 1.9 is preferred, but EPP 1.7 will work too. The EPP mode of the parallel port is sometimes a setting in the BIOS.

Note that the popular "NetMOS" aka "MosChip 9805" PCI parport cards **do not work**. They do not meet the EPP spec, and cannot be reliably used with the 7i43. You have to find another card, sorry.

EPP is very reliable under normal circumstances, but bad cabling or excessively long cabling runs may cause communication timeouts. The driver exports a parameter named `hm2_7i43.<BoardNum>.io_error` to inform HAL of this condition. When the driver detects an EPP timeout, it sets `io_error` to True and stops communicating with the 7i43 board. Setting `io_error` back to False makes the driver start trying to communicate with the 7i43 again.

Access to the EPP bus is not threadsafe: only one realtime thread may access the EPP bus.

262.6. SEE ALSO

hostmot2(9)

262.7. LICENSE

GPL

Chapter 263. hm2_7i90(9)

263.1. NAME

hm2_7i90 - LinuxCNC HAL driver for the Mesa Electronics 7i90 EPP Anything IO board with HostMot2 firmware.

263.2. SYNOPSIS

loadrt hm2_7i90 [ioaddr=N[,N...]] [ioaddr_hi=N[,N...]] [epp_wide=N[,N...]] [debug_epp=N[,N...]]

ioaddr [default: 0 (parport0)]

The base address of the parallel port.

The number of ioaddr indexes/addresses given is used by the driver to determine how many boards to search for. Previously the number of config strings was used, but a blank config string is perfectly acceptable for 7i90.

ioaddr_hi [default: 0]

The secondary address of the parallel port, used to set EPP mode. 0 means to use ioaddr + 0x400.

epp_wide [default: 1]

Set to zero to disable the "wide EPP mode". "Wide" mode allows a 16- and 32-bit EPP transfers, which can reduce the time spent in the read and write functions. However, this may not work on all EPP parallel ports.

config [default: ""]

HostMot2 config strings, described in the hostmot2(9) manpage.

debug_epp [default: 0]

Developer/debug use only! Enable debug logging of most EPP transfers.

263.3. DESCRIPTION

hm2_7i90 is a device driver that interfaces the Mesa 7i90 board with the HostMot2 firmware to the LinuxCNC HAL.

The 7i90 firmware is stored on the 7i90 itself, it is not programmed by the driver at load time. The 7i90 firmware can be changed using the mesaflash program.

The driver talks with the 7i90 over the parallel port, via EPP.

263.4. Communicating with the board

The 7i90 communicates with the LinuxCNC computer over EPP, the Enhanced Parallel Port. This provides about 1 MBps of throughput, and the communication latency is very predictable and reasonably low.

The parallel port must support EPP 1.7 or EPP 1.9. EPP 1.9 is preferred, but EPP 1.7 will work too. The EPP mode of the parallel port is sometimes a setting in the BIOS.

Note that the popular "NetMOS" aka "MosChip 9805" PCI parport cards **do** not work. They do not meet the EPP spec, and cannot be reliably used with the 7i90. You have to find another card, sorry.

EPP is very reliable under normal circumstances, but bad cabling or excessively long cabling runs may cause communication timeouts. The driver exports a parameter named `hm2_7i90.<BoardNum>.io_error` to inform HAL of this condition. When the driver detects an EPP timeout, it sets `io_error` to `True` and stops communicating with the 7i90 board. Setting `io_error` back to `False` makes the driver start trying to communicate with the 7i90 again.

Access to the EPP bus is not threadsafe: only one realtime thread may access the EPP bus.

263.5. SEE ALSO

`hostmot2(9)`

263.6. LICENSE

GPL

Chapter 264. hm2_eth(9)

264.1. NAME

hm2_eth - LinuxCNC HAL driver for the Mesa Electronics Ethernet Anything IO boards, with HostMot2 firmware.

264.2. SYNOPSIS

```
loadrt hm2_eth [config="str[,str...]] [board_ip=ip[,ip...]] [board_mac=mac[,mac...]] [no_iptables=0|1]
```

config [default: ""]

HostMot2 config strings, described in the hostmot2(9) manpage.

board_ip [default: ""]

The IP address of the board(s), separated by commas. As shipped, the board address is 192.168.1.121.

no_iptables [default: 0]

Explicit override that disables all iptables interaction. By default hm2_eth installs **iptables** and **ip6tables** rules itself; rtapi_app raises **cap_net_admin** into its ambient capability set at startup so the calls succeed under both setuid-root and rootless (file-cap) installs. If the cap is not held the probe fails and rule installation is skipped with a warning; in that case configure the rules manually using the recipe in the NOTES section below. Set **no_iptables=1** when iptables is reachable but you prefer to manage the firewall externally (nftables, firewallld, systemd units).

264.3. DESCRIPTION

hm2_eth is a device driver that interfaces Mesa's ethernet based Anything I/O boards (with the HostMot2 firmware) to the LinuxCNC HAL. The supported boards are: 7I76E, 7I80DB, 7I80HD, 7I92, 7I93, 7I94, 7I95, 7I96, 7I96S, 7I97, 7I98. It also supports boards with the litehm2 firmware (<https://github.com/sensille/litehm2>). The board must have its firmware loaded on the board by the mesaflash(1) program.

hm2_eth is only available when LinuxCNC is configured with "uspace" realtime.

264.4. INTERFACE CONFIGURATION

hm2_eth should be used on a dedicated network interface, with only a cable between the PC and the

board. Wireless and USB network interfaces are not suitable.

These instructions assume your dedicated network interface is "eth1", 192.168.1/24 is an unused private network, that the hostmot2 board is using the default address of 192.168.1.121, that you are using Debian 7 or similar, and that you do not otherwise use iptables. If any of these are false, you will need to modify the instructions accordingly. After following all the instructions, reboot so that the changes take effect.

It is particularly important to check that the network 192.168.1/24 is not already the private network used by your internet router, because this is a commonly-used value. If you use another network, you will also need to reconfigure the hostmot2 card to use an IP address on that network by using the `mesaflash(1)` utility and change jumper settings. Typically, you will choose one of the networks in the [Private IPv4 address space](#). One common alternative is PC address 10.10.10.1, hostmot2 address 10.10.10.10.

Use of the dedicated ethernet interface while LinuxCNC is running can cause violation of realtime guarantees. `hm2_eth` will automatically mitigate most accidental causes of interference.

264.4.1. Configure network with static address

Add these lines to the file `/etc/network/interfaces` to configure the ethernet interface `eth1` with a static address:

```
auto eth1
iface eth1 inet static
    address 192.168.1.1
    hardware-irq-coalesce-rx-usecs 0
```

264.5. PACKET LOSS

While ethernet is fairly resistant to electrical noise, many systems will not have 100% perfect packet reception. The `hm2_eth` driver has a limited ability to deal with lost packets. Packet loss is detected by transmitting an expected read or write packet count with each request, and checking the value with each read response. When a lost packet is detected, the `packet-error` pin is asserted in that cycle, the `packet-error-level` pin is increased, and if it reaches a threshold then a permanent low-level I/O error is signaled.

However, not all `hm2` special functions know how to properly recover from lost packets. For instance, the encoder special function does not properly manage the index feature when packets are lost. The author believes that this can lead to rare failures in home-to-index, which can have severe consequences.

On the other hand, pid-stepper systems will run properly for extended periods of time with packet loss on the order of .01%, as long as following error is increased enough that having stale position feedback does not trigger a following error. Altering the HAL configuration so that during transient packet loss the pid and motion feedback value is equal to the command value, instead of the stale feedback value, appears to improve tuning. This can be accomplished with a `mux2(9)` component for each feedback signal, using `packet-error` as the `mux2 sel` input.

264.6. PINS

In addition to the pins documented in **hostmot2(9)**, **hm2_eth(9)** creates the following additional pins:

hm2_<BoardType>.<BoardNum>.packet-error (bit, out)

This pin is TRUE when the most recent cycle detected a read or write error, and FALSE at other times.

hm2_<BoardType>.<BoardNum>.packet-error-level (s32, out)

This pin shows the current error level, with higher numbers indicating a greater number of recent detected errors. The error level is always in the range from 0 to packet-error-limit, inclusive.

hm2_<BoardType>.<BoardNum>.packet-error-exceeded (bit, out)

This pin is TRUE when the current error level is equal to the maximum, and FALSE at other times.

264.7. PARAMETERS

In addition to the parameters documented in **hostmot2(9)**, **hm2_eth(9)** creates the following additional parameters:

hm2_<BoardType>.<BoardNum>.packet-error-decrement (s32, rw)

The amount deducted from **packet-error-level** in a cycle without detected read or write errors, without going below zero.

hm2_<BoardType>.<BoardNum>.packet-error-increment (s32, rw)

The amount added to **packet-error-level** in a cycle without detected read or write errors, without going above **packet-error-limit**.

hm2_<BoardType>.<BoardNum>.packet-error-limit (s32, rw)

The level at which a detected read or write error is treated as a permanent error. When this error level is reached, the board's **io-error** pin becomes TRUE and the condition must be manually reset.

hm2_<BoardType>.<BoardNum>.packet-read-timeout (s32, rw)

The length of time that must pass before a read request times out. If the value is less than or equal to 0, it is interpreted as 80% of the thread period. If the value is less than 100, it is interpreted as a percentage of the thread period. Otherwise, it is interpreted as a time in nanoseconds. In any case, the timeout is never less than 100 microseconds.

Setting this value too low can cause spurious read errors. Setting it too high can cause realtime delay errors.

264.8. NOTES

hm2_eth uses an iptables chain called "hm2-eth-rules-output". That technology is common to control network access to (INPUT chain), through (FORWARD chain) or from (OUTPUT chain) your computer. Someone who has configured a firewall on Linux has encountered iptables is familiar with that technology. This chain contains additional rules to control network interface while HAL is running. The chain is created if it does not exist, and a jump to it is inserted at the beginning of the OUTPUT chain if it

is not there already. If you have an existing iptables setup, you can insert a direct jump from OUTPUT to hm2-eth-rules-output in an order appropriate to your local network.

At (normal) exit, hm2_eth will remove the rules. After a crash, you can manually clear the rules with **sudo iptables -F hm2-eth-rules-output**; the rules are also removed by a reboot.

264.8.1. Manual iptables configuration

When LinuxCNC is installed without **cap_net_admin** on rtapi_app (typically because **sudo make setcap** was not run after the build), hm2_eth cannot install its rules and prints a warning. Set up the chain manually as root. Adjust the IP addresses, UDP destination port, and interface name to match your install:

```
HOST_IP=192.168.1.1
BOARD_IP=192.168.1.121
BOARD_DPORT=27181
IFACE=eth1

iptables -N hm2-eth-rules-output
iptables -I OUTPUT 1 -j hm2-eth-rules-output
iptables -A hm2-eth-rules-output \
    -p udp -m udp -d $BOARD_IP --dport $BOARD_DPORT \
    -s $HOST_IP -j ACCEPT
iptables -A hm2-eth-rules-output -o $IFACE -p icmp -j DROP
iptables -A hm2-eth-rules-output -o $IFACE \
    -j REJECT --reject-with icmp-admin-prohibited
ip6tables -N hm2-eth-rules-output
ip6tables -I OUTPUT 1 -j hm2-eth-rules-output
ip6tables -A hm2-eth-rules-output -o $IFACE -j DROP
```

For full IPv6 quiescence (no router solicitations or neighbor discovery on the dedicated interface), additionally add this line to **/etc/sysctl.d/99-hm2-eth.conf** and reboot:

```
net.ipv6.conf.IFACE.disable_ipv6 = 1
```

(The default ip6tables rule above only drops outbound IPv6; the kernel still generates the packets.) Tear down the runtime rules with:

```
iptables -F hm2-eth-rules-output
iptables -D OUTPUT -j hm2-eth-rules-output
iptables -X hm2-eth-rules-output
ip6tables -F hm2-eth-rules-output
ip6tables -D OUTPUT -j hm2-eth-rules-output
ip6tables -X hm2-eth-rules-output
```

"hardware-irq-coalesce-rx-usecs" decreases time waiting to receive a packet on most systems, but on at least some Marvel-chipset NICs it is harmful. If the line does not improve system performance, then remove it. A reboot is required for the value to be set back to its power-on default. This requires the ethtool package to be installed.

264.9. BUGS

Some hostmot2 functions such `uart` are coded in a way that causes additional latency when used with `hm2_eth`.

On the 7i92, the HAL pins for the LEDs are called `CR01..CR04`, but the silkscreens are `CR3..CR6`. Depending on the FPGA firmware, the LEDs may initially be under control of the ethernet engine. This can be changed until power cycle with

```
elbpcom 01D914000000
```

Depending on firmware version, this driver may cause the hardware error LED to light even though the driver and hardware are functioning normally. This will reportedly be fixed in future bitfile updates from Mesa.

264.10. SEE ALSO

`hostmot2(9)`, `elbpcom(1)`

264.11. LICENSE

GPL

Chapter 265. hm2_modbus(9)

265.1. NAME

hm2_modbus - A hostmot2 driver that implements the Modbus protocol using the PktUART ports.

265.2. SYNOPSIS

loadrt hm2_modbus ports=... mbccbs=...

ports [default: <empty>]

A comma separated list of PktUART HAL names to use as Modbus hardware channel. Each must be matched with an MBCCB file specified in the **mbccbs** parameter. Example:
`ports="hm2_7i96s.0.pktuart.0","hm2_5i25.0.pktuart.2"`

mbccbs [default: <empty>]

A comma separated list of "Modbus Command Control Binary" (MBCCB) file paths to use for each PktUART port as specified in the **ports** parameter. The path should be an absolute path to prevent nasty surprises. Example: `mbccbs="/path/to/rly-and-spindle.mbcb","/path/to/lightsparks.mbcb"`

debug [default: -1]

Set the message level of the running process. The message level is set if **debug** is set to a positive value between 0 and 5, where 0 means no messages at all and 5 means everything. A value of -1 does not touch the current message level.

Warning: setting **debug** to 0 (zero) will prevent any messages from being printed. Not even errors will be printed when you set it to zero and you may end up guessing why things went wrong.

Caveat Emptor: the driver must be compiled with debug messages enabled for it to start emitting messages at the debug level. Changing the message level is process-wide and all modules within the process will spit out messages at the requested level. This may cause quite some clutter in your terminal.

265.3. DESCRIPTION

The **hm2_modbus** driver implements the Modbus protocol and maps HAL pins to Modbus devices' coils, inputs and registers. The mappings may be a complex combination of types and pins. The configuration format is described in **mesambccc**(1).

The Mesa FPGA board must be flashed with a PktUART capable bit-file. It is recommended to use an FPGA bit-file that supports PktUART version 3 or later. The **hm2_modbus** driver will run with PktUART version 2, but it will lack several important bug fixes and features, like 2 stop-bits, correct and extended inter-frame delay for high speed communication and inter-character delay measurements. Warnings will be emitted if communication settings cannot be honored by the older PktUART version. PktUART versions older than 2 are not supported and the driver will abort with an error if encountered.

Please note, the hostmot2 software will automatically create all nodes for all available devices in the

board's bit-file. The PktUART nodes will be named *pktuart.0*, *pktuart.1*, etc.. You can see what your bit-file supports by using the **mesaflash**(1) utility (please adapt for your board and IP address accordingly):

```
sudo mesaflash --device 7i96s --addr 10.10.10.10 --readhmid
```

The **hostmot2** module should automatically print the name(s) of any PktUART found while the board's configuration is being traversed. You can check this on the command line by looking for lines like:

```
hm2/hm2_7i96s.0: created PktUART Interface function hm2_7i96s.0.pktuart.0.
```

The **hm2_modbus** driver exports a set of HAL pins and parameters that can be used to inspect status and alter some settings in a live environment.

Up to eight instances are supported, which are instantiated by setting the **ports** and **mbccbs** parameters. The instances are named *hm2_modbus.0*, *hm2_modbus.1*, etc.. The pin names generated by the driver will always be prefixed with the driver's name.

```
loadrt hm2_modbus ports="hm2_7i96s.0.pktuart.0" mbccbs="/path/to/myfile.mbccb"
```

The driver exports one function named *process*, which must be added to the servo-thread *after* hostmot2's read function and *before* hostmot2's write function:

```
addf hm2_7i96s.0.read      servo-thread
...
# Add any functions here that process data that will be sent to
# the Modbus device(s).
...
addf hm2_modbus.0.process  servo-thread
...
# Add any functions here that process data received from the
# Modbus device(s).
...
addf hm2_7i96s.0.write     servo-thread
```

There are no software limits to how many Modbus devices may share one and the same physical bus and by extension the same hm2_modbus instance. The Modbus protocol limits the number of devices to 247 (available device IDs). However, the practical limit will be effective communication speed and bus load.

265.3.1. PARAMETERS

Exported parameters for driver instance **N**:

hm2_modbus.N.baudrate (u32, readonly)

The communication baudrate.

hm2_modbus.N.drivedelay (u32, readonly)

The transmitter wait time between enabling the transmitter and start sending in bit-times.

hm2_modbus.N.icdelay (u32, readonly)

The maximum inter-character delay accepted in received frames in bit-times. Set to zero (0) when disabled.

hm2_modbus.N.parity' (u32, readonly)

The communication parity (0=None, 1=Odd, 2=Even).

hm2_modbus.N.rxdelay (u32, readonly)

The inter-frame delay required before a packet is accepted in bit-times.

hm2_modbus.N.stopbits (u32, readonly)

The communication number of stopbits (1 or 2).

hm2_modbus.N.txdelay (u32, readonly)

The inter-frame delay inserted after a packet in bit-times.

The parameters are all read/only. There is normally no need to alter any parameters. Any tuning of values should be done in the mbccs/mbccb file.

265.3.2. PINS

Each driver instance **N** exports the following pins to control the instance's operation and indicate the instance's status:

hm2_modbus.N.fault (bit, output)

Indicates a fault condition.

hm2_modbus.N.fault-command (u32, output)

The command index that caused the last fault condition.

hm2_modbus.N.last-error-code (u32, output)

The errno value of the error that caused the fault condition.

hm2_modbus.N.reset (bit, input)

Reset all commands error counters and re-enable disabled commands on the rising edge of the input pin.

hm2_modbus.N.suspend (bit, input)

Suspend all activity while set. The default can be set in the MBCCB file.

Suspended start (when set in the MBCCB file) can ensure that all HAL files and commands are parsed and executed (like setup and sets commands) before Modbus communication starts. This enables you to setup scale and offset pins without bad values being pushed to the Modbus device(s). The *last* HAL command after setting all relevant pins and signals would be to enable Modbus communication by issuing (replace **N** with actual instance number):

```
setup hm2_modbus.N.suspend false
```

It may be necessary to issue a delay command as the first or last init command to ensure flushing all pins before reading pin data that will be transferred to the Modbus device(s). See also *writelflush*

attribute in the MBCCB file.

It is possible to suspend the Modbus communication by setting the suspend pin to true in a live and running system. The suspend pin is probed every time at the end of the `<commands>` list and execution will become suspended if the pin is true.

Command pins

Each command in the MBCCB file (not init commands) will generate a set of pins to reflect the current state, where **MM** is the command number counting from zero (00):

hm2_modbus.N.command.MM.disable (bit, input)

Disable this command on the rising edge of this pin. You need to use the command's corresponding reset pin to re-enable it.

hm2_modbus.N.command.MM.disabled (bit, output)

Set if the command is no longer sent in the commands loop.

hm2_modbus.N.command.MM.error-code (u32, output)

The errno code of the last error. The following error codes can be set:

- 5, 0x05 (EIO): The receiver detected an overrun, a false start-bit or wrong parity.
- 9, 0x09 (EBADF): The reply returned an unsupported function.
- 11, 0x0b (EAGAIN): The command was manually disabled in the mbccb or via the disable pin.
- 22, 0x16 (EINVAL): An invalid value was detected (internal error).
- 27, 0x1b (EFBIG): The received data packet size exceeds the internally allocated buffer.
- 34, 0x22 (ERANGE): The received data packet was too small or the message's length indicator was wrong.
- 42, 0x2a (ENMSG): The inter-character delay was too long and the packet was dropped.
- 44, 0x2c (ECHRNG): The reply had a different function than the sent function.
- 52, 0x34 (EBADE): The CRC of the received packet was wrong.
- 74, 0x4a (EBADMSG): The reply had the error-bit set.
- 75, 0x4b (EOVERFLOW): The received packet was larger than the maximum 256 bytes.
- 90, 0x5a (EMSGSIZE): The message did not fit into the maximum PDU size of 253.
- 110, 0x6e (ETIMEDOUT): The command received no reply and timed out.

hm2_modbus.N.command.MM.errors (u32, output)

The number of consecutive errors seen in this command. The command will be disabled when this count reaches five (5). The value will be reset to zero (0) when the command succeeds.

hm2_modbus.N.command.MM.reset (bit, input)

Reset this command's error counter and re-enable the command on the rising edge of the input pin.
Note: Re-enabling the command will honor the *writelflush* setting of the command.

Each mbccb file will generate a set of pins as defined in the mbccb file. See **mesambccc(1)** for details.

265.4. SEE ALSO

hostmot2(9), **mesambccc(1)**, **mesaflash(1)**.

265.5. AUTHOR

This man page written by B.Stultiens, as part of the LinuxCNC project.

265.6. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>

265.7. COPYRIGHT

Copyright © 2025 B.Stultiens

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 266. hm2_pci(9)

266.1. NAME

hm2_pci - LinuxCNC HAL driver for the Mesa Electronics PCI-based Anything IO boards, with HostMot2 firmware.

266.2. SYNOPSIS

```
loadrt hm2_pci [config="str[,str...]"
```

config [default: ""]

HostMot2 config strings, described in the hostmot2(9) manpage.

266.3. DESCRIPTION

hm2_pci is a device driver that interfaces Mesa's PCI and PC-104/Plus based Anything I/O boards (with the HostMot2 firmware) to the LinuxCNC HAL.

The supported boards are: the 5i20, 5i21, 5i22, 5i23, 5i24, and 5i25 (all on PCI); the 4i65, 4i68, and 4i69 (on PC-104/Plus), and the 3x20 (using a 6i68 or 7i68 carrier card) and 6i25 (on PCI Express).

The driver optionally programs the board's FPGA with firmware when it registers the board with the hostmot2 driver. The firmware to load is specified in the **config** modparam, as described in the hostmot2(9) manpage, in the *config modparam* section.

266.4. SEE ALSO

hostmot2(9)

266.5. LICENSE

GPL

Chapter 267. hm2_rpspi(9)

267.1. NAME

hm2_rpspi - This driver has been superseded by the hm2_spix driver. LinuxCNC HAL driver for the Mesa Electronics SPI Anything IO boards, with HostMot2 firmware.

267.2. SYNOPSIS

loadrt hm2_rpspi

config [default: ""]

HostMot2 config strings, described in the **hostmot2(9)** manpage.

spiclk_rate [default: 31250]

Specify the SPI clock rate in kHz. See **SPI CLOCK RATES** below.

spiclk_rate_rd [default: -1 (same as spiclk_rate)]

Specify the SPI read clock rate in kHz. Usually you read and write at the same speed. However, you may want to reduce the reading speed if the round-trip is too long (see **SPI CLOCK RATES** below).

spiclk_base [default: 400000000]

This is the SPI clock divider calculation fallback value. Usually, the base rate is read from `/sys/kernel/debug/clk/vpu/clk_rate` and used in the divider calculation (for the Rpi3 it should be 250 MHz). The **spiclk_base** is *only* used as a fallback if the system's cannot be read. It is normally safe (and recommended) that you leave this parameter as is.

You should set this manually to 250000000 if your system does not provide access to the kernel clock settings. Otherwise, your SPI clock frequency will be only 62.5% of the requested value.

spi_pull_miso [default: 1 (pull-down)]

spi_pull_mosi [default: 1 (pull-down)]

spi_pull_sclk [default: 1 (pull-down)]

Enable or disable pull-up/pull-down on the SPI lines. A value of 0 disables any pull-up/down on the pin. A value of 1 means pull-down and 2 means pull-up. The chip enable line(s) are always pull-up enabled.

spi_probe [default: 1]

Probe SPI port and CE lines for a card. This is a bit-field indicating which combinations of SPI and CE should be probed:

- 1 = SPI0/CE0,
- 2 = SPI0/CE1,
- 4 = SPI1/CE0,
- 8 = SPI1/CE1,
- 16 = SPI1/CE2.

The probe is performed exactly in above order. Any boards found will be numbered 0...4 in the order found. See also **INTERFACE CONFIGURATION** below.

It is an error if a probe fails and the driver will abort. The SPI0/SPI1 peripherals are located at GPIO pins (with 40-pin I/O header pin-number in parentheses): - SPI0: MOSI=10(19), MISO=9(21), SCLK=11(23), CE0=8(24), CE1=7(26) - SPI1: MOSI=20(38), MISO=19(35), SCLK=21(40), CE0=18(12), CE1=17(11), CE2=16(36)

spi_debug [default: -1]

Set the message level of the running process. The message level is set if **spi_debug** is set to a positive value between 0 and 5, where 0 means no messages at all and 5 means everything. A value of -1 does not touch the current message level.

Caveat Emptor: Changing the message level is process-wide and all modules within the process will spit out messages at the requested level. This may cause quite some clutter in your terminal.

267.3. DESCRIPTION

hm2_rpspi is a device driver for the Raspberry Pi 2/3 that interfaces Mesa's SPI based Anything I/O boards (with the HostMot2 firmware) to the LinuxCNC HAL. This driver is not based on the linux spidev driver, but on a dedicated BCM2835-SPI driver.

The kernel's **spi_bcm2835** driver conflicts with this user-space driver and must be disabled before **hm2_rpspi** will load. Use **raspi-config** (Interface Options → SPI → Disable) and reboot. If the kernel module is still present at load time the driver will refuse to start with "Kernel SPI driver spi_bcm2835 is loaded and conflicts" rather than fight the kernel for the bus. Having both kernel and user-space SPI drivers installed otherwise leads to unexpected interactions and system instabilities.

The supported boards are: 7i90HD.

The board must have a compatible firmware (ie.: 7i90_spi_svst4_8.bit) loaded on the board by the **mesaflash**(1) program.

hm2_rpspi is only available when LinuxCNC is configured with "uspace" realtime. It works with Raspian and PREEMPT_RT kernel.

267.4. INTERFACE CONFIGURATION

Up to five devices (7i90 boards) are supported. Two on SPI0 and three on SPI1. It is recommended that you, at most, use two devices and each device connected to a separate SPI port. You can choose which CE lines you prefer or fit the design and setup the **spi_probe** parameter to instruct the driver where to search for the board(s).

267.5. REALTIME PERFORMANCE OF THE BCM2835-SPI DRIVER

TBD.

267.6. SPI CLOCK RATES

The maximum SPI clock of the BCM2835-SPI driver and the 7i90 is documented over 32 MHz. The SPI driver can provide frequencies well beyond what is acceptable for the 7i90. A safe value to start with would be 12.5 MHz (`spiclk_rate=12500`) and then work your way up from there.

The SPI driver generates (very) discrete clock frequency values, especially in the MHz range because of a simple clock divider structure. The base frequency is 250 MHz and the divider for SPI0/SPI1 scales using discrete factors. The following list specifies the **spiclk_rate** setting and the discrete SPI clock frequency (250 MHz / (2*n*) for *n* > 1):

Table 1. SPI clock rate and corresponding SPI clock frequency

Divider	spiclk_rate (kHz)	actual frequency
2	62500	62.500 MHz
3	41667	41.667 MHz
4	31250	31.250 MHz
5	25000	25.000 MHz
6	20834	20.833 MHz
7	17858	17.857 MHz
8	15625	15.625 MHz
9	13889	13.889 MHz
10	12500	12.500 MHz
11	11364	11.364 MHz
12	10417	10.417 MHz
13	9616	9.615 MHz
14+

The lowest selectable SPI clock frequency is 30 kHz (`spiclk_rate=30`) for SPI0 and SPI1. Theoretically, the SPI0 port could go slower, but there is no point in doing so. You should not expect any real-time performance with such slow setting, unless your machine is located next to a black hole.

The highest SPI clock frequency is, theoretically, 125 MHz. However, you will not be able to build any reliable hardware interface at that frequency. The driver limits the clock to 62.5 MHz (`cpiclk_rate=62500`). The chances are rather slim that you get the interface to work reliably at this frequency. The 7i90 interface only supports frequencies up to 50 MHz and that is with perfect cabling and impedance matching (in write direction only).

Writing to the 7i90 may be done faster than reading. This is especially important if you have "long" wires or any buffers on the SPI-bus path. You can set the read clock frequency to a lower value (using **spiclk_rate_rd**) to counter the effects of the SPI-bus round-trip needed for read actions. For example, you can write at 41.67 MHz and read at 25.00 MHz.

It should be noted that the RPi3 **must** have an adequate 5V power supply and the power should be properly decoupled right on the 40-pin I/O header. At high speeds and noise on the supply, there is the possibility of noise throwing off the SoC's PLL(s), resulting in strange behaviour.

For optimal performance on the RPi3, you must disable the "ondemand" CPU frequency governor. You may add the following to your /etc/rc.local file:

```
echo -n 1200000 > /sys/devices/system/cpu/cpufreq/policy0/scaling_min_freq
echo -n performance > /sys/devices/system/cpu/cpufreq/policy0/scaling_governor
```

Be sure to have a proper heatsink mounted on the SoC or it will get too warm and crashes.

267.7. NOTE

This driver has been superseded for most purposes by the hm2_spix driver.

267.8. SEE ALSO

hostmot2(9) hm2_spix(9)

267.9. LICENSE

GPL

Chapter 268. hm2_spi(9)

268.1. NAME

hm2_spi - This driver has been superseded by the hm2_spix driver. LinuxCNC HAL driver for the Mesa Electronics SPI Anything IO boards, with HostMot2 firmware.

268.2. SYNOPSIS

```
loadrt hm2_spi [config="str[,str...]] [spidev_path=path[,path...]] [spidev_rate=rate[,rate...]]
```

config [default: ""]

HostMot2 config strings, described in the hostmot2(9) manpage.

spidev_path [default: "/dev/spidev1.0"]

The path to the spi device node, a character special device in /dev

spidev_rate [default: 24000]

The desired rate of the SPI clock in kHz. If the exact specified clock is not available, a lower clock is used. Due to shortcomings in the spidev API, it is not possible for hal to report the actual clock used.

268.3. DESCRIPTION

hm2_spi is a device driver that interfaces Mesa's SPI based Anything I/O boards (with the HostMot2 firmware) to the LinuxCNC HAL.

The supported boards are: 7I90HD.

The board must have a compatible firmware loaded on the board by the mesaflash(1) program.

hm2_spi is only available when LinuxCNC is configured with "uspace" realtime.

268.4. INTERFACE CONFIGURATION

It is possible for one SPI bus to connect several devices; in this configuration, a master device has several chip select lines. In order to meet realtime deadlines, hm2_spi should be used on a dedicated SPI interface not shared with any other slaves.

268.5. REALTIME PERFORMANCE OF LINUX SPIDEV DRIVERS

As of kernel 3.8, most or all kernel SPI drivers do not achieve the high realtime response rate required for a typical LinuxCNC configuration. The driver was tested with a modified version of the spi-s3c64xx

SPI driver on the Odroid U3 platform. The patched kernel resides [on github](#).

268.6. SPI CLOCK RATES

The maximum SPI clock of the 7i90 is documented as 50MHz. Other elements of the data path between HAL and the 7i90 may impose other limitations.

268.7. NOTE

This driver has been superseded for most purposes by the hm2_spix driver.

268.8. SEE ALSO

hostmot2(9) hm2_spix(9)

268.9. LICENSE

GPL

Chapter 269. hm2_spix(9)

269.1. NAME

hm2_spix - LinuxCNC HAL driver for the Mesa Electronics Anything IO boards with SPI enabled HostMot2 firmware.

269.2. SYNOPSIS

loadrt hm2_spix [arg [arg [...]]]

config [default: ""]

HostMot2 config strings, described in the **hostmot2(9)** manpage.

spiclk_rate [default: 25000]

Specify the SPI clock rate in kHz for each probed board. See **SPI CLOCK RATES** below. Each entry follows the **spi_probe** setting, where each probe takes the next value of the **spi_rate** list. A **spi_rate** of 0 (zero) or less automatically selects the first rate in the list. You may truncate the list to the number of boards you use.

spiclk_rate_rd [default: same as spiclk_rate]

Specify the SPI read clock rate in kHz. Usually you read and write at the same speed. However, you may want to reduce the reading speed if the round-trip is too long (see **SPI CLOCK RATES** below). You may truncate the list to the number of boards you use.

spi_probe [default: 1]

Probe SPI port and CE lines for a card. This is a bit-field indicating which combinations of SPI and CE should be probed: - 1 = SPI0/CE0, - 2 = SPI0/CE1, - 4 = SPI1/CE0, - 8 = SPI1/CE1, - 16 = SPI1/CE2.

The probe is performed exactly in above order. Any boards found will be numbered 0...4 in the order found. It is an error if a probe fails and the driver will abort. See also **INTERFACE CONFIGURATION** below.

force_driver [default: <auto probe>]

Force a specific hardware driver to be selected. This is usually not necessary and the hm2_spix driver will normally select the appropriate hardware driver automatically. See also **HARDWARE DRIVERS** below.

spidev_path [default: <empty>]

Override the device node path to the spidev device. Default is /dev/spidevX.Y, where X.Y is {0.0, 0.1, 1.0, 1.1, 1.2} in that order. This option has only effect if the spix_spidev hardware driver is selected or forced to be used.

spi_noqueue [default: 0 (off)]

Force disable queued command processing. Normally, all requests are queued if requested by upstream and sent in one bulk transfer. This reduces overhead significantly by up to 35%. Disabling the queue makes each transfer visible and more easily debug-able. Set to any non-zero value to

disable the queue.

spi_debug [default: -1]

Set the message level of the running process. The message level is set if **spi_debug** is set to a positive value between 0 and 5, where 0 means no messages at all and 5 means everything. A value of -1 does not touch the current message level.

Caveat Emptor: changing the message level is process-wide and all modules within the process will spit out messages at the requested level. This may cause quite some clutter in your terminal.

269.3. DESCRIPTION

hm2_spix is a device driver for all computer boards with an available SPI port, including Raspberry Pi 3, 4 and 5. The SPI port interfaces with Mesa's SPI based Anything I/O boards with SPI enabled HostMot2 firmware to the LinuxCNC HAL.

This driver unifies all previous hostmot2 SPI hal drivers in one with dedicated hardware drivers for Raspberry Pi models 3, 4 and 5 and has a fall-back to spidev for unknown boards. Further hardware drivers may be created and integrated when requested.

The supported Mesa boards are: 7I90HD, 7I43, 7C80 and 7C81.

The board must have a compatible firmware (like: 7i90_spi_*.bit, 7c80_*.bit and 7c81_*.bit) loaded on the board by the **mesaflash(1)** program.

hm2_spix is only available when LinuxCNC is configured with "uspace" realtime. It works with Raspian and PREEMPT_RT kernel.

See also **NOTES** below.

269.4. HARDWARE DRIVERS

The following hardware drivers are implemented and probed in order:

Driver	Board
spix_rpi3	RPi3B, RPi3A+, RPi3B+, RPi4B, RPi4CM
spix_rpi5	RPi5B, RPi5CM
spix_spidev	Any board not recognised

Probing the hardware is implemented by matching known computer boards against the device-tree compatible string-list from /proc/device-tree/compatible. Normally, the first hardware driver giving a match will be selected. However, it is possible to force a specific driver to be used using the **force_driver** option with the name of the driver you want to use.

269.5. INTERFACE CONFIGURATION

Up to five device boards are supported. Two on SPI0 and three on SPI1. It is recommended that you, at most, use two devices and each device connected to a separate SPI port. You can choose which CE lines you prefer or fit your design and setup. Use the **spi_probe** parameter to instruct the driver where to search for the board(s).

For the Mesa 7C80 and 7C81 you'll always want to configure SPI0/CE0. These boards have a matching 40-pin header for the computer board.

The SPI ports are located on the 40-pin header for those computer boards with a compatible header. The GPIO numbers are only guaranteed to be valid for Raspberry Pi boards.

Port SPI0:

Pin	GPIO	40-pin	Devname
MOSI	10	19	
MISO	9	21	
SCLK	11	23	
CE0	8	24	/dev/spidev0.0
CE1	7	26	/dev/spidev0.1

Port SPI1:

Pin	GPIO	40-pin	Devname
MOSI	20	38	
MISO	19	35	
SCLK	21	40	
CE0	18	12	/dev/spidev1.0
CE1	17	11	/dev/spidev1.1
CE2	16	36	/dev/spidev1.2

269.6. REALTIME PERFORMANCE OF THE HM2_SPIX DRIVER

Using a RPi3 will work, but is not the best option. Currently, the RPi4 is known to work adequately. The newer RPi5 is a lot faster and will normally run a servo-thread at 1 kHz without problems.

All other computer boards and LinuxCNC configurations need to be tested thoroughly.

All other parameters: TBD.

269.7. SPI CLOCK RATES

The SPI driver can provide frequencies beyond what is acceptable for any board. A safe value to start with would be 12.5 MHz (`spiclk_rate=12500`) and then work your way up from there.

The SPI driver generates (very) discrete clock frequencies, especially in the high MHz range because of a simple clock divider structure. The base frequency is different between boards and the divider for SPI0/SPI1 scales using discrete factors with formula $f = \text{trunc}(\text{base} / (2 * \text{divider}))$. The following list specifies the highest possible **spiclk_rate** and **spiclk_rate_rd** frequencies (in kHz) for discrete divider settings:

	RPi3	RPi4	RPi5
Base	400 MHz	500 MHz	200 MHz
Fastest	50000	50000	50000
	40000	41666	33333
	33333	35714	25000
	28571	31250	20000
	25000	27777	16666
	22222	25000	14285
	20000	22727	12500
	18181	20833	11111
	16666	19230	10000
	15384	17857	9090

Slowest	SPI0:4	SPI0:4	SPI0:4
Slowest	SPI1:49	SPI1:62	SPI1:4

Note that the clock rate setting is heavily influenced by rounding and may be higher than expected if the divider rounds to the next lower value. You can check the actual clock rate by enabling informational messages (set **spi_debug=3**).

The slowest selectable SPI clock frequency for SPI0 and SPI1 are not for production systems. They can be selected for testing purposes. You should not expect any real-time performance with such slow setting.

The highest theoretically possible SPI clock frequency is higher than stated in the above table. However, you will not be able to build any reliable hardware interface at that frequency. The driver limits the clock to 50.0 MHz (`cpiclk_rate=50000`). The Mesa board interface supports frequencies up to 50 MHz and that is with good cabling in write direction only.

Writing to the Mesa board may be done faster than reading. This is especially important if you have "long" wires or any buffers on the SPI-bus path. You can set the read clock frequency to a lower value (using **spiclk_rate_rd**) to counter the effects of the SPI-bus round-trip needed for read actions. For

example, you can write at 33.33 MHz and read at 25.00 MHz.

The maximum SPI clock of the `spix_rpi5` driver has been tested up to 50 MHz write speed and 33 MHz read speed on the 7C80 and 7C81. However, it is not recommended to run at the limit on production systems. A safe setting would be to set one step below the maximum speeds.

269.8. NOTES

If you do not require the `spix_spidev` driver you must disable the kernel's SPI driver before **hm2_spix** will load. The conflicting module is **spi_bcm2835** on the RPi3 / RPi4 and **dw_spi_mmio** (with its dependency **dw_spi**) on the RPi5. The driver detects the kernel module at startup and refuses to load with "Kernel SPI driver ... is loaded and conflicts" rather than fight the kernel for the bus.

To disable on RPi3 / RPi4, run **raspi-config** and pick Interface Options → SPI → Disable, then reboot.

To disable on RPi5, blacklist both kernel modules. Create `/etc/modprobe.d/blacklist-linuxcnc.conf` containing:

```
blacklist dw_spi_mmio
blacklist dw_spi
```

Then reboot. If either module is built-in to the kernel rather than loadable, use a kernel command-line override (**modprobe.blacklist=dw_spi_mmio,dw_spi** in `/boot/firmware/cmdline.txt`).

Warning: having both kernel and user-space SPI drivers installed can result in unexpected interactions and system instabilities.

The Raspberry Pi **must** have an adequate power supply. At high speeds and noise on the supply, there is the possibility of strange behaviour if the noise gets out of hand.

The Mesa 7C80 provides enough local power to the host via the 40-pin interface header if your external power supply is adequate (on connector TB6). The Mesa 7C81 needs an adequate external 5V power supply (on connector TB1) and feeds it directly to the host interface header.

For the Raspberry Pi 4: Be sure to have a proper heat-sink mounted on the SoC or it will get too warm and may crash.

For the Raspberry Pi 5: Be sure to have a proper **active** heat-sink mounted on the SoC or it will get too warm and may crash.

269.9. SEE ALSO

hostmot2(9)

269.10. LICENSE

GPL

Chapter 270. HOMECOMP(9)

270.1. NAME

homecomp - homing module template

270.2. SYNOPSIS

Custom Homing module loaded with **[EMCMOT]HOMEMOD=homecomp**

270.3. DESCRIPTION

Example of a homing module buildable with halcompile. Demonstrates required code for #includes, function definitions, etc.

If **HOMING_BASE** is #defined and points to a valid **homing.c** file, an example of a customized homing module is built. This module creates input hal pins joint.n.request-custom-homing that enable an alternate joint homing state machine for requested joints. A hal output pin joint.N.is_custom-homing verifies selection"

The customized homing module utilizes many of the base homing api routines from homing.c without modification but augments other base functions to add support for custom hal pins and custom joint homing state machines. A user-built module will likely replace additional api functions or augment them with other customizations.

If **HOMING_BASE** is not #defined, an actual homing scheme is **not** implemented but all necessary functions are included as skeleton code. (All joints are effectively homed at all times and cannot be unhomed).

See the source code file: **src/emc/motion/homing.c** for the baseline implementation that includes all functions for the default **homemod** module.

To avoid updates that overwrite homecomp.comp, best practice is to rename the file and its component name (example: **user_homecomp.comp**, **user_homecomp**).

The (renamed) component can be built and installed with halcompile and then substituted for the default homing module (**homemod**) using:

```
$ linuxcnc -m user_homecomp someconfig.ini
```

or by inifile setting:

```
[EMCMOT]  
HOMEMOD=user_homecomp
```

Note: If using a deb install:

1. halcompile is provided by the package linuxcnc-dev
2. This source file for BRANCHNAME (master,2.9,etc) is downloadable from github: <https://github.com/LinuxCNC/linuxcnc/blob/BRANCHNAME/src/hal/components/homecomp.comp>

270.4. PINS

homecomp.N.is-module bit out (default: 1)

270.5. AUTHOR

Dewey Garrett

270.6. LICENSE

GPL

Chapter 271. hostmot2(9)

271.1. NAME

hostmot2 - LinuxCNC HAL driver for the Mesa Electronics HostMot2 firmware.

271.2. SYNOPSIS

See the config modparam section below for Mesa card configuration. Typically hostmot2 is loaded with no parameters unless debugging is required.

loadrt hostmot2 [debug_idrom=*N*] [debug_module_descriptors=*N*] [debug_pin_descriptors=*N*] [debug_modules=*N*]

debug_idrom [default: 0]

Developer/debug use only! Enable debug logging of the HostMot2 IDROM header.

debug_module_descriptors [default: 0]

Developer/debug use only! Enables debug logging of the HostMot2 Module Descriptors.

debug_pin_descriptors [default: 0]

Developer/debug use only! Enables debug logging of the HostMot2 Pin Descriptors.

debug_modules [default: 0]

Developer/debug use only! Enables debug logging of the HostMot2 Modules used.

use_serial_numbers [default: 0]

When creating HAL pins for smart-serial devices name the pins by the board serial number rather than which board and port they are connected to. With this option set to 1 pins will have names like **hm2_8i20.1234.current** rather than **hm2_5i23.0.8i20.0.1.current**. The identifier consists of the last 4 digits of the board serial number, which is normally on a sticker on the board. This will make configs less portable, but does mean that boards can be re-connected less carefully.

271.3. DESCRIPTION

hostmot2 is a device driver that interfaces the Mesa or litehm2 HostMot2 firmware to the LinuxCNC HAL. This driver by itself does nothing, the boards that actually run the firmware require their own drivers before anything can happen. Currently drivers are available for PCI, Ethernet, SPI and EPP interfaced cards.

The HostMot2 firmware provides modules such as encoders, PWM generators, step/dir generators, and general purpose I/O pins (GPIOs). These things are called "Modules". The firmware is configured, at firmware compile time, to provide zero or more instances of each of these Modules.

271.3.1. Board I/O Pins

The HostMot2 firmware runs on an FPGA board. The board interfaces with the computer via PCI, Ethernet, SPI, or EPP, and interfaces with motion control hardware, such as servos and stepper motors via I/O pins on the board.

Each I/O pin can be configured, at board-driver load time, to serve one of two purposes: Either as a particular I/O pin of a particular Module instance (encoder, pwmgen, stepgen etc), or as a general purpose digital I/O pin. By default all Module instances are enabled, and all the board's pins are used by the Module instances.

The user can disable Module instances at board-driver load time, by specifying a hostmot2 config string modparam. Any pins which belong to Module instances that have been disabled automatically become GPIOs.

All I/O pins have some HAL presence, whether they belong to an active module instance or are full GPIOs. GPIOs can be changed (at run-time) between inputs, normal outputs, and open drains, and have a flexible HAL interface. I/O pins that belong to active Module instances are constrained by the requirements of the owning Module, and have a more limited interface in HAL. This is described in the General Purpose I/O section below.

271.3.2. config modparam

All the board-driver modules (hm2_pci, hm2_eth etc) accept a load-time modparam of type string array, named "config". This array has one config string for each board the driver should use. Each board's config string is passed to and parsed by the hostmot2 driver when the board-driver registers the board.

The config string can contain spaces, so it is usually a good idea to wrap the whole thing in double-quotes (the " character).

The comma character (,) separates members of the config array from each other.

For example, if your control computer has one 5I20 and one 5I23 you might load the hm2_pci driver with a HAL command (in halcmd) something like this:

```
loadrt hm2_pci config="firmware=hm2/5i20/SVST8_4.BIT num_encoders=3 num_pwmgens=3  
num_stepgens=3,firmware=hm2/5i23/SVSS8_8.BIT sserial_port_0=0000 num_encoders=4"
```

Note: This assumes that the hm2_pci driver detects the 5I20 first and the 5I23 second. If the detection order does not match the order of the config strings, the hostmot2 driver will refuse to load the firmware and the board-driver (hm2_pci etc) will fail to load. To the best of my knowledge, there is no way to predict the order in which PCI boards will be detected by the driver, but the detection order will be consistent as long as PCI boards are not moved around. Best to try loading it and see what the detection order is.

The valid entries in the format string are:

- **[firmware=F]**
- **[num_dpils=N]**

- **[num_encoders=*N*]**
- **[ssi_chan_*N*=*abc%nq*]**
- **[biss_chan_*N*=*abc%nq*]**
- **[fanuc_chan_*N*=*abc%nq*]**
- **[num_inmux=*N*]**
- **[num_inms=*N*]**
- **[num_resolvers=*N*]**
- **[num_pwmgens=*N*]**
- **[num_3pwmgens=*N*]**
- **[num_oneshots=*N*]**
- **[num_periodms=*N*]**
- **[num_rcpwmgens=*N*]**
- **[num_stepgens=*N*]**
- **[stepgen_width=*N*]**
- **[sserial_port_0=00000000]**
- **[num_bspis=*N*]**
- **[num_leds=*N*]**
- **[num_ssrs=*N*]**
- **[num_outms=*N*]**
- **[num_xy2mods=*N*]**
- **[enable_raw]**

firmware [optional]

Load the firmware specified by *F* into the FPGA on this board. If no "**firmware=*F***" string is specified, the FPGA will not be re-programmed but may continue to run a previously downloaded firmware.

The requested firmware *F* is fetched by udev, which searches for the firmware in the system's firmware search path, usually `/lib/firmware`. *F* typically has the form "`hm2/<BoardType>/file.bit`"; a typical value for *F* might be "`hm2/5i20/SVST8_4.BIT`". The hostmot2 firmware files are supplied by the hostmot2-firmware packages, available from linuxcnc.org and can normally be installed by entering the command "`sudo apt-get install hostmot2-firmware-5i23`" to install the support files for the 5I23 for example.

Newer FPGA cards come pre-programmed with firmware and no "**firmware=**" string should be used with these cards. To change the firmware on these cards the "`mesaflash`" utility should be used. It is perfectly valid and reasonable to load these cards with no config string at all.

num_dplls [optional, default: -1]

The hm2dppl is a phase-locked loop timer module which may be used to reduce sample and write

time jitter for some hm2 modules. This parameter can be used to disable the hm2dpll by setting the number to 0. There is only ever one module of this type, with 4 timer channels, so the other valid numbers are -1 (enable all) and 1, both of which end up meaning the same thing.

num_encoders [optional, default: -1]

Only enable the first N encoders. If N is -1, all encoders are enabled. If N is 0, no encoders are enabled. If N is greater than the number of encoders available in the firmware, the board will fail to register.

ssi_chan_N [optional, default: ""]

Specifies how the bit stream from a Synchronous Serial Interface device will be interpreted. There should be an entry for each device connected. Only channels with a format specifier will be enabled (as the software can not guess data rates and bit lengths).

biss_chan_N [optional, default: ""]

As for ssi_chan_N, but for BiSS devices.

fanuc_chan_N [optional, default: ""]

Specifies how the bit stream from a Fanuc absolute encoder will be interpreted. There should be an entry for each device connected. Only channels with a format specifier will be enabled (as the software can not guess data rates and bit lengths).

num_resolvers [optional, default: -1]

Only enable the first N resolvers. If N = -1 then all resolvers are enabled. This module does not work with generic resolvers (unlike the encoder module which works with any encoder). At the time of writing this Hostmot2 Resolver function only works with the Mesa 7I49 card.

num_pwmgens [optional, default: -1]

Only enable the first N pwmgens. If N is -1, all pwmgens are enabled. If N is 0, no pwmgens are enabled. If N is greater than the number of pwmgens available in the firmware, the board will fail to register.

num_3pwmgens [optional, default: -1]

Only enable the first N Three-phase pwmgens. If N is -1, all 3pwmgens are enabled. If N is 0, no pwmgens are enabled. If N is greater than the number of pwmgens available in the firmware, the board will fail to register.

num_rcpwmgens [optional, default: -1]

Only enable the first N RC pwmgens. If N is -1, all rcpwmgens are enabled. If N is 0, no rcpwmgens are enabled. If N is greater than the number of rcpwmgens available in the firmware, the board will fail to register.

num_stepgens [optional, default: -1]

Only enable the first N stepgens. If N is -1, all stepgens are enabled. If N is 0, no stepgens are enabled. If N is greater than the number of stepgens available in the firmware, the board will fail to register.

num_xy2mods [optional, default: -1]

Only enable the first N xy2mods. If N is -1, all xy2mods are enabled. If N is 0, no xy2mods are enabled. If N is greater than the number of xy2mods available in the firmware, the board will fail to register.

stepgen_width [optional, default: 2]

Used to mask extra, unwanted, stepgen pins. Stepper drives typically require only two pins (step and dir) but the Hostmot2 stepgen can drive up to 8 output pins for specialised applications (depending on firmware). This parameter applies to all stepgen instances. Unused, masked pins will be available as GPIO.

sserial_port_N (N = 0 .. 3) [optional, default: 00000000 for all ports]

Up to 32 Smart Serial devices can be connected to a Mesa Anything I/O board, depending on the firmware used and the number of physical connections on the board. These are arranged in 1-4 ports (N) of 1 to 8 channels. Some Smart Serial (SSLBP) cards offer more than one load-time configuration, for example all inputs, or all outputs, or offering additional analogue input on some digital pins. To set the modes for port 0 use for example **sserial_port_0=0120xxxx**. A "0" in the string sets the corresponding channel to mode 0, a "1" to mode 1, and so on up to mode 9. An "x" in any position disables that channel and makes the corresponding FPGA pins available as GPIO. The string can be up to 8 characters long, and if it defines more modes than there are channels on the port then the extras are ignored. Channel numbering is left to right so the example above would set sserial device 0.0 to mode 0, 0.1 to mode 1, 0.2 to mode 2, 0.3 to mode 0 and disables channels 0.4 onwards. The sserial driver will auto-detect connected devices, no further configuration should be needed. Unconnected channels will default to GPIO, but the pin values will vary semi-randomly during boot when card-detection runs, to it is best to actively disable any channel that is to be used for GPIO. See SSERIAL(9) for more information.

num_bspis [optional, default: -1]

Only enable the first N Buffered SPI drivers. If N is -1 then all the drivers are enabled. Each BSPi driver can address 16 devices.

num_leds [optional, default: -1]

Only enable the first N of the LEDs on the FPGA board. If N is -1, then HAL pins for all the LEDs will be created. If N=0 then no pins will be added.

num_ssrs [optional, default: -1]

Only enable the first N of the SSR modules on the FPGA board. If N is -1, then HAL pins for all the SSR outputs will be created. If N=0 then no pins will be added.

enable_raw [optional]

If specified, this turns on a raw access mode, whereby a user can peek and poke the firmware from HAL. See Raw Mode below.

271.3.3. dpll

The hm2dpll module has pins like "hm2_<BoardType>_<BoardNum>.dpll" It is likely that the pin-count will decrease in the future and that some pins will become parameters. This module is a phase-locked

loop that will synchronise itself with the thread in which the hostmot2 "read" function is installed and will trigger other functions that are allocated to it at a specified time before or after the "read" function runs. This can be applied to the three absolute encoder types, quadrature encoder, stepgen, and xy2mod. In the case of the absolute encoders this allows the system to trigger a data transmission just prior to the time when the HAL driver reads the data. In the case of stepgens, quadrature encoders, and the xy2mod, the timers can be used to reduce position sampling jitter. This is especially valuable with the ethernet-interfaced cards.

Pins:

hm2<BoardType>.<BoardNum>.dpll.NN.timer-us (float, in)

This pin sets the triggering offset of the associated timer. There are 4 timers numbered 01 to 04, represented by the *NN* digits in the pin name. The units are microseconds (μ s). Generally the value for reads will be negative, and positive for writes, so that input data is sampled prior to the main hostmot read and output data is written some time after the main hostmot2 read. + For stepgen and quadrature encoders, the value needs to be more than the maximum variation between read times. -100 will suffice for most systems, and -50 will work on systems with good performance and latency. + For serial encoders, the value also needs to include the time it takes to transfer the absolute encoder position. For instance, if 50 bits must be read at 500 kHz then subtract an additional $50/500 \text{ kHz} = 100 \mu\text{s}$ to get a starting value of -200. + The xy2mod uses 2 DPLL timers, one for read and one for write. The read timer value can be the same as used by the stepgen and quadrature encoders so the same timer channel can be shared. The write timer is typically set to a time after the main hostmot2 write this may take some experimentation.

hm2<BoardType>.<BoardNum>.dpll.base-freq-khz (float, in)

This pin sets the base frequency of the phase-locked loop. By default it will be set to the nominal frequency of the thread in which the PLL is running and will not normally need to be changed.

hm2<BoardType>.<BoardNum>.dpll.phase-error-us (float, out)

Indicates the phase error of the DPLL. If the number cycles by a large amount it is likely that the PLL has failed to achieve lock and adjustments will need to be made.

hm2_<BoardType>.<BoardNum>.dpll.time-const (u32, in)

The filter time-constant for the PLL. The default value is a compromise between insensitivity to single-cycle variations and being resilient to changes to the Linux CLOCK_MONOTONIC timescale, which can instantly change by up to $\pm 500\text{ppm}$ from its nominal value, usually by timekeeping software like ntpd and ntpdate. Default 2000 (0x7d0).

hm2_<BoardType>.<BoardNum>.dpll.plimit (u32, in)

Sets the phase adjustment limit of the PLL. If the value is zero then the PLL will free-run at the base frequency independent of the servo thread rate. This is probably not what you want. Default 4194304 (0x400000) Units not known...

hm2_<BoardType>.<BoardNum>.dpll.ddsiz (u32, out)

Used internally by the driver, likely to disappear.

hm2_<BoardType>.<BoardNum>.dpll.prescale (u32, in)

Prescale factor for the rate generator. Default 1.

271.3.4. Encoder

Encoders have names like **hm2_<BoardType>.<BoardNum>.encoder.<Instance>.**. "Instance" is a two-digit number that corresponds to the HostMot2 encoder instance number. There are "num_encoders" instances, starting with 00.

So, for example, the HAL pin that has the current position of the second encoder of the first 5I25 board is: `hm2_5i25.0.encoder.01.position` (this assumes that the firmware in that board is configured so that this HAL object is available).

Each encoder uses three or four input I/O pins, depending on how the firmware was compiled. Three-pin encoders use A, B, and Index (sometimes also known as Z). Four-pin encoders use A, B, Index, and Index-mask.

The hm2 encoder representation is similar to the one described by the Canonical Device Interface (in the HAL General Reference document), and to the software encoder component. Each encoder instance has the following pins and parameters:

Pins:

count (s32 out)

Number of encoder counts since the previous reset.

count_64 (s64 out)

Number of encoder counts since the previous reset (64 bit).

position (float out)

Encoder position in position units (count / scale).

position-interpolated (float out)

Encoder interpolated position in position units (count / scale). Only valid when velocity is approximately constant and the time between counts is less than the velocity timeout parameter value. Do not use for position control. Useful for spindle synchronized moves with low resolution encoders.

position-latched (float out)

Encoder latched position in position units (count / scale).

velocity (float out)

Estimated encoder velocity in position units per second.

velocity-rpm (float out)

Estimated encoder velocity in position units per minute.

reset (bit in)

When this pin is True, the count and position pins are set to 0 (the value of the velocity pin is not affected by this). The driver does not reset this pin to FALSE after resetting the count to 0, that is the user's job.

index-enable (bit in/out)

When this pin is set to True, (and no-clear-on-index is false) the count (and therefore also position) are reset to zero on the next Index (Phase-Z) pulse. At the same time, index-enable is reset to zero to indicate that the pulse has occurred.

no-clear-on-index (bit in)

When this pin is set to True, the count (and therefore also position) are NOT reset to zero on the next Index (Phase-Z) pulse. On an index event the latched count and position will be set to indicate the count and position where the index occurred.

probe-enable (bit in/out)

When this pin is set to True, the encoder count (and therefore also position) are latched on the the next probe active edge. At the same time, probe-enable is reset to zero to indicate that latch event has occurred. (only present if supported by firmware)

probe-invert (bit r/w)

If set to True, the rising edge of the probe input pin triggers the latch event (if probe-enable is True). If set to False, the falling edge triggers. (only present if supported by firmware)

rawcounts (s32 out)

Total number of encoder counts since the start, not adjusted for index or reset.

rawcounts_64 (s64 out)

Total number of encoder counts since the start, not adjusted for index or reset. (64 bit)

count_latch (s32 out)

Encoder count at latch event. (index or probe)

count_latch_64 (s64 out)

Encoder count at latch event. (index or probe) (64 bit)

input-a, input-b, input-index (bit out)

Real time filtered values of A,B,Index encoder signals

quad-error-enable (bit in)

When this pin is True quadrature error reporting is enabled. When False, existing quadrature errors are cleared and error reporting is disabled.

quad-error (bit out)

This bit indicates that a quadrature sequence error has been detected. It can only be set if the corresponding quad-error-enable bit is True.

hm2_XXXX.N.encoder.sample-frequency (u32 in)

This is the sample frequency that determines all standard encoder channels digital filter time constant (see filter parameter).

hm2_XXXX.N.encoder.muxed-sample-frequency (u32 in)

This is the sample frequency that determines all muxed encoder channels digital filter time constant (see filter parameter). This also sets the encoder multiplexing frequency.

hm2_XXXX.N.encoder.muxed-skew (float in)

This sets the muxed encoder sample time delay (in ns) from the multiplex signal. Setting this properly can increase the usable multiplex frequency and compensate for cable delays (suggested value is 3* cable length in feet +20).

hm2_XXXX.N.encoder.hires-timestamp (bit in)

When this pin is True the encoder timestamp counter frequency is ca. 10 MHz. When False the timestamp counter frequency is ca. 2 MHz. This should be set True for frequency counting applications to improve the resolution. It should be set False when servo thread periods longer than 1 ms are used.

Parameters:**scale (float r/w)**

Converts from "count" units to "position" units.

index-invert (bit r/w)

If set to True, the rising edge of the Index input pin triggers the Index event (if index-enable is True). If set to False, the falling edge triggers.

index-mask (bit r/w)

If set to True, the Index input pin only has an effect if the Index-Mask input pin is True (or False, depending on the index-mask-invert pin below).

index-mask-invert (bit r/w)

If set to True, Index-Mask must be False for Index to have an effect. If set to False, the Index-Mask pin must be True.

counter-mode (bit r/w)

Set to False (the default) for Quadrature. Set to True for Step/Dir (in which case Step is on the A pin and Dir is on the B pin).

filter (bit r/w)

If set to True (the default), the quadrature counter needs 15 sample clocks to register a change on any of the three input lines (any pulse shorter than this is rejected as noise). If set to False, the quadrature counter needs only 3 clocks to register a change. The default encoder sample clock runs at approximately 25 to 33 MHz but can be changed globally with the sample-frequency or muxed-sample-frequency pin.

vel-timeout (float r/w)

When the encoder is moving slower than one pulse for each time that the driver reads the count from the FPGA (in the hm2_read() function), the velocity is harder to estimate. The driver can wait several iterations for the next pulse to arrive, all the while reporting the upper bound of the encoder

velocity, which can be accurately guessed. This parameter specifies how long to wait for the next pulse, before reporting the encoder stopped. This parameter is in seconds.

hm2_XXXX.N.encoder.timer-number (default: -1) (s32 r/w)

Sets the hm2dpll timer instance to be used to latch encoder counts. A setting of -1 does not latch encoder counts. A setting of 0 latches at the same time as the main hostmot2 read. A setting of 1..4 uses a time offset from the main hostmot2 read according to the dpll's timer-us setting.

Typically, timer-us should be a negative number with a magnitude larger than the largest latency (e.g., -100 for a system with mediocre latency, -50 for a system with good latency). A negative number specifies latching the specified time before the nominal hostmot2 read time.

If no DPLL module is present in the FPGA firmware, or if the encoder module does not support DPLL, then this pin is not created.

When available, this feature should typically be enabled. Doing so generally reduces following errors.

271.3.5. Synchronous Serial Interface (SSI)

(Not to be confused with the Smart Serial Interface)

One pin is created for each SSI instance regardless of data format:

hm2_XXXX.NN.ssi.MM.data-incomplete (bit, in)

This pin will be set "True" if the module was still transferring data when the value was read. When this problem exists there will also be a limited number of error messages printed to the UI. This pin should be used to monitor whether the problem has been addressed by config changes. Solutions to the problem depend on whether

- the encoder read is being triggered by the hm2dpll phase-locked-loop timer (described above)
- or by the trigger-encoders function (described below).

The names of the pins created by the SSI module will depend entirely on the format string for each channel specified in the loadrt command line. A typical format string might be **ssi_chan_0=error%1bposition%24g**.

This would interpret the LSB of the bit-stream as a bit-type pin named "error" and the next 24 bits as a Gray-coded encoder counter. The encoder-related HAL pins would all begin with "position".

There should be no spaces in the format string, as this is used as a delimiter by the low-level code.

The format consists of a string of alphanumeric characters that will form the HAL pin names, followed by a % symbol, a bit-count and a data type. All bits in the packet must be defined, even if they are not used. There is a limit of 64 bits in total.

The valid format characters and the pins they create are:

p: (Pad)

Does not create any pins, used to ignore sections of the bit stream that are not required.

b: (Boolean).

(bit, out) hm2_XXXX.N.ssi.MM.<name>.

If any bits in the designated field width are non-zero then the HAL pin will be "True".

(bit, out) hm2_XXXX.N.ssi.MM.<name>-not.

An inverted version of the above, the HAL pin will be "True" if all bits in the field are zero.

u: (Unsigned)

(float, out) hm2_XXXX.N.ssi.MM.<name>. The value of the bits interpreted as an unsigned integer then scaled such that the pin value will equal the scalemax parameter value when all bits are high. (for example if the field is 8 bits wide and the scalemax parameter was 20 then a value of 255 would return 20, and 0 would return 0.

s: (Signed)

(float, out) hm2_XXXX.N.ssi.MM.<name>.

The value of the bits interpreted as a 2s complement signed number then scaled similarly to the unsigned variant, except symmetrical around zero.

f: (bitField)

(bit, out) hm2_XXXX.N.ssi.MM.<name>-NN.

The value of each individual bit in the data field. NN starts at 00 up to the number of bits in the field.

(bit, out) hm2_XXXX.N.ssi.MM.<name>-NN-not.

An inverted version of the individual bit values.

e: (Encoder)

(s32, out) hm2_XXXX.N.ssi.MM.<name>.count.

The lower 32 bits of the total encoder counts. This value is reset both by the ...reset and the ...index-enable pins.

(s32, out) hm2_XXXX.N.ssi.MM.<name>.rawcounts.

The lower 32 bits of the total encoder counts. The pin is not affected by reset and index.

(float, out) hm2_XXXX.N.ssi.MM.<name>.position.

The encoder position in machine units. This is calculated from the full 64-bit buffers so will show a True value even after the counts pins have wrapped. It is zeroed by reset and index enable.

(bit, IO) hm2_XXXX.N.ssi.MM.<name>.index-enable.

When this pin is set "True" the module will wait until the raw encoder counts next passes through an integer multiple of the number of counts specified by counts-per-rev parameter and then it will zero the counts and position pins, and set the index-enable pin back to "False" as a signal to the system that "index" has been passed. this pin is used for spindle-synchronised motion and index-homing.

(bit, in) (bit, out) hm2_XXXX.N.ssi.MM.<name>.reset.

When this pin is set high the counts and position pins are zeroed.

h: (Split encoder, high-order bits)

Some encoders (Including Fanuc) place the encoder part-turn counts and full-turn counts in separate, non-contiguous fields. This tag defines the high-order bits of such an encoder module. There can be only one h and one l tag per channel, the behaviour with multiple such channels will be undefined.

l: (Split encoder, low-order bits)

Low order bits (see "h")

g: (Gray-code)

This is a modifier that indicates that the following format string is gray-code encoded. This is only valid for encoders (e, h l) and unsigned (u) data types.

m: (Multi-turn)

This is a modifier that indicates that the following format string is a multi-turn encoder. This is only valid for encoders (e, h l). A jump in encoder position of more than half the full scale is interpreted as a full turn and the counts are wrapped. With a multi-turn encoder this is only likely to be a data glitch and will lead to a permanent offset. This flag endures that such encoders will never wrap.

Parameters

Two parameters are universally created for all SSI instances

hm2_XXXX.N.ssi.MM.frequency-khz (float r/w)

This parameter sets the SSI clock frequency. The units are kHz, so 500 will give a clock frequency of 500,000 Hz.

hm2_XXXX.N.ssi.timer-number-num (s32 r/w)

This parameter allocates the SSI module to a specific hm2dpll timer instance. This pin is only of use in firmwares which contain a hm2dpll function and will default to 1 in cases where there is such a function, and 0 if there is not. The pin can be used to disable reads of the encoder, by setting to a nonexistent timer number, or to 0.

Other parameters depend on the data types specified in the config string.

p: (Pad)

No Parameters.

b: (Boolean)

No Parameters.

u: (Unsigned)

(float, r/w) hm2_XXXX.N.ssi.MM.<name>-scalemax. The scaling factor for the channel.

s: (Signed)

(float, r/w) hm2_XXXX.N.ssi.MM.<name>-scalemax. The scaling factor for the channel.

f: (bitField)

No parameters.

e: (Encoder)

(float, r/w) hm2_XXXX.N.ssi.MM.<name>.scale: (float, r.w) The encoder scale in counts per machine unit. (u32, r/w) hm2_XXXX.N.ssi.MM.<name>.counts-per-rev (u32, r/w) Used to emulate the index behaviour of an incremental+index encoder. This would normally be set to the actual counts per rev of the encoder, but can be any whole number of revs. Integer divisors or multipliers of the true PPR might be useful for index-homing. Non-integer factors might be appropriate where there is a synchronous drive ratio between the encoder and the spindle or ballscrew.

271.3.6. BiSS

BiSS is a bidirectional variant of SSI. Currently only a single direction is supported by LinuxCNC (encoder to PC).

One pin is created for each BiSS instance regardless of data format:

hm2_XXXX.NN.biss.MM.data-incomplete (bit, in)

This pin will be set "True" if the module was still transferring data when the value was read. When this problem exists there will also be a limited number of error messages printed to the UI. This pin should be used to monitor whether the problem has been addressed by config changes. Solutions to the problem depend on whether the encoder read is being triggered by the hm2dpll phase-locked-loop timer (described above) or by the trigger-encoders function (described below).

The names of the pins created by the BiSS module will depend entirely on the format string for each channel specified in the loadrt command line and follow closely the format defined above for SSI. Currently data packets of up to 96 bits are supported by the LinuxCNC driver, although the Mesa Hostmot2 module can handle 512 bit packets. It should be possible to extend the number of packets supported by the driver if there is a requirement to do so.

271.3.7. Fanuc encoder

The pins and format specifier for this module are identical to the SSI module described above, except that at least one pre-configured format is provided. A modparam of fanuc_chan_N=AA64 (case sensitive) will configure the channel for a Fanuc Aa64 encoder. The pins created are:

hm2XXXX._N.fanuc.MM.batt

indicates battery state

hm2XXXX._N.fanuc.MM.batt-not

inverted version of above

hm2XXXX._N.fanuc.MM.comm

The 0-1023 absolute output for motor commutation

hm2XXXX._N.fanuc.MM.crc

The CRC checksum. Currently HAL has no way to use this

hm2XXXX._N.fanuc.MM.encoder.count

Encoder counts

hm2XXXX._N.fanuc.MM.encoder.index-enable

Simulated index. Set by counts-per-rev parameter

hm2XXXX._N.fanuc.MM.encoder.position

Counts scaled by the ...scale parameter

hm2XXXX_N.fanuc.MM.encoder.rawcounts

Raw counts, unaffected by reset or index

hm2XXXX_N.fanuc.MM.encoder.reset

If high/True then counts and position = 0

hm2XXXX_N.fanuc.MM.valid

Indicates that the absolute position is valid

hm2XXXX_N.fanuc.MM.valid-not

Inverted version

271.3.8. resolver

Resolvers have names like **hm2_<BoardType>.<BoardNum>.resolver.<Instance>**. <Instance> is a 2-digit number, which for the 7I49 board will be between 00 and 05. This function only works with the Mesa Resolver interface boards (of which the 7I49 is the only example at the time of writing). This board uses an SPI interface to the FPGA card, and will only work with the correct firmware. The pins allocated will be listed in the dmesg output, but are unlikely to be usefully probed with HAL tools.

Pins:**angle (float, out)**

This pin indicates the angular position of the resolver. It is a number between 0 and 1 for each electrical rotation.

position (float, out)

Calculated from the number of complete and partial revolutions since startup, reset, or index-reset multiplied by the scale parameter.

velocity (float, out)

Calculated from the rotational velocity and the velocity-scale parameter. The default scale is electrical rotations per second.

velocity-rpm (float, out)

Simply velocity scaled by a factor of 60 for convenience.

count (s32, out)

This pins outputs a simulated encoder count at 2^{24} counts per rev (16777216 counts).

rawcounts (s32, out)

This is identical to the counts pin, except it is not reset by the "index" or "reset" pins. This is the pin which would be linked to the bldc HAL component if the resolver was being used to commutate a motor.

reset (bit, in)

Resets the position and counts pins to zero immediately.

joint-pos-fb (bit, in)

The Mesa resolver driver has the capability of emulating an absolute encoder using a position file (see the INI-config section of the manual) and the single-turn absolute operation of resolvers. At startup, and only if the **use-position-file** parameter is set to "True", the resolver driver will wait for a value to be written by the system to the axis.N.joint-pos-fb pin (which must be netted to this resolver pin) and will calculate the number of full turns that best matches the current resolver position. It will then pre-load the driver output with this offset. This should only be used on systems where axis movement in the unpowered state is unlikely. This feature will only work properly if the machine is initially homed to "index" and if the axis home positions are exactly zero.

index-enable (bit, in/out)

When this pin is set high the position and counts pins will be reset the next time the resolver passes through the zero position. At the same time the pin is driven low to indicate to connected modules that the index has been seen, and that the counters have been reset.

error (bit, out)

Indicates an error in the particular channel. If this value is "True" then the reported position and velocity are invalid.

Parameters:**scale (float, read/write)**

The position scale, in machine units per resolver electrical revolution.

velocity-scale (float, read/write)

The conversion factor between resolver rotation speed and machine velocity. A value of 1 will typically give motor speed in RPS, a value of 0.01666667 will give (approximate) RPM.

index-divisor (default 1) (u32, read/write)

The resolver component emulates an index at a fixed point in the sin/cos cycle. Some resolvers have multiple cycles per rev (often related to the number of pole-pairs on the attached motor). LinuxCNC requires an index once per revolution for proper threading etc. This parameter should be set to the number of cycles per rev of the resolver. CAUTION: Which pseudo-index is used will not necessarily be consistent between LinuxCNC runs. Do not expect to re-start a thread after restarting LinuxCNC. It is not appropriate to use this parameter for index-homing of axis drives.

excitation-khz (float, read/write)

This pin sets the excitation frequency for the resolver. This pin is module-level rather than instance-level as all resolvers share the same excitation frequency. Valid values are 10 (ca. 10 kHz), 5 (ca. 5 kHz) and 2.5 (ca. 2.5 kHz). The actual frequency depends on the FPGA frequency, and they correspond to `CLOCK_LOW/5000`, `CLOCK_LOW/10000` and `CLOCK_LOW/20000` respectively. The parameter will be set to the closest available of the three frequencies. A value of -1 (the default) indicates that the current setting should be retained.

use-position-file (bit, read/write)

In conjunction with **joint-pos-fb** (qv) emulate absolute encoders.

271.3.9. pwmgen

pwmgens have names like "**hm2_<BoardType>.<BoardNum>.pwmgen.<Instance>**". *<Instance>* is a two-digit number that corresponds to the HostMot2 pwmgen instance number. There are "num_pwmgens"-many instances, starting with 00.

So, for example, the HAL pin that enables output from the fourth pwmgen of the first 7I43 board is: **hm2_7i43.0.pwmgen.03.enable** (this assumes that the firmware in that board is configured so that this HAL object is available).

In HM2, each pwmgen uses three output I/O pins: **Not-Enable**, **Out0**, and **Out1**. The function of the Out0 and Out1 I/O pins varies with output-type parameter (see below).

The hm2 pwmgen representation is similar to the software pwmgen component. Each pwmgen instance has the following pins and parameters:

Pins:

enable (bit input)

If True, the pwmgen will set its Not-Enable pin False and output its pulses. If "enable" is False, pwmgen will set its Not-Enable pin True and not output any signals.

value (float input)

The current pwmgen command value, in arbitrary units.

Parameters:

scale (float rw)

Scaling factor to convert "value" from arbitrary units to duty cycle: $dc = value / scale$. Duty cycle has an effective range of -1.0 to +1.0 inclusive, anything outside that range gets clipped. The default scale is 1.0.

output-type (s32 rw)

This emulates the output_type load-time argument to the software pwmgen component. This parameter may be changed at runtime, but most of the time you probably want to set it at startup and then leave it alone. Accepted values are 1 (PWM on Out0 and Direction on Out1), 2 (Up on Out0 and Down on Out1), 3 (PDM mode, PDM on Out0 and Dir on Out1), and 4 (Direction on Out0 and PWM on Out1, "for locked antiphase").

offset-mode (bit input)

When True, offset-mode modifies the PWM behavior so that a PWM value of 0 results in a 50% duty cycle PWM output, a -1 value results in a 0% duty cycle and +1 results in a 100% duty cycle (with default scaling). This mode is used by some PWM motor drives and PWM to analog converters. Typically the direction signal is not used in this mode.

dither (bit input)

When True, dither causes the PWM output to dither between two adjacent PWM register values at the PWM frequency. This increases the PWM resolution when used for analog output purposes, increasing the maximum resolution from 12 to 16 bits. Dither is only supported with PWMGen

firmware version 1 or greater and only affects PWM outputs, not PDM outputs.

In addition to the per-instance HAL Parameters listed above, there are a couple of HAL Parameters that affect all the pwmgen instances:

pwm_frequency (u32 rw)

This specifies the PWM frequency, in Hz, of all the pwmgen instances running in the PWM modes (modes 1 and 2). This is the frequency of the variable-duty-cycle wave. Its effective range is from 1 Hz up to 386 kHz. Note that the max frequency is determined by the ClockHigh frequency of the Anything IO board; the 5I25 and 7I92 both have a 200 MHz clock, resulting in a 386 kHz max PWM frequency. Other boards may have different clocks, resulting in different max PWM frequencies. If the user attempts to set the frequency too high, it will be clipped to the max supported frequency of the board. Frequencies below about 5 Hz are not terribly accurate, but above 5 Hz they're pretty close. The default pwm_frequency is 20,000 Hz (20 kHz).

pdm_frequency (u32 rw)

This specifies the PDM frequency, in Hz, of all the pwmgen instances running in PDM mode (mode 3). This is the "pulse slot frequency"; the frequency at which the pdm generator in the AnyIO board chooses whether to emit a pulse or a space. Each pulse (and space) in the PDM pulse train has a duration of 1/pdm_frequency seconds. For example, setting the pdm_frequency to 2e6 (2 MHz) and the duty cycle to 50% results in a 1 MHz square wave, identical to a 1 MHz PWM signal with 50% duty cycle. The effective range of this parameter is from about 1525 Hz up to just under 200 MHz. Note that the max frequency is determined by the ClockHigh frequency of the Anything IO board; the 5I25 and 7I92 both have a 100 MHz clock, resulting in a 100 MHz max PDM frequency. Other boards may have different clocks, resulting in different max PDM frequencies. If the user attempts to set the frequency too high, it will be clipped to the max supported frequency of the board. The default pdm_frequency is 20,000 Hz (20 kHz).

271.3.10. 3ppwmgen

Three-Phase PWM generators (3ppwmgens) are intended for controlling the high-side and low-side gates in a 3-phase motor driver. The function is included to support the Mesa motor controller daughter-cards but can be used to control an IGBT or similar driver directly. 3ppwmgens have names like "hm2_<BoardType>.<BoardNum>.3ppwmgen.<Instance>" where <Instance> is a 2-digit number. There will be num_3ppwmgens instances, starting at 00. Each instance allocates 7 output and one input pins on the Mesa card connectors. Outputs are: PWM A, PWM B, PWM C, /PWM A, /PWM B, /PWM C, Enable. The first three pins are the high side drivers, the second three are their complementary low-side drivers. The enable bit is intended to control the servo amplifier. The input bit is a fault bit, typically wired to over-current detection. When set, the PWM generator is disabled. The three phase duty-cycles are individually controllable from -Scale to +Scale. Note that 0 corresponds to a 50% duty cycle and this is the initialization value.

Pins:

A-value, B-value, C-value (float input)

The PWM command value for each phase, limited to +/- "scale". Defaults to zero which is 50% duty cycle on high-side and low-sidepins (but see the "deadtime" parameter).

enable (bit input)

When high the PWM is enabled as long as the fault bit is not set by the external fault input pin. When low the PWM is disabled, with both high- side and low-side drivers low. This is not the same as 0 output (50% duty cycle on both sets of pins) or negative full scale (where the low side drivers are "on" 100% of the time).

fault (bit output)

Indicates the status of the fault bit. This output latches high once set by the physical fault pin until the "enable" pin is set to high.

Parameters:**deadtime (u32 rw)**

Sets the dead-time between the high-side driver turning off and the low-side driver turning on and vice-versa. Deadtime is subtracted from on time and added to off time symmetrically. For example with 20 kHz PWM (50 μ s period), 50% duty cycle and zero dead time, the PWM and NPWM outputs would be square waves (NPWM being inverted from PWM) with high times of 25 μ s. With the same settings but 1 μ s of deadtime, the PWM and NPWM outputs would both have high times of 23 μ s (25 - (2X 1 μ s), 1 μ s per edge). The value is specified in nanoseconds (ns) and defaults to a rather conservative 5000 ns. Setting this parameter to too low a value could be both expensive and dangerous as if both gates are open at the same time there is effectively a short circuit across the supply.

scale (float rw)

Sets the half-scale of the specified 3-phase PWM generator. PWM values from -scale to +scale are valid. Default is +/- 1.0

fault-invert (bit rw)

Sets the polarity of the fault input pin. A value of 1 means that a fault is triggered with the pin high, and 0 means that a fault is triggered when the pin is pulled low. Default 0, fault = low so that the PWM works with the fault pin unconnected.

sample-time (u32 rw)

Sets the time during the cycle when an ADC pulse is generated. 0 = start of PWM cycle and 1 = end. Not currently useful to LinuxCNC. Default is 0.5.

In addition the per-instance parameters above there is the following parameter that affects all instances:

frequency (u32 rw)

Sets the master PWM frequency. Maximum is approx 48 kHz, minimum is 1 kHz. Defaults to 20 kHz.

271.3.11. oneshot

The oneshot is a hardware one-shot device suitable for various timing, delay, signal conditioning, PWM generation, and watchdog functions. The oneshot module includes 2 timers to allow variable pulse delays for applications like phase control. Trigger sources can be software, external inputs, the DPLL timer, a built in rate generator or the other timer. Oneshots have names like "**hm2_<BoardType>**

.<BoardNum>.oneshot.<Instance>" where <Instance> is a 2-digit number. There will be num_oneshots instances, starting at 00. Each instance allocates up to two input and two output pins.

Pins:

width1 (float rw)

Sets the pulse width of timer1 in ms. Default is 1 ms (1/1000 s).

width2 (float rw)

Sets the pulse width of timer2 in ms. Default is 1 ms (1/1000 s).

filter1 (float rw)

Sets digital filter time constant for timer1's external trigger input Filter time is in ms. Default filter time constant time is 0.1 ms. External trigger response will be delayed by the filter time setting.

filter2 (float rw)

Sets digital filter time constant for timer2's external trigger input Filter time is in ms. Default filter time constant time is 0.1 ms. External trigger response will be delayed by the filter time setting.

rate (float rw)

Sets the frequency of the built in rate generator (in Hz)

trigger_select1, trigger_select2 (u32 rw)

Sets the trigger source for timer1, timer2 respectively. Trigger sources are:

```
0 Trigger disabled
1 Software trigger: triggered when hal pin swtrigger1 is true
2 External hardware: trigger
3 DPLL trigger: triggered by selected DPLL timer
4 Rate trigger: triggered by build in rate generator.
5 Timer1 trigger: triggered by timer1 output
6 Timer2 trigger: triggered by timer2 output
```

trigger_on_rise1, trigger_on_rise2 (bit rw)

When true, triggers timer1, timer2 respectively on the rising edge of the trigger source.

trigger_on_fall1, trigger_on_fall2 (bit rw)

When true, triggers timer1, timer2 respectively on the falling edge of the trigger source.

retriggerable1, retriggerable2 (bit rw)

When true, the associated timer is retriggerable, meaning the timer will reset to full time on a trigger event even during the output pulse period. When false the timer is not retriggerable, meaning it will ignore trigger events during the output pulse period.

enable1, enable2 (bit rw)

Trigger enable for timer1 and timer2 respectively True to enable.

reset1, reset2 (bit rw)

If true, resets timer1 and timer2 respectively, aborting any pulse in progress.

out1,out2 (bit ro)

Pulse output status bits for timer1 and timer2.

exttrigger1, exttrigger2 (bit ro)

External trigger input status bits for timer1 and timer2. These monitor the filtered inputs.

swtrigger1, swtrigger2 (bit rw)

Software trigger inputs to trigger timer1 and timer2.

271.3.12. periodm

The periodm is a period/width/duty cycle measuring module. It can measure period, frequency, pulse width and duty cycle. It can also average readings for noise filtering.

Pins:**period_us (float r)**

Input period in microseconds.

width_us (float r)

Input pulse width in microseconds.

duty_cycle (float r)

Input duty cycle (width/period) scaling and offset are changeable.

duty_cycle_scale (float rw)

Sets the scale of the duty cycle value, default is 100.

duty_cycle_offset (float rw)

Sets an offset to the duty cycle value, added after scaling. Default is 0.

averages (float rw)

Number of periods/widths to average. From 1 to 4095. Update rate of period, width, duty cycle, and frequency will be input frequency/averages.

frequency (float r)

Input frequency in Hz.

minimum_frequency (float w)

Minimum input frequency in Hz, if input frequency is lower than this threshold, the valid bit will be cleared.

filtertc_us (float w)

The periodm input is conditioned with a digital filter for noise rejection. The time constant of this

filter is settable via this pin in units of microseconds. Pulses shorter than this time constant will not be recognized.

valid (bit out)

The valid output bit is true when the input signal is present and the input frequency exceeds the minimum frequency setting.

invert (bit in)

The invert bit sets the input polarity, when false, the input is direct which means the input high time determines the width. When set true, the input is inverted so the input low time determines the width.

input_status (bit out)

The input_status bit reads the real time filtered input status (affected by invert pin).

271.3.13. rcpwmgen

The rcpwmgen is a simple PWM generator optimized for use with standard RC servos that use pulse width to determine position. rcpwmgens have names like "**hm2_<BoardType>.<BoardNum>.rcpwmgen.<Instance>**" where *<Instance>* is a 2-digit number. There will be *num_rcpwmgens*-many instances, starting at 00. Each instance allocates a single output pin. Unlike the standard PWM generator, the rcpwmgen output is specified in width rather than duty cycle so the pulse width is independent of the operating frequency. Resolution is approximately 1/2000 for standard 1 to 2 ms range RC servos.

Pins:**rate (float rw)**

Sets the master RC PWM frequency. Maximum is 1 kHz, minimum is 0.01 Hz. Defaults to 50 Hz.

width (float rw)

Sets the per channel pulse width in (ms/scale).

offset (float rw)

Sets the per channel pulse width offset in ms. This would be set to 1.5 ms for 1-2 ms servos for a 0 center position.

scale (float rw)

Sets the per channel pulse width scaling. For example, setting the scale to 90 and the offset to 1.5 ms would result in a position range of +-45 degrees and scale in degrees for 1-2 ms servos with a full motion range of 90 degrees.

271.3.14. stepgen

stepgens have names like "**hm2_<BoardType>.<BoardNum>.stepgen.<Instance>**". *<Instance>* is a two-digit number that corresponds to the HostMot2 stepgen instance number. There are "num_stepgens"-many instances, starting with 00.

So, for example, the HAL pin that has the current position feedback from the first stepgen of the second

5I22 board is: `hm2_5i22.1.stepgen.00.position-fb` (this assumes that the firmware in that board is configured so that this HAL object is available).

Each stepgen uses between 2 and 8 I/O pins. The signals on these pins depends on the `step_type` parameter (described below).

The stepgen representation is modeled on the stepgen software component. Each stepgen instance has the following pins and parameters:

Pins:

position-cmd (float input)

Target position of stepper motion, in arbitrary position units. This pin is only used when the stepgen is in position control mode (`control-type=0`).

velocity-cmd (float input)

Target velocity of stepper motion, in arbitrary position units per second. This pin is only used when the stepgen is in velocity control mode (`control-type=1`).

counts (s32 output)

Feedback position in counts (number of steps).

position-fb (float output)

Feedback position in scaled position units. This is similar to "`counts/position_scale`", but has finer than step resolution.

position-latched (float output)

latched-position in scaled position units. This is similar to "`counts/position_scale`", but has finer than step resolution.

velocity-fb (float output)

Feedback velocity in arbitrary position units per second.

enable (bit input)

This pin enables the step generator instance. When True, the stepgen instance works as expected. When False, no steps are generated and `velocity-fb` goes immediately to 0. If the stepgen is moving when `enable` goes False it stops immediately, without obeying the `maxaccel` limit.

position-reset (bit input)

Resets position to 0 when True. Useful for step/dir controlled spindles when switching between spindle and joint modes.

control-type (bit input)

Switches between position control mode (0) and velocity control mode (1). Defaults to position control (0).

index-enable (bit in/out)

When this pin is set to True, the step count (and therefore also position) are reset to zero on the next

stepgen index pulse. At the same time, index-enable is reset to zero to indicate that the pulse has occurred.

index-invert (bit r/w)

If set to True, the rising edge of the index input pin triggers the position clear event (if index-enable is True). If set to False, the falling edge triggers.

probe-enable (bit in/out)

When this pin is set to True, the step count (and therefore also position) are latched on the the next stepgen probe active edge. At the same time, probe-enable is reset to zero to indicate that a latch event has occurred.

probe-invert (bit r/w)

If set to True, the rising edge of the probe input pin triggers the latch event (if probe-enable is True). If set to False, the falling edge triggers.

Parameters:**position-scale (float r/w)**

Converts from counts to position units. $\text{position} = \text{counts} / \text{position_scale}$

maxvel (float r/w)

Maximum speed, in position units per second. If set to 0, the driver will always use the maximum possible velocity based on the current step timings and position-scale. The max velocity will change if the step timings or position-scale changes. Defaults to 0.

maxaccel (float r/w)

Maximum acceleration, in position units per second per second. Defaults to 1.0. If set to 0, the driver will not limit its acceleration at all. This requires that the position-cmd or velocity-cmd pin is driven in a way that does not exceed the machine's capabilities. This is probably what you want if you are going to be using the LinuxCNC trajectory planner to jog or run G-code.

steplen (u32 r/w)

Duration of the step signal, in nanoseconds.

stepspace (u32 r/w)

Minimum interval between step signals, in nanoseconds.

dirsetup (u32 r/w)

Minimum duration of stable Direction signal before a step begins, in nanoseconds.

dirhold (u32 r/w)

Minimum duration of stable Direction signal after a step ends, in nanoseconds.

step_type (u32 r/w)

Output format, like the step_type modparam to the software stepgen(9) component: 0 = Step/Dir, 1 = Up/Down, 2 = Quadrature, 3+ = table-lookup mode. In this mode the step_type parameter determines how long the step sequence is. Additionally the stepgen_width parameter in the loadrt config string

must be set to suit the number of pins per stepgen required. Any stepgen pins above this number will be available for GPIO. This mask defaults to 2. The maximum length is 16. Note that Table mode is not enabled in all firmwares but if you see GPIO pins between the stepgen instances in the dmesg/log hardware pin list then the option may be available.

In Quadrature mode (`step_type=2`), the stepgen outputs one complete Gray cycle (00 → 01 → 11 → 10 → 00) for each "step" it takes, so the scale must be divided by 4 relative to standard step/dir. In table mode, up to 6 I/O pins are individually controlled in an arbitrary sequence up to 16 phases long.

swap_step_dir (bit input)

This swaps the step and direction outputs on the selected stepgen. This parameter is only available if the firmware supports this option.

table-data-N (u32 r/w)

There are 4 `table-data-N` parameters, `table-data-0` to `table-data-3`. These each contain 4 bytes corresponding to 4 stages in the step sequence. For example `table-data-0 = 0x00000001` would set stepgen pin 0 (always called "Step" in the dmesg output) on the first phase of the step sequence, and `table-data-4 = 0x20000000` would set stepgen pin 6 ("TableSPin" in the dmesg output) on the 16th stage of the step sequence.

hm2_XXXX.N.stepgen.timer-number (default: -1) (s32 r/w)

Sets the `hm2dp11` timer instance to be used to latch stepgen counts. A setting of -1 does not latch stepgen counts. A setting of 0 latches at the same time as the main `hostmot2` read. A setting of 1..4 uses a time offset from the main `hostmot2` read according to the `dp11`'s `timer-us` setting.

Typically, `timer-us` should be a negative number with a magnitude larger than the largest latency (e.g., -100 for a system with mediocre latency, -50 for a system with good latency). A negative number specifies latching the specified time before the nominal `hostmot2` read time.

If no DPLL module is present in the FPGA firmware, or if the stepgen module does not support DPLL, then this pin is not created.

When available, this feature should typically be enabled. Doing so generally reduces following errors.

271.3.15. Smart Serial Interface

The Smart Serial Interface allows up to 32 different devices such as the Mesa 8i20 2.2 kW 3-phase drive or 7I64 48-way I/O cards to be connected to a single FPGA card. The driver auto-detects the connected hardware port, channel and device type. Devices can be connected in any order to any active channel of an active port (see the `config modparam` definition above).

For full details of the smart-serial devices see **sserial(9)**.

271.3.16. BSPI

The BSPI (Buffered SPI) driver is unusual in that it does not create any HAL pins. Instead the driver exports a set of functions that can be used by a sub-driver for the attached hardware. Typically, these would be written in the "comp".

Pre-processing language: see <https://linuxcnc.org/docs/html/hal/comp.html> or man halcompile for further details. See mesa_7i65(9) and the source of mesa_7i65.comp for details of a typical sub-driver. See hm2_bspi_setup_chan(3), hm2_bspi_write_chan(3), hm2_tram_add_bspi_frame(3), hm2_allocate_bspi_tram(3), hm2_bspi_set_read_function(3) and hm2_bspi_set_write_function(3) for the exported functions.

The names of the available channels are printed to standard output during the driver loading process and take the form **hm2_<board name>.<board index>.bspi.<index>**, e.g., **hm2_5i23.0.bspi.0**.

271.3.17. UART

The UART driver also does not create any HAL pins, instead it declares two simple read/write functions and a setup function to be utilised by user-written code. Typically this would be written in the "comp" pre-processing language: see <https://linuxcnc.org/docs/html/hal/comp.html> or man halcompile for further details. See mesa_uart(9) and the source of mesa_uart.comp for details of a typical sub-driver. See hm2_uart_setup_chan(3), hm2_uart_send(3), hm2_uart_read(3) and hm2_uart_setup(3).

The names of the available uart channels are printed to standard output during the driver loading process and take the form **hm2_<board name>.<board index>.uart.<index>**, e.g., **hm2_5i23.0.uart.0**.

271.3.18. General Purpose I/O

I/O pins on the board which are not used by a module instance are exported to HAL as "full" GPIO pins. Full GPIO pins can be configured at run-time to be inputs, outputs, or open drains, and have a HAL interface that exposes this flexibility. I/O pins that are owned by an active module instance are constrained by the requirements of the owning module, and have a restricted HAL interface.

GPIOs have names like "**hm2_<BoardType>.<BoardNum>.gpio.<IONum>**". <IONum> is a three-digit number. The mapping from <IONum> to connector and pin-on-that-connector is written to the syslog when the driver loads, and it is documented in Mesa's manual for the Anything I/O boards.

So, for example, the HAL pin that has the current inverted input value read from GPIO 012 of the second 7i43 board is: **hm2_7i43.1.gpio.012.in-not** (this assumes that the firmware in that board is configured so that this HAL object is available).

The HAL parameter that controls whether the last GPIO of the first 5i22 is an input or an output is: **hm2_5i22.0.gpio.095.is_output** (this assumes that the firmware in that board is configured so that this HAL object is available).

The hm2 GPIO representation is modeled after the Digital Inputs and Digital Outputs described in the Canonical Device Interface (part of the HAL General Reference document). Each GPIO can have the following HAL Pins:

in & in_not (bit out)

State (normal and inverted) of the hardware input pin. Both full GPIO pins and I/O pins used as inputs by active module instances have these pins.

out (bit in)

Value to be written (possibly inverted) to the hardware output pin. Only full GPIO pins have this pin.

Each GPIO can have the following Parameters:

is_output (bit r/w)

If set to 0, the GPIO is an input. The I/O pin is put in a high-impedance state (weakly pulled high), to be driven by other devices. The logic value on the I/O pin is available in the "in" and "in_not" HAL pins. Writes to the "out" HAL pin have no effect. If this parameter is set to 1, the GPIO is an output; its behavior then depends on the "is_opendrain" parameter. Only full GPIO pins have this parameter.

is_opendrain (bit r/w)

This parameter only has an effect if the "is_output" parameter is True. If this parameter is False, the GPIO behaves as a normal output pin: The I/O pin on the connector is driven to the value specified by the "out" HAL pin (possibly inverted), and the value of the "in" and "in_not" HAL pins is undefined. If this parameter is True, the GPIO behaves as an open-drain pin. Writing 0 to the "out" HAL pin drives the I/O pin low, writing 1 to the "out" HAL pin puts the I/O pin in a high-impedance state. In this high-impedance state the I/O pin floats (weakly pulled high), and other devices can drive the value; the resulting value on the I/O pin is available on the "in" and "in_not" pins. Only full GPIO pins and I/O pins used as outputs by active module instances have this parameter.

invert_output (bit r/w)

This parameter only has an effect if the "is_output" parameter is True. If this parameter is True, the output value of the GPIO will be the inverse of the value on the "out" HAL pin. Only full GPIO pins and I/O pins used as outputs by active module instances have this parameter.

When a physical I/O pin is used by a special function, the related **is_output**, and **is_opendrain** HAL parameters are aliased to the special function. For instance, if gpio 1 is taken over by pwmgen 0's first output, then aliases like `hm2_7i92.0.pwmgen.00.out0.invert_output` (referring to `hm2_7i92.0.gpio.001.invert_output`) will be automatically created. When more than one GPIO is connected to the same special function, an extra `.#.` is inserted so that the settings for each related GPIO can be set separately. For example, for the firmware SV12IM_2X7I48_72, the aliases `hm2_5i20.0.pwmgen.00.0.enable.invert_output` (referring to `hm2_5i20.0.gpio.000.invert_output`) and `hm2_5i20.0.pwmgen.00.1.enable.invert_output` (referring to `hm2_5i20.0.gpio.023.invert_output`) are both created.

271.3.19. inm and inmux

inm/inmuxs are input debouncing modules that support hardware digital filtering of input pins. In addition to the input filtering function, the inm/inmux modules support up to 4 simple quadrature counters for MPG use. The quadrature inputs for MPG encoders 0 through 3 are inm/inmux pins 0 through 7. MPG A,B inputs use the filter time constants programmed for inputs 0..7. Each inm/inmux input pin can have a slow or fast filter constant. Filter time constants are specified in units of scan times. inms have names like "**hm2_<BoardType>.<BoardNum>.inm.<Instance>**". inmuxes have names like "**hm2_<BoardType>.<BoardNum>.inmux.<Instance>**". "Instance" is a two-digit number that corresponds to the HostMot2 inm or inmux instance number. There are "num_inms" or "num_inmuxs" instances, starting with 00.

Each instance reads between 8 and 32 input pins. `inm` and `inmux` are identical except for pin names and the physical interface.

Pins:**input and input-not (bit out)**

True and inverted filtered input states.

raw-input and raw-input-not (bit out)

True and inverted unfiltered input states.

input-slow (bit in)

If True, selects the long time constant filter for the corresponding input bit, if False the short time constant is used.

enc0-count, enc1-count, enc2-count, enc3-count (s32 out)

MPG counters 0 through 3.

enc0-reset, enc1-reset, enc2-reset, enc3-reset (bit in)

Reset for MPG counters 0 through 3, count is forced to 0 if true.

Parameters:**scan_rate (u32 in)**

This sets the input scan rate in Hz. Default scan rate is 20 kHz (50 μ s scan period).

fast_scans (u32 in)

This sets the fast time constant for all input pins. This is the time constant used when the input-slow pin for the corresponding input is False. The range is 0 to 63 scan periods and the default value is 5 = 250 μ s at the default 20 kHz scan_rate.

slow_scans (u32 in)

This sets the slow time constant for all input pins. This is the time constant used when the input-slow pin for the corresponding input is True. The range is 0 to 1023 scan periods and the default value is 500 = 25 ms at the default 20 kHz scan_rate.

enc0_4xmode, enc1_4xmode, enc2_4xmode, and enc3_4xmode (bit in)

These set the MPG encoder operating modes to 4X when True and 1X when False.

scan_width (u32 out)

This read only parameter specifies the number of inputs scanned by the module.

271.3.20. led

Creates HAL pins for the LEDs on the FPGA board.

Pins:

CR<NN> (bit in)

The pins are numbered from CR01 upwards with the name corresponding to the PCB silkscreen. Setting the bit to "True" or 1 lights the LED.

271.3.21. Solid State Relay

SSRs have names like "**hm2_<BoardType>.<BoardNum>.ssr.<Instance>**". *Instance* is a two-digit number that corresponds to the HostMot2 SSR instance number. There are *num_ssrs* instances, starting with 00.

Each instance has a rate control pin and between 1 and 32 output pins.

Pins:**rate (u32 in)**

Set the internal frequency of the SSR instance, in Hz (approximate). The valid range is 25 kHz to 25 MHz. Values below the minimum will use the minimum, and values above the max will use the max. 1 MHz is a typical value, and appropriate for all Mesa cards, and is the default. Set to 0 to disable this SSR instance.

out-NN (bit in)

The state of this SSR instance's NNth output. Set to 0 to make the output pins act like an open switch (no connection), set to 1 to make them act like a closed switch.

invert-NN (bit in)

Inverts the state of this SSR instance's NNth output, defaults to 0. When invert-NN is set to 1, SSR output NN is closed when the out-NN pin is 0 and open when the out-NN pin is 1.

271.3.22. OutM Simple output module

OutMs have names like "**hm2_<BoardType>.<BoardNum>.OutM.<Instance>**". *Instance* is a two-digit number that corresponds to the HostMot2 OutM instance number. There are *num_outms* instances, starting with 00.

Each instance has between 1 and 32 output pins.

Pins:**out-NN (bit in)**

The sets the state of this OutM instance's NNth output. Normally the output pin follows the state of this pin but may be inverted by the invert-nn HAL pin.

invert-NN (bit in)

Inverts the state of the this OutM instance's NNth output, defaults to 0. When invert-NN is set to 1, OutM output NN is high when the out-NN pin is 0 and low when the out-NN pin is 1.

271.3.23. xy2mod

The xy2mod is a xy2-100 galvanometer interface. It supports 16 and 18 bit data modes and includes parabolic interpolation to provide position updates between servo thread invocations.

Pins:

posx_cmd, posy_cmd (float in)

X and Y position commands. Full scale is +-posn_scale default full scale (set by posx_scale and posy_scale) is +- 1

posx_fb, posy_fb (float out)

X and Y position feedback. Full scale is +-posN_scale default full scale is +- 1. This is feedback from the interpolator not the galvanometer.

velx_cmd, vely_cmd (float in)

X and Y velocity commands in units of fullscale_position/second

velx_fb, vely_fb (float out)

X and Y velocity feedback in units of fullscale_position/second

accx_cmd, accy_cmd (float in)

X and Y acceleration commands in units of fullscale_position/second²

posx_scale, posy_scale (float in)

This sets the full scale range of the position command and feedback, default is +- 1.0.

enable (bit in)

When False, output data is 0, all interpolator values are set to 0 and overflow flags are cleared. Must be True for normal operation.

controlx, controly (u32 in)

These set the galvanometer control bits. There 3 bits per channel in 16 bit mode but just 1 control bit in 18 bit mode, so values from 0..7 are valid in 16 bit mode but only 0 and 4 are valid in 18 bit mode.

commandx, commandy (u32 in)

These set the raw 16 bit data sent to the galvanometer in command mode.

commandmodex, commandmodey (bit in)

When set, these enable the command mode where 16 bit command data is sent to the galvanometer.

18bitmodex, 18bitmodey (bit in)

When True, these enable the 18 bit data mode for the respective channel.

posx-overflow, posy-overflow (bit out)

When true, these indicate an attempted position move beyond the full scale value.

velx-overflow, vely-overflow (bit out)

When True, these indicate an attempted velocity update move beyond the full scale value.

status (u32 out)

Raw 16 bit return status from galvanometer.

Parameters:**read-timer-number (s32 in)**

Selects the DPLL timer number for pre-read sampling of the position and velocity registers. If set to -1, pre-read sampling is disabled.

write-timer-number (s32 in)

Selects the DPLL timer number for post write update of the position and velocity registers. If set to -1, post write update is disabled.

271.3.24. Watchdog

The HostMot2 firmware may include a watchdog Module; if it does, the hostmot2 driver will use it. The HAL representation of the watchdog is named "**hm2_<BoardType>.<BoardNum>.watchdog**".

The watchdog starts out asleep and inactive. Once you access the board the first time by running the hm2 write() HAL function (see below), the watchdog wakes up. From then on it must be petted periodically or it will bite. Pet the watchdog by running the hm2 write() HAL function.

When the watchdog bites, all the board's I/O pins are disconnected from their Module instances and become high-impedance inputs (pulled high), and all communication with the board stops. The state of the HostMot2 firmware modules is not disturbed (except for the configuration of the I/O pins). Encoder instances keep counting quadrature pulses, and pwm- and step-generators keep generating signals (which are **not** relayed to the motors, because the I/O pins have become inputs).

Resetting the watchdog (by clearing the has_bit pin, see below) resumes communication and resets the I/O pins to the configuration chosen at load-time.

If the firmware includes a watchdog, the following HAL objects will be exported:

Pins:**has_bit (bit in/out)**

True if the watchdog has bit, False if the watchdog has not bit. If the watchdog has bit and the has_bit bit is True, the user can reset it to False to resume operation.

Parameters:**timeout_ns (u32 read/write)**

Watchdog timeout, in nanoseconds. This is initialized to 5,000,000 (5 milliseconds) at module load time. If more than this amount of time passes between calls to the hm2 write() function, the watchdog will bite.

271.3.25. Raw Mode

If the "enable_raw" config keyword is specified, some extra debugging pins are made available in HAL. The raw mode HAL pin names begin with "**hm2_<BoardType>.<BoardNum>.raw**".

With Raw mode enabled, a user may peek and poke the firmware from HAL, and may dump the internal state of the hostmot2 driver to the syslog.

Pins:

read_address (u32 in)

The bottom 16 bits of this is used as the address to read from.

read_data (u32 out)

Each time the hm2_read() function is called, this pin is updated with the value at .read_address.

write_address (u32 in)

The bottom 16 bits of this is used as the address to write to.

write_data (u32 in)

This is the value to write to .write_address.

write_strobe (bit in)

Each time the hm2_write() function is called, this pin is examined. If it is True, then value in .write_data is written to the address in .write_address, and .write_strobe is set back to False.

dump_state (bit in/out)

This pin is normally False. If it gets set to True, the hostmot2 driver will write its representation of the board's internal state to the syslog, and set the pin back to False.

271.3.26. Setting up Smart Serial devices

See setsserial(9) for the current way to set smart-serial eeprom parameters.

271.4. FUNCTIONS

hm2_<BoardType>.<BoardNum>.read-request

On boards with long turn around time for reads (at the time of writing, this applies only to ethernet boards), this function sends a read request. When multiple boards are used, this can reduce the servo thread execution time. In this case, the appropriate thread order would be

```
addf hm2_7i80.0.read-request
addf hm2_7i80.1.read-request
addf hm2_7i80.0.read
addf hm2_7i80.1.read
```

which causes the read request to be sent to board 1 before waiting for the response to the read request to arrive from board 0.

hm2_<BoardType>.<BoardNum>.read

This reads the encoder counters, stepgen feedbacks, and GPIO input pins from the FPGA.

hm2_<BoardType>.<BoardNum>.write

This updates the PWM duty cycles, stepgen rates, and GPIO outputs on the FPGA. Any changes to configuration pins such as stepgen timing, GPIO inversions, etc., are also effected by this function.

hm2_<BoardType>.<BoardNum>.read_gpio

Read the GPIO input pins. Note that the effect of this function is a subset of the effect of the .read() function described above. Normally only .read() is used. The only reason to call this function is if you want to do GPIO things in a faster-than-servo thread. (This function is not available on the 7I43 due to limitations of the EPP bus.)

hm2_<BoardType>.<BoardNum>.write_gpio

Write the GPIO control registers and output pins. Note that the effect of this function is a subset of the effect of the .write() function described above. Normally only .write() is used. The only reason to call this function is if you want to do GPIO things in a faster-than-servo thread. (This function is not available on the 7I43 due to limitations of the EPP bus.)

hm2_<BoardType>.<BoardNum>.trigger-encoders

This function will only appear if the firmware contains a BiSS, Fanuc or SSI encoder module and if the firmware does not contain a hm2dp11 module (qv) or if the modparam contains num_dp11s=0. This function should be inserted first in the thread so that the encoder data is ready when the main **hm2_*XXXX.NN.read*** function runs. An error message will be printed if the encoder read is not finished in time. It may be possible to avoid this by increasing the data rate. If the problem persists and if "stale" data is acceptable then the function may be placed later in the thread, allowing a full servo cycle for the data to be transferred from the devices. If available it is better to use the synchronous hm2dp11 triggering function.

271.5. SEE ALSO

hm2_pci(9), hm2_eth(9), hm2_spi(9), hm2_rpspi(9), hm2_7i43(9), hm2_7i90(9)

Mesa's documentation for the Anything I/O boards, at <https://www.mesanet.com>.

271.6. LICENSE

GPL

Chapter 272. HYPOT(9)

272.1. NAME

hypot - Three-input hypotenuse (Euclidean distance) calculator

272.2. SYNOPSIS

loadrt hypot [**count**=*N*|**names**=*name1*[,*name2*...]]

272.3. FUNCTIONS

hypot.*N*

272.4. PINS

hypot.*N*.in0 float in

hypot.*N*.in1 float in

hypot.*N*.in2 float in

hypot.*N*.out float out

$$\text{out} = \text{sqrt}(\text{in0}^2 + \text{in1}^2 + \text{in2}^2)$$

272.5. AUTHOR

Jeff Epler

272.6. LICENSE

GPL

Chapter 273. ILOWPASS(9)

273.1. NAME

`ilowpass` - Low-pass filter with integer inputs and outputs

273.2. SYNOPSIS

loadrt ilowpass [**count**=*N* | **names**=*name1* [, *name2* ...]]

273.3. DESCRIPTION

While it may find other applications, this component was written to create smoother motion while jogging with an MPG.

In a machine with high acceleration, a short jog can behave almost like a step function. By putting the **ilowpass** component between the MPG encoder **counts** output and the axis **jog-counts** input, this can be smoothed.

Choose **scale** conservatively so that during a single session there will never be more than about $2e9$ / **scale** pulses seen on the MPG. Choose **gain** according to the smoothing level desired. Divide the **axis.N.jog-scale** values by **scale**.

273.4. FUNCTIONS

ilowpass.N

Update the output based on the input and parameters.

273.5. PINS

ilowpass.N.in s32 in

ilowpass.N.out s32 out

out tracks **in** * **scale** through a low-pass filter of **gain** per period.

273.6. PARAMETERS

ilowpass.N.scale float rw (default: 1024)

A scale factor applied to the output value of the low-pass filter.

ilowpass.N.gain float rw (default: .5)

Together with the period, sets the rate at which the output changes. Useful range is between 0 and 1, with higher values causing the input value to be tracked more quickly. For instance, a setting of 0.9 causes the output value to go 90% of the way towards the input value in each period.

273.7. AUTHOR

Jeff Epler

273.8. LICENSE

GPL

Chapter 274. INTEG(9)

274.1. NAME

integ - Integrator with gain pin and windup limits

274.2. SYNOPSIS

loadrt integ [count=*N* | names=*name1*[,*name2*...]]

274.3. FUNCTIONS

integ.*N*

274.4. PINS

integ.*N*.in float in

integ.*N*.gain float in (default: *1.0*)

integ.*N*.out float out

The discrete integral of *gain* * *in* since *reset* was deasserted

integ.*N*.reset bit in

When asserted, set out to 0

integ.*N*.max- float in (default: *1e20*)

integ.*N*.min- float in (default: *-1e20*)

274.5. AUTHOR

Jeff Epler

274.6. LICENSE

GPL

Chapter 275. INVERT(9)

275.1. NAME

invert - Compute the inverse of the input signal

275.2. SYNOPSIS

The output will be the mathematical inverse of the input, ie **out** = 1 / **in**. The parameter **deadband** can be used to control how close to 0 the denominator can be before the output is clamped to 0. **deadband** must be at least 1e-8, and must be positive.

275.3. FUNCTIONS

invert.*N*

275.4. PINS

invert.*N*.in float in

Analog input value

invert.*N*.out float out

Analog output value

275.5. PARAMETERS

invert.*N*.deadband float rw

The **out** will be zero if **in** is between -**deadband** and +**deadband**.

275.6. SEE ALSO

```
invert(9), div2(9)
```

275.7. AUTHOR

Stephen Wille Padnos

275.8. LICENSE

GPL

Chapter 276. JOINT_AXIS_MAPPER(9)

276.1. NAME

joint_axis_mapper - Translate faults from Joint to Axis

276.2. SYNOPSIS

loadrt joint_axis_mapper

276.3. DESCRIPTION

By default *joint.n.amp-fault-in* triggers an error message *Joint n amplifier fault*.

This component is a translation layer that shows an additional message *{L} Axis fault detected*, with *{L}* being the axis letter associated with the faulted joint.

Usage example: `loadrt joint_axis_mapper coord=xyz addf joint_axis_mapper servo-thread`

`net x-fault joint.0.faulted ⇒ jam.x-fault net y-fault joint.1.faulted ⇒ jam.y-fault net z-fault joint.2.faulted ⇒ jam.z-fault`

276.4. FUNCTIONS

joint-axis-mapper.-

276.5. PINS

joint-axis-mapper.dummy bit out

halcompile requires at least one halpin

276.6. LICENSE

GPL

Chapter 277. JOYHANDLE(9)

277.1. NAME

joyhandle - sets nonlinear joypad movements, deadbands and scales

277.2. SYNOPSIS

loadrt joyhandle [**count**=*N* | **names**=*name1*[,*name2*...]]

277.3. DESCRIPTION

The component **joyhandle** uses the following formula for a non linear joypad movements:

$$y = (\text{scale} * (a * x^{\text{power}} + b * x)) + \text{offset}$$

The parameters *a* and *b* are adjusted in such a way, that the function starts at (*deadband*,*offset*) and ends at (1,*scale*+*offset*).

Negative values will be treated point symmetrically to origin. Values $-\text{deadband} < x < +\text{deadband}$ will be set to zero.

Values $x > 1$ and $x < -1$ will be skipped to $\pm(\text{scale}+\text{offset})$. Invert transforms the function to a progressive movement.

With power one can adjust the nonlinearity (default = 2). Default for deadband is 0.

Valid values are: $\text{power} \geq 1.0$ (reasonable values are 1.x .. 4-5, take higher power-values for higher deadbands (>0.5), if you want to start with a nearly horizontal slope), $0 \leq \text{deadband} < 0.99$ (reasonable 0.1).

An additional offset component can be set in special cases (default = 0).

All values can be adjusted for each instance separately.

277.4. FUNCTIONS

joyhandle.N

277.5. PINS

joyhandle.N.in float in

joyhandle.N.out float out

277.6. PARAMETERS

joyhandle.N.power float rw (default: 2.0)

joyhandle.N.deadband float rw (default: 0.)

joyhandle.N.scale float rw (default: 1.)

joyhandle.N.offset float rw (default: 0.)

joyhandle.N.inverse bit rw (default: 0)

277.7. AUTHOR

Paul Willutzki

277.8. LICENSE

GPL

Chapter 278. kins(9)

278.1. NAME

kins, genhexkins, genserkins, maxkins, pentakins, pumakins, rotatekins, scarakins, tripodkins, trivkins - kinematics definitions for LinuxCNC

278.2. SYNOPSIS

loadrt trivkins (use for most cartesian machines)

loadrt corexykins

loadrt genhexkins

loadrt genserkins

loadrt lineardeltakins (see separate manpage)

loadrt matrixkins

loadrt maxkins

loadrt pentakins

loadrt pumakins

loadrt rosekins

loadrt rotarydeltakins

loadrt rotatekins

loadrt scarakins

loadrt tripodkins

loadrt xyzab_tdr_kins

loadrt xyzac-trt-kins

loadrt xyzbc-trt-kins

loadrt 5axiskins

278.3. DESCRIPTION

Rather than exporting HAL pins and functions, these components provide the forward and inverse kinematics definitions for LinuxCNC.

278.3.1. trivkins - generalized trivial kinematics

Joint numbers are assigned sequentially according to the axis letters specified with the **coordinates=** parameter.

If the coordinates= parameter is omitted, joint numbers are assigned **sequentially** to every known axis letter ("xyzabcuvw").

Example: loadrt trivkins

Assigns all axis letters to joint numbers in sequence: x==joint0, y==joint1, z==joint2 a==joint3, b==joint4, c==joint5 u==joint6, v==joint7, w==joint8

Example: loadrt trivkins coordinates=xyz

Assigns: x==joint0, y==joint1, z==joint2

Example: loadrt trivkins coordinates=xz

Assigns: x==joint0, z==joint1

Example: loadrt trivkins coordinates=xyzy

Assigns: x==joint0, y0==joint1, z==joint2, y1==joint3:

The default kinematics type is **KINEMATICS_IDENTITY**. GUIs may provide special features for configurations using this default kinematics type. For instance, the AXIS GUI automatically handles joint and world mode operations so that the distinctions between joints and axes are not visible to the operator. This is feasible since there is an exact correspondence between a joint number and its matching axis letter.

The kinematics type can be set with the **kinstype=** parameter

kinstype=1 for **KINEMATICS_IDENTITY** (default if **kinstype=** omitted)

+

kinstype=[b|B] for **KINEMATICS_BOTH**

+

kinstype=[f|F] for **KINEMATICS_FORWARD_ONLY**

+

kinstype=[i|I] for **KINEMATICS_INVERSE_ONLY**

+

Example: loadrt trivkins coordinates=xyz kinstype=b

Use **kinstype=B** (**KINEMATICS_BOTH**) for configurations that need to move joints independently (joint mode) or as coordinated (teleop) movements in world coordinates.

When using the axis gui with **KINEMATICS_BOTH**, the **\$** key is used to toggle between joint and teleop (world) modes.

An axis letter may be used more than once (**duplicated**) to assign multiple joints to a single axis coordinate letter.

Example: coordinates=xyyzw kinstype=B

Assigns: x==joint0, y==joint1 AND joint2, z==joint3, w==joint4

The above example illustrates a gantry configuration that uses **duplicated** coordinate letters to indicate that two joints (joint1 and joint2) move a single axis (y). Using kinstype=**B** allows the configuration to be toggled between joint and world modes of operation. Homing configuration options are available to synchronize the final homing move for selected joints—see the documentation for **Homing Configuration**.

NOTES for duplicated coordinates

When **duplicated** coordinate letters are used, specifying KINEMATICS_BOTH (kinstype=**B**) allows a gui to support jogging of each individual joint in **joint mode**. **Caution** is required for machines where the movement of a single joint (in a set specified by a **duplicated** coordinate letter) can lead to gantry racking or other unwanted outcomes. When the kinstype= parameter is omitted, operation defaults to KINEMATICS_IDENTITY (kinstype=**1**) and a gui may allow jogging based upon a selected axis coordinate letter (or by a keyboard key) before homing is completed and the machine is still in **joint mode**. The joint selected will depend upon the gui implementation but typically only one of the multiple joints in the set will jog. Consequently, specifying KINEMATICS_BOTH is recommended as it enables support for unambiguous, independent jogging of each individual joint. Machines that implement homing for all joints (including the provisions for synchronizing the final homing move for multiple joints) may be homed at machine startup and automatically switch to **world** mode where per-coordinate jogging is available.

278.3.2. corexykins - CoreXY Kinematics

$$X = 0.5 * (JOINT_0 + JOINT_1)$$

$$Y = 0.5 * (JOINT_0 - JOINT_1)$$

$$Z = JOINT_2$$

[KINS]JOINTS= must specify 3 or more joints (maximum 9). If enabled by the number of [KINS]JOINTS= specified, JOINT_3,4,5,6,7,8 correspond to coordinates A,B,C,U,V,W respectively.

278.3.3. genhexkins - Hexapod Kinematics

Gives six degrees of freedom in position and orientation (XYZABC). The location of base and platform joints is defined by HAL parameters. The forward kinematics iteration is controlled by HAL pins. (See switchkins documentation for more info)

genhexkins.base.N.x

+

genhexkins.base.N.y

+

genhexkins.base.N.z

+

genhexkins.platform.N.x

+

genhexkins.platform.N.y

+

genhexkins.platform.N.z

Parameters describing the N th joint's coordinates.

genhexkins.spindle-offset

Added to all joints Z coordinates to change the machine origin. Facilitates adjusting spindle position.

genhexkins.base-n.N.x

+

genhexkins.base-n.N.y

+

genhexkins.base-n.N.z

+

genhexkins.platform-n.N.x

+

genhexkins.platform-n.N.y

+

genhexkins.platform-n.N.z

Parameters describing unit vectors of N th joint's axis. Used to calculate strut length correction for cardanic joints and non-captive actuators.

genhexkins.screw-lead

Lead of strut actuator screw, positive for the right-handed thread. Default is 0 (strut length correction disabled).

genhexkins.correction.N

Current values of strut length correction for non-captive actuators with cardanic joints.

genhexkins.convergence-criterion

Minimum error value that ends iterations with converged solution.

genhexkins.limit-iterations

Limit of iterations, if exceeded iterations stop with no convergence.

genhexkins.max-error

Maximum error value, if exceeded iterations stop with no convergence.

genhexkins.last-iterations

Number of iterations spent for the last forward kinematics solution.

genhexkins.max-iterations

Maximum number of iterations spent for a converged solution during current session.

genhexkins.tool-offset

TCP offset from platform origin along Z to implement RTCP function. To avoid joints jump change tool offset only when the platform is not tilted.

278.3.4. genserkins - generalized serial kinematics

Kinematics that can model a general serial-link manipulator with up to 6 angular joints. See switchkins documentation for more info.

The kinematics use Denavit-Hartenberg definition for the joint and links. The DH definitions are the ones used by John J Craig in "Introduction to Robotics: Mechanics and Control" The parameters for the manipulator are defined by HAL pins. Note that this uses a convention sometimes known as "Modified DH Parameters" and this must be borne in mind when setting up the system. <https://w.wiki/NcY>

genserkins.A-N

+

genserkins.ALPHA-N

+

genserkins.D-N

Parameters describing the N^{th} joint's geometry.

278.3.5. matrixkins - Calibrated kinematics for 3-axis cartesian machines

Similar to trivkins, but allows calibrating out small imperfections in axis alignment. See matrixkins(9) man page for detailed instructions.

278.3.6. maxkins - 5-axis kinematics example

Kinematics for Chris Radek's tabletop 5 axis mill named *max* with tilting head (B axis) and horizontal rotary mounted to the table (C axis). Provides UVW motion in the rotated coordinate system. The source file, maxkins.c, may be a useful starting point for other 5-axis systems.

278.3.7. pentakins - Pentapod Kinematics

Gives five degrees of freedom in position and orientation (XYZAB). The location of base and effector joints is defined by HAL parameters. The forward kinematics iteration is controlled by HAL pins.

pentakins.base.N.x

+

pentakins.base.N.y

+

pentakins.base.N.z

+

pentakins.effector.N.r

+

pentakins.effector.N.z

Parameters describing the N^{th} effector joint's radius and axial position.

pentakins.convergence-criterion

Minimum error value that ends iterations with converged solution.

pentakins.limit-iterations

Limit of iterations, if exceeded iterations stop with no convergence.

pentakins.max-error

Maximum error value, if exceeded iterations stop with no convergence.

pentakins.last-iterations

Number of iterations spent for the last forward kinematics solution.

pentakins.max-iterations

Maximum number of iterations spent for a converged solution during current session.

pentakins.tool-offset

TCP offset from effector origin along Z to implement RTCP function. To avoid joints jump change tool offset only when the platform is not tilted.

278.3.8. pumakins - kinematics for puma typed robots

Kinematics for a puma-style robot with 6 joints:

pumakins.A2

+

pumakins.A3

+

pumakins.D3

+

pumakins.D4

Describe the geometry of the robot

278.3.9. rosekins - kinematics for a rose engine using

a transverse, longitudinal, and rotary joint (3 joints)

278.3.10. rotarydeltakins - kinematics for a rotary delta machine

Rotary delta robot (3 Joints)

278.3.11. rotatekins - Rotated Kinematics

The X and Y axes are rotated 45 degrees compared to the joints 0 and 1.

278.3.12. scarakins - kinematics for SCARA-type robots

(See switchkins documentation for more info)

scarakins.D1

Vertical distance from the ground plane to the center of the inner arm.

scarakins.D2

Horizontal distance between joint[0] axis and joint[1] axis, i.e., the length of the inner arm.

scarakins.D3

Vertical distance from the center of the inner arm to the center of the outer arm. May be positive or negative depending on the structure of the robot.

scarakins.D4

Horizontal distance between joint[1] axis and joint[2] axis, i.e., the length of the outer arm.

scarakins.D5

Vertical distance from the end effector to the tooltip. Positive means the tooltip is lower than the end effector, and is the normal case.

scarakins.D6

Horizontal distance from the centerline of the end effector (and the joints 2 and 3 axis) and the tooltip. Zero means the tooltip is on the centerline. Non-zero values should be positive, if negative they introduce a 180 degree offset on the value of joint[3].

278.3.13. tripodkins - Tripod Kinematics

The joints represent the distance of the controlled point from three predefined locations (the motors), giving three degrees of freedom in position (XYZ)

tripodkins.Bx

+

tripodkins.Cx

+

tripodkins.Cy

The location of the three motors is (0,0), (Bx,0), and (Cx,Cy)

278.3.14. xyzac-trt-kins - 5 Axis mill (Table Rotary/Tilting)

Tilting table (A) and horizontal rotary mounted to table (C axis) (5 Joints 0:x,1:y,2:z,3:a,4:c) with provisions to switch between xyzac and trivkins kinematic types. The joint mapping can be altered with the coordinates parameter in the same way as supported by trivkins. (See switchkins documentation for more info)

278.3.15. xyzbc-trt-kins - 5 Axis mill (Table Rotary/Tilting)

(5 Joints 0:x,1:y,2:z,3:b,4:c) with provisions to switch between xyzbc and trivkins kinematic types. The joint mapping can be altered with the coordinates parameter in the same way as supported by trivkins. (See switchkins documentation for more info)

278.3.16. 5axiskins - 5 Axis bridge mill

XYZBCW—the W coordinate values (typically used for tool motion) are incorporated into XYZ positioning. (Only 5 joints are needed by the kinematics module but an additional joint is needed to display W values). (See switchkins documentation for more info)

By default, 5axiskins uses coordinates XYZBCW assigned consecutively to joints 0..5. The module coordinates parameter may be used to assign multiple joints to an axis letter and/or to assign joints to additional coordinates A,U,V with a one-to-one correspondence to the assigned joints. Example: XYZBCWYV (8 joints total numbered 0..7) uses two joints for Y (joints 1,6) and adds an additional coordinate V that has a one-to-one relation to joint 7.

Note: These kinematics may be used with the vismach 5axisgui providing that the joint-letter assignments agree with the default ordering expected by it (XYZBCW -> joints 0..5)

278.4. SEE ALSO

For additional information, see following subsections of the section *Advanced Topics* of the LinuxCNC documentation:

- **Kinematics**
- **5-Axis Kinematics**
- **Switchable Kinematics**

The HAL component **userkins.comp** is a template for making kinematic modules using the halcompile tool. The unmodified template supports an identity xyz configuration that uses 3 joints. See **userkins(9)** for more info.

Chapter 279. KNOB2FLOAT(9)

279.1. NAME

knob2float - Convert counts (probably from an encoder) to a float value

279.2. SYNOPSIS

loadrt knob2float [count=*N* | names=*name1*[,*name2*...]]

279.3. FUNCTIONS

knob2float.*N*

279.4. PINS

knob2float.*N*.counts s32 in

Counts

knob2float.*N*.enable bit in

When TRUE, output is controlled by count, when FALSE, output is fixed

knob2float.*N*.scale float in

Amount of output change per count

knob2float.*N*.out float out

Output value

279.5. PARAMETERS

knob2float.*N*.max-out float rw (default: 1.0)

Maximum output value, further increases in count will be ignored

knob2float.*N*.min-out float rw (default: 0.0)

Minimum output value, further decreases in count will be ignored

279.6. AUTHOR

John Kasunich

279.7. LICENSE

GPL

Chapter 280. LASERPOWER(9)

280.1. NAME

laserpower - Scales laser power output based upon velocity input power and distance to go

280.2. SYNOPSIS

loadrt laserpower [count=*N* | names=*name1* [, *name2* ...]]

280.3. DESCRIPTION

During operation laserpower must be scaled proportionally to actual velocity vs commanded velocity. This prevents uneven laser power when rounding tight corners.

Component laserpower operates in 2 modes. Raster mode (when **raster_mode**=1). During raster mode **raster_power** is scaled between **min_power** and **max_power** proportionally to **req_velocity** and **cur_velocity**.

Velocity mode (when **raster_mode**=0). During velocity mode **vector_power** corresponds to the power level desired when reaching the next control point. This allows vector power to be scaled along moves.

280.4. FUNCTIONS

laserpower.*N*

280.5. PINS

laserpower.*N*.min-power float in

Minimum allowed power level.

laserpower.*N*.max-power float in

Maximum allowed power level

laserpower.*N*.req-velocity float in

Requested motion velocity

laserpower.*N*.cur-velocity float in

Current motion velocity

laserpower.*N*.enabled bit in

True when laser output enabled

laserpower.*N*.raster-mode bit in

false for vector mode, true for raster mode

laserpower.N.raster-power float in

Requested power level during raster operations

laserpower.N.vector-power float in

Requested power level during vector operations

laserpower.N.distance-to-go float in

Distance to go of current move

laserpower.N.power float out

Current power level command

laserpower.N.command-power float out

Commanded power before normalization and velocity scaling

laserpower.N.start-power float out

Power level when reqPower last changed

laserpower.N.start-distance float out

Distance amount when reqPower last changed

laserpower.N.vel-scale float out

Velocity related scaling component.

280.6. LICENSE

GPL

Chapter 281. LATENCYBINS(9)

281.1. NAME

latencybins - comp utility for scripts/latency-histogram

281.2. SYNOPSIS

loadrt latencybins [**count**=*N* | **names**=*name1* [, *name2* ...]]

281.3. DESCRIPTION

Read **availablebins** pin for the number of bins available. Set the **maxbinnumber** pin for the number of \pm bins. Ensure **maxbinnumber** \leq **availablebins**.

For **maxbinnumber** = *N*, the bins are numbered:

- -*N* ... 0 ... +*N* bins
(the -0 bin is not populated)
(total effective bins = 2 * **maxbinnumber** + 1)

Set **nsbinsize** pin for the binsize (ns).

Iterate:

- Set **index** pin to a bin number: $0 \leq \text{index} \leq \text{maxbinnumber}$.
- Read check pin and verify that check pin == **index** pin.
- Read output pins:
 - **pbinvalue** is count for bin = +**index**
 - **nbinvalue** is count for bin = -**index**
 - **pextra** is count for all bins > **maxbinnumber**
 - **nextra** is count for all bins < **maxbinnumber**
 - **latency-min** is max negative latency
 - **latency-max** is max positive latency

If **index** is out of range (**index** < 0 or **index** > **maxbinnumber**) then **pbinvalue** = **nbinvalue** = -1. The reset pin may be used to restart.

The latency pin outputs the instantaneous latency.

Maintainers note: hardcoded for MAXBINNUMBER==1000

281.4. FUNCTIONS

latencybins.N

281.5. PINS

latencybins.N.maxbinnumber s32 in (default: 1000)

latencybins.N.index s32 in

latencybins.N.reset bit in

latencybins.N.nsbinsize s32 in

latencybins.N.check s32 out

latencybins.N.latency s32 out

latencybins.N.latency-max s32 out

latencybins.N.latency-min s32 out

latencybins.N.pbinvalue s32 out

latencybins.N.nbinvalue s32 out

latencybins.N.pextra s32 out

latencybins.N.nextra s32 out

latencybins.N.variance s32 out

latencybins.N.availablebins s32 out (default: 1000)

281.6. AUTHOR

Dewey Garrett

281.7. LICENSE

GPL

Chapter 282. LATENCYBINSTREAM(9)

282.1. NAME

latencybinstream - comp utility for scripts/latency-histogram.py

282.2. SYNOPSIS

loadrt latencybinstream [**count**=*N* | **names**=*name1* [, *name2* ...]] [**keys**=*value* [, *value* ...]]

keys

Stream shmem unique key for each instance

282.3. DESCRIPTION

Calculates a latency histogram of the thread the component is running in. The histogram data is sent in a HAL stream for maximum transfer speed and streaming prevents any RT to non-RT data race condition.

Read the **availablebins** pin for the number of bins available. Set the **maxbinnumber** pin for the number of \pm bins. Ensure **maxbinnumber** \leq **availablebins**.

For **maxbinnumber** = *N*, the bins are numbered:

- -*N* ... 0 ... +*N* bins
(total effective bins = $2 * \text{maxbinnumber} + 1$)
- Any data outside the bins is counted and available at the start and end of the data stream (ntail and ptail, see stream format below).

Set **nsbinsize** pin for the bin width in nanoseconds (ns).

Stream format and how to obtain the histogram data:

- Set **stream** pin to high
- Read the fifo data when it becomes available. The data streamed has the following sequence:
 - *ntail* -*N* ... 0 ... *N* *ptail*
 - This gives $2 * \text{maxbinnumber} + 1 + 2$ values streamed
- Read the latency pins that reflect the values at the time when **stream** was asserted.
- Set **stream** pin to low

The reset pin may be used to restart. Note that the reset pin is set to high at startup. You must set it to low before data collection begins.

The **latency** pin outputs the instantaneous latency. The average, minimum, maximum and variance available from pins **latency-avg**, **latency-min**, **latency-max** and **variance** respectively, but they are only updated on the rising edge of the **stream** pin.

Maintainers note: hardcoded for MAXBINNUMBER==1000

282.4. FUNCTIONS

latencybinstream.N

282.5. PINS

latencybinstream.N.maxbinnumber s64 in (default: 1000)

Number of active bins N on each side (-N...0...N).

latencybinstream.N.nsbinsize s64 in

Time interval for one bin in nanoseconds (ns).

latencybinstream.N.reset bit in (default: 1)

Reset state and bins.

latencybinstream.N.stream bit in (default: 0)

Set to high to stream all bins and tails on rising edge.

latencybinstream.N.stream-error bit out

Set if the data stream did not fit and was never sent.

latencybinstream.N.latency s64 out

Last measured latency.

latencybinstream.N.latency-avg s64 out

Average latency (when stream pin is asserted).

latencybinstream.N.latency-max s64 out

Maximum latency (when stream pin is asserted).

latencybinstream.N.latency-min s64 out

Minimum latency (when stream pin is asserted).

latencybinstream.N.variance s64 out

Variance of the latency (when stream pin is asserted).

latencybinstream.N.stream-time s64 out

The time it took for the stream data to be pushed out in nanoseconds (ns).

latencybinstream.N.availablebins s64 out (default: 1000)

Hard-coded maximum number of bins. You need to change the source code if you need more bins.

282.6. AUTHOR

B.Stultiens

282.7. LICENSE

GPL

Chapter 283. lcd(9)

283.1. NAME

lcd - Stream HAL data to an LCD screen

283.2. SYNOPSIS

loadrt lcd fmt_strings=""Plain Text %4.4f\nAnd So on|Second Page, Next Inst""

283.3. FUNCTIONS

lcd (requires a floating-point thread).

All LCD instances are updated by the same function.

283.4. PINS

lcd.NN.out (u32) out

The output byte stream is sent via this pin. One character is sent every thread invocation. There is no handshaking provided.

lcd.NN.page.PP.arg.NN (float/s32/u32/bit) in

The input pins have types matched to the format string specifiers.

lcd.NN.page_num (u32) in

Selects the page number. Multiple layouts may be defined, and this pin switches between them.

lcd.NN.contrast (float) in

Attempts to set the contrast of the LCD screen using the byte sequence ESC C and then a value from 0x20 to 0xBF (matching the Mesa 7173). The value should be between 0 and 1.

283.5. PARAMETERS

lcd.NN.decimal-separator (u32) rw

Sets the decimal separator used for floating point numbers. The default value is 46 (0x2E) which corresponds to ".". If a comma is required then set this parameter to 44 (0x2C).

283.6. DESCRIPTION

lcd takes format strings much like those used in C and many other languages in the printf and scanf functions and their variants.

The component was written specifically to support the Mesa 7173 pendant controller, however, it may be of use streaming data to other character devices and, as the output format mimics the ADM3 terminal

format, it could be used to stream data to a serial device. Perhaps even a genuine ADM3. The strings contain a mixture of text values (which are displayed directly), "escaped" formatting codes and numerical format descriptors. For a detailed description of formatting codes see: <https://en.wikipedia.org/wiki/Printf>.

The component can be configured to display an unlimited number of differently-formatted pages, which may be selected with a HAL pin.

283.6.1. Escaped codes

- `\n` Inserts a clear-to-end, carriage return and line feed character. This will still linefeed and clear even if an automatic wrap has occurred (lcd has no knowledge of the width of the lcd display). To print in the rightmost column it is necessary to allow the format to wrap and omit the `\n` code.
- `\t` Inserts a tab (actually 4 spaces in the current version rather than a true tab).
- `\NN` inserts the character defined by the hexadecimal code *NN*. As the `,` character is used in the format string to separate LCD instances it must be represented by `\2C` in the format string (the decimal separator is handled differently).
- `\\` Inserts a literal `\`.

283.6.2. Numerical formats

lcd differs slightly from the standard printf conventions. One significant difference is that width limits are strictly enforced to prevent the LCD display wrapping and spoiling the layout. The field width includes the sign character so that negative numbers will often have a smaller valid range than positive. Numbers that do not fit in the specified width are displayed as a line of asterisks (`*****`).

Each format begins with a `"%"` symbol. (For a literal `%` use `"%%"`). Immediately after the `%` the following modifiers may be used:

- `" "` (space) Pad the number to the specified width with spaces. This is the default and is not strictly necessary.
- `"0"` Pad the number to the specified width with the numeral 0.
- `"+"` Force display of a `+` symbol before positive numbers. This (like the `-` sign) will appear immediately to the left of the digits for a space-padded number and in the extreme left position for a 0-padded number.
- `"1234567890"` A numerical entry (other than the leading 0 above) defines the total number of characters to display including the decimal separator and the sign. Whilst this number can be as many digits as required, the maximum field width is 20 characters. The inherent precision of the "double" data type means that more than 14 digits will tend to show errors in the least significant digits. The integer data types will never fill more than 10 decimal digits.

Following the width specifier should be the decimal specifier. This can only be a full-stop character (`.`) as the comma (`,`) is used as the instance separator. Currently lcd does not access the locale information to determine the correct separator but the **decimal-separator** HAL parameter can be used to choose any desired separator.

Following the decimal separator should be a number that determines how many places of decimals to display. This entry is ignored in the case of integer formats.

All the above modifiers are optional, but to specify a decimal precision the decimal point must precede the precision, e.g., as in "%.3f". The default decimal precision is 4.

The numerical formats supported are:

- **%f %F** (for example, %+09.3f): These create a floating-point type HAL pin. The example would be displayed in a 9-character field, with 3 places of decimals, as a decimal separator, padded to the left with 0s and with a sign displayed for both positive and negative. Conversely a plain %f would be 6 digits of decimal, variable format width, with a sign only shown for negative numbers. Both %f and %F create exactly the same format.
- **%i %d** (For example %+ 4d): Creates a signed (s32) HAL pin. The example would display the value at a fixed 4 characters, space padded, width including the "+" giving a range of +999 to -999. %i and %d create identical output.
- **%u** (for example %08u): Creates an unsigned (u32) HAL pin. The example would be a fixed 8 characters wide, padded with zeros.
- **%x, %X**: Creates an unsigned (u32) HAL pin and displays the value in Hexadecimal. Both %x and %X display capital letters for digits ABCDEF. A width may be specified, though the u32 HAL type is only 8 hex digits wide.
- **%o**: Creates an unsigned (u32) pin and displays the value in octal representation.
- **%c**: Creates a u32 HAL pin and displays the character corresponding to the value of the pin. Values less than 32 (space) are suppressed. A width specifier may be used, for example %20c might be used to create a complete line of one character.
- **%b**: This specifier has no equivalent in printf. It creates a bit (boolean) type HAL pin. The b should be followed by two characters and the display will show the first of these when the pin is true, and the second when false. Note that the characters follow, not precede the "b", unlike the case with other formats. The characters may be "escaped" Hex values. For example "%b\FF " will display a solid black block if true, and a space if false and "%b\7F\7E" would display right-arrow for false and left-arrow for true. An unexpected value of *E* indicates a formatting error.

Pages: The page separator is the "|" (pipe) character (if the actual character is needed then \7C may be used). A "Page" in this context refers to a separate format which may be displayed on the same display.

Instances: The instance separator is the comma. This creates a completely separate lcd instance, for example to drive a second lcd display on the second 7I73. The use of comma to separate instances is built in to the modparam reading code so not even escaped commas "\", can be used. A comma may be displayed by using the \2C sequence.

283.7. AUTHOR

Andy Pugh

283.8. LICENSE

GPL

Chapter 284. LED_DIM(9)

284.1. NAME

led_dim - HAL component for dimming LEDs

284.2. SYNOPSIS

loadrt led_dim [count=*N*|names=*name1*[,*name2*...]]

284.3. DESCRIPTION

Component for LED dimming according to human perception of brightness of light. .LP The output is calculated using the CIE 1931 formula.

284.4. FUNCTIONS

led-dim.*N*

Update the output value

284.5. PINS

led-dim.*N*.in float in

Brightness input value → 0 to 1

led-dim.*N*.out float out

Luminance output value → 0 to 1

284.6. AUTHOR

Alexander Rössler

284.7. LICENSE

GPL

Chapter 285. LIMIT1(9)

285.1. NAME

limit1 - Limit the output signal to fall between min and max

285.2. SYNOPSIS

loadrt limit1 [**count**=*N* | **names**=*name1* [, *name2* ...]]

285.3. FUNCTIONS

limit1.N

285.4. PINS

limit1.N.in float in

limit1.N.out float out

limit1.N.min- float in (default: *-1e20*)

limit1.N.max- float in (default: *1e20*)

285.5. AUTHOR

Jeff Epler

285.6. LICENSE

GPL

Chapter 286. LIMIT2(9)

286.1. NAME

limit2 - Limit the output signal to fall between min and max and limit its slew rate to less than maxv per second. When the signal is a position, this means that position and velocity are limited.

286.2. SYNOPSIS

loadrt limit2 [**count**=*N*|**names**=*name1*[,*name2*...]]

286.3. FUNCTIONS

limit2.N

286.4. PINS

limit2.N.in float in

limit2.N.out float out

limit2.N.load bit in

When TRUE, immediately set **out** to **in**, ignoring maxv

limit2.N.min- float in (default: *-1e20*)

limit2.N.max- float in (default: *1e20*)

limit2.N.maxv float in (default: *1e20*)

286.5. AUTHOR

Jeff Epler

286.6. LICENSE

GPL

Chapter 287. LIMIT3(9)

287.1. NAME

limit3 - Follow input signal while obeying limits

287.2. SYNOPSIS

Limit the output signal to fall between min and max, limit its slew rate to less than maxv per second, and limit its second derivative to less than maxa per second squared. When the signal is a position, this means that the position, velocity, and acceleration are limited.

287.3. FUNCTIONS

limit3.N

287.4. PINS

limit3.N.in float in

limit3.N.enable bit in (default: 1)

1: out follows in, 0: out returns to 0 (always per constraints)

limit3.N.out float out

limit3.N.load bit in (default: 0)

When TRUE, immediately set **out** to **in**, ignoring maxv and maxa

limit3.N.min- float in (default: $-1e20$)

limit3.N.max- float in (default: $1e20$)

limit3.N.maxv float in (default: $1e20$)

limit3.N.maxa float in (default: $1e7$)

Max Acceleration. Note that the component becomes unstable with maxa greater than about $1e7$ in a 1kHz thread

limit3.N.smooth-steps u32 in (default: 2)

Smooth out acceleration this many periods before reaching input or max/min limit. Higher values avoid oscillation, but will accelerate slightly more slowly.

287.5. AUTHOR

John Kasunich

287.6. LICENSE

GPL

Chapter 288. LIMIT_AXIS(9)

288.1. NAME

limit_axis - Dynamic range based axis limits

288.2. SYNOPSIS

loadrt limit_axis [count=*N* | names=*name1*[,*name2*...]] [**personality**=*P1*[,*P2*...]]

288.3. DESCRIPTION

Limit axis to certain limits at varying inputs.

For example on a spindle with C rotation, to avoid hitting a gantry when the height is above Z-10.

- Use Z axis as feedback
- Use 2 ranges (0,-10) (-10, -40)
- When Z is above 10, C rotation is limited to range 0
- When Z is below 10, C rotation is limited to range 1

Usage:

```
loadrt limit_axis count=3 personality=2,3,2
# or
loadrt limit_axis names=limit_x,limit_y,limit_z personality=2,3,2
```

The **personality** argument defines how many ranges are supported by each instance. Note that no spaces can be used in the **names=** and **personality=** parameters.

Caveats:

- Searches ranges from 0 to 9 and will take the first range that matches
- Ranges are inclusive **min_range** ≤ feedback ≤ **max_range**
- Max can not be less than minimum for any group
- **sticky** indicates, to not check other ranges if the feedback is still in the current range
- **enable** allows for a range to be turned on/off, for cases such as avoiding a tool changer, but allowing sometimes

288.4. FUNCTIONS

limit-axis.*N*

288.5. PINS

limit-axis.N.error-no-range bit out

error pin indicating that no range matches the fb

limit-axis.N.min-output float out

Minimum limit output

limit-axis.N.max-output float out

Maximum limit output

limit-axis.N.fb float in

Feedback pin, the value of this pin determines which range is active

limit-axis.N.current-range u32 out

Indicates which range is currently active

limit-axis.N.min-limit-MM float in (MM=00..personality)

The array of minimum limits to select from

limit-axis.N.max-limit-MM float in (MM=00..personality)

The array of maximum limits

limit-axis.N.min-range-MM float in (MM=00..personality)

Defines the range of values with which the fb is compared to set the range

limit-axis.N.max-range-MM float in (MM=00..personality)

Defines the range of values with which the fb is compared to set the range

limit-axis.N.enable-MM bit in (MM=00..personality)

Used to enable and disable a specific range

limit-axis.N.sticky-MM bit in (MM=00..personality)

Used to make specific range *sticky* or not

limit-axis.N.error-range-MM bit out (MM=00..personality) (default: 1)

Error bit indicating that the fb pin falls outside all ranges

limit-axis.N.error-limit-MM bit out (MM=00..personality) (default: 1)

Error bit indicating that the max limit is not larger than the min limit

288.6. AUTHOR

Chad Woitas

288.7. LICENSE

GPL

Chapter 289. LINCURVE(9)

289.1. NAME

lincurve - one-dimensional lookup table

289.2. SYNOPSIS

loadrt lincurve [**count**=*N* | **names**=*name1*[,*name2*...]] [**personality**=*P1*[,*P2*...]]

289.3. DESCRIPTION

This component can be used to map any floating-point input to a floating-point output. Typical uses would include linearisation of thermocouples, defining PID gains that vary with external factors or to substitute for any mathematical function where absolute accuracy is not required.

The component can be thought of as a 2-dimensional graph of points in (x,y) space joined by straight lines. The input value is located on the x axis, followed up until it touches the line, and the output of the component is set to the corresponding y-value.

The (x,y) points are defined by the x-val-NN and y-val-NN parameters which need to be set in the HAL file using "setp" commands.

The maximum number of (x,y) points supported is 16.

For input values less than the x-val-00 breakpoint the y-val-00 is returned. For x greater than the largest x-val-NN the yval corresponding to x-max is returned (ie, no extrapolation is performed.)

Sample usage: loadrt lincurve count=3 personality=4,4,4 for a set of three 4-element graphs.

289.4. FUNCTIONS

lincurve.N

289.5. PINS

lincurve.N.in- float in

The input value

lincurve.N.out- float out

The output value

lincurve.N.out-io float io

The output value, compatible with PID gains

289.6. PARAMETERS

lincurve.N.x-val-MM float rw (MM=00..personality)

axis breakpoints

lincurve.N.y-val-MM float rw (MM=00..personality)

output values to be interpolated

289.7. AUTHOR

Andy Pugh

289.8. LICENSE

GPL

Chapter 290. lineardeltakins(9)

290.1. NAME

lineardeltakins - Kinematics for a linear delta robot

290.2. SYNOPSIS

loadrt lineardeltakins

290.3. KINEMATICS

The kinematics model is appropriate for a rostock/kossel-style design with three joints arranged in an equilateral triangle. (0,0) is always the center of the working volume. Joint 0 is at (0,R) and subsequent joints are 120 degrees clockwise (note that joint 0 is not at zero radians). The length of the arm is L .

Joints 0-2 are the linear carriages. Axes ABC and UVW are passed through unchanged in joints 3-8, so that e.g., A can still be used to control an extruder.

290.4. PINS

lineardeltakins.R float in

Effective diameter of the platform.

The radius R is different than the distance from the center of the table to the center of the belt/smooth rod/extrusion that the joints ride on. In RepRap delta parlance, R is DELTA_RADIUS which is computed as

$\text{DELTA_SMOOTH_ROD_OFFSET} - \text{DELTA_EFFECTOR_OFFSET} - \text{DELTA_CARRIAGE_OFFSET}$.

lineardeltakins.L float in

Length of the rod connecting the carriage to the effector. In RepRap delta parlance, L is DELTA_DIAGONAL_ROD.

290.5. NOTES

The R and L values can be adjusted while LinuxCNC is running. However, doing so while in coordinated mode will lead to a step change in joint position, which generally will trigger a following error if in joint mode with machine on.

Chapter 291. LOGIC(9)

291.1. NAME

logic - LinuxCNC HAL component providing configurable logic functions

291.2. SYNOPSIS

loadrt logic [**count**=*N* | **names**=*name1*[,*name2*...]] **personality**=*0xXXXX*[,*0xXXXX*...]

count

The number of logical gates.

names

The named logical gates to create.

personality

Comma separated list of hexadecimal number. Each number defines the behaviour of the individual logic gate. The list must have the same number of personalities as the N count.

291.3. DESCRIPTION

General 'logic function' component. Can perform 'and', 'or', 'nand', 'nor' and 'xor' of up to 16 inputs.

Determine the proper value for 'personality' by adding the inputs and outputs then convert to hex:

- The number of input pins, usually from 2 to 16
- 256 (0x100) if the 'and' output is desired
- 512 (0x200) if the 'or' output is desired
- 1024 (0x400) if the 'xor' (exclusive or) output is desired
- 2048 (0x800) if the 'nand' output is desired
- 4096 (0x1000) if the 'nor' output is desired

Outputs can be combined, for example 2 + 256 + 1024 = 1282 converted to hex would be 0x502 and would have two inputs and have both 'xor' and 'and' outputs.

291.4. FUNCTIONS

logic.N

Read the inputs and toggle the output bit.

291.5. PINS

logic.N.in-MM bit in (MM=00..personality & 0xff)

logic.N.and bit out [if personality & 0x100]

logic.N.or bit out [if personality & 0x200]

logic.N.xor bit out [if personality & 0x400]

logic.N.nand bit out [if personality & 0x800]

logic.N.nor bit out [if personality & 0x1000]

291.6. EXAMPLES

This is an OR circuit connected to three different signals, two inputs named sig-in-0 and sig-in-1, and one output named sig-out. First the circuit is defined, then its function is connected to the servo real time thread, last, its pins are connected to the wanted signals.

```
loadrt logic count=1 personality=0x202
addf logic.0 servo-thread
net sig-in-0 => logic.0.in-00
net sig-in-1 => logic.0.in-01
net sig-out  <= logic.0.or
```

This is a named AND circuit with two inputs and one output.

```
loadrt logic names=both personality=0x102
addf both servo-thread
net sig-in-0 => both.in-00
net sig-in-1 => both.in-01
net sig-out  <= both.and
```

291.7. SEE ALSO

and2(9), lut5(9), not(9), or2(9), xor2(9)

291.8. AUTHOR

Jeff Epler

291.9. LICENSE

GPL

Chapter 292. LOWPASS(9)

292.1. NAME

lowpass - Low-pass filter

292.2. SYNOPSIS

loadrt lowpass [**count**=*N*|**names**=*name1*[,*name2*...]]

292.3. FUNCTIONS

lowpass.N

292.4. PINS

lowpass.N.in float in

lowpass.N.out float out

out += (in - out) * gain

lowpass.N.load bit in

When TRUE, copy **in** to **out** instead of applying the filter equation.

292.5. PARAMETERS

lowpass.N.gain float rw

292.6. NOTES

gain pin setting

The digital filter implemented is equivalent to a unity-gain continuous-time single-pole low-pass filter that is preceded by a zero-order-hold and sampled at a fixed period. For a pole at **-a** (radians/seconds) the corresponding continuous-time lowpass filter LaPlace transfer function is:

$$H(s) = a/(s + a)$$

For a sampling period **T** (seconds), the gain for this HAL lowpass component is:

$$\text{gain} = 1 - e^{(-a * T)}$$

e = 2.71828 [https://en.wikipedia.org/wiki/E_\(mathematical_constant\)](https://en.wikipedia.org/wiki/E_(mathematical_constant))

Examples: T = 0.001 seconds (typical servo thread period) a = (2 * pi * 100) (**100Hz** bandwidth single pole)
gain = **0.466**

```
T = 0.001 seconds (typical servo thread period)
a = (2 * pi * 10)      ( *10Hz* bandwidth single pole)
gain = *0.0609*
```

```
T = 0.001 seconds (typical servo thread period)
a = (2 * pi * 1)       ( *1Hz* bandwidth single pole)
gain = *0.0063*
```

292.7. AUTHOR

Jeff Epler

292.8. LICENSE

GPL

Chapter 293. LUT5(9)

293.1. NAME

lut5 - Arbitrary 5-input logic function based on a look-up table

293.2. SYNOPSIS

loadrt lut5 [**count**=*N* | **names**=*name1* [, *name2* ...]]

293.3. DESCRIPTION

lut5 constructs a logic function with up to 5 inputs using a **look-up table**. The value for **function** can be determined by writing the truth table, and computing the sum of **all** the **weights** for which the output value would be **TRUE**. The weights are hexadecimal not decimal so hexadecimal math must be used to sum the weights. A wiki page has a calculator to assist in computing the proper value for function.

<https://wiki.linuxcnc.org/cgi-bin/wiki.pl?Lut5>

Note that LUT5 will generate any of the 4,294,967,296 logical functions of 5 inputs so **AND**, **OR**, **NAND**, **NOR**, **XOR** and every other combinatorial function is possible.

293.3.1. Example Functions

A 5-input **and** function is TRUE only when all the inputs are true, so the correct value for **function** is **0x80000000**.

A 2-input **or** function would be the sum of **0x2** + **0x4** + **0x8**, so the correct value for **function** is **0xe**.

A 5-input **or** function is TRUE whenever any of the inputs are true, so the correct value for **function** is **0xffffffe**. Because every weight except **0x1** is true the function is the sum of every line except the first one.

A 2-input **xor** function is TRUE whenever exactly one of the inputs is true, so the correct value for **function** is **0x6**. Only **in-0** and **in-1** should be connected to signals, because if any other bit is **TRUE** then the output will be **FALSE**.

Weights for each line of truth table					
Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	Weight
0	0	0	0	0	0x00000001
0	0	0	0	1	0x00000002
0	0	0	1	0	0x00000004
0	0	0	1	1	0x00000008

Weights for each line of truth table					
0	0	1	0	0	0x00000010
0	0	1	0	1	0x00000020
0	0	1	1	0	0x00000040
0	0	1	1	1	0x00000080
0	1	0	0	0	0x00000100
0	1	0	0	1	0x00000200
0	1	0	1	0	0x00000400
0	1	0	1	1	0x00000800
0	1	1	0	0	0x00001000
0	1	1	0	1	0x00002000
0	1	1	1	0	0x00004000
0	1	1	1	1	0x00008000
1	0	0	0	0	0x00010000
1	0	0	0	1	0x00020000
1	0	0	1	0	0x00040000
1	0	0	1	1	0x00080000
1	0	1	0	0	0x00100000
1	0	1	0	1	0x00200000
1	0	1	1	0	0x00400000
1	0	1	1	1	0x00800000
1	1	0	0	0	0x01000000
1	1	0	0	1	0x02000000
1	1	0	1	0	0x04000000
1	1	0	1	1	0x08000000
1	1	1	0	0	0x10000000
1	1	1	0	1	0x20000000
1	1	1	1	0	0x40000000
1	1	1	1	1	0x80000000

293.4. FUNCTIONS

lut5.N

293.5. PINS

lut5.N.in-0 bit in

lut5.N.in-1 bit in

lut5.N.in-2 bit in

lut5.N.in-3 bit in

lut5.N.in-4 bit in

lut5.N.out bit out

293.6. PARAMETERS

lut5.N.function u32 rw

293.7. SEE ALSO

and(9), **logic(9)**, **not(9)**, **or2(9)**, **xor2(9)**.

293.8. AUTHOR

Jeff Epler

293.9. LICENSE

GPL

Chapter 294. MAJ3(9)

294.1. NAME

maj3 - Compute the majority of 3 inputs

294.2. SYNOPSIS

loadrt maj3 [**count**=*N* | **names**=*name1*[,*name2*...]]

294.3. FUNCTIONS

maj3.N

294.4. PINS

maj3.N.in1 bit in

maj3.N.in2 bit in

maj3.N.in3 bit in

maj3.N.out bit out

294.5. PARAMETERS

maj3.N.invert bit rw

294.6. AUTHOR

Jeff Epler

294.7. LICENSE

GPL

Chapter 295. MATCH8(9)

295.1. NAME

match8 - 8-bit binary match detector

295.2. SYNOPSIS

loadrt match8 [count=*N* | names=*name1*[,*name2*...]]

295.3. FUNCTIONS

match8.*N*

295.4. PINS

match8.*N*.in bit in (default: *TRUE*)

cascade input - if false, output is false regardless of other inputs

match8.*N*.a0 bit in

match8.*N*.a1 bit in

match8.*N*.a2 bit in

match8.*N*.a3 bit in

match8.*N*.a4 bit in

match8.*N*.a5 bit in

match8.*N*.a6 bit in

match8.*N*.a7 bit in

match8.*N*.b0 bit in

match8.*N*.b1 bit in

match8.*N*.b2 bit in

match8.*N*.b3 bit in

match8.*N*.b4 bit in

match8.*N*.b5 bit in

match8.*N*.b6 bit in

match8.*N*.b7 bit in

match8.*N*.out bit out

true only if in is true and a[m] matches b[m] for m = 0 thru 7

295.5. AUTHOR

John Kasunich

295.6. LICENSE

GPL

Chapter 296. matrix_kb(9)

296.1. NAME

matrix_kb - Convert integers to HAL pins. Optionally scan a matrix of I/O ports to create those integers.

296.2. SYNOPSIS

loadrt matrix_kb config=*RxCs,RxCs...* **names**=*name1,name2...*

Creates a component configured for R rows and N columns of matrix keyboard.

If the **s** option is specified then a set of output rows will be cyclically toggled, and a set of input columns will be scanned.

The **names** parameter is optional, but if used then the HAL pins and functions will use the specified names rather than the default ones. This can be useful for readability and 2-pass HAL parsing.

There must be no spaces in the parameter lists.

296.3. DESCRIPTION

This component was written to convert matrix keyboard scancodes into HAL pins. However, it might also find uses in converting integers from 0 to *N* into *N* HAL pins.

The component can work in two ways, and the HAL pins created vary according to mode.

In the default mode the component expects to be given a scan code from a separate driver but could be any integer from any source. Most typically this will be the keypad scancode from a Mesa 7I73. The default codes for keyup and keydown are based on the Mesa 7I73 specification with 0x40 indicating a keydown and 0x80 a keyup event. If using the 7I73 it is important to match the keypad size jumpers with the HAL component. Valid configs for the 7I73 are 4x8 and 8x8. Note that the component will only work properly with the version 12 (0xC) 7I73 firmware. The firmware version is visible on the component parameters in HAL.

In the optional scan-generation mode the **matrix_kb.N.keycode** pin changes to an output pin and a set of output row pins and input column pins are created. These need to be connected to physical inputs and outputs to scan the matrix and return values to HAL. Note the **negative-logic** parameter described below, this will need to be set on the most common forms of inputs which float high when unconnected.

In both modes a set of HAL output pins are created corresponding to each node of the matrix.

296.4. FUNCTIONS

matrix_kb.N

Perform all requested functions. Should be run in a slow thread for effective debouncing.

296.5. PINS

matrix_kb.N.col-CC-in bit in

The input pin corresponding to column C.

matrix_kb.N.key.rRcC bit out

The pin corresponding to the key at row R column C of the matrix.

matrix_kb.N.keycode unsigned in or out, depending on mode

This pin should be connected to the scancode generator if hardware such as a 7173 is being used. In this mode it is an input pin. In the internally-generated scanning mode this pin is an output, but will not normally be connected.

matrix_kb.N.row-RR-out bit out

The row scan drive pins. Should be connected to external hardware pins connected to the keypad.
The row scan drive pins. Should be connected to external hardware pins connected to the keypad.

296.6. PARAMETERS

matrix_kb.N.key_rollover unsigned r/w (default 2)

With most matrix keyboards the scancodes are only unambiguous with 1 or 2 keys pressed. With more keys pressed phantom keystrokes can appear. Some keyboards are optimised to reduce this problem, and some have internal diodes so that any number of keys may be pressed simultaneously. Increase the value of this parameter if such a keyboard is connected, or if phantom keystrokes are more acceptable than only two keys being active at one time.

matrix_kb.N.negative-logic bit r/w (default 1), only in scan mode

When no keys are pressed a typical digital input will float high. The input will then be pulled low by the keypad when the corresponding poll line is low. Set this parameter to 0 if the I/O in use requires one row at a time to be high, and a high input corresponds to a button press.

Chapter 297. MATRIXKINS(9)

297.1. NAME

matrixkins - Calibrated kinematics for 3-axis machines

297.2. SYNOPSIS

loadrt matrixkins [**count**=*N*|**names**=*name1*[,*name2*...]]

297.3. DESCRIPTION

The matrixkins component implements custom kinematics for 3-axis Cartesian machines that allows compensating minor alignment inaccuracies in software.

297.3.1. KINEMATICS MODEL

By default identity matrix is used, which is equal to trivial kinematics:

```
| X_joint |   | 1 0 0 |   | X_axis |
| Y_joint | = | 0 1 0 | * | Y_axis |
| Z_joint |   | 0 0 1 |   | Z_axis |
```

Adjusting the calibration matrix allows compensating out many mechanical issues, including:

1. Scale error of each axis.
2. Perpendicularity between each pair of axes.
3. Parallelism between spindle rotational axis and Z movement.
4. Perpendicularity between spindle rotational axis and X/Y movement.

The matrix coefficients are set by parameters C_xx .. C_zz. For 3 axis machine, the equations become:

```
X_joint = C_xx * X_axis + C_xy * Y_axis + C_xz * Z_axis
Y_joint = C_yx * X_axis + C_yy * Y_axis + C_yz * Z_axis
Z_joint = C_zx * X_axis + C_zy * Y_axis + C_zz * Z_axis
```

If the machine has more than 3 axes, the rest are passed through without adjustment.

297.3.2. CALIBRATION INSTRUCTIONS

For a 3 axis milling machine, the following process can be used to accurately measure and compensate the mechanical alignment.

Tools required:

1. Dial indicator that can be mounted on spindle.

2. Straight rod that can be mounted on spindle.
3. Calipers.

Process:

1. Head tramming

Mechanically tram the spindle to the table surface as well as you can. The perpendicularity of spindle vs. table cannot be compensated in software, and the spindle axis will act as the reference for all further steps.

You can measure the perpendicularity by mounting the dial indicator on the spindle. Search for "mill tramming" online for detailed process.

2. X and Y axis squaring

Cut octagon out of some rigid material. It is best to cut a roughing path first and a thin finishing pass last, to get the best accuracy. Make the octagon as large as your calipers can measure. Before unmounting the workpiece, mark the X and Y directions on it.

Measure width along X and Y axes. If your axis scales are set correctly, they should be identical. If they are not, you can adjust `c[0]` and `c[4]` to compensate. Note that endmill diameter will affect the actual dimensions of the test octagon, but not the ratio between sides.

Measure width along both diagonals. If the X and Y axes are square to each other, the readings should be identical.

To compensate, set $C_{xy} = (B^2 - A^2) / (2 * A * B)$ where A is the diagonal in X+/Y+ direction and B is the diagonal in X+/Y- direction.

This adjusts Y axis direction while keeping X axis as it was. Alternatively you can set `C_yx` to adjust X axis instead. The choice affects alignment with respect to e.g. table slots.

3. X axis squaring to spindle

Mount the dial indicator so that it rotates around the spindle axis, like in tramming measurement. Mark a spot on the table where the indicator touches when it is in positive X direction from spindle center. Zero the dial indicator.

Rotate dial indicator 180 degrees around the spindle. Move X axis in positive direction until the indicator touches the same spot. Ideally indicator reads 0 again.

To compensate, set $C_{zx} = D / X$ where D is the new dial indicator reading, and X is the length moved along X axis.

4. Y axis squaring to spindle

Same as step 3, except move the machine in positive Y direction.

To compensate, set $C_{zy} = D / Y$ where D is the new dial indicator reading, and Y is the length moved.

5. Z axis parallelism to spindle in X direction

Mount straight rod to the spindle. Position dial indicator so that it measures horizontally against the positive X side of the rod, close to the spindle.

Spin the spindle by hand to see if there is any runout. Zero the dial indicator at the midway position.

Raise Z axis until dial indicator measures close to the bottom end of the rod. Spin the spindle by hand and take note of the midway value.

Set $C_{xz} = -X / Z$ where X is the dial indicator difference between bottom and top and Z is the amount you raised the Z axis.

6. Z axis parallelism to spindle in Y direction

Same as step 5, except measure on the positive Y side of the rod.

Set $C_{yz} = -Y / Z$ where Z is the dial indicator difference and Z is the amount you raised the Z axis.

297.3.3. CONFIGURATION FILES

Specify matrixkins in LinuxCNC INI file as:

```
[KINS]
KINEMATICS=matrixkins
```

In your HAL configuration file, set the parameters C_{xx} .. C_{zz} :

```
setp matrixkins.C_xx 1 # X axis scale
setp matrixkins.C_xy 0 # Skew Y axis towards X axis
setp matrixkins.C_xz 0 # Skew Z axis towards X axis
setp matrixkins.C_yx 0 # Skew X axis towards Y axis
setp matrixkins.C_yy 1 # Y axis scale
setp matrixkins.C_yz 0 # Skew Z axis towards Y axis
setp matrixkins.C_zx 0 # Skew X axis towards Z axis
setp matrixkins.C_zy 0 # Skew Y axis towards Z axis
setp matrixkins.C_zz 1 # Z axis scale
```

The parameters can be modified during runtime using halcmd. To avoid sudden movements, it is better to turn off machine power before changes.

If recalibration is performed with already existing calibration being in effect, the adjustment values should be added to the old values instead of replacing them.

297.4. PINS

matrixkins.N.dummy bit out (default: 1)

297.5. SEE ALSO

kins(9)

297.6. LICENSE

GPL

Chapter 298. MAX31855(9)

298.1. NAME

max31855 - Support for the MAX31855 Thermocouple-to-Digital converter using bitbanged spi

298.2. SYNOPSIS

loadrt max31855 [**count**=*N* | **names**=*name1*[,*name2*...]] [**personality**=*P1*[,*P2*...]]

298.3. DESCRIPTION

The component requires at least 3 pins to bitbang spi protocol, for example:

```
loadrt max31855 personality=1

setp hm2_6i25.0.gpio.023.is_output true
setp hm2_6i25.0.gpio.024.is_output true

net spi.clk.in    hm2_6i25.0.gpio.023.out    max31855.0.clk.out
net spi.cs.in     hm2_6i25.0.gpio.024.out    max31855.0.cs.out
net spi.data0.in  hm2_6i25.0.gpio.033.in_not max31855.0.data.0.in

addf max31855.0.bitbang-spi servo-thread
```

The MAX31855 supports a range of -270C to 1800C, however linearization data is only available for the -200C to 1350C range, beyond which raw temperature is returned.

Temperature pins are provided for readings in Celsius, Fahrenheit and Kelvin, temperature values are not updated while a fault condition is present.

The personality parameter is used to indicate the number of sensors. Multiple sensors share the clk and cs pins, but connect to discrete data input pins. A maximum of 15 sensors are supported.

298.4. FUNCTIONS

max31855.N.bitbang-spi

298.5. PINS

max31855.N.data.M.in bit in (**M**=0..(**personality** & 0xf))

Pin(s) connected to data out.

max31855.N.cs.out bit out

Pin connected to cs, pulled low to shift data, pulled high for data refresh.

max31855.N.clk.out bit out

Pin connected to clk.

max31855.N.temp-celsius.M float out (M=0..(personality & 0xf))

Temperature output values in Celsius.

max31855.N.temp-fahrenheit.M float out (M=0..(personality & 0xf))

Temperature in Fahrenheit.

max31855.N.temp-kelvin.M float out (M=0..(personality & 0xf))

Temperature in Kelvin.

max31855.N.fault.M bit out (M=0..(personality & 0xf))

Fault condition detected.

max31855.N.fault-flags.M u32 out (M=0..(personality & 0xf))

Fault flags: 0x1 = open sensor, 0x2 short to gnd, 0x3 short to vcc.

298.6. AUTHOR

Joseph Calderon

298.7. LICENSE

GPL

Chapter 299. MESA_7I65(9)

299.1. NAME

mesa_7i65 - Support for the Mesa 7i65 Octuple Servo Card

299.2. SYNOPSIS

loadrt mesa_7i65

299.3. DESCRIPTION

The component takes parameters in the form of a comma-separated list of bspi (buffered SPI) instance names, for example:

```
loadrt mesa_7i65 bspi_chans=hm2_5i23.0.bspi.0, hm2_5i23.0.bspi.1
```

The BSPI instances are printed to the dmesg buffer during the Hostmot2 setup sequence, one for each bspi instance included in the bitfile loaded to each installed card during the Hostmot2 setup sequence. Type "dmesg" at the terminal prompt to view the output.

299.4. PINS

mesa-7i65.N.analogue.M.out float in (M=0..7)

Analogue output values. The value will be limited to a -1.0 to +1.0 range

mesa-7i65.N.analogue.M.in float out (M=0..7)

Analogue outputs read by the 7i65 (in Volts)

mesa-7i65.N.digital.M.in bit out (M=0..3)

Miscellaneous Digital Inputs

mesa-7i65.N.enable.M.out bit in (M=0..7)

Amplifier-enable control pins

mesa-7i65.N.watchdog.has-bit bit out

Indicates the status of the 7i65 Watchdog (which is separate from the FPGA card watchdog)

299.5. PARAMETERS

mesa-7i65.N.scale-M float rw (M=0..7) (default: 10)

Analogue output scale factor. For example if the scale is 7 then an input of 1.0 will give 7V on the output terminals

mesa-7i65.N.is-bipolar-*M* bit rw (M=0..7) (default: 1)

Set this value to TRUE for a plus/minus "scale" output. Set to 0 for a 0-"scale" output

299.6. AUTHOR

Andy Pugh / Cliff Blackburn

299.7. LICENSE

GPL

Chapter 300. MESA_PKTGYRO_TEST(9)

300.1. NAME

mesa_pktgyro_test - PktUART simple test with Microstrain 3DM-GX3-15 gyro

300.2. SYNOPSIS

loadrt mesa_pktgyro_test [count=*N*|names=*name1*[,*name2*...]]

300.3. DESCRIPTION

This component is written in order to test the PktUART driver for Mesa. It resembles partly Andy Pugh's mesa_uart.comp .

This module uses the names= mode of loadrt declaration to specify which PktUART instances to enable. A check is included to ensure that the count= option is not used instead. For simplicity we test only one PktUART instance, therefore load the component like this:

```
loadrt mesa_uart names=hm2_5i25.0.pktuart.0
```

The PktUART instance names are printed to the dmesg buffer during the Hostmot2 setup sequence, one for each PktUART instance included in the bitfile loaded to each installed card during the Hostmot2 setup sequence. Type "dmesg" at the terminal prompt to view the output. If you want to work with more than one PktUART instance, consult Andy Pugh's mesa_uart.comp

In order to compile and install do:

```
halcompile --install src/hal/drivers/mesa_pktgyro_test.comp
```

The component exports only one function, namely receive, which needs to be added to a realtime thread. To test this component set DEBUG=5 before and execute this HAL script:

```
loadrt hostmot2
loadrt hm2_pci
loadrt mesa_pktgyro_test names=hm2_5i25.0.pktuart.0
loadrt threads name1=test1 period1=10000000
addf hm2_5i25.0.pktuart.0.receive test1
start
```

Check linuxcnc.log for debug output.

300.4. FUNCTIONS

mesa-pktgyro-test.*N*.receive

300.5. PINS

mesa-pktgyro-test.N.rxbytes s32 out

Number of Bytes received or negative Error code

300.6. AUTHOR

Boris Skegin

300.7. LICENSE

GPL

Chapter 301. MESA_UART(9)

301.1. NAME

`mesa_uart` - An example component demonstrating how to access the Hostmot2 UART

301.2. SYNOPSIS

loadrt mesa_uart [**count**=*N*|**names**=*name1*[,*name2*...]]

301.3. DESCRIPTION

This component creates 16 input and 16 output pins. It transmits {name}.N.tx-bytes on the selected UART every thread cycle and reads up to 16 bytes each cycle out of the receive FIFO and writes the values to the associated output pins. {name}.rx-bytes indicates how many pins have been written to. (pins > rx-bytes simply hold their previous value)

This module uses the `names=` mode of `loadrt` declaration to specify which UART instances to enable. A check is included to ensure that the `count=` option is not used instead.

The component takes parameters in the form of a comma-separated list of UART instance names, for example:

```
loadrt mesa_uart names=hm2_5i23.0.uart.0,hm2_5i23.0.uart.7
```

Note that no spaces are allowed in the string unless it is delimited by double quotes.

The UART instance names are printed to the `dmesg` buffer during the Hostmot2 setup sequence, one for each UART instance included in the bitfile loaded to each installed card during the Hostmot2 setup sequence. Type "`dmesg`" at the terminal prompt to view the output.

The component exports two functions, `send` and `receive`, which need to be added to a realtime thread.

The above example will output data on UART channels 0 and 7 and the pins will have the names of the individual UARTS. (they need not be on the same card, or even the same bus).

Read the documents on "halcompile" for help with writing realtime components: <http://linuxcnc.org/docs/html/hal/comp.html>

301.4. FUNCTIONS

`mesa-uart.N.send`

`mesa-uart.N.receive`

301.5. PINS

mesa-uart.N.tx-data-MM u32 in (MM=00..15)

Data to be transmitted

mesa-uart.N.rx-data-MM u32 out (MM=00..15)

Data received

mesa-uart.N.tx-bytes s32 in

Number of bytes to transmit

mesa-uart.N.rx-bytes s32 out

Number of Bytes received

301.6. AUTHOR

Andy Pugh andy@bodgesoc.org

301.7. LICENSE

GPL

Chapter 302. MESSAGE(9)

302.1. NAME

message - Display a message (deprecated, see pushmsg)

302.2. SYNOPSIS

loadrt message [**count**=*N* | **names**=*name1*[,*name2*...]] [**messages**=*value*[,*value*...]]

messages

The messages to display. These should be listed, comma-delimited, inside a single set of quotes. See the "Description" section for an example. If there are more messages than "count" or "names" then the excess will be ignored. If there are fewer messages than "count" or "names" then an error will be raised and the component will not load.

302.3. DESCRIPTION

DEPRECATED: this component only emits at the ERROR level. For new configurations, use **pushmsg**(9) which supports all four **rtapi_print_msg()** levels (error, warning, info, debug), HAL value substitution into the message text, plus the same trigger/force/edge behaviour from a single **loadrt** line.

Allows HAL pins to trigger a message. Example hal commands:

```
loadrt message names=oillow,oilpressure,inverterfail messages="Slideway oil low,No oil
pressure,Spindle inverter fault"
addf oillow servo-thread
addf oilpressure servo-thread
addf inverterfail servo-thread

setp oillow.edge 0 #this pin should be active low
net no-oil classicladder.0.out-21 oillow.trigger
net no-pressure classicladder.0.out-22 oilpressure.trigger
net no-inverter classicladder.0.out-23 inverterfail.trigger
```

When any pin goes active, the corresponding message will be displayed.

302.4. FUNCTIONS

message.*N*

Display a message

302.5. PINS

message.*N*.trigger bit in (default: *FALSE*)

signal that triggers the message

message.N.force bit in (default: *FALSE*)

A FALSE → TRUE transition forces the message to be displayed again if the trigger is active

302.6. PARAMETERS**message.N.edge bit rw (default: *TRUE*)**

Selects the desired edge: FALSE means falling, TRUE means rising

302.7. AUTHOR

Les Newell

302.8. LICENSE

GPL v2

Chapter 303. MILLTURN(9)

303.1. NAME

millturn - Switchable kinematics for a mill-turn machine

303.2. SYNOPSIS

loadrt millturn [**count**=*N* | **names**=*name1*[,*name2*...]]

303.3. DESCRIPTION

This is a switchable kinematics module using 3 cartesian linear joints (XYZ) and 1 angular joint (A). The module contains two kinematic models:

type0 (default) is a mill (XYZA) configuration with A being a rotary axis.

type1 is a turn (Z-YX) configuration with A configured to be a spindle.

For an example configuration, run the sim config: *configs/sim/axis/vismach/millturn/millturn.ini*.

Further explanations can be found in the README in *configs/sim/axis/vismach/millturn*.

millturn.comp was constructed by modifying the template file: userkins.comp.

For more information on how to modify userkins.comp run: \$ man userkins. Also, see additional information inside: *userkins.comp*.

For information on kinematics in general see the kinematics document chapter (docs/src/motion/kinematics.txt) and for switchable kinematics in particular see the switchkins document chapter (docs/src/motion/switchkins.txt)

303.4. FUNCTIONS

millturn.N.fdemo

303.5. PINS

millturn.N.fpin s32 out (default: 0)

pin to demonstrate use of a conventional (non-kinematics) function fdemo

303.6. AUTHOR

David Mueller

303.7. LICENSE

GPL

Chapter 304. MINMAX(9)

304.1. NAME

minmax - Track the minimum and maximum values of the input to the outputs

304.2. SYNOPSIS

loadrt minmax [**count**=*N* | **names**=*name1*[,*name2*...]]

304.3. FUNCTIONS

minmax.N

304.4. PINS

minmax.N.in float in

minmax.N.reset bit in

When reset is asserted, *in* is copied to the outputs

minmax.N.max- float out

minmax.N.min- float out

304.5. AUTHOR

Jeff Epler

304.6. LICENSE

GPL

Chapter 305. motion(9)

305.1. NAME

motion, axis - accepts NML motion commands, interacts with HAL in realtime

305.2. SYNOPSIS

```
loadrt motmod [base_period_nsec=period] [base_thread_fp=0 or 1] [servo_period_nsec=period]
[traj_period_nsec=period] ] [num_dio=[1-64]_ | names_dout=name[,...] names_din=name[,...]]
[num_aio=[1-64] | names_aout=name[,...] _names_ain=*name[,...]] ] [num_spindles=[1-8]]
[unlock_joints_mask=_jointmask] [num_extra_joints=[0-16]]
```

The limits for the following items are compile-time settings:

num_joints

Maximum number of joints is set by **EMCMOT_MAX_JOINTS**.

num_dio

Maximum number of digital IO pins is set by **EMCMOT_MAX_DIO**. Minimum is 1, if **num_dio** is not specified, it defaults to **DEFAULT_DIO**.

names_dout

A comma-separated list of names for digital output pins. This parameter is mutually exclusive with **num_dio**, but can be combined with **names_din**. A maximum of **EMCMOT_MAX_DIO** names can be specified. The default digital output pin has names like **motion.digital-out-00** whereas **names_dout=is-homing-x,is-homing-y** will create the HAL pins **motion.dout-is-homing-x** and **motion.dout-is-homing-y**.

names_din

A comma-separated list of names for digital input pins. This parameter is mutually exclusive with **num_dio**, but can be combined with **names_dout**. A maximum of **EMCMOT_MAX_DIO** names can be specified. The default digital input pin has names like **motion.digital-in-00** whereas **names_din=homed-x,homed-y** will create the HAL pins **motion.din-homed-x** and **motion.din-homed-y**.

num_aio

Maximum number of analog IO pins is set by **EMCMOT_MAX_AIO**. Minimum is 1, if **num_aio** is not specified, it defaults to **DEFAULT_AIO**.

names_aout

A comma-separated list of names for analog output pins. This parameter is mutually exclusive with **num_aio**, but can be combined with **names_ain**. A maximum of **EMCMOT_MAX_AIO** names can be specified. The default analog output pin has names like **motion.analog-out-00** whereas **names_aout=feedrate1,feedrate2** will create the HAL pins **motion.aout-feedrate1** and **motion.aout-feedrate2**.

names_ain

A comma-separated list of names for analog input pins. This parameter is mutually exclusive with **num_aio**, but can be combined with **names_aout**. A maximum of **EMCMOT_MAX_AIO** names can be specified. The default analog input pin has names like **motion.analog-in-00** whereas **names_ain=proxy1,proxy2** will create the HAL pins **motion.ain-proxy1** and **motion.ain-proxy2**.

num_misc_error

Maximum number of extra error inputs is set by **EMCMOT_MAX_MISC_ERRORS**.

names_misc_errors

A comma-separated list of names for extra error inputs. This parameter is mutually exclusive with **num_misc_error**. If using **num_misc_error** the additional error input pins will have names like **motion.misc-error-00** whereas **names_misc_errors=overtemp,undertemp** will create hal pins **motion.err-overtemp** and **motion.err-undertemp**.

num_spindles

Maximum number of spindles is set by **EMCMOT_MAX_SPINDLES**.

Pin names starting with "**joint**" or "**axis**" are read and updated by the motion-controller function.

305.3. DESCRIPTION

NOTE

The **base_thread_fp** parameter is deprecated and ignored. All threads now unconditionally save and restore floating point state. This parameter will be removed in a future version.

These pins and parameters are created by the realtime **motmod** module. This module provides a HAL interface for LinuxCNC's motion planner. Basically **motmod** takes in a list of waypoints and generates a nice blended and constraint-limited stream of joint positions to be fed to the motor drives.

The optional **num_extrajoints** parameter specifies a quantity of joints that participate in homing but are not used by kinematics transformations. After homing, control of an *extra* joint is transferred to a posthome command HAL pin (**joint.N.posthome-cmd**) and the motor feedback value is ignored. *Extra* joints must be managed by independent motion planners/controllers (typically using **limit3** HAL components). Extra joints maybe unhomed only when motion is disabled.

The maximum **num_extrajoints** value is equal to the **num_joints** value. (Note that using the maximum value would allow no operation in world coordinates). The **num_joints** value must be equal to the sum of the number of joints used for kinematics calculations plus the number of *extra* joints.

The **num_joints** parameter is conventionally set using the INI file setting **[KINS]JOINTS=value**. The **num_extrajoints** is set by the additional **motmod** parameter **[EMCMOT]motmod num_extrajoints=value**. HAL pin numbering for all joints is zero based [**0 ... num_joints-1**]. When specified, *extra* joints are assigned the last **num_extrajoints** in the numbering sequence. For example, specifying **[KINS]JOINTS=5** and **[EMCMOT]motmod num_extrajoints=2** for a 3 joint trivkins configuration **[KINS] KINEMATICS=trivkins coordinates=xyz** uses joints 0,1,2 for the kinematic joints and joints 3,4 for the *extra* joints.

An equal number of digital or analog IO pins will always be created. For example, if **names_din** is specified with two pins, two named input and two default named output pins will be created. In cases where **names_dout** is specified with two pins and **names_din** with three pins, two named output and one default named output pin will be created, along with three named input pins. This principle applies independently to digital and analog IO pins, allowing for scenarios such as having three digital pins and two analog pins.

305.4. MOTION PINS

motion-command-handler.time OUT S32

Time (in CPU clocks) for the motion module motion-command-handler

motion-controller.time OUT S32

Time (in CPU clocks) for the motion module motion-controller

motion.adaptive-feed IN FLOAT

When adaptive feed is enabled with M52 P1, the commanded velocity is multiplied by this value. This effect is multiplicative with the NML-level feed override value and motion.feed-hold. Negative values are valid and will run the G-code path in reverse.

motion.analog-in-NN IN FLOAT

These pins are used by M66 Enn wait-for-input mode.

motion.analog-out-NN OUT FLOAT

These pins are used by M67-68.

motion.coord-error OUT BIT

TRUE when motion has encountered an error, such as exceeding a soft limit

motion.coord-mode OUT BIT

TRUE when motion is in "coordinated mode", as opposed to "teleop mode"

motion.current-vel OUT FLOAT

Current cartesian velocity

motion.digital-in-NN IN BIT

These pins are used by M66 Pnn wait-for-input mode.

motion.digital-out-NN OUT BIT

These pins are controlled by the M62 through M65 words.

motion.distance-to-go OUT FLOAT

Distance remaining in the current move

motion.enable IN BIT

If this bit is driven FALSE, motion stops, the machine is placed in the "machine off" state, and a message is displayed for the operator. For normal motion, drive this bit TRUE.

motion.eoffset-active OUT BIT

Indicates external offsets are active (non-zero)

motion.eoffset-limited OUT BIT

Indicates motion with external offsets was limited by a soft limit constraint ([`AXIS_L`]`MIN_LIMIT`,`MAX_LIMIT`).

motion.feed-hold IN BIT

When Feed Stop Control is enabled with M53 P1, and this bit is TRUE, the feed rate is set to 0.

Note: feed-hold applies to G-code commands — not jogs.

motion.feed-inhibit IN BIT

When this pin is TRUE, machine motion is inhibited for G-code commands.

If the machine is performing a spindle synchronized move when this pin goes TRUE, the spindle synchronized motion will finish, and any following moves will be inhibited (this is to prevent damage to the machine, the tool, or the work piece).

If the machine is in the middle of a (non-spindle synchronized) move when this pin goes TRUE, the machine will decelerate to a stop at the maximum allowed acceleration rate.

Motion resumes when this pin goes FALSE.

Note: feed-inhibit applies to G-code commands — not jogs.

motion.feed-upm OUT FLOAT

Current feed rate in G-code program units per minute for `motion.motion-type feed(2)` and `arc(3)`. Value is the G-code program F value multiplied by the current feed override value and the `motion.adaptive-feed` setting (if M52 active). Value is zero if `motion.feed-hold` or `motion.feed-inhibit` are asserted. If units (G20 or G21) are not specified in the G-code file then units will be the last units used.

motion.feed-inches-per-minute OUT FLOAT

Current feed rate in inches per minute for `motion.motion-type feed(2)` and `arc(3)`. Value is the inch equivalent of the G-code program F value multiplied by the current feed override value and the `motion.adaptive-feed` setting (if M52 active). Value is zero if `motion.feed-hold` or `motion.feed-inhibit` are asserted.

motion.feed-inches-per-second OUT FLOAT

Current feed rate in inches per second for `motion.motion-type feed(2)` and `arc(3)`. Value is the inch equivalent of the G-code program F value multiplied by the current feed override value and the `motion.adaptive-feed` setting (if M52 active). Value is zero if `motion.feed-hold` or `motion.feed-inhibit` are asserted.

motion.feed-mm-per-minute OUT FLOAT

Current feed rate in mm per minute for `motion.motion-type feed(2)` and `arc(3)`. Value is the mm equivalent of the G-code program F value multiplied by the current feed override value and the

motion.adaptive-feed setting (if M52 active). Value is zero if motion.feed-hold or motion.feed-inhibit are asserted.

motion.feed-mm-per-second OUT FLOAT

Current feed rate in mm per second for motion.motion-type feed(2) and arc(3). Value is the mm equivalent of the G-code program F value multiplied by the current feed override value and the motion.adaptive-feed setting (if M52 active). Value is zero if motion.feed-hold or motion.feed-inhibit are asserted.

motion.homing-inhibit IN BIT

If this bit is TRUE, initiation of any joint homing move (including "Home All") is disallowed and an error is reported. By default, homing is allowed in joint mode whenever motion is enabled.

motion.is-all-homed OUT BIT

TRUE if all active joints is homed.

motion.jog-inhibit IN BIT

If this bit is TRUE, jogging of any joint or axis is disallowed and an error is reported.

motion.jog-stop IN BIT

If any jog is active when the pin state changes to TRUE then that jog will be stopped following the associated acceleration values.

motion.jog-stop-immediate IN BIT

If any jog is active when the pin state changes to TRUE then that jog will be stopped immediately.

motion.jog-is-active OUT BIT

TRUE if any joint or axis is jogging.

motion.in-position OUT BIT

TRUE if the machine is in position (i.e., not currently moving towards the commanded position).

motion.misc-error-NN IN BIT

Extra error inputs for faults such as over-temperature sensors, low coolant warnings, custom HAL component errors. If driven TRUE this will disable a machine. Similar to spindle.amp-fault-in.

motion.motion-enabled OUT BIT

+

motion.motion-type OUT S32

These values are from src/emc/nml_intf/motion_types.h:

```
0: Idle (no motion)
```

```
1: Traverse
```

2: Linear feed

3: Arc feed

4: Tool change

5: Probing

6: Rotary unlock for traverse

motion.on-soft-limit OUT BIT

motion.probe-input IN BIT

G38.n uses the value on this pin to determine when the probe has made contact. TRUE for probe contact closed (touching), FALSE for probe contact open.

motion.program-line OUT S32

The current program line while executing. Zero if not running or between lines while single stepping.

motion.requested-vel OUT FLOAT

The current requested velocity in user units per second. This value is the F-word setting from the G-code file, possibly reduced to accommodate machine velocity and acceleration limits. The value on this pin does not reflect the feed override or any other adjustments.

motion.servo.last-period OUT U32

The number of CPU clocks between invocations of the servo thread. Typically, this number divided by the CPU speed gives the time in seconds, and can be used to determine whether the realtime motion controller is meeting its timing constraints

motion.switchkins-type IN float

Kinematics modules that define the functions kinematicsSwitchable() and kinematicsSwitch() receive the **integer** value of this pin to select the machine kinematics functions. Extra G-code commands may be required to synchronize task and motion before and after changes to the pin value.

motion.teleop-mode OUT BIT

Motion mode is teleop (axis coordinate jogging available).

motion.tooloffset.L OUT FLOAT

Current tool offset for each axis where (**L** is the axis letter, one of: **x y z a b c u v w**)

motion.tp-reverse OUT BIT

Trajectory planning is reversed (reverse run)

305.4.1. Interpreter Metadata Pins

These pins provide geometric intent and interpreter state for the segment of motion currently being

executed. Unlike standard position feedback, these values are synchronized with the trajectory planner's execution point.

Interpreter Status Pins

- `motion.interp.line-number` (s32, out)
The current G-code line number being executed.
- `motion.interp.motion-type` (s32, out)
The type of motion currently in progress:
 - 0: None
 - 1: Rapid (G0)
 - 2: Feed (G1)
 - 3: Arc (G2, G3)
 - 4: Tool Change/Other
- `motion.interp.feedrate` (float, out)
The interpreted feedrate for the current segment in units per minute.

Interpreter Geometric Pins

- `motion.interp.heading` (float, out)
The XY plane heading of the current linear move in degrees. Measured counter-clockwise from the +X axis (0 to 360). This could be used to control a tangential knife.
- `motion.interp.arc-radius` (float, out)
The radius of the current circular move. This value is 0.0 during linear moves. This could be used to modify plasma cutting parameters based on the arc radius and when hole cutting.
- `motion.interp.arc-center-x` (float, out)
The absolute X-coordinate of the center point for the current arc. 0 if in YZ plane
- `motion.interp.arc-center-y` (float, out)
The absolute Y-coordinate of the center point for the current arc. 0 if in XZ plane
- `motion.interp.arc-center-z` (float, out)
The absolute Y-coordinate of the center point for the current arc if in XZ or YZ plane.
- `motion.interp.normal-heading` (float, out)
the heading from the current point back to the arc centre for the current arc.
- `motion.interp.iscircle` (bit, out)
True if the current arc is a full circle and not a helix.

NOTE

These pins represent the **commanded geometric intent** from the interpreter and are updated in real-time as each motion segment is consumed by the trajectory planner.

305.5. AXIS PINS

(L is the axis letter, one of: **x y z a b c u v w**)

axis.L.eoffset OUT FLOAT

Current external offset.

axis.L.eoffset-clear IN BIT

Clear external offset request

axis.L.eoffset-counts IN S32

Counts input for external offset. The eoffset-counts are transferred to an internal register. The applied external offset is the product of the register counts and the eoffset-scale value. The register is **reset to zero at each machine startup**. If the machine is turned off with an external offset active, the eoffset-counts pin should be set to zero before restarting.

axis.L.eoffset-enable IN BIT

Enable for external offset (also requires INI file setting for [AXIS_L]OFFSET_AV_RATIO)

axis.L.eoffset-request OUT FLOAT

Debug pin for requested external offset.

axis.L.eoffset-scale IN FLOAT

Scale for external offset.

axis.L.jog-accel-fraction IN FLOAT

Sets acceleration for wheel jogging to a fraction of the INI max_acceleration for the axis. Values greater than 1 or less than zero are ignored.

axis.L.jog-counts IN S32

Connect to the "counts" pin of an external encoder to use a physical jog wheel.

axis.L.jog-enable IN BIT

When TRUE (and in manual mode), any change to "jog-counts" will result in motion. When false, "jog-counts" is ignored.

axis.L.jog-scale IN FLOAT

Sets the distance moved for each count on "jog-counts", in machine units.

axis.L.jog-vel-mode IN BIT

When FALSE (the default), the jogwheel operates in position mode. The axis will move exactly jog-scale units for each count, regardless of how long that might take. When TRUE, the wheel operates in velocity mode - motion stops when the wheel stops, even if that means the commanded motion is not completed.

axis.L.kb-jog-active OUT BIT

(free planner axis jogging active (keyboard or halui))

axis.L.pos-cmd OUT FLOAT

The axis commanded position. There may be several offsets between the axis and motor coordinates: Backlash compensation, screw error compensation, and home offsets. External offsets are reported separately (axis.L.eoffset).

axis.L.teleop-pos-cmd OUT FLOAT**axis.L.teleop-tp-enable OUT BIT**

TRUE when the "teleop planner" is enabled for this axis.

axis.L.teleop-vel-cmd OUT FLOAT

The axis's commanded velocity.

axis.L.teleop-vel-lim OUT FLOAT

The velocity limit for the teleop planner.

axis.L.wheel-jog-active OUT BIT

+

305.6. JOINT PINS

N is the joint number (0 ... *num_joints*-1)

Note: Pins marked **(DEBUG)** serve as debugging aids and are subject to change or removal at any time.

joint.N.acc-cmd OUT FLOAT (DEBUG)

The joint's commanded acceleration.

joint.N.active OUT BIT (DEBUG)

TRUE when this joint is active.

joint.N.amp-enable-out OUT BIT

TRUE if the amplifier for this joint should be enabled.

joint.N.amp-fault-in IN BIT

Should be driven TRUE if an external fault is detected with the amplifier for this joint.

joint.N.backlash-corr OUT FLOAT (DEBUG)

Backlash or screw compensation raw value.

joint.N.backlash-filt OUT FLOAT (DEBUG)

Backlash or screw compensation filtered value (respecting motion limits).

joint.N.backlash-vel OUT FLOAT (DEBUG)

Backlash or screw compensation velocity.

joint.N.coarse-pos-cmd OUT FLOAT (DEBUG)

joint.N.error OUT BIT (DEBUG)

TRUE when this joint has encountered an error, such as a limit switch closing.

joint.N.f-error OUT FLOAT (DEBUG)

The actual following error.

joint.N.f-error-lim OUT FLOAT (DEBUG)

The following error limit.

joint.N.f-errored OUT BIT (DEBUG)

TRUE when this joint has exceeded the following error limit.

joint.N.faulted OUT BIT (DEBUG)

joint.N.free-pos-cmd OUT FLOAT (DEBUG)

The "free planner" commanded position for this joint.

joint.N.free-tp-enable OUT BIT (DEBUG)

TRUE when the "free planner" is enabled for this joint.

joint.N.free-vel-lim OUT FLOAT (DEBUG)

The velocity limit for the free planner.

joint.N.home-state OUT S32 (DEBUG)

homing state machine state

joint.N.home-sw-in IN BIT

Should be driven TRUE if the home switch for this joint is closed.

joint.N.homed OUT BIT (DEBUG)

TRUE if the joint has been homed.

joint.N.homing OUT BIT

TRUE if the joint is currently homing.

joint.N.in-position OUT BIT (DEBUG)

TRUE if the joint is using the "free planner" and has come to a stop.

joint.N.index-enable IO BIT

Should be attached to the index-enable pin of the joint's encoder to enable homing to index pulse.

joint.N.is-unlocked IN BIT

Indicates joint is unlocked (see JOINT UNLOCK PINS).

joint.N.jog-accel-fraction IN FLOAT

Sets acceleration for wheel jogging to a fraction of the INI max_acceleration for the joint. Values greater than 1 or less than zero are ignored.

joint.N.jog-counts IN S32

Connect to the "counts" pin of an external encoder to use a physical jog wheel.

joint.N.jog-enable IN BIT

When TRUE (and in manual mode), any change to "jog-counts" will result in motion. When false, "jog-counts" is ignored.

joint.N.jog-scale IN FLOAT

Sets the distance moved for each count on "jog-counts", in machine units.

joint.N.jog-vel-mode IN BIT

When FALSE (the default), the jogwheel operates in position mode. The joint will move exactly jog-scale units for each count, regardless of how long that might take. When TRUE, the wheel operates in velocity mode - motion stops when the wheel stops, even if that means the commanded motion is not completed.

joint.N.kb-jog-active OUT BIT (DEBUG)

(free planner joint jogging active (keyboard or halui))

joint.N.motor-offset OUT FLOAT (DEBUG)

joint motor offset established when joint is homed.

joint.N.motor-pos-cmd OUT FLOAT

The commanded position for this joint.

joint.N.motor-pos-fb IN FLOAT

The actual position for this joint.

joint.N.neg-hard-limit OUT BIT (DEBUG)

The negative hard limit for the joint

joint.N.neg-lim-sw-in IN BIT

Should be driven TRUE if the negative limit switch for this joint is tripped.

joint.N.pos-cmd OUT FLOAT

The joint (as opposed to motor) commanded position. There may be several offsets between the joint and motor coordinates: backlash compensation, screw error compensation, and home offsets.

joint.N.pos-fb OUT FLOAT

The joint feedback position. This value is computed from the actual motor position minus joint offsets. Useful for machine visualization.

joint.N.pos-hard-limit OUT BIT (DEBUG)

The positive hard limit for the joint.

joint.N.pos-lim-sw-in IN BIT

Should be driven TRUE if the positive limit switch for this joint is tripped.

joint.N.unlock OUT BIT

TRUE if the axis is a locked joint (typically a rotary) and a move is commanded (see JOINT UNLOCK PINS).

joint.N.vel-cmd OUT FLOAT (DEBUG)

The joint's commanded velocity.

joint.N.jerk-cmd OUT FLOAT (DEBUG)

The joint's commanded jerk (rate of change of acceleration). Only active when S-curve trajectory planning is enabled (INI file [TRAJ]PLANNER_TYPE=1 and [TRAJ]MAX_LINEAR_JERK>0). Jerk limits are set via INI file [JOINT_N]MAX_JERK or via the ini.N.max_jerk HAL pin.

joint.N.wheel-jog-active OUT BIT (DEBUG)

+

305.7. JOINT posthome pins

Each joint designated as an *extra* joint is provided with a HAL pin **joint.N.posthome-cmd**. The pin value is ignored prior to homing. After homing, the pin value is augmented by the motor offset value and routed to the **joint.N.motor-pos-cmd**.

305.8. JOINT unlock pins

The joint pins used for unlocking a joint (**joint.N.unlock**, **joint.N.is-unlocked**), are created according to the **unlock_joints_mask=jointmask** parameter for motmod. These pins may be required for locking indexers (typically a rotary joint).

The jointmask bits are: (lsb)0:joint0, 1:joint1, 2:joint2, ...

Example: loadrt motmod ... **unlock_joints_mask=0x38** creates unlock pins for joints 3, 4, 5.

305.9. SPINDLE PINS

(*M* is the spindle number (0 ... **num_spindles-1**))

spindle.M.amp-fault-in IN BIT

Should be driven TRUE if an external fault is detected with the amplifier for this spindle.

spindle.M.at-speed IN BIT

Motion will pause until this pin is TRUE, under the following conditions: Before the first feed move after each spindle start or speed change; before the start of every chain of spindle-synchronized moves; and if in CSS mode, at every rapid → feed transition.

spindle.M.brake OUT BIT

TRUE when the spindle brake should be applied.

spindle.M.forward OUT BIT

TRUE when the spindle should rotate forward.

spindle.M.index-enable I/O BIT

For correct operation of spindle synchronized moves, this signal must be hooked to the index-enable pin of the spindle encoder.

spindle.M.inhibit IN BIT

When TRUE, the spindle speed is set and held to 0.

spindle.M.is-oriented IN BIT

Acknowledge pin for spindle-orient. Completes orient cycle. If spindle-orient was true when spindle-is-oriented was asserted, the spindle-orient pin is cleared and the spindle-locked pin is asserted. Also, the spindle-brake pin is asserted.

spindle.M.locked OUT BIT

Spindle orient complete pin. Cleared by any of M3, M4 or M5.

spindle.M.on OUT BIT

TRUE when spindle should rotate.

spindle.M.orient OUT BIT

Indicates start of spindle orient cycle. Set by M19. Cleared by any of M3, M4 or M5.

If spindle-orient-fault is not zero during spindle-orient true, the M19 command fails with an error message.

spindle.M.orient-angle OUT FLOAT

Desired spindle orientation for M19. Value of the M19 R word parameter plus the value of the [RS274NGC]ORIENT_OFFSET INI parameter.

spindle.M.orient-fault IN S32

Fault code input for orient cycle. Any value other than zero will cause the orient cycle to abort.

spindle.M.orient-mode OUT BIT

Desired spindle rotation mode. Reflects M19 P parameter word.

spindle.M.reverse OUT BIT

TRUE when the spindle should rotate backward.

spindle.M.revs IN FLOAT

For correct operation of spindle synchronized moves, this signal must be hooked to the position pin of the spindle encoder.

spindle.M.speed-cmd-rps FLOAT OUT

Commanded spindle speed in units of revolutions per second.

spindle.M.speed-in IN FLOAT

Actual spindle speed feedback in revolutions per second; used for G96 (constant surface speed) and G95 (feed per revolution) modes.

spindle.M.speed-out OUT FLOAT

Desired spindle speed in rotations per minute.

spindle.M.speed-out-abs OUT FLOAT

Desired spindle speed in rotations per minute, always positive regardless of spindle direction.

spindle.M.speed-out-rps OUT FLOAT

Desired spindle speed in rotations per second.

spindle.M.speed-out-rps-abs OUT FLOAT

Desired spindle speed in rotations per second, always positive regardless of spindle direction.

305.10. MOTION PARAMETERS

Many of the parameters serve as debugging aids, and are subject to change or removal at any time.

motion-command-handler.tmax RW S32

Show information about the execution time of these HAL functions in CPU clocks.

motion-command-handler.tmax-increased RO S32**motion-controller.tmax RW S32**

Show information about the execution time of these HAL functions in CPU clocks.

motion-controller.tmax-increased RO BIT

+

motion.debug-*

These values are used for debugging purposes.

305.11. FUNCTIONS

Generally, these functions are both added to the servo-thread in the order shown.

motion-command-handler

Receive and process incoming motion commands. The pin named **motion-command-handler.time** and parameters **motion-command-handler.tmax**, **tmax-increased** are created for this function.

motion-controller

Runs the LinuxCNC motion controller. The pin named **motion-controller.time** and parameters **motion-controller.tmax**, **tmax-increased** are created for this function.

305.12. BUGS

This manual page is incomplete.

Identification of pins categorized with **(DEBUG)** is dubious.

305.13. SEE ALSO

iocontrol(1), milltask(1), spindle(9)

Chapter 306. MOVEOFF(9)

306.1. NAME

moveoff - Component for HAL-only offsets

306.2. SYNOPSIS

loadrt moveoff [**count**=*N* | **names**=*name1*[,*name2*...]] [**personality**=*P1*[,*P2*...]]

306.3. DESCRIPTION

The moveoff component is used to offset joint positions using custom HAL connections. Implementing an offset-while-program-is-paused functionality is supported with appropriate connections for the input pins. Nine joints are supported.

The axis offset pin values (offset-in-M) are continuously applied (respecting limits on value, velocity, and acceleration) to the output pins (offset-current-M, pos-plusoffset-M, fb-minusoffset-M) when both enabling input pins (apply-offsets and move-enable) are TRUE. The two enabling inputs are anded internally. A **warning** pin is set and a message issued if the apply-offsets pin is deasserted while offsets are applied. The warning pin remains TRUE until the offsets are removed or the apply-offsets pin is set.

Typically, the move-enable pin is connected to external controls and the apply-offsets pin is connected to halui.program.is-paused (for offsets only while paused) or set to TRUE (for continuously applied offsets).

Applied offsets are **automatically returned** to zero (respecting limits) when either of the enabling inputs is deactivated. The zero value tolerance is specified by the epsilon input pin value.

Waypoints are recorded when the moveoff component is enabled. Waypoints are managed with the waypoint-sample-secs and waypoint-threshold pins. When the backtrack-enable pin is TRUE, the auto-return path follows the recorded waypoints. When the memory available for waypoints is exhausted, offsets are frozen and the waypoint-limit pin is asserted. This restriction applies regardless of the state of the backtrack-enable pin. An enabling pin must be deasserted to allow a return to the original (non-offset position).

Backtracking through waypoints results in **slower** movement rates as the moves are point-to-point respecting velocity and acceleration settings. The velocity and acceleration limit pins can be managed dynamically to control offsets at all times.

When backtrack-enable is FALSE, the auto-return move is **NOT** coordinated, each axis returns to zero at its own rate. If a controlled path is wanted in this condition, each axis should be manually returned to zero before deasserting an enabling pin.

The waypoint-sample-secs, waypoint-threshold, and epsilon pins are evaluated only when the component is idle.

The offsets-applied output pin is provided to indicate the current state to a GUI so that program resumption can be managed. If the offset(s) are non-zero when the apply-offsets pin is deasserted (for

example when resuming a program when offsetting during a pause), offsets are returned to zero (respecting limits) and an **Error** message is issued.

Caution: If offsets are enabled and applied and the machine is turned off for any reason, any **external** HAL logic that manages the enabling pins and the offset-in-M inputs is responsible for their state when the machine is subsequently turned on again.

This HAL-only means of offsetting is typically not known to LinuxCNC nor available in GUI preview displays. **No protection is provided** for offset moves that exceed soft limits managed by LinuxCNC. Since soft limits are not honored, an offset move may encounter hard limits (or **CRASH** if there are no limit switches). Use of the offset-min-M and offset-max-M inputs to limit travel is recommended. Triggering a hard limit will turn off the machine — see **Caution** above.

The offset-in-M values may be set with inifile settings, controlled by a GUI, or managed by other HAL components and connections. Fixed values may be appropriate in simple cases where the direction and amount of offset is well-defined but a control method is required to deactivate an enabling pin in order to return offsets to zero. GUIs may provide means for users to set, increment, decrement, and accumulate offset values for each axis and may set offset-in-M values to zero before deasserting an enabling pin.

The default values for accel, vel, min, max, epsilon, waypoint-sample-secs, and waypoint-threshold may not be suitable for any particular application. This HAL component is unaware of limits enforced elsewhere by LinuxCNC. Users should test usage in a simulator application and understand all hazards **before** use on hardware.

The module personality item sets the number of joints supported (default==3, maximum is 9).

Use of the names= option for naming is **required** for compatibility with the gui provided as scripts/moveoff_gui: loadrt moveoff names=**mv** personality=number_of_joints

306.4. FUNCTIONS

moveoff.N.read-inputs

Read all inputs

moveoff.N.write-outputs

Write computed offset outputs (offset-current-M, pos-plusoffset-M, fb-minusoffset-M). All other outputs are updated by read-inputs().

306.5. PINS

moveoff.N.power-on bit in

Connect to motion.motion-enabled

moveoff.N.move-enable bit in

Enable offsets (Enabling requires apply-offset TRUE also)

moveoff.N.apply-offsets bit in

Enable offsets (Enabling requires move-enable TRUE also)

moveoff.N.backtrack-enable bit in (default: 1)

Enable backtrack on auto-return

moveoff.N.epsilon float in (default: 0.0005)

When enabling pins are deactivated, return to un-offsetted position within epsilon units. Warning: values that are too small in value may cause overshoot. A minimum value of 0.0001 is **silently enforced**.

moveoff.N.waypoint-threshold float in (default: 0.02)

Minimum distance (in a single axis) for a new waypoint

moveoff.N.waypoint-sample-secs float in (default: 0.02)

Minimum sample interval (in seconds) for a new waypoint

moveoff.N.warning bit out

Set TRUE if apply-offsets is deasserted while offset-applied is TRUE.

moveoff.N.offset-applied bit out

TRUE if one or more offsets are applied.

moveoff.N.waypoint-limit bit out (default: 0)

Indicates waypoint limit reached (motion ceases), an enabling pin must be deasserted to initiate return to original position.

moveoff.N.waypoint-ct s32 out

Waypoint count (for debugging)

moveoff.N.waypoint-percent-used s32 out

Percent of available waypoints used

moveoff.N.offset-in-M float in (M=0..personality)

Joint offset input value

moveoff.N.pos-M float in (M=0..personality)

Joint position (typ: axis.0.motor-pos-cmd)

moveoff.N.fb-M float in (M=0..personality)

Joint feedback (typ from encoder and input to pid controller (pid.feedback))

moveoff.N.offset-current-M float out (M=0..personality)

Joint offset current value

moveoff.N.pos-plusoffset-M float out (M=0..personality)

Computed joint position plus offset (typically connect to pid command input)

moveoff.N.fb-minusoffset-*M* float out (M=0..personality)

Computed Joint feedback minus offset (typically connected to axis.0.motor-pos-fb)

moveoff.N.offset-vel-*M* float in (M=0..personality) (default: 10)

Joint offset velocity limit

moveoff.N.offset-accel-*M* float in (M=0..personality) (default: 100)

Joint offset acceleration limit

moveoff.N.offset-min-*M* float in (M=0..personality) (default: -1e20)

Minimum limit for applied joint offset (typ negative)

moveoff.N.offset-max-*M* float in (M=0..personality) (default: 1e20)

Maximum limit for applied offset (typ positive)

moveoff.N.dbg-waypoint-limit-test bit in

Debug input to test with limited number of waypoints

moveoff.N.dbg-state s32 out

Debug output for current state of state machine

306.6. EXAMPLES

Example simulator configs that demonstrate the moveoff component and a simple gui (scripts/moveoff_gui) are located in configs/sim/axis/moveoff. The AXIS GUI is used for the demonstrations and the configs can be adapted for other GUIs like Touchy and Gscreen. An example with the Touchy GUI is provided in configs/sim/touchy/ngcgui/.

306.7. SEE ALSO

moveoff_gui(1)

306.8. AUTHOR

Dewey Garrett and Andy Pugh

306.9. LICENSE

GPL

Chapter 307. MULT2(9)

307.1. NAME

mult2 - Product of two inputs

307.2. SYNOPSIS

loadrt mult2 [**count**=*N*|**names**=*name1*[,*name2*...]]

307.3. FUNCTIONS

mult2.*N*

307.4. PINS

mult2.*N*.in0 float in

mult2.*N*.in1 float in

mult2.*N*.out float out

out = in0 * in1

307.5. SEE ALSO

```
invert(9), div2(9)
```

307.6. AUTHOR

John Kasunich

307.7. LICENSE

GPL

Chapter 308. MULTICLICK(9)

308.1. NAME

multiclick - Single-, double-, triple-, and quadruple-click detector

308.2. SYNOPSIS

loadrt multiclick [count=*N* | names=*name1*[,*name2*...]]

308.3. DESCRIPTION

A click is defined as a rising edge on the *in* pin, followed by the *in* pin being True for at most *max-hold-ns* nanoseconds, followed by a falling edge.

A double-click is defined as two clicks, separated by at most *max-space-ns* nanoseconds with the *in* pin in the False state.

I bet you can guess the definition of triple- and quadruple-click.

You probably want to run the input signal through a debounce component before feeding it to the multiclick detector, if the input is at all noisy.

The **-click* pins go high as soon as the input detects the correct number of clicks.

The **-click-only* pins go high a short while after the click, after the click separator space timeout has expired to show that no further click is coming. This is useful for triggering halui MDI commands.

308.4. FUNCTIONS

multiclick.*N*

Detect single-, double-, triple-, and quadruple-clicks

308.5. PINS

multiclick.*N.in* bit in

The input line, this is where we look for clicks.

multiclick.*N.single-click* bit out

Goes high briefly when a single-click is detected on the *in* pin.

multiclick.*N.single-click-only* bit out

Goes high briefly when a single-click is detected on the *in* pin and no second click followed it.

multiclick.*N.double-click* bit out

Goes high briefly when a double-click is detected on the *in* pin.

multiclick.N.double-click-only bit out

Goes high briefly when a double-click is detected on the *in* pin and no third click followed it.

multiclick.N.triple-click bit out

Goes high briefly when a triple-click is detected on the *in* pin.

multiclick.N.triple-click-only bit out

Goes high briefly when a triple-click is detected on the *in* pin and no fourth click followed it.

multiclick.N.quadruple-click bit out

Goes high briefly when a quadruple-click is detected on the *in* pin.

multiclick.N.quadruple-click-only bit out

Goes high briefly when a quadruple-click is detected on the *in* pin and no fifth click followed it.

multiclick.N.state s32 out

308.6. PARAMETERS

multiclick.N.invert-input bit rw (default: *FALSE*)

If *FALSE* (the default), clicks start with rising edges. If *TRUE*, clicks start with falling edges.

multiclick.N.max-hold-ns u32 rw (default: *250000000*)

If the input is held down longer than this, it's not part of a multi-click. (Default 250,000,000 ns, 250 ms.)

multiclick.N.max-space-ns u32 rw (default: *250000000*)

If the input is released longer than this, it's not part of a multi-click. (Default 250,000,000 ns, 250 ms.)

multiclick.N.output-hold-ns u32 rw (default: *100000000*)

Positive pulses on the output pins last this long. (Default 100,000,000 ns, 100 ms.)

308.7. AUTHOR

Sebastian Kuzminsky

308.8. LICENSE

GPL

Chapter 309. MULTISWITCH(9)

309.1. NAME

multiswitch - This component toggles between a specified number of output bits.

309.2. SYNOPSIS

loadrt multiswitch personality=*P* [cfg=*value*[,*value*...]]

cfg

cfg should be a comma-separated list of sizes, for example `cfg=2,4,6` would create 3 instances of 2, 4 and 6 bits respectively. Ignore the "personality" parameter, that is auto-generated.

309.3. FUNCTIONS

multiswitch.*N*

309.4. PINS

multiswitch.*N*.up bit in (default: *false*)

Receives signal to toggle up

multiswitch.*N*.down bit in (default: *false*)

Receives signal to toggle down

multiswitch.*N*.bit-*MM* bit out (*MM*=00..*personality*) (default: *false*)

Output bits

309.5. PARAMETERS

multiswitch.*N*.top-position u32 rw

Number of positions

multiswitch.*N*.position s32 rw

Current state (may be set in the HAL)

309.6. AUTHOR

ArcEye schooner30.AT.tiscali.co.uk / Andy Pugh andy.AT.bodgesoc.org

309.7. LICENSE

GPL

Chapter 310. MUX16(9)

310.1. NAME

mux16 - Select from one of sixteen input values

310.2. SYNOPSIS

loadrt mux16 [**count**=*N* | **names**=*name1* [, *name2* ...]]

310.3. FUNCTIONS

mux16.N

310.4. PINS

mux16.N.use-graycode bit in

This signifies the input will use Gray code instead of binary. Gray code is a good choice when using physical switches because for each increment only one select input changes at a time.

mux16.N.suppress-no-input bit in

This suppresses changing the output if all select lines are false. This stops unwanted jumps in output between transitions of input. but make in00 unavailable.

mux16.N.debounce-time float in

sets debounce time in seconds. eg. .10 = a tenth of a second input must be stable this long before outputs changes. This helps to ignore *noisy* switches.

mux16.N.selM bit in (M=0..3)

Together, these determine which **inN** value is copied to **out**.

mux16.N.out-f float out

mux16.N.out-s s32 out

Follows the value of one of the **inN** values according to the four **sel** values and whether use-graycode is active. The s32 value will be truncated and limited to the max and min values of signed values.

sel3	sel2	sel1	sel0	out follows
0	0	0	0	in00
0	0	0	1	in01
0	0	1	0	in02
0	0	1	1	in03
0	1	0	0	in04

0	1	0	1	in05
0	1	1	0	in06
0	1	1	1	in07
1	0	0	0	in08
1	0	0	1	in09
1	0	1	0	in10
1	0	1	1	in11
1	1	0	0	in12
1	1	0	1	in13
1	1	1	0	in14
1	1	1	1	in15

mux16.N.inMM float in (MM=00..15)

array of selectable outputs

310.5. PARAMETERS

mux16.N.elapsed float r

Current value of the internal debounce timer for debugging.

mux16.N.selected s32 r

Current value of the internal selection variable after conversion for debugging

310.6. SEE ALSO

mux2(9), mux4(9), mux8(9), mux_generic(9).

310.7. AUTHOR

Chris S Morley

310.8. LICENSE

GPL

Chapter 311. MUX2(9)

311.1. NAME

mux2 - Select from one of two input values

311.2. SYNOPSIS

loadrt mux2 [**count**=*N* | **names**=*name1* [, *name2* ...]]

311.3. FUNCTIONS

mux2.N

311.4. PINS

mux2.N.sel bit in

mux2.N.out float out

Follows the value of **in0** if **sel** is FALSE, or **in1** if **sel** is TRUE

mux2.N.in1 float in

mux2.N.in0 float in

311.5. SEE ALSO

mux4(9), **mux8(9)**, **mux16(9)**, **mux_generic(9)**.

311.6. AUTHOR

Jeff Epler

311.7. LICENSE

GPL

Chapter 312. MUX4(9)

312.1. NAME

mux4 - Select from one of four input values

312.2. SYNOPSIS

loadrt mux4 [**count**=*N* | **names**=*name1* [, *name2* ...]]

312.3. FUNCTIONS

mux4.N

312.4. PINS

mux4.N.sel0 bit in

mux4.N.sel1 bit in

Together, these determine which **in***N* value is copied to **out**.

mux4.N.out float out

Follows the value of one of the **in***N* values according to the two **sel** values

sel1	sel0	out follows
0	0	in0
0	1	in1
1	0	in2
1	1	in3

mux4.N.in0 float in

mux4.N.in1 float in

mux4.N.in2 float in

mux4.N.in3 float in

312.5. SEE ALSO

mux2(9), **mux8**(9), **mux16**(9), **mux_generic**(9).

312.6. AUTHOR

Jeff Epler

312.7. LICENSE

GPL

Chapter 313. MUX8(9)

313.1. NAME

mux8 - Select from one of eight input values

313.2. SYNOPSIS

loadrt mux8 [**count**=*N* | **names**=*name1* [, *name2* ...]]

313.3. FUNCTIONS

mux8.N

313.4. PINS

mux8.N.sel0 bit in

mux8.N.sel1 bit in

mux8.N.sel2 bit in

Together, these determine which **inN** value is copied to **out**.

mux8.N.out float out

Follows the value of one of the **inN** values according to the three **sel** values

sel2	sel1	sel0	out follows
0	0	0	in0
0	0	1	in1
0	1	0	in2
0	1	1	in3
1	0	0	in4
1	0	1	in5
1	1	0	in6
1	1	1	in7

mux8.N.in0 float in

mux8.N.in1 float in

mux8.N.in2 float in

mux8.N.in3 float in

mux8.N.in4 float in

mux8.N.in5 float in

mux8.N.in6 float in

mux8.N.in7 float in

313.5. SEE ALSO

mux2(9), mux4(9), mux16(9), mux_generic(9).

313.6. AUTHOR

Stuart Stevenson

313.7. LICENSE

GPL

Chapter 314. mux_generic(9)

314.1. NAME

mux_generic - select one from several inputs and forwards it to a single output

314.2. SYNOPSIS

loadrt mux_generic config="<input_type><output_type><size>[,<input_type><output_type><size>],..."


Types: **b** = bit, **f** = float, **s** = signed integer, **u** = unsigned integer

Example: **loadrt mux_generic config="bb8,fu12"**

314.3. FUNCTIONS

mux-gen.NN Depending on the data types can run in either a floating point or non-floating point thread.

314.4. PINS



mux-gen.N.suppress-no-input bit in

This suppresses changing the output if all select lines are false. This stops unwanted jumps in output between transitions of input but makes in00 unavailable.

mux-gen.N.debounce-us unsigned in

sets debounce time in microseconds, e.g. 100000 = a tenth of a second. The selection inputs must be stable this long before the output changes. This helps to ignore *noisy* switches.

mux-gen.N.sel-bit-BB bit in (BB=0..bit width of size)

mux-gen.N.sel-int unsigned in

Together, these determine which **inM** value is copied to **output**. The bit pins are interpreted as binary bits, and the result is simply added on to the integer pin input. It is expected that either one or the other would normally be used. However, the possibility exists to use a higher-order bit to "shift" the

values set by the integer pin. The sel-bit pins are only created when the size of the mux_gen component is an integer power of two. This component (unlike mux16) does not offer the option of decoding Gray-code, however the same effect can be achieved by arranging the order of the input values to suit.

mux-gen.N.in--MM variable-type in

The possible output values that are selected by the selection pins.

mux-gen.N.out-[bit/float/s32/u32] variable-type out

Follows the value of one of the **in***N* values according to the selection bits and/or the selection number. Values will be converted/truncated according to standard C rules. This means, for example that a float input greater than 2147483647 will give an S32 output of -2147483648.

314.5. PARAMETERS

mux-gen.N.elapsed float r

Current value of the internal debounce timer for debugging.

mux-gen.N.selected s32 r

Current value of the internal selection variable after conversion for debugging. Possibly useful for setting up gray-code switches.

314.6. DESCRIPTION

This component is a more general version of the other multiplexing components. It allows the creation of arbitrary-size multiplexers (up to 1024 entries) and also supports differing data types on the input and output pins. The configuration string is a comma-separated list of code-letters and numbers, such as "bb4,fu12". This would create a 4-element bit-to-bit mux and a 12-element float-to-unsigned mux. The code letters are **b** = bit, **f** = float, **s** = signed integer, **u** = unsigned integer. The first letter code is the input type, the second is the output type. The codes are not case-sensitive. The order of the letters is significant but the position in the string is not. Do not insert any spaces in the config string. Any non-zero float value will be converted to a "true" output in bit form. Be wary that float datatypes can be very, very, close to zero and not actually be equal to zero.

Each mux has its own HAL function and must be added to a thread separately. If neither input nor output is of type float then the function is base-thread (non floating-point) safe. Any mux_generic with a floating point input or output can only be added to a floating-point thread.

314.7. SEE ALSO

mux2(9), mux4(9), mux8(9), mux16(9)

314.8. AUTHOR

Andy Pugh

314.9. LICENSE

GPL

Chapter 315. NEAR(9)

315.1. NAME

near - Determine whether two values are roughly equal.

315.2. SYNOPSIS

loadrt near [**count**=*N* | **names**=*name1*[,*name2*...]]

315.3. FUNCTIONS

near.N

315.4. PINS

near.N.in1- float in

near.N.in2- float in

near.N.out bit out

out is true if **in1** and **in2** are within a factor of **scale** (i.e., for in1 positive, $\text{in1}/\text{scale} \leq \text{in2} \leq \text{in1} * \text{scale}$), OR if their absolute difference is no greater than **difference** (i.e., $|\text{in1} - \text{in2}| \leq \text{difference}$). **out** is false otherwise.

315.5. PARAMETERS

near.N.scale float rw (default: 1)

near.N.difference float rw (default: 0)

315.6. AUTHOR

Chris Radek

315.7. LICENSE

GPL

Chapter 316. NOT(9)

316.1. NAME

not - Inverter

316.2. SYNOPSIS

loadrt not [**count**=*N*|**names**=*name1*[,*name2*...]]

316.3. DESCRIPTION

The **out** output pin is set to the inverted logic level of the **in** input pin.

316.4. FUNCTIONS

not.N

316.5. PINS

not.N.in bit in

not.N.out bit out

316.6. SEE ALSO

and2(9), **logic(9)**, **lut5(9)**, **or2(9)**, **xor2(9)**.

316.7. AUTHOR

Jeff Epler

316.8. LICENSE

GPL

Chapter 317. OFFSET(9)

317.1. NAME

offset - Adds an offset to an input, and subtracts it from the feedback value.

317.2. SYNOPSIS

loadrt offset [**count**=*N*|**names**=*name1*[,*name2*...]]

317.3. FUNCTIONS

offset.N.update-output

Updated the output value by adding the offset to the input.

offset.N.update-feedback

Update the feedback value by subtracting the offset from the feedback.

317.4. PINS

offset.N.offset float in

The offset value

offset.N.in float in

The input value

offset.N.out float out

The output value

offset.N.fb-in float in

The feedback input value

offset.N.fb-out float out

The feedback output value

317.5. AUTHOR

Jeff Epler

317.6. LICENSE

GPL

Chapter 318. OHMIC(9)

318.1. NAME

ohmic - LinuxCNC HAL component that uses a Mesa THCAD for ohmic sensing

318.2. SYNOPSIS

loadrt ohmic [count=*N* | names=*name1*[,*name2*...]]

318.3. DESCRIPTION

Mesa THCAD Card component to scale input and outputs from the Mesa THCAD2, THCAD5, THCAD10, and THCAD300 cards.

Allows user configurable voltage thresholds for ohmic sensing.

Output pins are provided for:

ohmic-volts -the voltage sensed on ohmic sensing.

thcad-volts -the actual voltage measured by the THCAD.

ohmic-on -true if ohmic-volts \geq ohmic-threshold, false if ohmic-volts \leq ohmic-low.

A THCAD-5 would often be used for ohmic sensing in conjunction with a 24 Volt isolated power supply and a 390 k Ω series resistor resulting in a voltage divider of 4.9.

This would result in a full scale reading of 24.5 Volts which is above the power supply output voltage.

The circuit will remain protected by the THCAD's ability to tolerate a 500 Volt over-voltage indefinitely.

It is optional that power to the ohmic sensing circuit be disconnected unless probing is in progress.

318.4. FUNCTIONS

ohmic.*N*

318.5. PINS

ohmic.*N*.is-probing bit in

True if probing

ohmic.*N*.ohmic-low float in (default: 21)

The threshold volts below which ohmic sensing is set to be false

ohmic.N.ohmic-threshold float in (default: 22)

The threshold volts above which ohmic sensing is set to be true

ohmic.N.thcad-0-volt-freq float in

0 volt calibration data for THCAD card in Hz

ohmic.N.thcad-divide float in (default: 32)

THCAD divider set by links on THCAD board (1, 32, 64, or 128)

ohmic.N.thcad-fullscale float in (default: 5)

THCAD full scale in Volt (5, 10, or 300 Volt)

ohmic.N.thcad-max-volt-freq float in

Full scale calibration data for THCAD Card in Hz

ohmic.N.velocity-in float in

The velocity returned from the THCAD and read by the Mesa encoder input

ohmic.N.volt-divider float in (default: 4.9)

The divide ratio

ohmic.N.ohmic-on bit out

True if ohmic circuit is closed (material is sensed)

ohmic.N.ohmic-volts float out

Calculated ohmic voltage

318.6. EXAMPLES

The below HAL example assumes a THCAD5 card using a 1/32 frequency setting and a voltage divider internal to the plasma cutter with range extended to 24.5 volts by a series 390K external resistor as per the manual. Additional information and wiring diagram is contained in the Plasma Primer in the LinuxCNC documentation.

Example Calibration Data: 0V = 122.9 kHz, 10V = 925.7 kHz should be entered as 122900 and 925700.

```
loadrt ohmic names=ohmicsense
addf ohmicsense servo-thread
setp ohmicsense.thcad-0-volt-freq 122900
setp ohmicsense.thcad-max-volt-freq 925700
setp ohmicsense.thcad-divide 32
setp ohmicsense.thcad-fullscale 5
setp ohmicsense.volt-divider 4.9
setp ohmicsense.threshold 22
setp ohmicsense.ohmic-low 21
net ohmic-vel ohmicsense.velocity-in <= hm2_7i76e.0.encoder.00.velocity
net ohmic-enable ohmicsense.is_probing <= plasmac.ohmic-enable
net ohmic-true ohmicsense.ohmic-on => plasmac.ohmic-probe
```

318.7. AUTHOR

Rod Webster

318.8. LICENSE

GPL

Chapter 319. ONESHOT(9)

319.1. NAME

oneshot - one-shot pulse generator

319.2. SYNOPSIS

loadrt oneshot [count=*N* | names=*name1*[,*name2*...]]

319.3. DESCRIPTION

creates a variable-length output pulse when the input changes state. This function needs to run in a thread which supports floating point (typically the servo thread). This means that the pulse length has to be a multiple of that thread period, typically 1ms. For a similar function that can run in the base thread, and which offers higher resolution, see "edge".

319.4. FUNCTIONS

oneshot.*N*

Produce output pulses from input edges

319.5. PINS

oneshot.*N*.in bit in

Trigger input

oneshot.*N*.reset bit in

Reset

oneshot.*N*.out bit out

Active high pulse

oneshot.*N*.out-not bit out

Active low pulse

oneshot.*N*.width float in (default: 0)

Pulse width in seconds

oneshot.*N*.time-left float out

Time left in current output pulse

319.6. PARAMETERS

oneshot.N.retriggerable bit rw (default: *TRUE*)

Allow additional edges to extend pulse

oneshot.N.rising bit rw (default: *TRUE*)

Trigger on rising edge

oneshot.N.falling bit rw (default: *FALSE*)

Trigger on falling edge

319.7. AUTHOR

John Kasunich

319.8. LICENSE

GPL

Chapter 320. opto_ac5(9)

320.1. NAME

opto_ac5 - Realtime driver for opto22 PCI-AC5 cards

320.2. SYNOPSIS

loadrt opto_ac5 [portconfig0=0xN] [portconfig1=0xN]

320.3. DESCRIPTION

These pins and parameters are created by the realtime **opto_ac5** module. The portconfig0 and portconfig1 variables are used to configure the two ports of each card. The first 24 bits of a 32 bit number represent the 24 i/o points of each port. The lowest (rightmost) bit would be HAL pin 0 which is header connector pin 47. Then next bit to the left would be HAL pin 1, header connector pin 45 and so on, until bit 24 would be HAL pin 23, header connector pin 1. "1" bits represent output points. So channel 0..11 as inputs and 12..23 as outputs would be represented by (in binary) 111111111110000000000000 which is 0xfff000 in hexadecimal. That is the number you would use, e.g.

```
loadrt opto_ac5 portconfig0=0xfff000
```

If no portconfig variable is specified the default configuration is 12 inputs then 12 outputs.

Up to 4 boards are supported. Boards are numbered starting at 0.

Portnumber can be 0 or 1. Port 0 is closest to the card bracket.

320.4. PINS

opto_ac5.BOARDNUMBER.port.PORTNUMBER.in-PINNUMBER OUT bit

+

opto_ac5.BOARDNUMBER.port.PORTNUMBER.in-PINNUMBER-not OUT bit

Connect a HAL bit signal to this pin to read an i/o point from the card. The PINNUMBER represents the position in the relay rack. E.g., PINNUMBER 0 is position 0 in a opto22 relay rack and would be pin 47 on the 50 pin header connector. The **-not** pin is inverted so that LOW gives TRUE and HIGH gives FALSE.

opto_ac5.BOARDNUMBER.port.PORTNUMBER.out-PINNUMBER IN bit

Connect a HAL bit signal to this pin to write to an i/o point of the card. The PINNUMBER represents the position in the relay rack. E.g., PINNUMBER 23 is position 23 in a opto22 relay rack and would be pin 1 on the 50 pin header connector.

opto_ac5.BOARDNUMBER.led.NUMBER OUT bit

Turns one of the on board LEDS on/off. LEDS are numbered 0 to 3.

320.5. PARAMETERS

opto_ac5.*BOARDNUMBER*.port.*PORTNUMBER*.out-*PINNUMBER*-invert W bit

When TRUE, invert the meaning of the corresponding **-out** pin so that TRUE gives LOW and FALSE gives HIGH.

320.6. FUNCTIONS

opto_ac5.0.digital-read

Add this to a thread to read all the input points.

opto_ac5.0.digital-write

Add this to a thread to write all the output points and LEDS.

320.7. BUGS

All boards are loaded with the same port configurations as the first board.

320.8. SEE ALSO

<https://wiki.linuxcnc.org/cgi-bin/wiki.pl?OptoPciAc5>

Chapter 321. OR2(9)

321.1. NAME

or2 - Two-input OR gate

321.2. SYNOPSIS

loadrt or2 [**count**=*N*|**names**=*name1*[,*name2*...]]

321.3. DESCRIPTION

The **out** pin is computed from the value of the **in0** and **in1** pins according to the following truth table:

in1	in0	out
0	0	0
0	1	1
1	0	1
1	1	1

321.4. FUNCTIONS

or2.N

321.5. PINS

or2.N.in0 bit in

First input

or2.N.in1 bit in

Second input

or2.N.out bit out

Output

321.6. SEE ALSO

logic(9)

321.7. AUTHOR

Jeff Epler

321.8. LICENSE

GPL

Chapter 322. ORIENT(9)

322.1. NAME

orient - Provide a PID command input for orientation mode based on current spindle position, target angle and orient mode

322.2. SYNOPSIS

```
loadrt orient [count=N|names=name1[,name2...]]
```

322.3. DESCRIPTION

This component is designed to support a spindle orientation PID loop by providing a command value, and fit with the motion spindle-orient support pins to support the M19 code.

The spindle is assumed to have stopped in an arbitrary position. The spindle encoder position is linked to the **position** pin. The current value of the position pin is sampled on a positive edge on the **enable** pin, and **command** is computed and set as follows:

$\text{floor}(\text{number of full spindle revolutions in the } \mathbf{position} \text{ sampled on positive edge}) + \mathbf{angle}/360$ (the fractional revolution) $+1/-1/0$ depending on **mode**.

The **mode** pin is interpreted as follows:

- 0: the spindle rotates in the direction with the lesser angle, which may be clockwise or counterclockwise.
- 1: the spindle rotates always rotates clockwise to the new angle.
- 2: the spindle rotates always rotates counterclockwise to the new angle.

322.3.1. HAL USAGE

On **spindle.N.orient** disconnect the spindle control and connect to the orient-pid loop:

```
loadrt orient names=orient
loadrt pid names=orient-pid
net orient-angle spindle.N.orient-angle orient.angle
net orient-mode spindle.N.orient-mode orient.mode
net orient-enable spindle.N.orient orient.enable orient-pid.enable
net spindle-in-pos orient.is-oriented spindle.N.is-oriented
net spindle-pos encoder.position orient.position orient-pid.feedback
net orient-command orient.command orient-pid.command
```

322.4. FUNCTIONS

orient.N

Update **command** based on **enable**, **position**, **mode** and **angle**.

322.5. PINS

orient.N.enable bit in

enable angular output for orientation mode

orient.N.mode s32 in

0: rotate - shortest move; 1: always rotate clockwise; 2: always rotate counterclockwise

orient.N.position float in

spindle position input, unit 1 rev

orient.N.angle float in

orient target position in degrees, $0 \leq \text{angle} < 360$

orient.N.command float out

target spindle position, input to PID command

orient.N.poserr float out

in degrees - aid for PID tuning

orient.N.is-oriented bit out

This pin goes high when poserr < tolerance. Use to drive spindle.N.is-oriented

orient.N.tolerance float in (default: 0.5)

The tolerance in degrees for considering the align completed

322.6. AUTHOR

Michael Haberler

322.7. LICENSE

GPL

Chapter 323. OUTPUT_BUFFER(9)

323.1. NAME


output_buffer - Feed through multiple bits when enable pin is set

323.2. SYNOPSIS

loadrt output_buffer [count=*N* | names=*name1*[,*name2*...]] [personality=*P1*[,*P2*...]]

323.3. DESCRIPTION

Feed through up to 32 bit inputs to their outputs when enable set, otherwise outputs will be the value of *off-level* (default 0).



The number of channels are determined by the value of *personality*.

323.4. FUNCTIONS

output-buffer.N

323.5. PINS

output-buffer.N.enable bit in

Enable input

output-buffer.N.off-level bit in (default: 0)

Signal level when output is off (enable=0)

output-buffer.N.in-M bit in (M=0..personality)

Inputs

output-buffer.*N*.out-*M* bit out (M=0..personality)

Outputs (Follow inputs when enable=1)

323.6. EXAMPLES

loadrt output_buffer count=1 personality=8 will create a 8 bit buffer.

323.7. AUTHOR

Hans Unzner

323.8. LICENSE

GPL

Chapter 324. pid(9)

324.1. NAME

pid - proportional/integral/derivative controller with automatic tuning support

324.2. SYNOPSIS

```
loadrt pid [num_chan=num | names=name1[,name2...]] [debug=*_dbg]
```

324.3. DESCRIPTION

pid is a classic Proportional/Integral/Derivative controller, used to control position or speed feedback loops for servo motors and other closed-loop applications.

pid supports a maximum of sixteen controllers. The number that are actually loaded is set by the **num_chan** argument when the module is loaded. Alternatively, specify **names=** and unique names separated by commas.

The **num_chan=** and **names=** specifiers are mutually exclusive. If neither **num_chan=** nor **names=** are specified, the default value is three. If **debug** is set to 1 (the default is 0), some additional HAL parameters will be exported, which might be useful for tuning, but are otherwise unnecessary.

In the following description, it is assumed that we are discussing position loops. However this component can be used to implement other loops such as speed loops, torch height control, and others.

Each loop has a number of pins and parameters, whose names begin with **pid.N.**, where *N* is the channel number. Channel numbers start at zero.

The three most important pins are *command*, *feedback*, and *output*. For a position loop, *command* and *feedback* are in position units. For a linear axis, this could be inches, mm, metres, or whatever is relevant. Likewise, for a angular axis, it could be degrees, radians, etc. The units of the *output* pin represent the change needed to make the feedback match the command. As such, for a position loop *output* is a velocity, in inches/sec, mm/sec, degrees/sec, etc.

Each loop has several other pins as well. *error* is equal to *command* minus *feedback*. *enable* is a bit that enables the loop. If *enable* is false, all integrators are reset, and the output is forced to zero. If *enable* is true, the loop operates normally.

The PID gains, limits, and other *tunable* features of the loop are implemented as parameters. These are as follows:

Pgain Proportional gain

Igain Integral gain

Dgain Derivative gain

bias Constant offset on output

FF0 Zeroth order Feedforward gain

FF1 First order Feedforward gain

FF2 Second order Feedforward gain

FF3 Third order Feedforward gain

deadband Amount of error that will be ignored

maxerror Limit on error

maxerrorI Limit on error integrator

maxerrorD Limit on error differentiator

maxcmdD Limit on command differentiator

maxcmdDD Limit on command 2nd derivative

maxcmdDDD Limit on command 3rd derivative

maxoutput Limit on output value

All of the limits (max____) are implemented such that if the parameter value is zero, there is no limit.

A number of internal values which may be useful for testing and tuning are also available as parameters. To avoid cluttering the parameter list, these are only exported if "debug=1" is specified on the insmod command line.

errorI Integral of error

errorD Derivative of error

commandD Derivative of the command

commandDD 2nd derivative of the command

commandDDD 3rd derivative of the command

The PID loop calculations are as follows (see the code in pid.c for all the nitty gritty details):

```
error = command - feedback
if ( abs(error) < deadband ) then error = 0
limit error to +/- maxerror
errorI += error * period
limit errorI to +/- maxerrorI
errorD = (error - previouserror) / period
limit errorD to +/- maxerrorD
commandD = (command - previouscommand) / period
limit commandD to +/- maxcmdD
```

```

commandDD = (commandD - previouscommandD) / period
limit commandDD to +/- maxcmdDD
commandDDD = (commandDD - previouscommandDD) / period
limit commandDDD to +/- maxcmdDDD
output = bias + error * Pgain + errorI * Igain +
         errorD * Dgain + command * FF0 + commandD * FF1 +
         commandDD * FF2 + commandDDD * FF3
limit output to +/- maxoutput

```

This component has a built in auto tune mode. It works by setting up a limit cycle to characterize the process. This is called the Relay method and described in the 1984 Automation paper **Automatic Tuning of Simple Regulators with Specifications on Phase and Amplitude Margins** by Karl Johan Åström and Tore Hägglund (doi:10.1016/0005-1098(84)90014-1), <https://lup.lub.lu.se/search/ws/files/6340936/8509157.pdf>. Using this method, **Pgain/Igain/Dgain** or **Pgain/Igain/FF1** can be determined using the Ziegler-Nichols algorithm. When using **FF1** tuning, scaling must be set so that **output** is in user units per second.

During auto tuning, the **command** input should not change. The limit cycle is setup around the commanded position. No initial tuning values are required to start auto tuning. Only **tune-cycles**, **tune-effort** and **tune-mode** need be set before starting auto tuning. Note that setting **tune-mode** to true disable the control loop. When auto tuning completes, the tuning parameters will be set, the output set to bias and the controller still be disabled. If running from LinuxCNC, the FERROR setting for the axis being tuned may need to be loosened up, as it must be larger than the limit cycle amplitude in order to avoid a following error.

To perform auto tuning, take the following steps. Move the axis to be tuned somewhere near the center of it's travel. Set **tune-cycles** (the default value should be fine in most cases) and **tune-mode**. Set **tune-effort** to a small value. Set **enable** to true. Set **tune-mode** to true. Set **tune-start** to true. If no oscillation occurs, or the oscillation is too small, slowly increase **tune-effort**. Set **tune-start** to true. If no oscillation occurs, or the oscillation is too small, slowly increase **tune-effort**. Auto tuning can be aborted at any time by setting **enable** or **tune-mode** to false.

324.4. NAMING

The names for pins, parameters, and functions are prefixed as: **pid.N.** for N=0,1,...,num-1 when using **num_chan=num nameN.** for nameN=name1,name2,... when using **names=name1,name2,...**

The **pid.N.** format is shown in the following descriptions.

324.5. FUNCTIONS

pid.N.do-pid-calcs (uses floating-point) performs the PID calculations for control loop *N*.

324.6. PINS

pid.N.command float in

The desired (commanded) value for the control loop.

pid.N.Pgain float in

Proportional gain. Results in a contribution to the output that is the error multiplied by **Pgain**.

pid.N.Igain float in

Integral gain. Results in a contribution to the output that is the integral of the error multiplied by **Igain**. For example an error of 0.02 that lasted 10 seconds would result in an integrated error (**errorI**) of 0.2, and if **Igain** is 20, the integral term would add 4.0 to the output.

pid.N.Dgain float in

Derivative gain. Results in a contribution to the output that is the rate of change (derivative) of the error multiplied by **Dgain**. For example an error that changed from 0.02 to 0.03 over 0.2 seconds would result in an error derivative (**errorD**) of 0.05, and if **Dgain** is 5, the derivative term would add 0.25 to the output.

pid.N.feedback float in

The actual (feedback) value, from some sensor such as an encoder.

pid.N.output float out

The output of the PID loop, which goes to some actuator such as a motor.

pid.N.command-deriv float in

The derivative of the desired (commanded) value for the control loop. If no signal is connected then the derivative will be estimated numerically.

pid.N.feedback-deriv float in

The derivative of the actual (feedback) value for the control loop. If no signal is connected then the derivative will be estimated numerically. When the feedback is from a quantized position source (e.g., encoder feedback position), behavior of the D term can be improved by using a better velocity estimate here, such as the velocity output of encoder(9) or hostmot2(9).

pid.N.error-previous-target bit in

Use previous invocation's target vs. current position for error calculation, like the motion controller expects. This may make torque-mode position loops and loops requiring a large I gain easier to tune, by eliminating velocity-dependent following error.

pid.N.error float out

The difference between command and feedback.

pid.N.enable bit in

When true, enables the PID calculations. When false, **output** is zero, and all internal integrators, etc, are reset.

pid.N.index-enable bit in

On the falling edge of **index-enable**, pid does not update the internal command derivative estimate. On systems which use the encoder index pulse, this pin should be connected to the index-enable signal. When this is not done, and FF1 is nonzero, a step change in the input command causes a single-cycle spike in the PID output. On systems which use exactly one of the **-deriv** inputs, this

affects the D term as well.

pid.N.bias float in

bias is a constant amount that is added to the output. In most cases it should be left at zero. However, it can sometimes be useful to compensate for offsets in servo amplifiers, or to balance the weight of an object that moves vertically. **bias** is turned off when the PID loop is disabled, just like all other components of the output. If a non-zero output is needed even when the PID loop is disabled, it should be added with an external HAL sum2 block.

pid.N.FF0 float in

Zero order feed-forward term. Produces a contribution to the output that is **FF0** multiplied by the commanded value. For position loops, it should usually be left at zero. For velocity loops, **FF0** can compensate for friction or motor counter-EMF and may permit better tuning if used properly.

pid.N.FF1 float in

First order feed-forward term. Produces a contribution to the output that is **FF1** multiplied by the derivative of the commanded value. For position loops, the contribution is proportional to speed, and can be used to compensate for friction or motor CEMF. For velocity loops, it is proportional to acceleration and can compensate for inertia. In both cases, it can result in better tuning if used properly.

pid.N.FF2 float in

Second order feed-forward term. Produces a contribution to the output that is **FF2** multiplied by the second derivative of the commanded value. For position loops, the contribution is proportional to acceleration, and can be used to compensate for inertia. For velocity loops, the contribution is proportional to jerk, and should usually be left at zero.

pid.N.FF3 float in

Third order feed-forward term. Produces a contribution to the output that is **FF3** multiplied by the third derivative of the commanded value. For position loops, the contribution is proportional to jerk, and can be used to compensate for residual errors during acceleration. For velocity loops, the contribution is proportional to snap(jounce), and should usually be left at zero.

pid.N.deadband float in

Defines a range of "acceptable" error. If the absolute value of **error** is less than **deadband**, it will be treated as if the error is zero. When using feedback devices such as encoders that are inherently quantized, the deadband should be set slightly more than one-half count, to prevent the control loop from hunting back and forth if the command is between two adjacent encoder values. When the absolute value of the error is greater than the deadband, the deadband value is subtracted from the error before performing the loop calculations, to prevent a step in the transfer function at the edge of the deadband (see **BUGS**).

pid.N.maxoutput float in

Output limit. The absolute value of the output will not be permitted to exceed **maxoutput**, unless **maxoutput** is zero. When the output is limited, the error integrator will hold instead of integrating, to prevent windup and overshoot.

pid.N.maxerror float in

Limit on the internal error variable used for P, I, and D. Can be used to prevent high **Pgain** values from generating large outputs under conditions when the error is large (for example, when the command makes a step change). Not normally needed, but can be useful when tuning non-linear systems.

pid.N.maxerrorD float in

Limit on the error derivative. The rate of change of error used by the **Dgain** term will be limited to this value, unless the value is zero. Can be used to limit the effect of **Dgain** and prevent large output spikes due to steps on the command and/or feedback. Not normally needed.

pid.N.maxerrorI float in

Limit on error integrator. The error integrator used by the **Igain** term will be limited to this value, unless it is zero. Can be used to prevent integrator windup and the resulting overshoot during/after sustained errors. Not normally needed.

pid.N.maxcmdD float in

Limit on command derivative. The command derivative used by **FF1** will be limited to this value, unless the value is zero. Can be used to prevent **FF1** from producing large output spikes if there is a step change on the command. Not normally needed.

pid.N.maxcmdDD float in

Limit on command second derivative. The command second derivative used by **FF2** will be limited to this value, unless the value is zero. Can be used to prevent **FF2** from producing large output spikes if there is a step change on the command. Not normally needed.

pid.N.maxcmdDDD float in

Limit on command third derivative. The command third derivative used by **FF3** will be limited to this value, unless the value is zero. Can be used to prevent **FF3** from producing large output spikes if there is a step change on the command. Not normally needed.

pid.N.saturated bit out

When true, the current PID output is saturated. That is, + **output** = ± **maxoutput**.

pid.N.saturated-s float out**pid.N.saturated-count s32 out**

When true, the output of PID was continually saturated for this many seconds (**saturated-s**) or periods (**saturated-count**).

324.6.1. Additional auto tuning pins

pid.N.tune-mode bit in

When true, enables auto tune mode. When false, normal PID calculations are performed.

pid.N.tune-start bit io

When set to true, starts auto tuning. Cleared when the auto tuning completes.

pid.N*.tune-type u32 rw

When set to 0, **Pgain/Igain/Dgain** are calculated. When set to 1, **Pgain/Igain/FF1** are calculated.

pid.N.tune-cycles u32 rw

Determines the number of cycles to run to characterize the process. **tune-cycles** actually sets the number of half cycles. More cycles results in a more accurate characterization as the average of all cycles is used.

pid.N.tune-effort float rw

The maximum output value used during automatic tuning. Determines the effort used in setting up the limit cycle in the process. **tune-effort** should be set to a positive value less than **maxoutput**. Start with something small and work up to a value that results in a good portion of the maximum motor current being used. The smaller the value, the smaller the amplitude of the limit cycle.

pid.N.ultimate-gain float ro (only if debug=1)

Determined from process characterization. **ultimate-gain** is the ratio of **tune-effort** to the limit cycle amplitude multiplied by 4.0 divided by Pi.

pid.N.ultimate-period float ro (only if debug=1)

Determined from process characterization. **ultimate-period** is the period of the limit cycle.

324.7. PARAMETERS

pid.N.errorI float ro (only if debug=1)

Integral of error. This is the value that is multiplied by **Igain** to produce the Integral term of the output.

pid.N.errorD float ro (only if debug=1)

Derivative of error. This is the value that is multiplied by **Dgain** to produce the Derivative term of the output.

pid.N.commandD float ro (only if debug=1)

Derivative of command. This is the value that is multiplied by **FF1** to produce the first order feed-forward term of the output.

pid.N.commandDD float ro (only if debug=1)

Second derivative of command. This is the value that is multiplied by **FF2** to produce the second order feed-forward term of the output.

pid.N.commandDDD float ro (only if debug=1)

Third derivative of command. This is the value that is multiplied by **FF3** to produce the third order feed-forward term of the output.

324.8. BUGS

Some people would argue that deadband should be implemented such that error is treated as zero if it is

within the deadband, and be unmodified if it is outside the deadband. This was not done because it would cause a step in the transfer function equal to the size of the deadband. People who prefer that behavior are welcome to add a parameter that will change the behavior, or to write their own version of **pid**. However, the default behavior should not be changed.

Negative gains may lead to unwanted behavior. It is possible in some situations that negative FF gains make sense, but in general all gains should be positive. If some output is in the wrong direction, negating gains to fix it is a mistake; set the scaling correctly elsewhere instead.

Chapter 325. PLASMAC(9)

325.1. NAME

plasmac - A plasma cutter controller

325.2. SYNOPSIS

loadrt plasmac

325.3. DESCRIPTION

A plasma cutting table control component for use with the LinuxCNC 2.10.

325.3.1. VERSION

016

325.3.2. SUMMARY

Usage of this component is demonstrated in the QtPlasmaC example configurations included with LinuxCNC.

325.3.3. DISCLAIMER

THE AUTHOR OF THIS SOFTWARE ACCEPTS ABSOLUTELY NO LIABILITY FOR ANY HARM OR LOSS RESULTING FROM ITS USE.

IT IS EXTREMELY UNWISE TO RELY ON SOFTWARE ALONE FOR SAFETY.

Any machinery capable of harming persons must have provisions for completely stopping all motors and moving parts etc. before persons enter any danger area.

All machinery must be designed to comply with local and national safety codes, and the author of this software can not, and does not, take any responsibility for such compliance.

325.4. FUNCTIONS

plasmac.-

325.5. PINS

plasmac.arc-fail-delay float in

arc start failure timeout (seconds)

plasmac.arc-lost-delay float in

arc lost delay during a cut (seconds)

plasmac.arc-ok-high float in

maximum voltage level for Arc OK signal [mode 0] (volts)

plasmac.arc-ok-in bit in

external arc ok input signal [mode 1 & mode 2]

plasmac.arc-ok-low float in

minimum voltage level for Arc OK signal [mode 0] (volts)

plasmac.arc-max-starts s32 in

maximum attempts at starting the arc

plasmac.arc-voltage-in float in

arc voltage input [mode 0 & mode 1] see Notes above

plasmac.arc-voltage-offset float in

offset to set arc voltage to 0 at 0 volts

plasmac.arc-voltage-scale float in

scale to convert arc_voltage input to actual volts

plasmac.axis-x-max-limit float in

axis x maximum limit, connect to ini.x.max-limit

plasmac.axis-x-min-limit float in

axis x minimum limit, connect to ini.x.min-limit

plasmac.axis-x-position float in

current x axis position, connect to axis.x.pos-cmd

plasmac.axis-y-max-limit float in

axis y maximum limit, connect to ini.y.max-limit

plasmac.axis-y-min-limit float in

axis y minimum limit, connect to ini.y.min-limit

plasmac.axis-y-position float in

current y axis position, connect to axis.y.pos-cmd

plasmac.axis-z-max-limit float in

axis z maximum limit, connect to ini.z.max-limit

plasmac.axis-z-min-limit float in

axis z minimum limit, connect to ini.z.min-limit

plasmac.axis-z-position float in

current z axis position, connect to joint.N.pos-fb

plasmac.breakaway bit in

torch breakaway switch (optional, see float_switch)

plasmac.consumable-change bit in

change consumables in torch

plasmac.cornerlock-enable bit in

enable corner lock

plasmac.cornerlock-threshold float in

corner lock threshold (% of requested feed rate), speeds below this disable THC

plasmac.current-velocity float in

current machine velocity, connect to motion.current-vel

plasmac.cut-feed-rate float in

cut feed rate from current material (machine units per minute)

plasmac.cut-height float in

cut height (machine units)

plasmac.cut-recovery bit in

recover from cut error

plasmac.cut-volts float in

cut voltage (volts)

plasmac.cutting-start bit in

start a new cut, connect to spindle.0.on

plasmac.debug-print bit in

if true will print state changes as a debug aid

plasmac.dry-run bit in

perform a dry run without probing

plasmac.external-estop bit in

external E-stop input

plasmac.feed-override float in

feed override value from GUI (connect to halui.feed-override.value)

plasmac.feed-reduction float in

reduce adaptive feed to this percentage (connect to motion.analog-out-03)

plasmac.feed-upm float in

requested feed_rate, connect to motion.feed-upm to use as the default (G-code units per minute)

plasmac.float-switch bit in

float switch input (can also act as breakaway if it actuates when torch breaks away)

plasmac.float-switch-travel float in

float switch travel (machine units)

plasmac.gcode-scale float in (default: 1)

current G-code scale

plasmac.height-override float in

height override adjustment (volts)

plasmac.height-per-volt float in

torch height change per volt (machine units)

plasmac.homed bit in

machine is homed

plasmac.ignore-arc-ok-0 bit in

Do not require arc ok for start or cutting.

plasmac.ignore-arc-ok-1 bit in

Do not require arc ok for start or cutting.

plasmac.kerf-width float in

placeholder for better G-code portability between GUIs

plasmac.laser-mode bit in

laser mode for fiber lasers

plasmac.laser-recovery-start s32 in

start laser offset for cut recovery

plasmac.laser-x-offset s32 in

alignment laser x axis offset (scaled units)

plasmac.laser-y-offset s32 in

alignment laser y axis offset (scaled units)

plasmac.lowpass-frequency float in

lowpass cutoff frequency for arc voltage output

plasmac.machine-is-on bit in

machine is on signal, connect to halui.machine.is-on

plasmac.material-thickness float in

material thickness (machine units)

plasmac.max-offset s32 in (default: 5)

maximum height offset (mm)

plasmac.mesh-arc-ok bit in (default: *FALSE*)

Do not require arc ok for mesh mode.

plasmac.mesh-enable bit in

enable mesh cutting mode

plasmac.mode s32 in

operating mode

plasmac.motion-type s32 in

motion type, connect to motion.motion-type

plasmac.move-down bit in

external thc down switch [mode 2]

plasmac.move-up bit in

external thc up switch [mode 2]

plasmac.multi-tool bit in (default: 1)

allows the use of multiple tools

plasmac.offset-feed-rate float in

probe offset velocity (machine units per minute)

plasmac.offset-probe-delay float in

wait for probe to deploy (seconds)

plasmac.offset-probe-x float in

X axis offset for offset probe (machine units)

plasmac.offset-probe-y float in

Y axis offset for offset probe (machine units)

plasmac.offset-set-probe bit in

deploy probe for setting offsets

plasmac.offset-set-scribe bit in

deploy scribe for setting offsets

plasmac.offsets-active bit in

offsets are active, connect to motion.eoffset-active

plasmac.offsets-limited bit in

offsets are limited, connect to motion.eoffset-limited

plasmac.ohmic-max-attempts s32 in

maximum ohmic probe attempts before fallback to float switch

plasmac.ohmic-probe bit in

ohmic probe input, from ohmic-sense-out or external component/pin

plasmac.ohmic-probe-enable bit in

enable ohmic probe

plasmac.ohmic-probe-offset float in

Z axis offset for ohmic probe (machine units)

plasmac.ohmic-sense-on-delay s32 in (default: 3)

debounce cycles for ohmic sense on

plasmac.ohmic-sense-off-delay s32 in (default: 3)

debounce cycles for ohmic sense off

plasmac.ohmic-sense-in bit in

ohmic sense relay input

plasmac.ohmic-test bit in

test for shorted torch

plasmac.ok-sample-counts s32 in (default: 10)

arc_ok number of valid samples required [mode 0]

plasmac.ok-sample-threshold float in (default: 10)

arc_ok maximum arc voltage deviation allowed [mode 0]

plasmac.override-jog bit in

override jog inhibit

plasmac.pause-at-end float in

time to pause at end of cut

plasmac.paused-motion-speed float in

multiplier for speed of motion when paused, from -1 to 1

plasmac.pid-d-gain float in

derivative gain input [mode 0 & mode 1]

plasmac.pid-i-gain float in

integral gain input [mode 0 & mode 1]

plasmac.pid-p-gain float in

proportional gain input [mode 0 & mode 1]

plasmac.pierce-delay float in

time required to pierce stock (seconds)

plasmac.pierce-height float in

pierce height (machine units)

plasmac.probe-feed-rate float in

probe down velocity (machine units per minute)

plasmac.probe-final-speed s32 in (default: 1)

final probe speed (steps per servo period)

plasmac.probe-start-height float in

probe starting height

plasmac.probe-test bit in

probe test only

plasmac.program-is-idle bit in

program is idle, connect to halui.program.is-idle

plasmac.program-is-paused bit in

program is paused, connect to halui.program.is-paused

plasmac.program-is-running bit in

program is running, connect to halui.program.is-running

plasmac.puddle-jump-delay float in

Delay move from pierce height to cut height (seconds), leave disconnected if not required.

plasmac.puddle-jump-height float in

Puddle jump height (percentage of pierce height), leave disconnected if not required.

plasmac.requested-velocity float in

deprecated

plasmac.resolution s32 in (default: 100)

multiplier for resolution of the offset counts

plasmac.restart-delay float in

time from arc failure till next restart attempt

plasmac.safe-height float in

requested safe traverse height (machine units)

plasmac.scribe-arm-delay float in

delay from scribe arm to scribe on

plasmac.scribe-on-delay float in

delay from scribe on to motion beginning

plasmac.scribe-start bit in

start a new scribe, connect to spindle.1.on

plasmac.setup-feed-rate float in

feed rate for moves to pierce and cut heights (machine units per minute)

plasmac.skip-ihs-distance float in

skip IHS if less than this distance from last cut

plasmac.slat-height float in

slat height (machine units)

plasmac.spotting-start bit in

start a new spot, connect to spindle.2.on

plasmac.spotting-threshold float in

threshold voltage to start spotting delay

plasmac.spotting-time float in

torch off delay after spotting threshold reached

plasmac.thc-auto bit in

enable automatic thc activation

plasmac.thc-delay float in

delay from cut feed rate reached to THC activate (seconds) [non auto THC]

plasmac.thc-disable bit in

thc disable

plasmac.thc-enable bit in

enable/disable thc and set the IHS skip type

plasmac.thc-feed-rate float in

maximum feed rate for thc (machine units per minute)

plasmac.thc-sample-counts s32 in (default: 50)

the number of valid samples required [auto THC]

plasmac.thc-sample-threshold float in (default: 1)

the maximum arc voltage deviation allowed [auto THC]

plasmac.thc-threshold float in

thc threshold (volts), changes below this have no effect

plasmac.torch-enable bit in

enable torch

plasmac.torch-off bit in

turn torch off

plasmac.torch-pulse-abort bit in

torch pulse abort

plasmac.torch-pulse-hold bit in

torch pulse hold

plasmac.torch-pulse-start bit in

torch pulse start

plasmac.torch-pulse-time float in

torch pulse time (seconds)

plasmac.tube-cut bit in

set the current job as tube cutting

plasmac.units-per-mm float in

for scale calcs, connect to halui.machine.units-per-mm

plasmac.use-auto-volts bit in

use calculated voltage for thc baseline

plasmac.voidlock-enable bit in

enable voidlock [mode 0 & mode 1]

plasmac.voidlock-off-cycles s32 in (default: 10)

number of sampling cycles to deactivate voidlock

plasmac.voidlock-on-cycles s32 in (default: 2)

number of sampling cycles to activate voidlock

plasmac.voidlock-slope s32 in (default: 500)

voidlock slope in volts per second

plasmac.x-offset s32 in

offset to apply to axis x for consumable change and cut recovery (scaled units)

plasmac.x-offset-current float in

current x axis offset, connect to axis.x.eoffset

plasmac.xy-feed-rate float in

feed-rate for consumable change

plasmac.y-offset s32 in

offset to apply to axis y for consumable change and cut recovery (scaled units)

plasmac.y-offset-current float in

current y axis offset, connect to axis.y.eoffset

plasmac.z-offset-current float in

current z axis offset, connect to axis.z.eoffset

plasmac.zero-window float in (default: 0.1)

sets window that voltage fluctuations show as zero (-0.1 to 0.1 at default value)

plasmac.pierce-type s32 in (default: 0)

allows motion to progress during pierce. 0=No movement, 1=Wiggle, 2=Ramp

plasmac.pierce-motion-delay float in (default: 0)

delay starting motion during pierce delay period. This is a % of Pierce Delay. Only used when pierce-with-motion is True.

plasmac.cut-height-delay float in (default: 0)

at the end of transition to end-pierce-height how long to pause before transition to cut height.

plasmac.pierce-end-height float in (default: 0)

height at end of piercing (in machine units). Can be different to Cut Height. Default 0 means not used. i.e. no change in height.

plasmac.gouge-speed float in (default: 0)

ramp starting speed for gouge. In machine units/min.

plasmac.gouge-speed-distance float in (default: 0)

distance gouge will run in machine units. Gouge plus creep distance should not be longer than any lead in.

plasmac.creep-speed float in (default: 0)

ramp creep or intermediate speed. Comes after gouge and is before cut speed. In machine units/min.

plasmac.creep-speed-distance float in (default: 0)

distance creep will run in machine units. Gouge plus creep distance should not be longer than any lead in.

plasmac.adaptive-feed float out

for reverse-run, connect to motion.adaptive-feed

plasmac.arc-ok-out bit out

arc ok output

plasmac.arc-voltage-out float out

arc voltage output [mode 0 & mode 1]

plasmac.consumable-changing bit out

consumables are being changed

plasmac.cornerlock-is-locked bit out

corner locked indicator

plasmac.current-feed-rate float out

current feed rate per minute (for auto-thc)

plasmac.cut-length float out

length of current cut job

plasmac.cut-recovering bit out

recovering from cut error

plasmac.cut-time float out

cut time of current job

plasmac.cutting-stop bit out

stop manual cut, connect to halui.spindle.0.stop

plasmac.feed-hold bit out

feed hold, connect to motion.feed-hold

plasmac.jog-inhibit bit out

jog inhibit, connect to motion.jog-inhibit

plasmac.laser-recovery-state s32 out

laser recovery status

plasmac.led-down bit out

thc move down indicator

plasmac.led-up bit out

thc move up indicator

plasmac.offset-scale float out

offset scale, connect to axis.<x y z>.eoffset-scale

plasmac.ohmic-enable bit out

on only while probing

plasmac.ohmic-sense-out bit out

ohmic sense output state

plasmac.paused-motion bit out

paused motion flag, true when paused motion is active

plasmac.paused-time float out

paused time during current job

plasmac.pierce-count s32 out

number of pierce attempts (torch starts)

plasmac.probe-out bit out

probe for tube cutting, connect to motion.probe-input

plasmac.probe-test-error bit out

minimum limit reached while probe testing

plasmac.probe-time float out

probe time of current job

plasmac.program-pause bit out

pause the current program, connect to halui.program.pause

plasmac.program-resume bit out

resume the currently paused program, connect to halui.program.resume

plasmac.program-run bit out

run the currently loaded program, connect to halui.program.run

plasmac.program-stop bit out

stop current program, connect to halui.program.stop

plasmac.rapid-time float out

rapid motion time of current job

plasmac.requested-feed-rate float out

requested feed rate (for auto-thc)

plasmac.run-time float out

run time of current job

plasmac.safe-height-is-limited bit out

safe height is limited indicator

plasmac.sensor-active bit out

one of float, ohmic, or breakaway is detected

plasmac.scribe-arm bit out

arm the scribe

plasmac.scribe-on bit out

turn scribe on

plasmac.state-out s32 out

current state

plasmac.stop-type-out s32 out

current stop type

plasmac.thc-active bit out

thc status output

plasmac.thc-enabled bit out

thc is enabled

plasmac.torch-on bit out

turn torch on, connect to your torch on input

plasmac.torch-time float out

torch on time of current job

plasmac.voidlock-is-locked bit out

voidlock is locked indicator [mode 0 & mode 1]

plasmac.x-offset-counts s32 out

x offset for consumable change, connect to axis.x.eoffset-counts

plasmac.xy-offset-enable bit out

enable x and y offsets, connect to axis.<x & y>.eoffset-enable

plasmac.y-offset-counts s32 out

y offset for consumable change, connect to axis.y.eoffset-counts

plasmac.z-height float out

current z axis height relative to the probed zero height

plasmac.z-offset-counts s32 out

z offset for height control, connect to axis.z.eoffset-counts

plasmac.z-offset-enable bit out

enable z offsets, connect to axis.z.eoffset-enable

plasmac.z-relative float out

distance of Z from last probed height

plasmac.low-cut-volts s32 in

low cut voltage threshold while thc active

plasmac.target-samples s32 in (default: 6)

number of samples for setting target_volts

plasmac.target-volts float out

target voltage for thc, set by arc voltage at cut height

325.6. AUTHOR

Phillip A Carter & Gregory D Carl

325.7. LICENSE

GPLv2 or greater

Chapter 326. PUSHMSG(9)

326.1. NAME

pushmsg - Push configurable RT messages to non-RT logging on pin change

326.2. SYNOPSIS

loadrt pushmsg [msgs=value[,value...]]

msgs

Comma separated list of custom messages in format level|pinname|message

326.3. DESCRIPTION

The **pushmsg** component enables you to generate configurable messages to your GUI, terminal or other interface from real-time components using HAL pins.

Up to 64 messages can be configured using the **msgs** module parameter using the following syntax:

"level|pinname|message" [...]

level

is a letter denoting the severity level of the message with:

- **e** - error
- **w** - warning
- **i** - info
- **d** - debug

pinname

is the HAL pin name base used in the creation of the trigger pins:

- **pushmsg.<pinname>.trigger** (bit) - The trigger input to activate the message
- **pushmsg.<pinname>.edge** (bit) - The trigger input edge selection with FALSE=rising trigger edge and TRUE=falling trigger edge
- **pushmsg.<pinname>.force** (bit) - An always active rising edge trigger to activate the message, regardless of the setting of the global enable pin (**pushmsg.enable**)

message

is a free form text message.

The text may include **{t:refname}** placeholders for HAL pin value substitutions (use **\{** to embed a literal curly brace). Up to two placeholders are supported. Each placeholder creates a typed input pin **pushmsg.<pinname>.<refname>** that the user wires up to the source signal. The type letter in the placeholder selects the pin type:

- **b** - bit

- **s** - s32
- **u** - u32
- **l** - s64
- **k** - u64
- **f** - float

Each message line is limited to 128 characters in length. The length count includes the **level** indicator, **pinname**, **message** text and the **|** separator characters.

HAL file example:

```
loadrt pushmsg msgs="e|nooil|No oil pressure","w|low|Oil {f:level} L low"
addf pushmsg servo-thread
net no-oil classicladder.0.out-21 pushmsg.nooil.trigger
net oil-level oil.level pushmsg.low.level
...
```

The INI-file may be an administrative help for message configuration. A longer list is much easier to read and maintain when split over multiple lines. The INI-file format supports continuations that improve readability and maintainability.

Example INI expansion:

```
[PUSHMSG]
# Note: no surrounding whitespace, last line has no comma
MSGs=\
"e|nooil|No oil pressure",\
"w|low|Oil {f:level} L low"
```

The HAL file then looks like:

```
loadrt pushmsg msgs=[PUSHMSG]MSGs
addf pushmsg servo-thread
...
```

326.4. FUNCTIONS

pushmsg.-

326.5. PINS

pushmsg.enable bit in (default: *TRUE*)

Enable message generation through trigger input pins

326.6. AUTHOR

LinuxCNC

326.7. LICENSE

GPL

Chapter 327. pwmgen(9)

327.1. NAME

pwmgen - software PWM/PDM generation

327.2. SYNOPSIS

loadrt pwmgen output_type=type0[,type1...]

327.3. DESCRIPTION

pwmgen is used to generate PWM (pulse width modulation) or PDM (pulse density modulation) signals. The maximum PWM frequency and the resolution is quite limited compared to hardware-based approaches, but in many cases software PWM can be very useful. If better performance is needed, a hardware PWM generator is a better choice.

pwmgen supports a maximum of eight channels. The number of channels actually loaded depends on the number of *type* values given. The value of each *type* determines the outputs for that channel.

type 0: single output

A single output pin, **pwm**, whose duty cycle is determined by the input value for positive inputs, and which is off (or at **min-dc**) for negative inputs. Suitable for single ended circuits.

type 1: pwm/direction

Two output pins, **pwm** and **dir**. The duty cycle on **pwm** varies as a function of the input value. **dir** is low for positive inputs and high for negative inputs.

type 2: up/down

Two output pins, **up** and **down**. For positive inputs, the PWM/PDM waveform appears on **up**, while **down** is low. For negative inputs, the waveform appears on **down**, while **up** is low. Suitable for driving the two sides of an H-bridge to generate a bipolar output.

327.4. FUNCTIONS

pwmgen.make-pulses (no floating-point)

Generates the actual PWM waveforms, using information computed by **update**. Must be called as frequently as possible, to maximize the attainable PWM frequency and resolution, and minimize jitter. Operates on all channels at once.

pwmgen.update (uses floating point)

Accepts an input value, performs scaling and limit checks, and converts it into a form usable by **make-pulses** for PWM/PDM generation. Can (and should) be called less frequently than **make-pulses**. Operates on all channels at once.

327.5. PINS

pwmgen.N.enable bit in

Enables PWM generator *N* - when false, all **pwmgen.N** output pins are low.

pwmgen.N.value float in

Commanded value. When **value** = 0.0, duty cycle is 0%, and when **value** = \pm **scale**, duty cycle is \pm 100% (subject to **min-dc** and **max-dc** limitations).

pwmgen.N*.pwm bit out (output types 0 and 1 only)

PWM/PDM waveform.

pwmgen.N.dir bit out (output type 1 only)

Direction output: low for forward, high for reverse.

pwmgen.N.up bit out (output type 2 only)

PWM/PDM waveform for positive input values, low for negative inputs.

pwmgen.N.down bit out (output type 2 only)

PWM/PDM waveform for negative input values, low for positive inputs.

pwmgen.N.curr-dc float out

The current duty cycle, after all scaling and limits have been applied. Range is from -1.0 to +1.0.

pwmgen.N.max-dc float in/out

The maximum duty cycle. A value of 1.0 corresponds to 100%. This can be useful when using transistor drivers with bootstrapped power supplies, since the supply requires some low time to recharge.

pwmgen.N.min-dc float in/out

The minimum duty cycle. A value of 1.0 corresponds to 100%. Note that when the pwm generator is disabled, the outputs are constantly low, regardless of the setting of **min-dc**.

pwmgen.N.scale float in/out

pwmgen.N.offset float in/out

These parameters provide a scale and offset from the **value** pin to the actual duty cycle. The duty cycle is calculated according to $dc = (value/scale) + offset$, with 1.0 meaning 100%.

pwmgen.N.pwm-freq float in/out

PWM frequency in Hz. The upper limit is half of the frequency at which **make-pulses** is invoked, and values above that limit will be changed to the limit. If **dither-pwm** is false, the value will be changed to the nearest integer submultiple of the **make-pulses** frequency. A value of zero produces Pulse Density Modulation instead of Pulse Width Modulation.

pwmgen.N.dither-pwm bit in/out

Because software-generated PWM uses a fairly slow timebase (several to many microseconds), it has limited resolution. For example, if **make-pulses** is called at a 20 kHz rate, and **pwm-freq** is 2 kHz,

there are only 10 possible duty cycles. If **dither-pwm** is false, the commanded duty cycle will be rounded to the nearest of those values. Assuming **value** remains constant, the same output will repeat every PWM cycle. If **dither-pwm** is true, the output duty cycle will be dithered between the two closest values, so that the long-term average is closer to the desired level. **dither-pwm** has no effect if **pwm-freq** is zero (PDM mode), since PDM is an inherently dithered process.

Chapter 328. RASTER(9)

328.1. NAME

raster - Outputs laser power based upon pre programmed rastering data

328.2. SYNOPSIS

loadrt raster [**count**=*N* | **names**=*name1* [, *name2* ...]]

328.3. DESCRIPTION

The raster component converts a single raster program line to laser output. The position pin is slaved to the axis that the raster line maps too. The raster program must be programmed for each raster line that is to be executed. The port must be programmed prior to a raster line being executed.

A python component RasterProgrammer ([lib/python/RasterProgrammer.py](#)) is provided to ease programming of the raster component. An example [configs/sim/axis/laser](#) shows how these pieces could be integrated for a functional laser engraver config.

A program line format is as follows:

```
{program_offset};{bits_per_pixel};{pixels_per_unit};{number_of_ pixels};{pixel_data ....}
```

- **program_offset**: a float. It indicates the start position of the raster line relative to the current axis position. A negative **program_offset** indicates that the raster sweeps from positive to negative. A zero or positive **program_offset*** indicates that the raster sweeps from negative to positive direction.
- **bits_per_pixel**: an integer. It indicates the precision of a pixel value and consequently the number of bytes consumed per pixel value. A bits per pixel of 4 takes 1 character (0-F) and scales out from from 0.0 to 1.0 (0 being 0 and E being 1.0). F corresponds to off or -1.0. A bits per pixel of 8 takes 2 characters per pixel, 12 takes 3 characters per pixel etc...
- **pixels_per_unit**: a float that represents the size of a pixel in machine units. 1 would correspond to 1 pixel per machine unit, 100 would correspond to 100 pixels per machine unit.
- **number_of_pixels**: an integer that indicates the length of the raster line in pixels. The length of the rasterline in machine units would be **number_of_pixels** / **pixels_per_unit**
- **pixel_data**: a series of hexadecimal digits ([0-9][a-f][A-F]) the represents the pixel data. **bits_per_pixel** determines the resolution of a pixel and how many hexadecimal digits per pixel. pixel data characters have no delimiter between each pixel.
4 bpp is one character per pixel
8 bpp is 2 characters per pixel
12 bpp is 3
etc...

328.4. FUNCTIONS

raster.N

328.5. PINS

raster.N.position float in

input coordinate for raster

raster.N.reset bit in

resets the component

raster.N.program port in

pixel data used by the raster

raster.N.run bit in

starts the raster

raster.N.enabled bit out (default: 0)

When a valid raster program is running.

raster.N.output float out (default: -1)

current output level command

raster.N.fault bit out (default: 0)

If error has occurred

raster.N.fault-code s32 out (default: 0)

Code of fault

raster.N.state s32 out (default: 0)

current state

raster.N.program-position float out (default: 0.0)

base position of program at run start

raster.N.program-offset float out (default: 0.0)

offset to start of pixel data

raster.N.bpp s32 out (default: 0)

bits per pixel.

raster.N.ppu float out (default: 0.0)

pixels per unit

raster.N.count s32 out (default: 0)

pixel count

raster.N.bitmap-position float out (default: 0.0)

calculated position in bitmap

raster.N.current-pixel-value float out (default: -1.0)

current loaded pixel value

raster.N.previous-pixel-value float out (default: -1.0)

previously loaded pixel value

raster.N.current-pixel-index s32 out (default: -1)

currently loaded pixel index

raster.N.fraction float out (default: 0.0)

328.6. LICENSE

GPL

Chapter 329. RESET(9)

329.1. NAME

reset - Resets an IO signal

329.2. SYNOPSIS

loadrt reset [count=*N* | names=*name1* [,*name2*...]]

329.3. DESCRIPTION

Component to reset IO signals.

This function works like a conditional sets - it is fed with a float and/or bit/s32/u32 pins that are I/O, but are save the value only if the **trigger** pin is set. The values assigned to those signals are passed via the input pins reset_float/s32/u32/bit.

329.4. FUNCTIONS

reset.*N*

Update the output value

329.5. PINS

reset.*N*.trigger bit in

Trigger input

reset.*N*.out-u32 u32 io (default: 0)

Unsigned 32 bit integer output value

reset.*N*.reset-u32 u32 in (default: 0)

Unsigned 32 bit integer reset value

reset.*N*.out-s32 s32 io (default: 0)

Signed 32 bit integer output value

reset.*N*.reset-s32 s32 in (default: 0)

Signed 32 bit integer reset value

reset.*N*.out-float float io (default: 0.0)

Float output value

reset.*N*.reset-float float in (default: 0.0)

Float reset value

reset.N.out-bit bit io (default: *false*)

Bit integer output value

reset.N.reset-bit bit in (default: *false*)

Bit reset value

reset.N.retriggerable bit in (default: *true*)

Allow additional edges to reset

reset.N.rising bit in (default: *true*)

Trigger on rising edge

reset.N.falling bit in (default: *false*)

Trigger on falling edge

329.6. AUTHOR

Alexander Rössler

329.7. LICENSE

GPL

Chapter 330. rosekins(9)

330.1. NAME

rosekins - Kinematics for a rose engine

330.2. SYNOPSIS

loadrt rosekins

330.3. KINEMATICS

joint_0 linear,
transverse (perpendicular to spindle) joint_1 linear,
longitudinal (parallel to spindle identity to z) joint_2 rotary,
spindle (workholding, not tool holding, e.g. not a highspeed spindle)

330.4. PINS

rosekins.revolutions float out

Count of crossings of the negative X axis. Clockwise crossings increment revolutions by 1, counterclockwise crossings decrement by 1.

rosekins.theta_degrees float out

Principal value for $\arctan(Y/X)$

rosekins.bigtheta_degrees float out

Accumulated angle ($\theta + \text{revolutions} * 360$)

330.5. NOTES

Theta is the principal value of $\arctan(Y/X)$. Joint_2 angle values are not limited to principal values of $\arctan(Y/X)$ but accumulate continuously as the spindle is rotated. HAL pins are provided for the principal value and a count of the number of revolutions.

The transverse motion is exactly perpendicular to the spindle. In a traditional rose engine, the transverse motion is created by *rocking* the headstock about a pivot. A typical pivot length combined with the limited amount of X travel in a real machine make the perpendicular approximation a reasonable model.

Chapter 331. SAFETY_LATCH(9)

331.1. NAME

safety_latch - latch for error signals

331.2. SYNOPSIS

loadrt safety_latch [count=*N* | names=*name1*[,*name2*...]]

331.3. DESCRIPTION

HAL component that implements a safety latch for error signals with customizable harm, healing and latching features.

When the component is not enabled the error input value is forwarded to output without further modifications.

If error-in is true the error count is increased by harm. If error-in is false the error count is decreased by heal. When the error count exceeds the threshold value error-out is set to true. If latching is false the error-out pin will only return to false when reset is set to true.

The inputs pin min and max clamp the error count value to a specified range.

331.4. FUNCTIONS

safety-latch.*N*

331.5. PINS

safety-latch.*N*.error-in bit in (default: *false*)

Error Input

safety-latch.*N*.heal s32 in (default: *1*)

Heal when ok per tick

safety-latch.*N*.harm s32 in (default: *1*)

Harm when error per tick

safety-latch.*N*.latching bit in (default: *true*)

If a reset is necessary to heal an error

safety-latch.*N*.reset bit in (default: *false*)

Reset input

safety-latch.N.threshold s32 in (default: 100)

Error output threshold

safety-latch.N.min s32 in (default: 0)

Minimum count

safety-latch.N.max s32 in (default: 1000)

Maximum count

safety-latch.N.enable bit in (default: *true*)

If not enabled the error count is passed to the output

safety-latch.N.count s32 out (default: 0)

Current count

safety-latch.N.error-out bit out (default: *false*)

Error output

safety-latch.N.ok-out bit out (default: *true*)

Ok output

331.6. AUTHOR

Alexander Rössler

331.7. LICENSE

GPL

Chapter 332. SAMPLE_HOLD(9)

332.1. NAME

sample_hold - Sample and Hold

332.2. SYNOPSIS

loadrt sample_hold [**count**=*N*|**names**=*name1*[,*name2*...]]

332.3. FUNCTIONS

sample-hold.*N*

332.4. PINS

sample-hold.*N*.in s32 in

sample-hold.*N*.hold bit in

sample-hold.*N*.out s32 out

332.5. SEE ALSO

tristate(9)

332.6. AUTHOR

Stephen Wille Padnos

332.7. LICENSE

GPL

Chapter 333. sampler(9)

333.1. NAME

sampler - sample data from HAL in real time

333.2. SYNOPSIS

loadrt sampler depth=depth1[,depth2...] cfg=string1[,string2...]

333.3. DESCRIPTION

The HAL component **sampler** and the program **halsampler**(1) are used together to sample HAL data in real time and store it in a file. Of these, **sampler** performs in realtime, exporting HAL pins and creates a FIFO (first-in, first out queue) in shared memory. It then samples data from the HAL and sends these to the FIFO. The application **halsampler** copies data from the FIFO to stdout, where it can be redirected to a file or piped to some other program.

333.4. OPTIONS

depth=depth1[,depth2...]

sets the depth of the realtime → non-realtime FIFO that **sampler** creates to buffer the realtime data. Multiple values of *depth* (separated by commas) can be specified if you need more than one FIFO (for example if you want to sample data from two different realtime threads).

cfg=string1[,string2...]

defines the set of HAL pins that **sampler** exports and later samples data from. One *string* must be supplied for each FIFO, separated by commas. **sampler** exports one pin for each character in *string*. Legal characters are:

- **F, f** (float pin)
- **B, b** (bit pin)
- **S, s** (s32 pin)
- **U, u** (u32 pin)

333.5. FUNCTIONS

sampler.N

One function is created per FIFO, numbered from zero.

333.6. PINS

sampler.N.pin.M input

Pin for the data that will wind up in column *M* of FIFO *N* (and in column *M* of the output file). The pin type depends on the config string.

sampler.N.curr-depth s32 output

Current number of samples in the FIFO. When this reaches *depth* new data will begin overwriting old data, and some samples will be lost.

sampler.N.full bit output

TRUE when the FIFO *N* is full, FALSE when there is room for another sample.

sampler.N.enable bit input

When TRUE, samples are captured and placed in FIFO *N*, when FALSE, no samples are acquired. Defaults to TRUE.

333.7. PARAMETERS

sampler.N.overruns s32 read/write

The number of times that **sampler** has tried to write data to the HAL pins but found no room in the FIFO. It increments whenever **full** is true, and can be reset by the **setp** command.

sampler.N.sample-num s32 read/write

A number that identifies the sample. It is automatically incremented for each sample, and can be reset using the **setp** command. The sample number can optionally be printed in the first column of the output from **halsampler**, using the **-t** option (see **man 1 halsampler**).

333.8. SEE ALSO

halsampler(1), streamer(9), halstreamer(1)

333.9. AUTHOR

Original version by John Kasunich, as part of the LinuxCNC project. Improvements by several other members of the LinuxCNC development team.

333.10. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

333.11. COPYRIGHT

Copyright © 2006 John Kasunich.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 334. SCALE(9)

334.1. NAME

scale - LinuxCNC HAL component that applies a scale and offset to its input

334.2. SYNOPSIS

loadrt scale [count=*N* | names=*name1*[,*name2*...]]

334.3. FUNCTIONS

scale.*N*

334.4. PINS

scale.*N*.in float in

scale.*N*.gain float in

scale.*N*.offset float in

scale.*N*.out float out

out = in * gain + offset

334.5. AUTHOR

Jeff Epler

334.6. LICENSE

GPL

Chapter 335. SCALED_S32_SUMS(9)

335.1. NAME

scaled_s32_sums - Sum of four inputs (each with a scale)

335.2. SYNOPSIS

loadrt scaled_s32_sums [**count**=*N* | **names**=*name1*[,*name2*...]]

335.3. FUNCTIONS

scaled-s32-sums.*N*

335.4. PINS

scaled-s32-sums.*N*.in0 s32 in

scaled-s32-sums.*N*.in1 s32 in

scaled-s32-sums.*N*.in2 s32 in

scaled-s32-sums.*N*.in3 s32 in

scaled-s32-sums.*N*.scale0 float in (default: 1.0)

scaled-s32-sums.*N*.scale1 float in (default: 1.0)

scaled-s32-sums.*N*.scale2 float in (default: 1.0)

scaled-s32-sums.*N*.scale3 float in (default: 1.0)

scaled-s32-sums.*N*.out-s s32 out

scaled-s32-sums.*N*.out-f float out

out-s = out-f = (in0 * scale0) + (in1 * scale1) + (in2 * scale2) + (in3 * scale3)

335.5. SEE ALSO

sum2(9), weighted_sum(9)

335.6. AUTHOR

Chris S Morley

335.7. LICENSE

GPL

Chapter 336. SELECT8(9)

336.1. NAME

select8 - 8-bit binary match detector

336.2. SYNOPSIS

loadrt select8 [**count**=*N* | **names**=*name1* [, *name2* ...]]

336.3. FUNCTIONS

select8.N

336.4. PINS

select8.N.enable bit in (default: *TRUE*)

Set enable to FALSE to cause all outputs to be set FALSE.

select8.N.sel s32 in

The number of the output to set TRUE. All other outputs will be set FALSE.

select8.N.outM bit out (**M**=0..7)

Output bits. If enable is set and the sel input is between 0 and 7, then the corresponding output bit will be set true.

336.5. SEE ALSO

demux(9)

336.6. AUTHOR

Stephen Wille Padnos

336.7. LICENSE

GPL

Chapter 337. SERPORT(9)

337.1. NAME

`serport` - Hardware driver for the digital I/O bits of the 8250 and 16550 serial port.

337.2. SYNOPSIS

loadrt serport io=addr[,addr...]

The pin numbers refer to the 9-pin serial pinout. Keep in mind that these ports generally use rs232 voltages, not 0/5V signals.

Specify the I/O address of the serial ports using the module parameter **io=addr[,addr...]**. These ports must not be in use by the kernel. To free up the I/O ports after bootup, install `setserial` and execute a command like:

```
sudo setserial /dev/ttyS0 uart none
```

but it is best to ensure that the serial port is never used or configured by the Linux kernel by setting a kernel commandline parameter or not loading the serial kernel module if it is a modularized driver.

337.3. FUNCTIONS

serport.N.read

serport.N.write

337.4. PINS

serport.N.pin-1-in bit out

Also called DCD (data carrier detect); pin 8 on the 25-pin serial pinout

serport.N.pin-6-in bit out

Also called DSR (data set ready); pin 6 on the 25-pin serial pinout

serport.N.pin-8-in bit out

Also called CTS (clear to send); pin 5 on the 25-pin serial pinout

serport.N.pin-9-in bit out

Also called RI (ring indicator); pin 22 on the 25-pin serial pinout

serport.N.pin-1-in-not bit out

Inverted version of pin-1-in

serport.N.pin-6-in-not bit out

Inverted version of pin-6-in

serport.N.pin-8-in-not bit out

Inverted version of pin-8-in

serport.N.pin-9-in-not bit out

Inverted version of pin-9-in

serport.N.pin-3-out bit in

Also called TX (transmit data); pin 2 on the 25-pin serial pinout

serport.N.pin-4-out bit in

Also called DTR (data terminal ready); pin 20 on the 25-pin serial pinout

serport.N.pin-7-out bit in

Also called RTS (request to send); pin 4 on the 25-pin serial pinout

337.5. PARAMETERS

serport.N.pin-3-out-invert bit rw

serport.N.pin-4-out-invert bit rw

serport.N.pin-7-out-invert bit rw

serport.N.ioaddr u32 r

337.6. LICENSE

GPL

Chapter 338. setsserial(9)

338.1. NAME

setsserial - a utility for setting Smart Serial NVRAM parameters.

338.2. SYNOPSIS

loadrt setsserial cmd="command parameter/device value/filename"

NOTE: This rather clunky utility is no longer needed except for flashing new smart-serial remote firmware. Smart-serial remote parameters can now be set in the HAL file in the normal way.

338.3. FUNCTIONS

None

338.4. PINS

None

338.5. USAGE

```
loadrt setsserial cmd="set hm2_8i20.001f.nvmaxcurrent 750"
```

Commands available are **set** and **flash**.

This utility should be used under halcmd, without LinuxCNC running or any realtime threads running.

A typical command sequence would be:

```
halrun
loadrt hostmot2 use_serial_numbers=1 loadrt hm2_pci config
="firmware=hm2/5i23/svss8_8.bit"
show param
loadrt setsserial cmd="set hm2_8i20.001f.nvmaxcurrent 750"
exit
```

This example uses the option to have the HAL pins and parameters labelled by the serial number of the remote. This is not necessary but can reduce the scope for confusion. (The serial number is normally on a sticker on the device.)

The next line loads the hm2_pci driver in the normal way. The hm2_7i43 driver should work equally well, as should any future 7i80 driver. If the card has already been started up and a firmware has been loaded, then the config string may be omitted.

"show param" is optional, but provides a handy list of all the devices and parameters. It also shows the current values of the parameters which can be useful for determining scaling. u32 pin values are always shown in hex, but new values can be entered in decimal or hex. Use the Ox123ABC format to enter a hex value.

The next line invokes setsserial. This is run in a slightly strange way in order to have kernel-level access to a live Hostmot2 config. It is basically a HAL module that always fails to load. This may lead to error messages being printed to the **halcmd:** prompt. These can often be ignored. All the real feedback is via the dmesg command. It is suggested to have a second terminal window open to run dmesg after each command.

On exiting there will typically be a further error message related to the driver failing to unload setsserial. This can be ignored.

The parameter changes will not show up until the drivers are reloaded.

Flashing Firmware To flash new firmware to an FPGA card such as the 5i25 or 5i20 the "mesaflash" utility should be used. Setsserial is only useful for changing/updating the firmware on smart-serial remote such as the 8i20. The firmware should be placed somewhere in the /lib/firmware/hm2 tree, where the Linux firmware loading macros can find it.

The flashing routine operates in a realtime thread, and can only send prompts to the user through the kernel log (dmesg). It is most convenient to open two terminal windows, one for command entry and one to monitor progress.

In the first terminal enter

```
tail -f /var/log/kern.log
```

This terminal will now display status information.

The second window will be used to enter the commands. It is important that LinuxCNC and/or HAL are not already loaded when the process is started. To flash new firmware it is necessary to move a jumper on the smart-serial remote drive and to switch smart-serial communication to a slower baudrate.

A typical command sequence is then

```
halrun
loadrt hostmot2 sserial_baudrate=115200 loadrt hm2_pci config
="firmware=hm2/5i23/svss8_8.bit"
loadrt setsserial cmd="flash hm2_5i23.0.8i20.0.1 hm2/8i20/8i20T.BIN"
exit
```

It is not necessary (or useful) to specify a config string in a system using the 5i25 or 6i25 cards.

Note that it is necessary to exit halrun and unload the realtime environment before flashing the next card (exit)

The correct sserial channel name to use can be seen in the dmesg output in the feedback terminal after the loadrt hm2_pci step of the sequence.

338.6. LICENSE

GPL

Chapter 339. siggen(9)

339.1. NAME

siggen - signal generator

339.2. SYNOPSIS

loadrt siggen[num_chan=num | names=name1[,name2...]]

339.3. DESCRIPTION

siggen is a signal generator that can be used for testing and other applications that need simple waveforms. It produces sine, cosine, triangle, sawtooth, and square waves of variable frequency, amplitude, and offset, which can be used as inputs to other HAL components.

siggen supports a maximum of sixteen channels. The number of channels actually loaded is set by the **num_chan** argument when the module is loaded. Alternatively, specify **names=** and unique names separated by commas.

The **num_chan=** and **names=** specifiers are mutually exclusive. If neither **num_chan=** nor **names=** are specified, the default value is one.

339.4. NAMING

The names for pins, parameters, and functions are prefixed as:

siggen.N. for $N = 0, 1, \dots, num-1$ when using **num_chan=num**

nameN. for $nameN = name1, name2, \dots$ when using **names=name1,name2,...**

The **siggen.N.** format is shown in the following descriptions.

339.5. FUNCTIONS

siggen.N.update (uses floating-point)

Updates output pins for signal generator N . Each time it is called it calculates a new sample. It should be called many times faster than the desired signal frequency, to avoid distortion and aliasing.

339.6. PINS

siggen.N.frequency float in

The output frequency for signal generator N , in Hertz. The default value is 1.0 Hertz.

siggen.N.amplitude float in

The output amplitude for signal generator *N*. If **offset** is zero, the outputs will swing from **-amplitude** to **+amplitude**. The default value is 1.00.

siggen.N.offset float in

The output offset for signal generator *N*. This value is added directly to the output signal. The default value is zero.

siggen.N.reset bit in

Resets output pins to predetermined states:

sine: 0

sawtooth: 0

square: -1 * amplitude

cosine: -1 * amplitude

triangle: -1 * amplitude

siggen.N.clock bit out

The clock output. Bit type clock signal output at the commanded frequency.

siggen.N.square float out

The square wave output. Positive while **triangle** and **cosine** are ramping upwards, and while **sine** is negative.

siggen.N.sine float out

The sine output. Lags **cosine** by 90 degrees.

siggen.N.cosine float out

The cosine output. Leads **sine** by 90 degrees.

siggen.N.triangle float out

The triangle wave output. Ramps up while **square** is positive, and down while **square** is negative. Reaches its positive and negative peaks at the same time as **cosine**.

siggen.N.sawtooth float out

The sawtooth output. Ramps upwards to its positive peak, then instantly drops to its negative peak and starts ramping again. The drop occurs when **triangle** and **cosine** are at their positive peaks, and coincides with the falling edge of **square**.

339.7. PARAMETERS

None

Chapter 340. SIM_AXIS_HARDWARE(9)

340.1. NAME

`sim_axis_hardware` - A component to simulate home and limit switches

340.2. SYNOPSIS

loadrt `sim_axis_hardware` [`count=N`|`names=name1[,name2...]`]

340.3. DESCRIPTION

This component creates simulated home and limit switches based on the current position. `.br` It currently can supply simulation for X, tandem X, Y, tandem Y, Z, U, V, and A axes.

340.4. FUNCTIONS

`sim-axis-hardware.N.update`

340.5. PINS

`sim-axis-hardware.N.Xcurrent-pos` float in

The current position on the axis - eg connect to `joint.0.motor-pos-fb`

`sim-axis-hardware.N.X2current-pos` float in

`sim-axis-hardware.N.Ycurrent-pos` float in

`sim-axis-hardware.N.Y2current-pos` float in

`sim-axis-hardware.N.Zcurrent-pos` float in

`sim-axis-hardware.N.Acurent-pos` float in

`sim-axis-hardware.N.Ucurrent-pos` float in

`sim-axis-hardware.N.Vcurrent-pos` float in

`sim-axis-hardware.N.Xhomesw-pos` float in (default: 1)

The position of the home switch

sim-axis-hardware.N.X2homesw-pos float in (default: 1)

sim-axis-hardware.N.Yhomesw-pos float in (default: 1)

sim-axis-hardware.N.Y2homesw-pos float in (default: 1)

sim-axis-hardware.N.Zhomesw-pos float in (default: 1)

sim-axis-hardware.N.Ahomesw-pos float in (default: 1)

sim-axis-hardware.N.Uhomesw-pos float in (default: 1)

sim-axis-hardware.N.Vhomesw-pos float in (default: 1)

sim-axis-hardware.N.Xmaxsw-upper float in

The upper range of the maximum limit switch, above this is false.

sim-axis-hardware.N.X2maxsw-upper float in

sim-axis-hardware.N.Ymaxsw-upper float in

sim-axis-hardware.N.Y2maxsw-upper float in

sim-axis-hardware.N.Zmaxsw-upper float in

sim-axis-hardware.N.Amaxsw-upper float in

sim-axis-hardware.N.Umaxsw-upper float in

sim-axis-hardware.N.Vmaxsw-upper float in

sim-axis-hardware.N.Xmaxsw-lower float in

The lower range of the maximum limit switch, below this is false.

sim-axis-hardware.N.X2maxsw-lower float in

sim-axis-hardware.N.Ymaxsw-lower float in

sim-axis-hardware.N.Y2maxsw-lower float in

sim-axis-hardware.N.Zmaxsw-lower float in

sim-axis-hardware.N.Amaxsw-lower float in

sim-axis-hardware.N.Umaxsw-lower float in

sim-axis-hardware.N.Vmaxsw-lower float in

sim-axis-hardware.N.Xminsw-upper float in

The upper range of the minimum limit switch, above this is false.

sim-axis-hardware.N.X2minsw-upper float in

sim-axis-hardware.N.Yminsw-upper float in

sim-axis-hardware.N.Y2minsw-upper float in

sim-axis-hardware.N.Zminsw-upper float in

sim-axis-hardware.N.Aminsw-upper float in

sim-axis-hardware.N.Uminsw-upper float in

sim-axis-hardware.N.Vminsw-upper float in

sim-axis-hardware.N.Xminsw-lower float in

The lower range of the minimum limit switch, below this is false.

sim-axis-hardware.N.X2minsw-lower float in

sim-axis-hardware.N.Yminsw-lower float in

sim-axis-hardware.N.Y2minsw-lower float in

sim-axis-hardware.N.Zminsw-lower float in

sim-axis-hardware.N.Aminsw-lower float in

sim-axis-hardware.N.Uminsw-lower float in

sim-axis-hardware.N.Vminsw-lower float in

sim-axis-hardware.N.Xhomesw-hyst float in (default: .025)

range that home switch will be true +/- half this to the home position

sim-axis-hardware.N.X2homesw-hyst float in (default: .025)

sim-axis-hardware.N.Yhomesw-hyst float in (default: .025)

sim-axis-hardware.N.Y2homesw-hyst float in (default: .025)

sim-axis-hardware.N.Zhomesw-hyst float in (default: .025)

sim-axis-hardware.N.Ahomesw-hyst float in (default: .025)

sim-axis-hardware.N.Uhomesw-hyst float in (default: .025)

sim-axis-hardware.N.Vhomesw-hyst float in (default: .025)

sim-axis-hardware.N.Xhoming bit in

True is homing in progress

sim-axis-hardware.N.X2homing bit in

sim-axis-hardware.N.Yhoming bit in

sim-axis-hardware.N.Y2homing bit in

sim-axis-hardware.N.Zhoming bit in

sim-axis-hardware.N.Ahoming bit in

sim-axis-hardware.N.Uhoming bit in

sim-axis-hardware.N.Vhoming bit in

sim-axis-hardware.N.Xhomesw-out bit out

Home switch for the X axis

sim-axis-hardware.N.X2homesw-out bit out

sim-axis-hardware.N.Yhomesw-out bit out

sim-axis-hardware.N.Y2homesw-out bit out

sim-axis-hardware.N.Zhomesw-out bit out

sim-axis-hardware.N.Ahomesw-out bit out

sim-axis-hardware.N.Uhomesw-out bit out

sim-axis-hardware.N.Vhomesw-out bit out

sim-axis-hardware.N.homesw-all bit out

sim-axis-hardware.N.Xmaxsw-out bit out

Max limit switch

sim-axis-hardware.N.Xminsw-out bit out

min limit switch

sim-axis-hardware.N.Xbothsw-out bit out

True for both max and min limit switch

sim-axis-hardware.N.X2maxsw-out bit out**sim-axis-hardware.N.X2minsw-out bit out****sim-axis-hardware.N.X2bothsw-out bit out****sim-axis-hardware.N.Ymaxsw-out bit out****sim-axis-hardware.N.Yminsw-out bit out****sim-axis-hardware.N.Ybothsw-out bit out****sim-axis-hardware.N.Y2maxsw-out bit out****sim-axis-hardware.N.Y2minsw-out bit out****sim-axis-hardware.N.Y2bothsw-out bit out****sim-axis-hardware.N.Zmaxsw-out bit out****sim-axis-hardware.N.Zminsw-out bit out****sim-axis-hardware.N.Zbothsw-out bit out****sim-axis-hardware.N.Amaxsw-out bit out****sim-axis-hardware.N.Aminsw-out bit out****sim-axis-hardware.N.Abothsw-out bit out****sim-axis-hardware.N.Umaxsw-out bit out****sim-axis-hardware.N.Uminsw-out bit out****sim-axis-hardware.N.Ubothsw-out bit out****sim-axis-hardware.N.Vmaxsw-out bit out****sim-axis-hardware.N.Vminsw-out bit out****sim-axis-hardware.N.Vbothsw-out bit out****sim-axis-hardware.N.limitsw-all bit out****sim-axis-hardware.N.limitsw-homesw-all bit out**

True for all limits and all home.

sim-axis-hardware.N.Xmaxsw-homesw-out bit out
sim-axis-hardware.N.Xminsw-homesw-out bit out
sim-axis-hardware.N.Xbothsw-homesw-out bit out
sim-axis-hardware.N.X2maxsw-homesw-out bit out
sim-axis-hardware.N.X2minsw-homesw-out bit out
sim-axis-hardware.N.X2bothsw-homesw-out bit out
sim-axis-hardware.N.Ymaxsw-homesw-out bit out
sim-axis-hardware.N.Yminsw-homesw-out bit out
sim-axis-hardware.N.Ybothsw-homesw-out bit out
sim-axis-hardware.N.Y2maxsw-homesw-out bit out
sim-axis-hardware.N.Y2minsw-homesw-out bit out
sim-axis-hardware.N.Y2bothsw-homesw-out bit out
sim-axis-hardware.N.Zmaxsw-homesw-out bit out
sim-axis-hardware.N.Zminsw-homesw-out bit out
sim-axis-hardware.N.Zbothsw-homesw-out bit out
sim-axis-hardware.N.Amaxsw-homesw-out bit out
sim-axis-hardware.N.Aminsw-homesw-out bit out
sim-axis-hardware.N.Abothsw-homesw-out bit out
sim-axis-hardware.N.Umaxsw-homesw-out bit out
sim-axis-hardware.N.Uminsw-homesw-out bit out
sim-axis-hardware.N.Ubothsw-homesw-out bit out
sim-axis-hardware.N.Vmaxsw-homesw-out bit out
sim-axis-hardware.N.Vminsw-homesw-out bit out
sim-axis-hardware.N.Vbothsw-homesw-out bit out
sim-axis-hardware.N.limit-offset float in (default: *.01*)

how much the limit switches are offset from inputted position. added to max, subtracted from min

340.6. AUTHOR

Chris S Morley

340.7. LICENSE

GPL

Chapter 341. sim_encoder(9)

341.1. NAME

sim_encoder - simulated quadrature encoder

341.2. SYNOPSIS

loadrt sim_encoder [num_chan=num | names=name1[,name2...]]

341.3. DESCRIPTION

sim_encoder can generate quadrature signals as if from an encoder. It also generates an index pulse once per revolution. It is mostly used for testing and simulation, to replace hardware that may not be available. It has a limited maximum frequency, as do all software based pulse generators.

sim_encoder supports a maximum of eight channels. The number of channels actually loaded is set by the **num_chan=** argument when the module is loaded. Alternatively, specify **names=** and unique names separated by commas.

The **num_chan=** and **names=** specifiers are mutually exclusive. If neither **num_chan=** nor **names=** are specified, the default value is one.

341.4. FUNCTIONS

sim-encoder.make-pulses (no floating-point)

Generates the actual quadrature and index pulses. Must be called as frequently as possible, to maximize the count rate and minimize jitter. Operates on all channels at once.

sim-encoder.update-speed (uses floating-point)

Reads the **speed** command and other parameters and converts the data into a form that can be used by **make-pulses**. Changes take effect only when **update-speed** runs. Can (and should) be called less frequently than **make-pulses**. Operates on all channels at once.

341.5. NAMING

The names for pins and parameters are prefixed as: **sim-encoder.N.** for N=0,1,...,num-1 when using **num_chan=num** **nameN.** for nameN=name1,name2,... when using **names=name1,name2,...**

The **sim-encoder.N.** format is shown in the following descriptions.

341.6. PINS

sim-encoder.N.phase-A bit out

One of the quadrature outputs.

sim-encoder.N.phase-B bit out

The other quadrature output.

sim-encoder.N.phase-Z bit out

The index pulse.

sim-encoder.N.speed float in

The desired speed of the encoder, in user units per per second. This is divided by **scale**, and the result is used as the encoder speed in revolutions per second.

341.7. PARAMETERS

sim-encoder.N.ppr u32 rw

The pulses per revolution of the simulated encoder. Note that this is pulses, not counts, per revolution (ppr). Each pulse or cycle from the encoder results in four counts, because every edge is counted. Default value is 100 ppr, or 400 counts per revolution.

sim-encoder.N.scale float rw

Scale factor for the **speed** input. The **speed** value is divided by **scale** to get the actual encoder speed in revolutions per second. For example, if **scale** is set to 60, then **speed** is in revolutions per minute (RPM) instead of revolutions per second. The default value is 1.00.

Chapter 342. SIM_HOME_SWITCH(9)

342.1. NAME

sim_home_switch - Home switch simulator

342.2. SYNOPSIS

loadrt sim_home_switch [count=*N* | names=*name1* [, *name2* ...]]

342.3. DESCRIPTION

After tripping home switch, travel in opposite direction is required (amount set by the hysteresis pin). A pin (index-enable) is provided for use when **[JOINT_n]HOME_USE_INDEX** is specified to reset the I/O pin **joint.N.index-enable**.

342.4. FUNCTIONS

sim-home-switch.*N*

342.5. PINS

sim-home-switch.*N*.cur-pos float in

Current position (typically: joint.n.motor-pos-fb)

sim-home-switch.*N*.home-pos float in (default: 1)

Home switch position

sim-home-switch.*N*.hysteresis float in (default: 0.1)

Travel required to backoff (hysteresis)

sim-home-switch.*N*.home-sw bit out

Home switch activated

sim-home-switch.*N*.index-enable bit io

typ: connect to joint.N.index-enable

sim-home-switch.*N*.index-delay-ms float in (default: 10)

delay in msec to reset index-enable

342.6. AUTHOR

Dewey Garrett

342.7. LICENSE

GPL

Chapter 343. SIM_MATRIX_KB(9)

343.1. NAME

`sim_matrix_kb` - convert HAL pin inputs to keycodes

343.2. SYNOPSIS

loadrt `sim_matrix_kb` [`count=N` | `names=name1[,name2...]`]

343.3. FUNCTIONS

`sim-matrix-kb.N`

343.4. PINS

`sim-matrix-kb.N.out u32 out`

pin that outputs the Keycode

`sim-matrix-kb.N.button.c00.rMM bit in (MM=00..07)`

array of inputs

`sim-matrix-kb.N.button.c01.rMM bit in (MM=00..07)`

array of inputs

`sim-matrix-kb.N.button.c02.rMM bit in (MM=00..07)`

array of inputs

`sim-matrix-kb.N.button.c03.rMM bit in (MM=00..07)`

array of inputs

`sim-matrix-kb.N.button.c04.rMM bit in (MM=00..07)`

array of inputs

`sim-matrix-kb.N.button.c05.rMM bit in (MM=00..07)`

array of inputs

`sim-matrix-kb.N.button.c06.rMM bit in (MM=00..07)`

array of inputs

`sim-matrix-kb.N.button.c07.rMM bit in (MM=00..07)`

array of inputs

343.5. AUTHOR

Chris S Morley

343.6. LICENSE

GPL

Chapter 344. SIM_PARPORT(9)

344.1. NAME

`sim_parport` - A component to simulate the pins of the `hal_parport` component

344.2. SYNOPSIS

loadrt `sim_parport` [`count=N` | `names=name1[,name2...]`]

344.3. DESCRIPTION

`Sim_parport` is used to replace the pins of a real parport without changing any of the pins names in the rest of the config.

It has pass-through pins (ending in -fake) that allows connecting to other components.

eg `pin-02-in` will follow `pin-02-in-fake` 's logic.

`pin_01_out-fake` will follow `pin_01_out` (possibly modified by `pin_01_out-invert`)

It creates all possible pins of both *in* and *out* options of the `hal_parport` component.

This allows using other hardware I/O in place of the parport (without having to change the rest of the config)

or simulating hardware such as limit switches.

it's primary use is in Stepconf for building simulated configs.

You must use the `names=` option to have the right pin names.

eg. `names=parport.0,parport.1`

The read and write functions pass the logic from pins to fake pins or vice vera

The reset function is a no operation.

344.4. FUNCTIONS

`sim-parport.N.read`

`sim-parport.N.write`

`sim-parport.N.reset`

344.5. PINS

sim-parport.N.pin-01-out bit in
sim-parport.N.pin-02-out bit in
sim-parport.N.pin-03-out bit in
sim-parport.N.pin-04-out bit in
sim-parport.N.pin-05-out bit in
sim-parport.N.pin-06-out bit in
sim-parport.N.pin-07-out bit in
sim-parport.N.pin-08-out bit in
sim-parport.N.pin-09-out bit in
sim-parport.N.pin-14-out bit in
sim-parport.N.pin-16-out bit in
sim-parport.N.pin-17-out bit in
sim-parport.N.pin-01-out-fake bit out
sim-parport.N.pin-02-out-fake bit out
sim-parport.N.pin-03-out-fake bit out
sim-parport.N.pin-04-out-fake bit out
sim-parport.N.pin-05-out-fake bit out
sim-parport.N.pin-06-out-fake bit out
sim-parport.N.pin-07-out-fake bit out
sim-parport.N.pin-08-out-fake bit out
sim-parport.N.pin-09-out-fake bit out
sim-parport.N.pin-14-out-fake bit out
sim-parport.N.pin-16-out-fake bit out
sim-parport.N.pin-17-out-fake bit out
sim-parport.N.pin-02-in bit out
sim-parport.N.pin-03-in bit out
sim-parport.N.pin-04-in bit out
sim-parport.N.pin-05-in bit out
sim-parport.N.pin-06-in bit out
sim-parport.N.pin-07-in bit out
sim-parport.N.pin-08-in bit out
sim-parport.N.pin-09-in bit out
sim-parport.N.pin-10-in bit out
sim-parport.N.pin-11-in bit out
sim-parport.N.pin-12-in bit out
sim-parport.N.pin-13-in bit out
sim-parport.N.pin-15-in bit out
sim-parport.N.pin-02-in-fake bit in
sim-parport.N.pin-03-in-fake bit in
sim-parport.N.pin-04-in-fake bit in

sim-parport.N.pin-05-in-fake bit in
sim-parport.N.pin-06-in-fake bit in
sim-parport.N.pin-07-in-fake bit in
sim-parport.N.pin-08-in-fake bit in
sim-parport.N.pin-09-in-fake bit in
sim-parport.N.pin-10-in-fake bit in
sim-parport.N.pin-11-in-fake bit in
sim-parport.N.pin-12-in-fake bit in
sim-parport.N.pin-13-in-fake bit in
sim-parport.N.pin-15-in-fake bit in
sim-parport.N.pin-02-in-not bit out
sim-parport.N.pin-03-in-not bit out
sim-parport.N.pin-04-in-not bit out
sim-parport.N.pin-05-in-not bit out
sim-parport.N.pin-06-in-not bit out
sim-parport.N.pin-07-in-not bit out
sim-parport.N.pin-08-in-not bit out
sim-parport.N.pin-09-in-not bit out
sim-parport.N.pin-10-in-not bit out
sim-parport.N.pin-11-in-not bit out
sim-parport.N.pin-12-in-not bit out
sim-parport.N.pin-13-in-not bit out
sim-parport.N.pin-15-in-not bit out
sim-parport.N.reset-time float in

344.6. PARAMETERS

sim-parport.N.pin-01-out-invert bit rw
sim-parport.N.pin-02-out-invert bit rw
sim-parport.N.pin-03-out-invert bit rw
sim-parport.N.pin-04-out-invert bit rw
sim-parport.N.pin-05-out-invert bit rw
sim-parport.N.pin-06-out-invert bit rw
sim-parport.N.pin-07-out-invert bit rw
sim-parport.N.pin-08-out-invert bit rw
sim-parport.N.pin-09-out-invert bit rw
sim-parport.N.pin-14-out-invert bit rw
sim-parport.N.pin-16-out-invert bit rw
sim-parport.N.pin-17-out-invert bit rw
sim-parport.N.pin-01-out-reset bit rw
sim-parport.N.pin-02-out-reset bit rw
sim-parport.N.pin-03-out-reset bit rw
sim-parport.N.pin-04-out-reset bit rw
sim-parport.N.pin-05-out-reset bit rw
sim-parport.N.pin-06-out-reset bit rw
sim-parport.N.pin-07-out-reset bit rw
sim-parport.N.pin-08-out-reset bit rw
sim-parport.N.pin-09-out-reset bit rw
sim-parport.N.pin-14-out-reset bit rw
sim-parport.N.pin-16-out-reset bit rw
sim-parport.N.pin-17-out-reset bit rw

344.7. AUTHOR

Chris S Morley

344.8. LICENSE

GPL

Chapter 345. SIM_SPINDLE(9)

345.1. NAME

`sim_spindle` - Simulated spindle with index pulse

345.2. SYNOPSIS

loadrt sim_spindle [count=*N* | names=*name1*[,*name2*...]]

345.3. FUNCTIONS

sim-spindle.*N*

345.4. PINS

sim-spindle.*N*.velocity-cmd float in

Commanded speed

sim-spindle.*N*.position-fb float out

Feedback position, in revolutions

sim-spindle.*N*.index-enable bit io

Reset **position-fb** to 0 at the next full rotation

345.5. PARAMETERS

sim-spindle.*N*.scale float rw (default: 1.0)

factor applied to **velocity-cmd**.

The result of **velocity-cmd** * **scale** be in revolutions per second. For example, if **velocity-cmd** is in revolutions/minute, **scale** should be set to 1/60 or 0.016666667.

345.6. AUTHOR

Michael Haberler

345.7. LICENSE

GPL

Chapter 346. SIMPLE_TP(9)

346.1. NAME

simple_tp - This component is a single axis simple trajectory planner, same as used for jogging in LinuxCNC.

346.2. SYNOPSIS

Used by PNCconf to allow testing of acceleration and velocity values for an axis.

346.3. FUNCTIONS

simple-tp.N.update

346.4. PINS

simple-tp.N.target-pos float in

target position to plan for.

simple-tp.N.maxvel float in

Maximum velocity

simple-tp.N.maxaccel float in

Acceleration rate

simple-tp.N.enable bit in

If disabled, planner sets velocity to zero immediately.

simple-tp.N.current-pos float out

position commanded at this point in time.

simple-tp.N.current-vel float out

velocity commanded at this moment in time.

simple-tp.N.active bit out

if active is true, the planner is requesting movement.

346.5. AUTHOR

Chris S Morley

346.6. LICENSE

GPL

Chapter 347. SPHEREPROBE(9)

347.1. NAME

sphereprobe - Probe a pretend hemisphere

347.2. SYNOPSIS

loadrt sphereprobe [count=*N* | names=*name1* [, *name2* ...]]

347.3. FUNCTIONS

sphereprobe.*N*

update probe-out based on inputs

347.4. PINS

sphereprobe.*N*.px s32 in

sphereprobe.*N*.py s32 in

sphereprobe.*N*.pz s32 in

rawcounts position from software encoder

sphereprobe.*N*.cx s32 in

sphereprobe.*N*.cy s32 in

sphereprobe.*N*.cz s32 in

Center of sphere in counts

sphereprobe.*N*.r s32 in

Radius of hemisphere in counts

sphereprobe.*N*.probe-out bit out

347.5. AUTHOR

Jeff Epler

347.6. LICENSE

GPL

Chapter 348. SPINDLE(9)

348.1. NAME

spindle - Control a spindle with different acceleration and deceleration and optional gear change scaling

348.2. SYNOPSIS

loadrt spindle [count=*N* | names=*name1*[,*name2*...]]

348.3. DESCRIPTION

This component will control a spindle with adjustable acceleration and deceleration.

NOTE: This component is unfortunately named and creates pins with names very much like those created by the motion component.
In nearly every case this is not the documentation page that you are looking for.
See <http://linuxcnc.org/docs/html/man/man9/motion.9.html> instead.

It is designed for use with non-servo spindle drives that have separate fwd/reverse inputs, such as DC drives and inverters. If a spindle encoder is available it is used to tailor the acceleration and deceleration to the spindle load. If not the spindle speed is simulated. The component allows for gearboxes with up to 16 gears. Each gear has individual control of speeds, acceleration, driver gain and direction.

348.4. FUNCTIONS

spindle.*N*

348.5. PINS

spindle.*N*.select-gear u32 in

Select a gear. Must be in the range 0 → number of available gears -1. If you use this, do not use the select.x input pins.

spindle.*N*.commanded-speed float in

Commanded spindle speed (in RPM)

spindle.*N*.actual-speed float in

Actual spindle speed from a spindle encoder (in RPS). If you do not have a spindle encoder set the simulate_encoder parameter to 1.

spindle.*N*.simulate-encoder bit in

If you do not have an encoder, set this to 1.

spindle.N.enable bit in

If FALSE, the spindle is stopped at the gear's maximum deceleration.

spindle.N.spindle-lpf float in

Smooth the spindle-rpm-abs output when at speed, 0 = disabled. Suitable values are probably between 1 and 20 depending on how stable your spindle is.

spindle.N.spindle-rpm float out

Current spindle speed in RPM. +ve = forward, -ve = reverse. Uses the encoder input if available. If not, uses a simulated encoder speed.

spindle.N.spindle-rpm-abs float out

Absolute spindle speed in RPM. Useful for spindle speed displays.

spindle.N.output float out

Scaled output

spindle.N.current-gear u32 out

Currently selected gear.

spindle.N.at-speed bit out

TRUE when the spindle is at speed

spindle.N.forward bit out

TRUE for forward rotation

spindle.N.reverse bit out

TRUE for reverse rotation. Both forward and reverse are false when the spindle is stopped.

spindle.N.brake bit out

TRUE when decelerating

spindle.N.zero-speed bit out

TRUE when the spindle is stationary

spindle.N.limited bit out

TRUE when the commanded spindle speed is >max or <min.

348.6. SEE ALSO

motion(9)

348.7. NOTES

The following pins are created depending the *numgears*= parameter. One of each pin is created for each gear. If no gears are specified then one gear will be created. For instance if you have *gears*=2 on your command line, you will have two scale pins:

spindle.N.scale.0**spindle.N.scale.1****spindle.N.scale.x float in**

Scale the output. For multiple gears you would use a different scale for each gear. If you need to reverse the output for some gears, use a negative scale.

spindle.N.min.x float in

Set the minimum speed allowed (in RPM). The limit output will be TRUE while the commanded speed is between 0 RPM and the min speed.

spindle.N.max.x float in

Set the maximum speed allowed (in RPM). The limit output will be TRUE while the commanded speed is above this value.

spindle.N.accel.x float in

Set the maximum acceleration. If you do not have a spindle encoder this is in RPM/second. If you do have an encoder the output is the actual speed plus this value. This way the acceleration can be dependent on the spindle load.

spindle.N.decel.x float in

Set the minimum deceleration. If you do not have a spindle encoder this is in RPM/second. If you do have an encoder the output is the actual speed minus this value.

spindle.N.speed-tolerance.x float in

Tolerance for *at-speed* signal (in RPM). Actual spindle speeds within this amount of the commanded speed will cause the at-speed signal to go TRUE.

spindle.N.zero-tolerance.x float in

Tolerance for *zero-speed* signal (in RPM).

spindle.N.offset.x float in

The output command is offset by this amount (in RPM).

spindle.N.select.x bit in

Selects this gear. If no select inputs are active, gear 0 is selected. If multiple select inputs are active then the highest is selected.

348.8. AUTHOR

Les Newell

348.9. LICENSE

GPL

Chapter 349. SPINDLE_MONITOR(9)

349.1. NAME

spindle_monitor - spindle at-speed and underspeed detection

349.2. SYNOPSIS

loadrt spindle_monitor [count=*N* | names=*name1*[,*name2*...]]

349.3. FUNCTIONS

spindle-monitor.*N*

349.4. PINS

spindle-monitor.*N*.spindle-is-on bit in

spindle-monitor.*N*.spindle-command float in

spindle-monitor.*N*.spindle-feedback float in

spindle-monitor.*N*.spindle-at-speed bit out

spindle-monitor.*N*.spindle-underspeed bit out

349.5. PARAMETERS

spindle-monitor.*N*.level u32 rw

state machine state

spindle-monitor.*N*.threshold float rw

349.6. AUTHOR

Sebastian Kuzminsky

349.7. LICENSE

gpl v2 or higher

Chapter 350. sserial(9)

350.1. NAME

sserial - Smart Serial LinuxCNC HAL driver for the Mesa Electronics HostMot2 Smart-Serial remote cards

350.2. SYNOPSIS

The Mesa Smart-Serial interface is a 2.5Mbs proprietary interface between the Mesa Anything-IO cards and a range of subsidiary devices termed "smart-serial remotes". The remote cards perform a variety of functions, but typically they combine various classes of IO. The remote cards are self-configuring, in that they tell the main LinuxCNC Hostmot2 driver what their pin functions are and what they should be named.

Many sserial remotes offer different pinouts depending on the mode they are started up in. This is set using the `sserial_port_N=` option in the `hm2_pci` modparam. See the `hostmot2` manpage for further details.

It is likely that this documentation will be permanently out of date.

Each Anything-IO board can attach up to 8 sserial remotes to each header (either the 50-pin headers on the 5I20/5I22/5I23/7I43 or the 25-pin connectors on the 5I25, 6I25 and 7I80). The remotes are grouped into "ports" of up to 8 "channels". Typically each header will be a single 8 channel port, but this is not necessarily always the case.

350.3. PORTS

In addition to the per-channel/device pins detailed below there are three per-port pins and three parameters.

Pins:

sserial.port-N.run (bit, in):: Enables the specific Smart Serial module.

```
Setting this pin low will disable all boards on the port and puts the
port in a pass-through mode where device parameter setting is possible.
It is necessary to toggle the state of this pin if there is a
requirement to alter a remote parameter on a live system.
This pin defaults to TRUE and can be left unconnected.
However, toggling the pin low-to-high will re-enable a faulted drive,
so the pin could usefully be connected to the `iocontrol.0.user-enable-out` pin.
```

run_state (u32, ro):: Shows the state of the sserial communications state-machine.

```
This pin will generally show a value of 0x03 in normal operation, 0x07 in setup mode and
0x00 when the "run" pin is false.
```

error-count (u32, ro):: Indicates the state of the Smart Serial error handler, see the parameters section for more details.

Parameters:

fault-inc (u32 r/w):: Any over-run or handshaking error in the

SmartSerial communications will increment the .fault-count pin by the amount specified by this parameter. Default = 10.

fault-lim (u32 r/w):: When the fault counter reaches this threshold the

Smart Serial interface on the corresponding port will be stopped and an error printed in dmesg. Together these three pins allow for control over the degree of fault- tolerance allowed in the interface. The default values mean that if more than one transaction in ten fails, more than 20 times, then a hard error will be raised. If the increment were to be set to zero then no error would ever be raised, and the system would carry on regardless. Conversely setting decrement to zero, threshold to 1 and limit to 1 means that absolutely no errors will be tolerated. (This structure is copied directly from vehicle ECU practice.)

Any other parameters than the ones above are created by the card itself from data in the remote firmware. They may be set in the HAL file using "setp" in the usual way.

NOTE

Because a Smart-Serial remote can only communicate non-process data to the host card in setup mode, it is necessary to stop and re-start the smart-serial port associated with the card to alter the value of a parameter.

NOTE

In the case of parameters beginning with "nv" (which are stored in non-volatile memory) the effect will not be seen until after the next power cycle of the drive.

Unchanged values will not be re-written so it is safe to leave the "setp" commands in the HAL file or delete them as you see fit.

350.4. DEVICES

The other pins and parameters created in HAL depend on the devices detected. The following list of Smart Serial devices is by no means exhaustive.

350.4.1. 8I20

The 8I20 is a 2.2 kW three-phase drive for brushless DC motors and AC servo motors. 8I20 pins and parameters have names like "hm2__<BoardType>_.<BoardNum>.8i20.<PortNum>.<ChanNum>.<Pin>", for example "hm2_5i23.0.8i20.1.3.current" would set the phase current for the drive connected to the fourth channel of the second sserial port of the first 5I23 board. Note that the sserial ports do not necessarily correlate in layout or number to the physical ports on the card.

Pins:**angle (float in)**

The rotor angle of the motor in fractions of a full **phase** revolution. An angle of 0.5 indicates that the

motor is half a turn / 180 degrees / π radians from the zero position. The zero position is taken to be the position that the motor adopts under no load with a positive voltage applied to the A (or U) phase and both B and C (or V and W) connected to -V or 0 V. A 6 pole motor will have 3 zero positions per physical rotation. Note that the 8I20 drive automatically adds the phase lead/lag angle, and that this pin should see the raw rotor angle. There is a HAL module (bldc) which handles the complexity of differing motor and drive types.

current (float, in)

The phase current command to the drive. This is scaled from -1 to +1 for forwards and reverse maximum currents. The absolute value of the current is set by the max_current parameter.

bus-voltage (float, ro)

The drive bus voltage in V. This will tend to show 25.6 V when the drive is unpowered and the drive will not operate below about 50 V.

temp (float, ro)

The temperature of the driver in degrees C.

comms (u32, ro)

The communication status of the drive. See the manual for more details.

status and fault. (bit, ro)

The following fault/status bits are exported. For further details see the 8I20 manual:

fault.U-current / fault.U-current-not fault.V-current / fault.V-current-not fault.W-current / fault.W-current-not fault.bus-high / fault.bus-high-not fault.bus-overv / fault.bus-overv-not fault.bus-underv / fault.bus-underv-not fault.framingr / fault.framingr-not fault.module / fault.module-not fault.no-enable / fault.no-enable-not fault.overcurrent / fault.overcurrent-not fault.overrun / fault.overrun-not fault.overtemp / fault.overtemp-not fault.watchdog / fault.watchdog-not
+ status.brake-old / status.brake-old-not status.brake-on / status.brake-on-not status.bus-underv / status.bus-underv-not status.current-lim / status.current-lim-no status.ext-reset / status.ext-reset-not status.no-enable / status.no-enable-not status.pid-on / status.pid-on-not status.sw-reset / status.sw-reset-not status.wd-reset / status.wd-reset-not

Parameters:

The following parameters are exported. See the PDF documentation downloadable from Mesa for further details:

```

hm2_5i25.0.8i20.0.1.angle-maxlim
hm2_5i25.0.8i20.0.1.angle-minlim
hm2_5i25.0.8i20.0.1.angle-scalemax
hm2_5i25.0.8i20.0.1.current-maxlim
hm2_5i25.0.8i20.0.1.current-minlim
hm2_5i25.0.8i20.0.1.current-scalemax
hm2_5i25.0.8i20.0.1.nvbrakeoffv
hm2_5i25.0.8i20.0.1.nvbrakeonv
hm2_5i25.0.8i20.0.1.nvbusoverv
hm2_5i25.0.8i20.0.1.nvbusundervmax
hm2_5i25.0.8i20.0.1.nvbusundervmin
hm2_5i25.0.8i20.0.1.nvkdihi
hm2_5i25.0.8i20.0.1.nvkdil
hm2_5i25.0.8i20.0.1.nvkdilo
hm2_5i25.0.8i20.0.1.nvkdp
hm2_5i25.0.8i20.0.1.nvkqihi
hm2_5i25.0.8i20.0.1.nvkqil
hm2_5i25.0.8i20.0.1.nvkqilo
hm2_5i25.0.8i20.0.1.nvkqp
hm2_5i25.0.8i20.0.1.nvmaxcurrent
hm2_5i25.0.8i20.0.1.nvrembaudrate
hm2_5i25.0.8i20.0.1.swrevision
hm2_5i25.0.8i20.0.1.unitnumber

```

max_current (float, rw)

Sets the maximum drive current in Amps. The default value is the maximum current programmed into the drive EEPROM. The value must be positive, and an error will be raised if a current in excess of the drive maximum is requested.

serial_number (u32, ro)

The serial number of the connected drive. This is also shown on the label on the drive.

350.4.2. 7I64

The 7I64 is a 24-input 24-output IO card. 7I64 pins and parameters have names like "hm2<BoardType>.<BoardNum>.7i64.<PortNum>.<ChanNum>.<Pin>", for example **hm2_5i23.0.7i64.1.3.output-01**.

Pins:

7i64.0.0.output-NN (bit, in)

Writing a 1 or TRUE to this pin will enable output driver *NN*. Note that the outputs are drivers (switches) rather than voltage outputs. The LED adjacent to the connector on the board shows the status. The output can be inverted by setting a parameter.

7i64.0.0.input-*NN* (bit, out)

The value of input *NN*. Note that the inputs are isolated and both pins of each input must be connected, typically to signal and the ground of the signal. (This need not be the ground of the board.)

7i64.0.0.input-*NN*-not (bit, out)

An inverted copy of the corresponding input.

7i64.0.0.analog0 & 7i64.0.0.analog1 (float, out)

The two analogue inputs (0 to 3.3 V) on the board.

Parameters:**7i64.0.0.output-*NN*-invert (bit, rw)**

Setting this parameter to 1 / TRUE will invert the output value, such that writing 0 to `.gpio.NN.out` will enable the output and vice-versa.

350.4.3. 7I76

The 7I76 is not really a smart-serial device. It serves as a breakout for a number of other Hostmot2 functions. There are connections for 5 step generators (for which see the main hostmot2 manpage). The stepgen pins are associated with the 5I25 (`hm2_5i25.0.stepgen.00....`), whereas the smart-serial pins are associated with the 7I76 (`hm2_5i25.0.7i76.0.0.output-00`).

Pins:

7i76.0.0.spinout (float in):: This controls the analogue output of the 7I76.

```
This is intended as a speed control signal for a VFD.
.7i76.0.0.output-__NN__ (bit out):: (_NN_ = 0 to 15). 16 digital outputs.
The sense of the signal can be set via a parameter.
.7i76.0.0.input-__NN__ (bit out):: (_NN_ = 0 to 31) 32 digital inputs.
.7i76.0.0.input-__NN__-not (bit in):: (_NN_ = 0 to 31) An inverted copy of the inputs
provided for convenience.
The two complementary pins may be connected to different signal nets.
```

Parameters:

7i76.0.0.nvunitnumber (u32 ro):: Indicates the serial number of the device and should match a sticker on the card.

```
This can be useful for working out which card is which.
.7i76.0.0.nvwatchdogtimeout (u32 ro):: The sserial remote watchdog timeout.
This is separate from the Anything-IO card timeout.
This is unlikely to need to be changed.
.7i76.0.0.output-__NN__-invert (bit rw):: Invert the sense of the corresponding output
pin.
.7i76.0.0.spindir-invert (bit rw):: Invert the sense of the spindle direction pin.
.7i76.0.0.spinena-invert (bit rw):: Invert the sense of the spindle-enable pin.
.7i76.0.0.spinout-maxlim (float rw):: The maximum speed request allowable
.7i76.0.0.spinout-minlim (float rw):: The minimum speed request.
.7i76.0.0.spinout-scalemax (float rw):: The spindle speed scaling.
```

This is the speed request which would correspond to full-scale output from the spindle control pin.

For example with a 10 V drive voltage and a 10000 RPM scalemax a value of 10,000 RPM on the spinout pin would produce 10 V output.

However, if spinout-maxlim were set to 5000 RPM then no voltage above 5 V would be output.

.7i76.0.0.swrevision (u32 ro):: The onboard firmware revision number.

Utilities (man setsserial for details) exist to update and change this firmware.

350.4.4. 7I77

The 7I77 is an 6-axis servo control card. The analogue outputs are smart-serial devices, but the encoders are conventional hostmot2 encoders and further details of them may be found in the hostmot2 manpage.

Pins:

7i77.0.1.analogoutN (float in):: (N = 0 to 5) This controls the analog output of the 7I77.

Parameters:

7i77.0.0.spinout-scalemax (float rw):: The spindle speed scaling.

This is the speed request which would correspond to full-scale output from the spindle control pin.

For example with a 10V drive voltage and a 10000RPM scalemax a value of 10000RPM on the spinout pin would produce 10V output.

However, if spinout-maxlim were set to 5000RPM then no voltage above 5V would be output.

.7i77.0.0.analogout__N__-maxlim (float rw):: (_N_ = 0 to 5) The maximum speed request allowable

.7i77.0.0.analogout__N__-minlim (float rw):: (_N_ = 0 to 5) The minimum speed request.

.7i77.0.0.analogout__N__-scalemax (float rw):: (_N_ = 0 to 5) The analog speed scaling.

This is the speed request which would correspond to full-scale output from the spindle control pin.

For example with a 10V drive voltage and a 10000RPM scalemax a value of 10000RPM on the spinout pin would produce 10V output.

However, if spinout-maxlim were set to 5000RPM then no voltage above 5V would be output.

350.4.5. 7I69

The 7I69 is a 48 channel digital IO card. It can be configured in four different modes:

MODE 0

Bidirectional mode (48 bits in 48 bits out)

MODE 1

Input only mode (48 bits in)

MODE 2

Output only mode (48 bits out)

MODE 3

24/24mode (24 bits in = bits 0..23 and 24 bits out = bits 24..47)

MODE 4

Bidirectional mode (48 bits in 48 bits out) plus 4 MPG encoder channels on inputs 0 through 7

Pins:

7i69.0.0.input-NN-not (bit out):: Digital input, inverted.

Parameters:**350.4.6. 7I70**

7i69.0.0.swrevision (u32 ro):: The onboard firmware revision number. Utilities exist to update and change this firmware.

The 7I70 is a remote isolated 48 input card. The 7I70 inputs sense positive inputs relative to a common field ground. Input impedance is 10 K Ω and input voltage can range from 5 VDC to 32 VDC. All inputs have LED status indicators. The input common field ground is galvanically isolated from the communications link.

The 7I70 has three software selectable modes. These different modes select different sets of 7I70 data to be transferred between the host and the 7I70 during real time process data exchanges. For high speed applications, choosing the correct mode can reduced the data transfer sizes, resulting in higher maximum update rates.

MODE 0

Input mode (48 bits input data only)

MODE 1

Input plus analog mode (48 bits input data plus 6 channels of analog data)

MODE 2

Input plus field voltage

Pins:

7i70.0.0.input-NN-not (bit in):: (NN = 0 to 47) An inverted copy of the inputs provided for convenience. The two complementary pins may be connected to different signal nets.

Parameters:**350.4.7. 7I71**

7i69.0.0.swrevision (u32 ro):: The onboard firmware revision number. Utilities exist to update and change this firmware.

The 7I71 is a remote isolated 48 output card. The 48 outputs are 8 VDC to 28 VDC sourcing drivers (common + field power) with 300 mA maximum current capability. All outputs have LED status indicators.

The 7I71 has two software selectable modes. For high speed applications, choosing the correct mode can reduced the data transfer sizes, resulting in higher maximum update rates:

MODE 0

Output only mode (48 bits output data only)

MODE 1

Outputs plus read back field voltage

Pins:

7i71.0.0.output-NN (bit out):: (NN = 0 to 47) 48 digital outputs.

The sense may be inverted by the invert parameter.
.7i71.0.0.output-__NN__ (bit out):: (_NN_ = 0 to 47) 48 digital outputs.
 The sense may be inverted by the invert parameter.

Parameters:

350.4.8. 7I73

7i69.0.0.swrevision (u32 ro):: The onboard firmware revision number. Utilities exist to update and change this firmware.

The 7I73 is a remote real time pendant or control panel interface.

The 7I73 supports up to four 50 kHz encoder inputs for MPGs, 8 digital inputs and 6 digital outputs and up to a 64 Key keypad. If a smaller keypad is used, more digital inputs and outputs become available. Up to eight 0.0 V to 3.3 V analog inputs are also provided. The 7I73 can drive a 4 line 20 character LCD for local DRO applications.

The 7I73 has 3 software selectable process data modes. These different modes select different sets of 7I73 data to be transferred between the host and the 7I73 during real time process data exchanges. For high speed applications, choosing the correct mode can reduced the data transfer sizes, resulting in higher maximum update rates

MODE 0

I/O + ENCODER

MODE 1

I/O + ENCODER + ANALOG IN

MODE 2

I/O + ENCODER + ANALOG IN FAST DISPLAY

Pins:

7i73.0.0.analoginN (float out):: Analogue inputs.

Up to 8 channels may be available dependent on software and hardware configuration modes

(see the PDF manual downloadable from <https://www.mesanet.com>).

7i73.0.1.display (modes 1 and 2) (u32 in):: Data for LCD display.

This pin may be conveniently driven by the HAL "lcd" component which allows the formatted display of the values any number of HAL pins and textual content.

7i73.0.1.output-NN (bit in):: Up to 22 digital outputs (dependent on config)

Parameters:

7i73.0.1.output-00-invert (u32 ro)::

For further details of the use of the above see the Mesa manual.

Chapter 351. stepgen(9)

351.1. NAME

stepgen - software step pulse generation

351.2. SYNOPSIS

```
loadrt stepgen step_type=type0[,type1...] [ctrl_type=type0[,type1...]] [user_step_type=,...]
```

351.3. DESCRIPTION

stepgen is used to control stepper motors. The maximum step rate depends on the CPU and other factors, and is usually in the range of 5 kHz to 25 kHz. If higher rates are needed, a hardware step generator is a better choice.

stepgen has two control modes, which can be selected on a channel by channel basis using **ctrl_type**. Possible values are "**p**" for position control, and "**v**" for velocity control. The default is position control, which drives the motor to a commanded position, subject to acceleration and velocity limits. Velocity control drives the motor at a commanded speed, again subject to accel and velocity limits. Usually, position mode is used for machine axes. Velocity mode is reserved for unusual applications where continuous movement at some speed is desired, instead of movement to a specific position. (Note that velocity mode replaces the former component **freqgen**.)

stepgen can control a maximum of 16 motors. The number of motors/channels actually loaded depends on the number of *type* values given. The value of each *type* determines the outputs for that channel. Position or velocity mode can be individually selected for each channel. Both control modes support the same 16 possible step types.

By far the most common step type is 0, standard step and direction. Others include up/down, quadrature, and a wide variety of three, four, and five phase patterns that can be used to directly control some types of motor windings. (When used with appropriate buffers of course.)

Some of the stepping types are described below, but for more details (including timing diagrams) see the **stepgen** section of the HAL reference manual.

type 0: step/dir

Two pins, one for step and one for direction. **make-pulses** must run at least twice for each step (once to set the step pin true, once to clear it). This limits the maximum step rate to half (or less) of the rate that can be reached by types 2-14. The parameters **steplen** and **stepspace** can further lower the maximum step rate. Parameters **dirsetup** and **dirhold** also apply to this step type.

type 1: up/down

Two pins, one for *step up* and one for *step down*. Like type 0, **make-pulses** must run twice per step, which limits the maximum speed.

type 2: quadrature

Two pins, phase-A and phase-B. For forward motion, A leads B. Can advance by one step every time **make-pulses** runs.

type 3: three phase, full step

Three pins, phase-A, phase-B, and phase-C. Three steps per full cycle, then repeats. Only one phase is high at a time - for forward motion the pattern is A, then B, then C, then A again.

type 4: three phase, half step

Three pins, phases A through C. Six steps per full cycle. First A is high alone, then A and B together, then B alone, then B and C together, etc.

types 5 through 8: four phase, full step

Four pins, phases A through D. Four steps per full cycle. Types 5 and 6 are suitable for use with unipolar steppers, where power is applied to the center tap of each winding, and four open-collector transistors drive the ends. Types 7 and 8 are suitable for bipolar steppers, driven by two H-bridges.

types 9 and 10: four phase, half step

Four pins, phases A through D. Eight steps per full cycle. Type 9 is suitable for unipolar drive, and type 10 for bipolar drive.

types 11 and 12: five phase, full step

Five pins, phases A through E. Five steps per full cycle. See HAL reference manual for the patterns.

types 13 and 14: five phase, half step

Five pins, phases A through E. Ten steps per full cycle. See HAL reference manual for the patterns.

type 15: user-specified

This uses the waveform specified by the **user_step_type** module parameter, which may have up to 10 steps and 5 phases.

351.4. FUNCTIONS

stepgen.make-pulses (no floating-point)

Generates the step pulses, using information computed by **update-freq**. Must be called as frequently as possible, to maximize the attainable step rate and minimize jitter. Operates on all channels at once.

stepgen.capture-position (uses floating point)

Captures position feedback value from the high speed code and makes it available on a pin for use elsewhere in the system. Operates on all channels at once.

stepgen.update-freq (uses floating point)

Accepts a velocity or position command and converts it into a form usable by **make-pulses** for step generation. Operates on all channels at once.

351.5. PINS

stepgen.N.counts s32 out

The current position, in counts, for channel *N*. Updated by **capture-position**.

stepgen.N.position-fb float out

The current position, in length units (see parameter **position-scale**). Updated by **capture-position**. The resolution of **position-fb** is much finer than a single step. If you need to see individual steps, use **counts**.

stepgen.N.enable bit in

Enables output steps - when false, no steps are generated.

stepgen.N.velocity-cmd float in (velocity mode only)

Commanded velocity, in length units per second (see parameter **position-scale**).

stepgen.N.position-cmd float in (position mode only)

Commanded position, in length units (see parameter **position-scale**).

stepgen.N.step bit out (step type 0 only)

Step pulse output.

stepgen.N.dir bit out (step type 0 only)

Direction output: low for forward, high for reverse.

stepgen.N.up bit out (step type 1 only)

Count up output, pulses for forward steps.

stepgen.N.down bit out (step type 1 only)

Count down output, pulses for reverse steps.

stepgen.N.phase-A thru phase-E bit out (step types 2-14 only)

Output bits. **phase-A** and **phase-B** are present for step types 2-14, **phase-C** for types 3-14, **phase-D** for types 5-14, and **phase-E** for types 11-14. Behavior depends on selected stepping type.

351.6. PARAMETERS

stepgen.N.frequency float ro

The current step rate, in steps per second, for channel *N*.

stepgen.N.maxaccel float rw

The acceleration/deceleration limit, in length units per second squared.

stepgen.N.maxvel float rw

The maximum allowable velocity, in length units per second. If the requested maximum velocity cannot be reached with the current combination of scaling and **make-pulses** thread period, it will be reset to the highest attainable value.

stepgen.N.position-scale float rw

The scaling for position feedback, position command, and velocity command, in steps per length unit.

stepgen.N.rawcounts s32 ro

The position in counts, as updated by **make-pulses**. (Note: this is updated more frequently than the **counts** pin.)

stepgen.N.steplen u32 rw

The length of the step pulses, in nanoseconds. Measured from rising edge to falling edge.

stepgen.N.stepspace u32 rw (step types 0 and 1 only)

The minimum space between step pulses, in nanoseconds. Measured from falling edge to rising edge. The actual time depends on the step rate and can be much longer. If **stepspace** is 0, then **step** can be asserted every period. This can be used in conjunction with **hal_parport**'s auto-resetting pins to output one step pulse per period. In this mode, **steplen** must be set for one period or less.

stepgen.N.dirsetup u32 rw (step type 0 only)

The minimum setup time from direction to step, in nanoseconds periods. Measured from change of direction to rising edge of step.

stepgen.N.dirhold u32 rw (step type 0 only)

The minimum hold time of direction after step, in nanoseconds. Measured from falling edge of step to change of direction.

stepgen.N.dirdelay u32 rw (step types 1 and higher only)

The minimum time between a forward step and a reverse step, in nanoseconds.

351.7. TIMING

There are five timing parameters which control the output waveform. No step type uses all five, and only those which will be used are exported to HAL. The values of these parameters are in nano-seconds, so no recalculation is needed when changing thread periods. In the timing diagrams that follow, they are identified by the following numbers:

(1) **stepgen.n.steplen**


(2) **stepgen.n.stepspace**

(3) **stepgen.n.dirhold**


(4) **stepgen.n.dirsetup**

(5) **stepgen.n.dirdelay**

For step type 0, timing parameters 1 thru 4 are used. The following timing diagram shows the output waveforms, and what each parameter adjusts.



For step type 1, timing parameters 1, 2, and 5 are used. The following timing diagram shows the output waveforms, and what each parameter adjusts.



For step types 2 and higher, the exact pattern of the outputs depends on the step type (see the HAL manual for a full listing). The outputs change from one state to another at a minimum interval of **steplen**. When a direction change occurs, the minimum time between the last step in one direction and the first in the other direction is the sum of **steplen** and **dirdelay**.

351.8. SEE ALSO

The HAL User Manual.

Chapter 352. STEPTEST(9)

352.1. NAME

steptest - Used by Stepconf to allow testing of acceleration and velocity values for an axis.

352.2. SYNOPSIS

loadrt steptest [count=*N* | names=*name1* [, *name2* ...]]

352.3. FUNCTIONS

steptest.*N*

352.4. PINS

steptest.*N*.jog-minus bit in

Drive TRUE to jog the axis in its minus direction

steptest.*N*.jog-plus bit in

Drive TRUE to jog the axis in its positive direction

steptest.*N*.run bit in

Drive TRUE to run the axis near its current position_fb with a trapezoidal velocity profile

steptest.*N*.maxvel float in

Maximum velocity

steptest.*N*.maxaccel float in

Permitted Acceleration

steptest.*N*.amplitude float in

Approximate amplitude of positions to command during *run*

steptest.*N*.dir s32 in

Direction from central point to test: 0 = both, 1 = positive, 2 = negative

steptest.N.position-cmd float out

steptest.N.position-fb float in

steptest.N.running bit out

steptest.N.run-target float out

steptest.N.run-start float out

steptest.N.run-low float out

steptest.N.run-high float out

steptest.N.pause s32 in (default: 0)

pause time for each end of run in seconds

352.5. PARAMETERS

steptest.N.epsilon float rw (default: .001)

steptest.N.elapsed float r

Current value of the internal timer

352.6. AUTHOR

Jeff Epler

352.7. LICENSE

GPL

Chapter 353. streamer(9)

353.1. NAME

streamer - stream file data into HAL in real time

353.2. SYNOPSIS

loadrt streamer depth=depth1[,depth2...] cfg=string1[,string2...]

353.3. DESCRIPTION

streamer and **halstreamer(1)** are used together to stream data from a file into the HAL in real time. **streamer** is a realtime HAL component that exports HAL pins and creates a FIFO in shared memory. **hal_streamer** is a non-realtime program that copies data from stdin into the FIFO, so that **streamer** can write it to the HAL pins.

353.4. OPTIONS

depth=depth1[,depth2...]

Sets the depth of the FIFO that the realtime **streamer** creates to receive data from the non-realtime **hal-streamer**. Multiple values of *depth* (separated by commas) can be specified if you need more than one FIFO (for example if you want to stream data to two different realtime threads).

cfg=string1[,string2...]

Defines the set of HAL pins that **streamer** exports and later writes data to. One *string* must be supplied for each FIFO, separated by commas. **streamer** exports one pin for each character in *string*. Legal characters are:

- **F, f** (float pin)
- **B, b** (bit pin)
- **S, s** (s32 pin)
- **U, u** (u32 pin)

353.5. FUNCTIONS

streamer.N

One function is created per FIFO, numbered from zero.

353.6. PINS

streamer.N.pin.M output

Data from column *M* of the data in FIFO *N* appears on this pin. The pin type depends on the config

string.

streamer.N.curr-depth s32 output

Current number of samples in the FIFO. When this reaches zero, new data will no longer be written to the pins.

streamer.N.empty bit output

TRUE when the FIFO *N* is empty, FALSE when valid data is available.

streamer.N.enable bit input

When TRUE, data from FIFO *N* is written to the HAL pins. When false, no data is transferred. Defaults to TRUE.

streamer.N.underruns s32 read/write

The number of times that **sampler** has tried to write data to the HAL pins but found no fresh data in the FIFO. It increments whenever **empty** is true, and can be reset by the **setp** command.

streamer.N.*clock bit input

Clock for data as specified by the clock-mode pin.

streamer.N.*clock-mode s32 input

Defines behavior of clock pin:

- 0 (**default**) free run at every iteration
- 1 clock on falling edge of clock pin
- 2 clock on rising edge of clock pin
- 3 clock on any edge of clock pin

353.7. SEE ALSO

halstreamer(1), sampler(9), halsampler(1)

353.8. BUGS

Should an enable HAL pin be added, to allow streaming to be turned on and off?

353.9. AUTHOR

Original version by John Kasunich, as part of the LinuxCNC project. Improvements by several other members of the LinuxCNC development team.

353.10. REPORTING BUGS

Report bugs at <https://github.com/LinuxCNC/linuxcnc/issues>.

353.11. COPYRIGHT

Copyright © 2006 John Kasunich.

This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Chapter 354. SUM2(9)

354.1. NAME

sum2 - Sum of two inputs (each with a gain) and an offset

354.2. SYNOPSIS

loadrt sum2 [count=*N* | names=*name1*[,*name2*...]]

354.3. FUNCTIONS

sum2.*N*

354.4. PINS

sum2.*N*.in0 float in

sum2.*N*.in1 float in

sum2.*N*.out float out

$\text{out} = \text{in0} * \text{gain0} + \text{in1} * \text{gain1} + \text{offset}$

354.5. PARAMETERS

sum2.*N*.gain0 float rw (default: *1.0*)

sum2.*N*.gain1 float rw (default: *1.0*)

sum2.*N*.offset float rw

354.6. SEE ALSO

scaled_s32_sums(9), weighted_sum(9)

354.7. AUTHOR

Jeff Epler

354.8. LICENSE

GPL

Chapter 355. supply(9)

355.1. NAME

supply - set output pins with values from parameters (obsolete)

355.2. SYNOPSIS

loadrt supply num_chan=num

355.3. DESCRIPTION

supply was used to allow the inputs of other HAL components to be manipulated for testing purposes. When it was written, the only way to set the value of an input pin was to connect it to a signal and connect that signal to an output pin of some other component, and then let that component write the pin value. **supply** was written to be that "other component". It reads values from parameters (set with the HAL command **setp**) and writes them to output pins.

Since **supply** was written, the **setp** command has been modified to allow it to set unconnected pins as well as parameters. In addition, the **sets** command was added, which can directly set HAL signals, as long as there are no output pins connected to them. Therefore, **supply** is obsolete.

supply supports a maximum of eight channels. The number of channels actually loaded is set by the **num_chan** argument when the module is loaded. If **numchan** is not specified, the default value is one.

355.4. FUNCTIONS

supply.N.update (uses floating-point)

Updates output pins for channel *N*.

355.5. PINS

supply.N.q bit out

Output bit, copied from parameter **supply.N.d**.

supply.N._q bit out

Output bit, inverted copy of parameter **supply.N.d**.

supply.N.variable float out

Analog output, copied from parameter **supply.N.value**.

supply.N._variable float out

Analog output, equal to -1.0 times parameter **supply.N.value**.

supply.N.d bit rw

Data source for **q** and **_q** output pins.

supply.N.value bit rw

Data source for **variable** and **_variable** output pins.

Chapter 356. THC(9)

356.1. NAME

thc - Torch Height Control

356.2. SYNOPSIS

loadrt thc

356.3. DESCRIPTION

356.3.1. Torch Height Control

Mesa THC > Encoder > LinuxCNC THC component

The Mesa THC sends a frequency based on the voltage detected to the encoder. The velocity from the encoder is converted to volts with the velocity scale parameter inside the THC component.

The THCAD card sends a frequency at 0 volts so the scale offset parameter is used to zero the calculated voltage.

356.3.2. Component Functions

If enabled and torch is on and X + Y velocity is within tolerance of set speed allow the THC to offset the Z axis as needed to maintain voltage.

If enabled and torch is off and the Z axis is moving up remove any correction at a rate not to exceed the rate of movement of the Z axis.

If enabled and torch is off and there is no correction pass the Z position and feed back untouched.

If not enabled pass the Z position and feed back untouched.

356.3.3. Physical Connections

Plasma Torch Arc Voltage Signal \Rightarrow 6 x 487k 1% resistors \Rightarrow THC Arc Voltage In

THC Frequency Signal \Rightarrow Encoder #0, pin A (Input)

Plasma Torch Arc OK Signal \Rightarrow input pin

output pin \Rightarrow Plasma Torch Start Arc Contacts

356.3.4. HAL Plasma Connections

encoder.nn.velocity \Rightarrow thc.encoder-vel (tip voltage)

spindle.0.on ⇒ output pin (start the arc)

thc.arc-ok ⇐ motion.digital-in-00 ⇐ input pin (arc ok signal)

356.3.5. HAL Motion Connections

thc.requested-vel ⇐ motion.requested-vel

thc.current-vel ⇐ motion.current-vel

356.4. FUNCTIONS

thc.-

356.5. PINS

thc.encoder-vel float in

Connect to hm2_5i20.0.encoder.00.velocity

thc.current-vel float in

Connect to motion.current-vel

thc.requested-vel float in

Connect to motion.requested-vel

thc.volts-requested float in

Tip Volts current_vel >= min_velocity requested

thc.vel-tol float in

Velocity Tolerance (Corner Lock)

thc.torch-on bit in

Connect to spindle.N.on

thc.arc-ok bit in

Arc OK from Plasma Torch

thc.enable bit in

Enable the THC, if not enabled Z position is passed through

thc.z-pos-in float in

Z Motor Position Command in from axis.n.motor-pos-cmd

thc.z-pos-out float out

Z Motor Position Command Out

thc.z-fb-out float out

Z Position Feedback to Axis

thc.volts float out

The Calculated Volts

thc.vel-status bit out

When the THC thinks we are at requested speed

thc.offset-value float out

The Current Offset

356.6. PARAMETERS

thc.vel-scale float rw

The scale to convert the Velocity signal to Volts

thc.scale-offset float rw

The offset of the velocity input at 0 volts

thc.velocity-tol float rw

The deviation percent from planned velocity

thc.voltage-tol float rw

The deviation of Tip Voltage before correction takes place

thc.correction-vel float rw

The amount of change in user units per period to move Z to correct

356.7. AUTHOR

John Thornton

356.8. LICENSE

GPLv2 or greater

Chapter 357. THCUD(9)

357.1. NAME

thcud - Torch Height Control Up/Down Input

357.2. SYNOPSIS

loadrt thcud

357.3. DESCRIPTION

Torch Height Control This THC takes either an up or a down input from a THC

If enabled and torch is on and X + Y velocity is within tolerance of set speed allow the THC to offset the Z axis as needed to maintain voltage.

If enabled and torch is off and the Z axis is moving up remove any correction at a rate not to exceed the rate of movement of the Z axis.

If enabled and torch is off and there is no correction pass the Z position and feed back untouched.

If not enabled pass the Z position and feed back untouched.

Typical Physical Connections using a Parallel Port

Parallel Pin 12 \Leftarrow THC controller Plasma Up

Parallel Pin 13 \Leftarrow THC controller Plasma Down

Parallel Pin 15 \Leftarrow Plasma Torch Arc Ok Signal

Parallel Pin 16 \Rightarrow Plasma Torch Start Arc Contacts

HAL Plasma Connections

net torch-up thcud.torch-up \Leftarrow parport.0.pin-12-in

net torch-down thcud.torch-down \Leftarrow parport.0.pin-13-in

net torch-on spindle.0.on \Rightarrow parport.0.pin-16-out (start the arc)

net arc-ok thcud.arc-ok \Leftarrow motion.digital-in-00 \Leftarrow parport.0.pin-15-in (arc ok signal)

HAL Motion Connections

net requested-vel thcud.requested-vel \Leftarrow motion.requested-vel

net current-vel thcud.current-vel \Leftarrow motion.current-vel

PyVCP Connections In the XML file you need something like:

```
<pyvcp>
<checkboxbutton>
  <text>"THC Enable"</text>
  <halpin>"thc-enable"</halpin>
</checkboxbutton>
</pyvcp>
```

Connect the PyVCP pins in the postgui.hal file like this:

```
net thc-enable thcud.enable ⇐ pyvcp.thc-enable
```

357.4. FUNCTIONS

thcud.-

357.5. PINS

thcud.torch-up bit in

Connect to an input pin

thcud.torch-down bit in

Connect to input pin

thcud.current-vel float in

Connect to motion.current-vel

thcud.requested-vel float in

Connect to motion.requested-vel

thcud.torch-on bit in

Connect to spindle.N.on

thcud.arc-ok bit in

Arc Ok from Plasma Torch

thcud.enable bit in

Enable the THC, if not enabled Z position is passed through

thcud.z-pos-in float in

Z Motor Position Command in from axis.n.motor-pos-cmd

thcud.z-pos-out float out

Z Motor Position Command Out

thcud.z-fb-out float out

Z Position Feedback to Axis

thcud.cur-offset float out

The Current Offset

thcud.vel-status bit out

When the THC thinks we are at requested speed

thcud.removing-offset bit out

Pin for testing

thcud.correction-vel float in

The Velocity to move Z to correct

357.6. PARAMETERS

thcud.velocity-tol float rw

The deviation percent from planned velocity

357.7. AUTHOR

John Thornton

357.8. LICENSE

GPLv2 or greater

Chapter 358. threads(9)

358.1. NAME

threads - creates hard realtime HAL threads

358.2. SYNOPSIS

loadrt threads name1=*name* period1=*period* [fp1=<0|1>] [<_thread-2-info_>] [<_thread-3-info_>]

358.3. DESCRIPTION

threads is used to create hard realtime threads which can execute HAL functions at specific intervals. It is not a true HAL component, in that it does not export any functions, pins, or parameters of its own. Once it has created one or more threads, the threads stand alone, and the **threads** component can be unloaded without affecting them. In fact, it can be unloaded and then reloaded to create additional threads, as many times as needed.

threads can create up to three realtime threads. Threads must be created in order, from fastest to slowest. Each thread is specified by three arguments. **name1** is used to specify the name of the first thread (thread 1). **period1** is used to specify the period of thread 1 in nanoseconds. Both *name* and *period* are required. The third argument, **fp1** is optional, and is used to specify if thread 1 will be used to execute floating point code. If not specified, it defaults to **1**, which means that the thread will support floating point. Specify **0** to disable floating point support, which saves a small amount of execution time by not saving the FPU context. For additional threads, **name2**, **period2**, **fp2**, **name3**, **period3**, and **fp3** work exactly the same. If more than three threads are needed, unload threads, then reload it to create more threads.

358.4. FUNCTIONS

None

358.5. PINS

None

358.6. PARAMETERS

None

358.7. BUGS

The existence of **threads** might be considered a bug. Ideally, creation and deletion of threads would be done directly with **halcmd** commands, such as "**newthread name period**", "**delthread name**", or similar. However, limitations in the current HAL implementation require thread creation to take place in kernel

space, and loading a component is the most straightforward way to do that.

Chapter 359. THREADTEST(9)

359.1. NAME

threadtest - LinuxCNC HAL component for testing thread behavior

359.2. SYNOPSIS

loadrt threadtest [**count**=*N*|**names**=*name1*[,*name2*...]]

359.3. FUNCTIONS

threadtest.N.increment

threadtest.N.reset

359.4. PINS

threadtest.N.count u32 out

359.5. AUTHOR

Jeff Epler

359.6. LICENSE

GPL

Chapter 360. TIME(9)

360.1. NAME

time - Time on in Hours, Minutes, Seconds

360.2. SYNOPSIS

loadrt time [**count**=*N* | **names**=*name1* [, *name2* ...]]

360.3. DESCRIPTION

Time

When either the **time.N.start** or **time.N.pause** bits goes true the cycle timer resets and starts to time until **time.N.start** AND **time.N.pause** go false. When the **time.N.pause** bit goes true timing is paused until **time.N.pause** goes false. If you connect **time.N.start** to **halui.program.is-running** and leave **time.N.pause** unconnected the timer will reset during a pause. See the example connections below for more information.

Time returns the hours, minutes, and seconds that **time.N.start** is true.

Sample PyVCP code to display the hours:minutes:seconds.

```
<pyvcp>
  <hbox>
    <label>
      <text>"Cycle Time"</text>
      <font>("Helvetica",14)</font>
    </label>
    <u32>
      <halpin>"time-hours"</halpin>
      <font>("Helvetica",14)</font>
      <format>"2d"</format>
    </u32>
    <label>
      <text>":"</text>
      <font>("Helvetica",14)</font>
    </label>
    <u32>
      <halpin>"time-minutes"</halpin>
      <font>("Helvetica",14)</font>
      <format>"2d"</format>
    </u32>
    <label>
      <text>":"</text>
      <font>("Helvetica",14)</font>
    </label>
    <u32>
      <halpin>"time-seconds"</halpin>
      <font>("Helvetica",14)</font>
```

```

        <format>"2d"</format>
    </u32>
</hbox>
</pyvcp>

```

In your **post-gui.hal** file you might use one of the following to connect this timer:

For a new config:

```

loadrt time
addf time.0 servo-thread
net cycle-timer      time.0.start <= halui.program.is-running
net cycle-timer-pause time.0.pause <= halui.program.is-paused
net cycle-seconds    pyvcp.time-seconds <= time.0.seconds
net cycle-minutes    pyvcp.time-minutes <= time.0.minutes
net cycle-hours      pyvcp.time-hours <= time.0.hours

```

Previous to this version if you wanted the timer to continue running during a pause instead of resetting, you had to use a HAL NOT component to invert the **halui.program.is-idle** pin and connect to **time.N.start** as shown below:

```

loadrt time
loadrt not
addf time.0 servo-thread
addf not.0 servo-thread
net prog-running not.0.in <= halui.program.is-idle
net cycle-timer time.0.start <= not.0.out
net cycle-seconds pyvcp.time-seconds <= time.0.seconds
net cycle-minutes pyvcp.time-minutes <= time.0.minutes
net cycle-hours pyvcp.time-hours <= time.0.hours

```

For those who have this setup already, you can simply add a net connecting **time.N.pause** to **halui.program.is-paused**:

```

net cycle-timer-pause time.0.pause <= halui.program.is-paused

```

360.4. FUNCTIONS

time.N

360.5. PINS

time.N.start bit in

Timer On

time.N.pause bit in (default: 0)

Pause

time.N.seconds u32 out

Seconds

time.N.minutes u32 out

Minutes

time.N.hours u32 out

Hours

360.6. AUTHOR

John Thornton, itaib, Moses McKnight

360.7. LICENSE

GPL

Chapter 361. TIMEDELAY(9)

361.1. NAME

timedelay - The equivalent of a time-delay relay

361.2. SYNOPSIS

loadrt timedelay [count=*N* | names=*name1* [, *name2* ...]]

361.3. FUNCTIONS

timedelay.*N*

361.4. PINS

timedelay.*N*.in bit in

timedelay.*N*.out bit out

Follows the value of **in** after applying the delays **on-delay** and **off-delay**.

timedelay.*N*.on-delay float in (default: 0.5)

The time, in seconds, for which **in** must be **true** before **out** becomes **true**

timedelay.*N*.off-delay float in (default: 0.5)

The time, in seconds, for which **in** must be **false** before **out** becomes **false**

timedelay.*N*.elapsed float out

Current value of the internal timer

361.5. AUTHOR

Jeff Epler, based on works by Stephen Wille Padnos and John Kasunich

361.6. LICENSE

GPL

Chapter 362. TIMEDELTA(9)

362.1. NAME

timedelta - LinuxCNC HAL component that measures thread scheduling timing behavior

362.2. SYNOPSIS

loadrt timedelta [count=*N* | names=*name1*[,*name2*...]]

362.3. FUNCTIONS

timedelta.*N*

362.4. PINS

timedelta.*N*.jitter s32 out (default: 0)

Worst-case scheduling error (in ns). This is the largest discrepancy between ideal thread period, and actual time between sequential runs of this component. This uses the absolute value of the error, so *got run too early* and *got run too late* both show up as positive jitter.

timedelta.*N*.current-jitter s32 out (default: 0)

Scheduling error (in ns) of the current invocation. This is the discrepancy between ideal thread period, and actual time since the previous run of this component. This uses the absolute value of the error, so *got run too early* and *got run too late* both show up as positive jitter.

timedelta.*N*.current-error s32 out (default: 0)

Scheduling error (in ns) of the current invocation. This is the discrepancy between ideal thread period, and actual time since the previous run of this component. This does not use the absolute value of the error, so *got run too early* shows up as negative error and *got run too late* shows up as positive error.

timedelta.*N*.min- s32 out (default: 0)

Minimum time (in ns) between sequential runs of this component.

timedelta.*N*.max- s32 out (default: 0)

Maximum time (in ns) between sequential runs of this component.

timedelta.*N*.reset bit in

Set this pin to True, then back to False, to reset some of the statistics.

timedelta.*N*.out s32 out

Time (in ns) since the previous run of this component. This should ideally be equal to the thread period.

timedelta.N.err s32 out (default: 0)

Cumulative time error (in ns). Probably not useful.

timedelta.N.avg-err float out (default: 0)

The average scheduling error (in ns).

362.5. AUTHOR

Jeff Epler

362.6. LICENSE

GPL

Chapter 363. TOF(9)

363.1. NAME

tof - IEC TOF timer - delay falling edge on a signal

363.2. SYNOPSIS

loadrt tof [**count**=*N* | **names**=*name1* [, *name2* ...]]

363.3. FUNCTIONS

tof.N

Update the timer

363.4. PINS

tof.N.in bit in

Input signal

tof.N.q bit out

Output signal

tof.N.et float out

Elapsed time since falling edge in seconds

363.5. PARAMETERS

tof.N.pt float rw

Delay time in seconds

363.6. AUTHOR

Chad Woitas

363.7. LICENSE

GPL

Chapter 364. TOGGLE(9)


364.1. NAME

`toggle` - *push-on, push-off* from momentary pushbuttons

364.2. SYNOPSIS

loadrt toggle [**count**=*N* | **names**=*name1*[,*name2*...]]

364.3. DESCRIPTION



364.4. FUNCTIONS

`toggle.N`

364.5. PINS

toggle.N.in bit in

button input

toggle.N.out bit io

on/off output

364.6. PARAMETERS

toggle.N.debounce u32 rw (default: 2)

debounce delay in periods

364.7. AUTHOR

John Kasunich

364.8. LICENSE

GPL

Chapter 365. TOGGLE2NIST(9)

365.1. NAME

toggle2nist - toggle button to nist logic


365.2. SYNOPSIS

loadrt toggle2nist [**count**=*N* | **names**=*name1*[,*name2*...]]

365.3. DESCRIPTION

Toggle2nist can be used with a momentary push button to control a device that has separate on and off inputs and an is-on output. A debounce delay in cycles can be set for *in*. (default = 2)

- On a rising edge on pin **in** when **is-on** is low: It sets **on** until **is-on** becomes high.
- On a rising edge on pin **in** when **is-on** is high: It sets **off** until **is-on** becomes low.



365.4. FUNCTIONS

toggle2nist.N

365.5. PINS

toggle2nist.N.in bit in

momentary button in

toggle2nist.N.is-on bit in

current state of device

toggle2nist.N.debounce u32 in (default: 2)

debounce delay for *in*-pin in cycles

toggle2nist.N.on bit out

turn device on

toggle2nist.N.off bit out

turn device off

365.6. AUTHOR

Anders Wallin, David Mueller

365.7. LICENSE

GPL

Chapter 366. TON(9)

366.1. NAME

ton - IEC TON timer - delay rising edge on a signal

366.2. SYNOPSIS

loadrt ton [**count**=*N*|**names**=*name1*[,*name2*...]]

366.3. FUNCTIONS

ton.N

Update the timer

366.4. PINS

ton.N.in bit in

Input signal

ton.N.q bit out

Output signal

ton.N.et float out

Elapsed time since rising edge in seconds

366.5. PARAMETERS

ton.N.pt float rw

Delay time in seconds

366.6. AUTHOR

Chad Woitas

366.7. LICENSE

GPL

Chapter 367. TP(9)

367.1. NAME

tp - IEC TP timer - generate a high pulse of defined duration on rising edge

367.2. SYNOPSIS

loadrt tp [count=N|names=name1[,name2...]]

367.3. FUNCTIONS

tp.N

Update the timer

367.4. PINS

tp.N.in bit in

Input signal

tp.N.q bit out

Output signal

tp.N.et float out

Elapsed time since start of pulse in seconds

367.5. PARAMETERS

tp.N.pt float rw

Pulse time in seconds

367.6. AUTHOR

Chad Woitas

367.7. LICENSE

GPL

Chapter 368. TPCOMP(9)

368.1. NAME

tpcomp - Trajectory Planning (tp) module skeleton

368.2. SYNOPSIS

Custom Trajectory Planning module loaded with **[TRAJ]TPMOD=tpcomp**

368.3. DESCRIPTION

Example of a trajectory planning (tp) module buildable with halcompile.

The tpcomp.comp file (src/hal/components/tpcomp.comp) illustrates a method to use halcompile to build a trajectory planning module based on the files used for the default trajectory planner (**tpmod**).

The example tpcomp.comp is not usable until modified for the user environment. To create a runnable tpcomp module, the tpcomp.comp file must be edited to supply 1) a valid *#define TOPDIR* and 2) references to valid source code file names for all files used.

To avoid updates that overwrite tpcomp.comp, best practice is to rename the file and its component name (example: **user_tpcomp.comp** creates module: **user_tpcomp**).

The (renamed) component can be built and installed with halcompile and then substituted for the default tp module (**tpmod**) using:

```
$ linuxcnc *-t user_tpcomp* someconfig.ini
```

or by inifile setting: **[TRAJ]TPMOD=user_tpcomp**

*Note:*If using a deb install:

1. halcompile is provided by the deb package linuxcnc-dev
2. This source file for BRANCHNAME (master,2.9,etc) is downloadable from github:

<https://github.com/LinuxCNC/linuxcnc/blob/BRANCHNAME/src/hal/components/tpcomp.comp>

368.4. PINS

tpcomp.N.is-module bit out (default: 1)

368.5. AUTHOR

Dewey Garrett

368.6. LICENSE

GPL

Chapter 369. TRISTATE_BIT(9)

369.1. NAME

`tristate_bit` - Place a signal on an I/O pin only when enabled, similar to a tristate buffer in electronics

369.2. SYNOPSIS

loadrt `tristate_bit` [**count**=*N* | **names**=*name1*[,*name2*...]]

369.3. FUNCTIONS

tristate-bit.N

If **enable** is TRUE, copy **in** to **out**.

369.4. PINS

tristate-bit.N.in- bit in

Input value

tristate-bit.N.out bit io

Output value

tristate-bit.N.enable bit in

When TRUE, copy in to out

369.5. AUTHOR

Jeff Epler

369.6. LICENSE

GPL

Chapter 370. TRISTATE_FLOAT(9)

370.1. NAME

`tristate_float` - Place a signal on an I/O pin only when enabled, similar to a tristate buffer in electronics

370.2. SYNOPSIS

loadrt `tristate_float` [**count**=*N* | **names**=*name1* [, *name2* ...]]

370.3. FUNCTIONS

tristate-float.N

If **enable** is TRUE, copy **in** to **out**.

370.4. PINS

tristate-float.N.in- float in

Input value

tristate-float.N.out float io

Output value

tristate-float.N.enable bit in

When TRUE, copy in to out

370.5. AUTHOR

Jeff Epler

370.6. LICENSE

GPL

Chapter 371. UPDOWN(9)

371.1. NAME

updown - Counts up or down, with optional limits and wraparound behavior

371.2. SYNOPSIS

loadrt updown [count=*N* | names=*name1* [, *name2* ...]]

371.3. FUNCTIONS

updown.*N*

Process inputs and update count if necessary

371.4. PINS

updown.*N*.countup bit in

Increment count when this pin goes from 0 to 1

updown.*N*.countdown bit in

Decrement count when this pin goes from 1 to 0

updown.*N*.reset bit in

Reset count when this pin goes from 0 to 1

updown.*N*.count s32 out

The current count

371.5. PARAMETERS

updown.*N*.clamp bit rw

If TRUE, then clamp the output to the min and max parameters.

updown.*N*.wrap bit rw

If TRUE, then wrap around when the count goes above or below the min and max parameters. Note that wrap implies (and overrides) clamp.

updown.*N*.max s32 rw (default: 0x7FFFFFFF)

If clamp or wrap is set, count will never exceed this number

updown.*N*.min s32 rw

If clamp or wrap is set, count will never be less than this number

371.6. AUTHOR

Stephen Wille Padnos

371.7. LICENSE

GPL

Chapter 372. USERKINS(9)

372.1. NAME

userkins - Template for user-built kinematics

372.2. SYNOPSIS

loadrt userkins [**count**=*N* | **names**=*name1*[,*name2*...]]

372.3. DESCRIPTION

The userkins.comp file is a template for creating kinematics that can be user-built using halcompile.

The unmodified userkins component can be used as a kinematics file for a machine with identity kinematics for an xyz machine employing 3 joints (motors).

372.3.1. USAGE

Copy the userkins.comp file to a user-owned directory (**mydir**).

Note: The userkins.comp file can be downloaded from: github.com/LinuxCNC/linuxcnc/raw/2.8/src/hal/components/userkins.comp where 2.8 is the branch name (use *master* for the master branch). For a RIP (run-in-place) build, the file is located in the git tree as: [src/hal/components/userkins.comp](#).

Edit the functions kinematicsForward() and kinematicsInverse() as required.

If required, add HAL pins following examples in the template code.

Build and install the component using halcompile:

```
$ cd mydir
$ [sudo] halcompile --install userkins.comp
# Note:
#     sudo is required when using a deb install
#     sudo is *not* required for run-in-place builds
# $ man halcompile for more info
```

Specify userkins in an ini file as:

```
[KINS]
KINEMATICS=userkins
JOINTS=3
# the number of JOINTS must agree with the
# number of joints used in your modified userkins.comp
```

Note: the manpage for userkins is not updated by [halcompile --install](#)

To use a different component name, rename the file (example mykins.comp) and change all instances of **userkins** to **mykins**.

372.3.2. NOTES

- The **fpin** pin is included to satisfy the requirements of the halcompile utility but it is not accessible to kinematics functions.
- HAL pins and parameters needed in kinematics functions (kinematicsForward(), kinematicsInverse()) must be setup in a function (**userkins_setup()**) invoked by the initial motion module call to kinematicsType().

372.4. FUNCTIONS

userkins.N.fdemo

372.5. PINS

userkins.N.fpin s32 out (default: 0)

pin to demonstrate use of a conventional (non-kinematics) function fdemo

372.6. AUTHOR

Dewey Garrett

372.7. LICENSE

GPL

Chapter 373. watchdog(9)

373.1. NAME

watchdog - monitor multiple inputs for a "heartbeat"

373.2. SYNOPSIS

loadrt watchdog num_inputs=N

You must specify the number of inputs, from 1 to 32. Each input has a separate timeout value.

373.3. FUNCTIONS

process

Check all input pins for transitions, clear the **ok-out** pin if any input has no transition within its timeout period. This function does not use floating point, and should be added to a fast thread.

set-timeouts

Check for timeout changes, and convert the float timeout inputs to int values that can be used in **process**. This function also monitors **enable-in** for false to true transitions, and re-enables monitoring when such a transition is detected. This function does use floating point, and it is appropriate to add it to the servo thread.

373.4. PINS

watchdog.input-N bit in

Input number *N*. The inputs are numbered from 0 to **num_inputs-1**.

watchdog.enable-in bit in (default: FALSE)

If TRUE, forces out-ok to be false. Additionally, if a timeout occurs on any input, this pin must be set FALSE and TRUE again to re-start the monitoring of input pins.

watchdog.ok-out bit out (default: FALSE)

OK output. This pin is true only if enable-in is TRUE and no timeout has been detected. This output can be connected to the enable input of a **charge_pump** or **stepgen** (in v mode), to provide a heartbeat signal to external monitoring hardware.

373.5. PARAMETERS

watchdog.timeout-N float in

Timeout value for input number *N*. The inputs are numbered from 0 to **num_inputs-1**. The timeout is in seconds, and may not be below zero. Note that a timeout of 0.0 will likely prevent **ok-out** from ever becoming true. Also note that excessively long timeouts are relatively useless for monitoring purposes.

373.6. LICENSE

GPL

Chapter 374. WCOMP(9)

374.1. NAME

wcomp - Window comparator

374.2. SYNOPSIS

loadrt wcomp [**count**=*N* | **names**=*name1*[,*name2*...]]

374.3. FUNCTIONS

wcomp.N

374.4. PINS

wcomp.N.in float in

Value being compared

wcomp.N.min- float in

Low boundary for comparison

wcomp.N.max- float in

High boundary for comparison

wcomp.N.out bit out

True if **in** is strictly between **min** and **max**

wcomp.N.under bit out

True if **in** is less than or equal to **min**

wcomp.N.over bit out

True if **in** is greater than or equal to **max**

374.5. NOTES

If **max** \leq **min** then the behavior is undefined.

374.6. AUTHOR

Jeff Epler

374.7. LICENSE

GPL

Chapter 375. weighted_sum(9)

375.1. NAME

weighted_sum - convert a group of bits to an integer

375.2. SYNOPSIS

loadrt weighted_sum wsum_sizes=size[,size,...]

Creates weighted sum groups each with the given number of input bits (*size*).

375.3. DESCRIPTION

The weighted_sum converts a group of bits to an integer. The conversion is the sum of the weights of the bits that are on plus any offset. The weight of the *m*-th bit is 2^m . This is similar to a binary coded decimal but with more options. The hold bit stops processing the input changes so the sum will not change.

The default value for each weight is 2^m where *m* is the bit number. This results in a binary to unsigned conversion.

There is a limit of 8 weighted summers and each may have up to 16 input bits.

375.4. FUNCTIONS

process_wsums (requires a floating point thread)

Read all input values and update all output values.

375.5. PINS

wsum.N.bit.M.in bit in

The m^{th} input of weighted summer *n*.

wsum.N.hold bit in

When TRUE, the *sum* output does not change. When FALSE, the *sum* output tracks the *bit* inputs according to the weights and offset.

wsum.N.sum signed out

The output of the weighted summer.

wsum.N.bit.M.weight signed rw

The weight of the m^{th} input of weighted summer *n*. The default value is 2^m .

wsum.N.offset signed rw

The offset is added to the weights corresponding to all TRUE inputs to give the final sum.

375.6. SEE ALSO

scaled_s32_sums(9), sum2(9)

Chapter 376. XHC_HB04_UTIL(9)

376.1. NAME

xhc_hb04_util - xhc-hb04 convenience utility

376.2. SYNOPSIS

loadrt xhc_hb04_util [count=*N* | names=*name1* [, *name2* ...]]

376.3. DESCRIPTION

Provides logic for a start/pause button and an interface to **halui.program.is_paused**, **is_idle**, **is_running** to generate outputs for **halui.program.pause**, **resume**, **run**.

Includes 4 simple lowpass filters with **coef** and **scale** pins. The coef value should be $0 \leq \text{coef} \leq 1$, smaller coef values slow response. See the lowpass manpage for calculating the filter time constant (\$ man lowpass).

376.4. FUNCTIONS

xhc-hb04-util.N

376.5. PINS

xhc-hb04-util.N.start-or-pause bit in
xhc-hb04-util.N.is-paused bit in
xhc-hb04-util.N.is-idle bit in
xhc-hb04-util.N.is-running bit in
xhc-hb04-util.N.pause bit out
xhc-hb04-util.N.resume bit out
xhc-hb04-util.N.run bit out
xhc-hb04-util.N.in0 s32 in
xhc-hb04-util.N.in1 s32 in
xhc-hb04-util.N.in2 s32 in
xhc-hb04-util.N.in3 s32 in
xhc-hb04-util.N.out0 s32 out
xhc-hb04-util.N.out1 s32 out
xhc-hb04-util.N.out2 s32 out
xhc-hb04-util.N.out3 s32 out
xhc-hb04-util.N.scale0 float in (default: *1.0*)
xhc-hb04-util.N.scale1 float in (default: *1.0*)
xhc-hb04-util.N.scale2 float in (default: *1.0*)
xhc-hb04-util.N.scale3 float in (default: *1.0*)
xhc-hb04-util.N.coef0 float in (default: *1.0*)
xhc-hb04-util.N.coef1 float in (default: *1.0*)
xhc-hb04-util.N.coef2 float in (default: *1.0*)
xhc-hb04-util.N.coef3 float in (default: *1.0*)
xhc-hb04-util.N.divide-by-k-in float in
xhc-hb04-util.N.divide-by-k-out float out
xhc-hb04-util.N.k float in (default: *1.0*)

376.6. AUTHOR

Dewey Garrett

376.7. LICENSE

GPL

Chapter 377. XOR2(9)

377.1. NAME

xor2 - Two-input XOR (exclusive OR) gate

377.2. SYNOPSIS

loadrt xor2 [**count**=*N* | **names**=*name1* [, *name2* ...]]

377.3. DESCRIPTION

The **out** pin is computed from the value of the **in0** and **in1** pins according to the following truth table:

in1	in0	out
0	0	0
0	1	1
1	0	1
1	1	0

377.4. FUNCTIONS

xor2.N

377.5. PINS

xor2.N.in0 bit in

First input

xor2.N.in1 bit in

Second input

xor2.N.out bit out

Output

377.6. SEE ALSO

and2(9), **logic(9)**, **lut5(9)**, **not(9)**, **or2(9)**.

377.7. AUTHOR

John Kasunich

377.8. LICENSE

GPL

Chapter 378. XYZAB_TDR_KINS(9)

378.1. NAME

xyzab_tdr_kins - Switchable kinematics for 5 axis machine with rotary table A and B

378.2. SYNOPSIS

loadrt xyzab_tdr_kins [**count**=*N*|**names**=*name1*[,*name2*...]]

378.3. DESCRIPTION

This is a switchable kinematics module for a 5-axis milling configuration using 3 cartesian linear joints (XYZ) and 2 rotary table joints (AB).

The module contains two kinematic models:

type0 (default) is a trivial XYZAB configuration with joints 0..4 mapped to axes XYZAB respectively.

type1 is a XYZAB configuration with tool center point (TCP) compensation.

For an example configuration, run the sim config: */configs/sim/axis/vismach/5axis/table-dual-rotary/xyzab-tdr.ini*.

Further explanations can be found in the README in */configs/sim/axis/vismach/5axis/table-dual-rotary/*.

xyzab_tdr_kins.comp was constructed by modifying the template file: *userkins.comp*.

For more information on how to modify *userkins.comp* run: `$ man userkins`. Also, see additional information inside: *userkins.comp*.

For information on kinematics in general see the kinematics document chapter (*docs/src/motion/kinematics.txt*) and for switchable kinematics in particular see the switchkins document chapter (*docs/src/motion/switchkins.txt*)

378.4. PINS

xyzab-tdr-kins.N.dummy s32 out (default: 0)

one pin needed to satisfy halcompile requirement

378.5. AUTHOR

David Mueller

378.6. LICENSE

GPL

Chapter 379. XYZACB_TRSRN(9)

379.1. NAME

xyzacb_trsrn - Switchable kinematics for 6 axis machine with a rotary table C, rotary spindle B and nutating spindle A

379.2. SYNOPSIS

loadrt xyzacb_trsrn [**count**=*N*|**names**=*name1*[,*name2*...]]

379.3. DESCRIPTION

FIXME

379.4. FUNCTIONS

xyzacb-trsrn.N.fdemo

379.5. PINS

xyzacb-trsrn.N.fpin s32 out (default: 0)

pin to demonstrate use of a conventional (non-kinematics) function fdemo

379.6. AUTHOR

David Mueller

379.7. LICENSE

GPL

Chapter 380. XYZBCA_TRSRN(9)

380.1. NAME

xyzbca_trsrn - Switchable kinematics for 6 axis machine with a rotary table B, rotary spindle C and nutating spindle A

380.2. SYNOPSIS

loadrt xzbca_trsrn [**count**=*N*|**names**=*name1*[,*name2*...]]

380.3. DESCRIPTION

FIXME

380.4. FUNCTIONS

xyzbca-trsrn.*N*.fdemo

380.5. PINS

xyzbca-trsrn.*N*.fpin s32 out (default: 0)

pin to demonstrate use of a conventional (non-kinematics) function fdemo

380.6. AUTHOR

David Mueller

380.7. LICENSE

GPL
